

Spare Parts List

Model AD


Mounted plough

No 733027



Notes

GB Model	GB Interbody clearance	GB Headstock
D Modell	D Körperlängsabstand	D Drehwerk
F Modèle	F Dégagement sous age	F Type de tête
E Modelo	E Separación entre cuerpos	E Tipo de cabezal



GB Serial number	Type: HD=Heavy Duty SL=Vibromat OL=On-land	GB Body no.
D Seriennummer		D Körper no.
F Numéro de série		F Type no.
E Numero de serie		E Tipo no.

Замовлення запчастин

(GB) Complete model code and serial number must be stated to avoid mistakes when ordering spare parts and misunderstandings regarding service consultations. The identification plate is located on the headstock.

(F) Le code complet et le numéro de série doivent être indiqués pour éviter des erreurs lors de la commande de pièces de rechange et des malentendus concernant des demandes de Service-Après-Vente. La plaque d'identité est située sur la tête.

(D) Um bei Ersatzteilbestellungen und Serviceleistungen Fehler und Mißverständnisse zu vermeiden ist es erforderlich, daß die genaue Bezeichnung und die Seriennummer angegeben werden. Die Plakette befindet sich am Drehwerk.

(E) Debe figura el código completo del modelo y el número de serie para evitar errores al pedir las piezas de recambio y al hacer consultas técnicas. La placa de identificación esta situada en el cabezal.

Plate		Page
244	Bodies no 6, 7, 8, 9 and 28	4
367	Bodies no 12, 15 and 19	8
494	Body no 14 (Plastic mouldboard)	12
414	Body no 20 (Finger Body) (Before 01.03.99)	14
1089	Bodies no. 29 and no. 30.....	16
301	Beam w/automatic reset.....	20
176	Disc coultter 18" and 20" (Before 01.02.99)	22
1071	Disc coultter 18" and 20", conventional plough (From 01.02.99)	24
177	Spring loaded disc coultter 18" and 20" (Before 01.01.99)	26
1072	Springloaded disc coultter 18" and 20", conventional plough (From 01.01.99)	28
341	Manure skimmer / Maize skimmer	30
462	Cross shaft for AD (Before 01.01.95)	32
567	Cross shaft for AD (From 01.01.95)	34
332	Parts for additional bodies	36
302	Frame	38
303	Front section.....	40
473	Cylinder for furrow adjustment D50 x 200 mm without stop (Before 01.08.96)	42
525	Hydraulic cylinder D50 x 200 mm (353701 - 353703) (From 01.08.96) (Before 01.04.01) 44	
1192	Hydraulic cylinder D50 x 200 mm (353901 - 353903) (From 01.04.01)	46
568	Cylinder for furrow width adjustment D75 x 200 mm (Before 01.08.96)	48
890	Hydraulic cylinder D75 x 200 mm (353704 - 353707)	(From 01.08.96) (Before 01.04.01) 50
1195	Hydraulic cylinder D75 x 200 mm (353904 - 353906) (From 01.04.01)	52
180	Depth wheel 500 x 165 and 6.00 x 9	54
1078	Transfers for AD	56
	Index.....	58




1	KK 07 30 00	Share 12" R (30 cm)	KK 07 38 03	Stay R + L for body no. 6, 7 and 8 A - saddle, L = 560 (And no. 9 before 01.12.95)	KK 07 06 41	Trashboard, L cpl.		
	KK 07 30 01	Share 12" L (30 cm)			KK 07 06 42	Trashboard, R + L cpl.		
	KK 07 30 02	Share 14" R (35 cm)	KK 07 38 31	Stay R + L for body no. 9 E - saddle, L = 725 (From 01.12.95)	17	KK 03 33 32	Cone screw M14 x 34 mm w/nut	
	KK 07 30 03	Share 14" L (35 cm)			18	KK 03 27 25	Hex screw M16 x 27 mm w/nut	
	KK 07 30 04	Share 16" R (40 cm)	KK 07 38 30	Stay R + L for body no. 9 A - saddle, L = 710 (From 01.12.95)	19	KK 03 31 07	Oval screw M12 x 35 mm w/nut	
	KK 07 30 05	Share 16" L (40 cm)			20	KK 01 32 34	Cone screw M12 x 38 mm w/nut	
	KK 07 30 06	Share 18" R (45 cm)	KK 06 38 01	Extra stay R + L, no. 9 E - saddle L = 550 (From 01.12.95)	21	KK 07 30 91	Share knife, R	
	KK 07 30 07	Share 18" L (45 cm)				KK 07 30 92	Share knife, L	
	KK 07 30 08	Share 20" R (50 cm)	KK 07 03 94	Extra stay R for body no. 9 E - saddle, cpl. w. bracket (pos. 12) (From 01.12.95)		KK 06 30 91	Share knife, R (for Sweden)	
	KK 07 30 09	Share 20" L (50 cm)	KK 07 03 95	Extra stay L for body no. 9 E - saddle, cpl. w. bracket (pos. 12) (From 01.12.95)		KK 06 30 92	Share knife, L (for Sweden)	
2	KK 05 30 90	Reversible point, R			23	KK 07 36 09	Landside, long R + L	
	KK 06 30 90	Reversible point, L	KK 07 38 03	Extra stay R + L, no. 9 A - saddle L = 560 (From 01.12.95)	24	KK 07 32 66	Bracket for stay, body no. 6 and 9, R	
3	KK 07 34 06	Saddle, R (for E-saddle)				KK 07 32 67	Bracket for stay, body no. 6 and 9, L	
	KK 07 34 07	Saddle, L (for E-saddle)	KK 07 03 90	Extra stay R for body no. 9 A - saddle, cpl. w. bracket (pos. 12) (From 01.12.95)	25	KK 07 34 14	Connecting plate, 16" - 20", R	
	KK 07 34 11	Saddle, R (for A-saddle)				KK 07 34 15	Connecting plate, 16" - 20", L	
	KK 07 34 12	Saddle, L (for A-saddle)	KK 07 03 91	Extra stay L for body no. 9 A - saddle, cpl. w. bracket (pos. 12) (From 01.12.95)	26	KK 07 30 40	Flush fit share 12", R	
4	KK 01 33 32	Cone screw M14 x 34 mm w/nut				KK 07 30 41	Flush fit share 12", L	
5	KK 03 31 00	Oval screw M12 x 30 mm w/nut	KK 08 38 09	Stay R + L for body no. 28 A - saddle (From 01.03.03)		KK 07 30 42	Flush fit share 14", R	
6	KK 07 32 60	Mouldboard 12" - 16" no. 6, R	KK 08 38 10	Stay R + L for body no. 28 E - saddle (From 01.03.03)		KK 07 30 43	Flush fit share 14", L	
	KK 07 32 61	Mouldboard 12" - 16" no. 6, L				KK 07 30 44	Flush fit share 16", R	
	KK 07 32 63	Mouldboard 12" - 14" no. 7, R	10	KK 07 36 08	Landside, R and L, short		KK 07 30 45	Flush fit share 16", L
	KK 07 32 64	Mouldboard 12" - 14" no. 7, L	11	KK 01 58 32	Nut M20 mm	27	KK 07 30 30	Flush point, R
	KK 07 32 80	Mouldboard 12" no. 8, R	12	KK 07 38 00	Bracket for stay, R for body no. 6, 7, 8 (And no. 9 before 01.12.95)		KK 07 30 31	Flush point, L
	KK 07 32 81	Mouldboard 12" no. 8, L				28	KK 01 29 27	Washer 17 x 30 x 3 mm (for use with two stays)
	KK 07 32 86	Mouldboard 14" - 18" no. 8, R	KK 07 38 01	Bracket for stay, L for body no. 6, 7, 8 (And no. 9 before 01.12.95)	30	KK 07 36 15	Furrow widener, R	
	KK 07 32 87	Mouldboard 14" - 18" no. 8, L				KK 07 36 16	Furrow widener, L	
	KK 07 32 90	Mouldboard 14" - 20" no. 9, R	KK 07 38 07	Bracket for stay, R for body no. 9 (From 01.12.95)	31	KK 07 30 88	Landside knife w/screw, R	
	KK 07 32 91	Mouldboard 14" - 20" no. 9, L				KK 07 30 89	Landside knife w/screw, L	
	KK 08 32 28	Mouldboard no. 28, R (From 01.03.03)	KK 07 38 08	Bracket for stay, L for body no. 9 (From 01.12.95)	32	KK 03 32 51	Screw M16 x 50 mm w/nut (for E-saddle) (Before 01.02.00)	
	KK 08 32 29	Mouldboard no. 28, L (From 01.03.03)				KK 03 32 56	Screw M16 x 55 mm w/ nut (for E-saddle) (From 01.02.00)	
7	KK 07 32 50	Shinpiece for no. 8, R	13	KK 01 29 19	Washer 12.5 x 23 x 3.2 mm		KK 03 32 86	Screw M16 x 85 mm w/nut (for A-saddle) (Before 01.02.00)
	KK 07 32 51	Shinpiece for no. 8, L	14	KK 05 33 87	Mouldboard extension, R		KK 03 32 95	Screw M16 x 95 mm w/nut (for A-saddle) (From 01.02.00)
	KK 07 32 56	Shinpiece for no. 6 and 9, R		KK 06 33 88	Mouldboard extension, L			
	KK 07 32 57	Shinpiece for no. 6 and 9, L	15	KK 07 33 10	Bracket for trashboard, R			
8	KK 03 27 35	Hex screw M16 x 35 mm w/nut		KK 07 33 11	Bracket for trashboard, L			
9	KK 06 38 01	Stay R + L for body no. 6, 7 and 8 E - saddle, L = 550 (And no. 9 before 01.12.95)	16	KK 07 33 00	Trashboard, R			
				KK 07 33 01	Trashboard L	33	KK 03 31 75	Screw M14 x 50 mm w/nut
				KK 07 06 40	Trashboard, R cpl.	34	KK 01 29 22	Washer 17 x 40 x 4.58 mm




35	KK 06 36 07	Plate
	KK 07 36 07	Plate cpl.
36	KK 01 33 46	Screw M14 x 45 mm w/nut
37	KK 07 36 14	Wearing plate
38	KK 01 33 33	Cone screw M14 x 34 mm
39	KK 08 32 35	Mouldboard knife R and L (From 01.12.01)
Pos. 100 - 107 Eco-share from 01.04.00		
100	KK 05 30 90	Reversible point, R
	KK 06 30 90	Reversible point, L
101	KK 01 32 28	Cone screw M12 x 34 mm w/nut
102	KK 07 36 34	Eco-share, R
	KK 07 36 35	Eco-share, L
103	KK 01 01 55	Bushing (for ploughs w/share bolt beam)
	KK 01 01 56	Bushing (for ploughs w/A-beam)
104	KK 03 27 40	Hex screw M16 x 40 mm w/nut (for ploughs w/E-saddle) (Before 01.03.00)
	KK 03 27 50	Hex screw M16 x 50 mm w/nut (for ploughs w/E-saddle) (From 01.03.00)
	KK 03 27 65	Hex screw M16 x 65 mm w/nut (for ploughs w/share bolt beam)
	KK 03 27 75	Hex screw M16 x 75 mm w/nut (for ploughs w/A-beam)
105	KK 01 33 46	Cone screw M14 x 45 mm w/flange nut (for ploughs w/E-saddle) (Before 01.03.00)
	KK 01 33 61	Cone screw M14 x 60 mm w/flange nut (for ploughs w/E-saddle) (From 01.03.00)
	KK 01 33 85	Cone screw M14 x 85 mm w/flange nut (for ploughs w/share bolt beam and A-beam)
106	KK 01 60 15	Flange nut M14
107	KK 01 29 29	Washer (for ploughs w/E-saddle) (From 01.03.00)





1	KK 01 29 19	Washer	KK 07 32 31	Shinpiece no. 19, L	KK 07 03 93	Extra stay L for body no. 19 A - saddle cpl.		
2	KK 07 33 00	Trashboard, R	16	KK 07 32 39	Connecting piece no. 12 and 15, R	w. bracket (pos. 6) (From 01.12.95)		
	KK 07 33 01	Trashboard, L		KK 07 32 40	Connecting piece no. 12 and 15, L	20	KK 07 36 09	Landside, long, R + L
	KK 07 06 40	Trashboard, R cpl.		KK 07 32 66	Connecting piece no. 19, R	21	KK 07 36 08	Landside, short, R + L
	KK 07 06 41	Trashboard, L cpl.		KK 07 32 67	Connecting piece no. 19, L	22	KK 03 27 25	Hex screw M16 x 27 mm
	KK 07 06 42	Trashboard, R + L cpl.	17	KK 03 27 50	Hex screw M16 x 50 mm w/nut (for use with two stays)	23	KK 01 32 34	Cone screw M12 x 38 mm w/nut
3	KK 07 33 10	Bracket, R		KK 03 27 35	Hex screw M16 x 35 mm w/nut (for use with one stay only)	24	KK 01 32 28	Cone screw M12 x 34 mm w/nut
	KK 07 33 11	Bracket, L				25	KK 05 30 90	Reversible point, R
4	KK 03 31 00	Oval screw M12 x 30 mm w/nut	18	KK 01 29 27	Washer 17 x 30 x 3 mm (for use with two stays)	26	KK 06 30 90	Reversible point, L
5	KK 01 58 34	Nut M20 mm					KK 07 30 54	Share 14", R
6	KK 07 38 00	Bracket, R	19	KK 07 38 05	Stay R + L for body no. 12 and 15 E - saddle, L = 540 (And no. 19 before 12.01.95)		KK 07 30 55	Share 14", L
	KK 07 38 01	Bracket, L		KK 07 38 31	Stay R + L for body no. 19 E - saddle, L = 730 (From 12.01.95)		KK 07 30 56	Share 16", R
7	KK 05 33 87	Mouldboard extention, R		KK 07 38 04	Stay R + L for body no. 12 and 15 A - saddle, L = 550 (And no. 19 before 12.01.95)		KK 07 30 57	Share 16", L
	KK 06 33 88	Mouldboard extention, L		KK 07 38 26	Stay R + L for body no. 19 A - saddle, L = 770 (From 12.01.95)		KK 07 30 80	Share 18", R
8	KK 07 32 36	Mouldboard no. 12, R		KK 07 38 26	Extra stay R + L, no. 15 E - saddle L = 770 (From 01.12.96)	27	KK 07 30 81	Share 18", L
	KK 07 32 37	Mouldboard no. 12, L		KK 07 03 88	Extra stay R for body no. 15 E - saddle cpl. w. bracket (pos. 6) (From 01.12.96)		KK 07 30 91	Share knife, R
	KK 07 32 24	Mouldboard no. 15, R		KK 07 03 89	Extra stay L for body no. 15 E - saddle cpl. w. bracket (pos. 6) (From 01.12.96)		KK 07 30 92	Share knife, L
	KK 07 32 25	Mouldboard no. 15, L		KK 07 38 29	Extra stay R + L, no. 15 A - saddle L = 785 (From 01.12.96)	28	KK 07 30 88	Landside knife, R w/nuts
	KK 07 32 90	Mouldboard no. 19, R		KK 07 03 98	Extra stay R for body no. 15 A - saddle cpl. w. bracket (pos. 6) (From 01.12.96)		KK 07 30 89	Landside knife, L w/nuts
	KK 07 32 91	Mouldboard no. 19, L		KK 07 03 99	Extra stay L for body no. 15 A - saddle cpl. w. bracket (pos. 6) (From 01.12.96)	29	KK 07 36 15	Furrow widener, R
9	KK 01 33 32	Cone screw M14 x 34 mm w/nut		KK 07 38 42	Extra stay R + L, no. 19 E - saddle L = 570 (From 01.12.95)		KK 07 36 16	Furrow widener, L
10	KK 03 31 07	Oval screw M12 x 35 mm w/nut		KK 07 03 96	Extra stay R for body no. 19 E - saddle cpl. w. bracket (pos. 6) (From 01.12.95)	30	KK 03 31 75	Screw M14 x 50 mm w/nut
11	KK 07 30 62	Share 14", R		KK 07 03 97	Extra stay L for body no. 19 E - saddle cpl. w. bracket (pos. 6) (From 01.12.95)	31	KK 03 32 51	Screw M16 x 50 mm w/nut (for E-saddle) (Before 01.02.00)
	KK 07 30 63	Share 14", L		KK 07 38 04	Extra stay R + L, no. 19 A - saddle L = 550 (From 01.12.95)		KK 03 32 56	Screw M16 x 56 mm w/nut (for E-saddle) (From 01.02.00)
	KK 07 30 64	Share 16", R		KK 07 03 92	Extra stay R for body no. 19 A - saddle cpl. w. bracket (pos. 6) (From 01.12.95)		KK 03 32 86	Screw M16 x 85 mm w/nut (for A-saddle) (Before 01.02.00)
	KK 07 30 65	Share 16", L					KK 03 32 95	Screw M16 x 95 mm w/nut (for A-saddle) (From 01.02.00)
12	KK 06 20 25	Nut M16 mm				32	KK 01 29 22	Washer 17 x 40 x 4.58 mm
13	KK 07 34 35	Saddle, R (for E-saddle)				34	KK 01 33 33	Cone screw M14 x 34 mm w/nut
	KK 07 34 36	Saddle, L (for E-saddle)				35	KK 06 36 07	Plate for On-Land ploughs
	KK 07 34 40	Saddle, R (for A-saddle)					KK 07 36 07	Plate for On-Land ploughs cpl.
	KK 07 34 41	Saddle, L (for A-saddle)				36	KK 01 33 46	Screw M14 x 45 mm w/nut
14	KK 07 34 17	Connecting plate no. 12 and 15, R				37	KK 03 31 07	Oval screw M12 x 35 mm
	KK 07 34 18	Connecting plate no. 12 and 15, L				38	KK 07 36 14	Wearing plate
15	KK 07 32 41	Shinpiece no. 12, R				39	KK 01 33 32	Cone screw M14 x 34 mm
	KK 07 32 42	Shinpiece no. 12, L						
	KK 07 32 27	Shinpiece no. 15, R						
	KK 07 32 28	Shinpiece no. 15, L						
	KK 07 32 30	Shinpiece no. 19, R						



40	KK 08 32 35	Mouldboard knife R and L (From 01.12.01)
Pos. 100 - 107 Eco-share from 01.04.00		
100	KK 05 30 90	Reversible point, R
	KK 06 30 90	Reversible point, L
101	KK 01 32 28	Cone screw M12 x 34 mm w/nut
102	KK 07 36 34	Eco-share, R
	KK 07 36 35	Eco-share, L
103	KK 01 01 55	Bushing (for ploughs w/share bolt beam)
	KK 01 01 56	Bushing (for ploughs w/A-beam)
104	KK 03 27 40	Hex screw M16 x 40 mm w/nut (for ploughs w/E-saddle) (Before 01.03.00)
	KK 03 27 50	Hex screw M16 x 50 mm w/nut (for ploughs w/E-saddle) (From 01.03.00)
	KK 03 27 65	Hex screw M16 x 65 mm w/nut (for ploughs w/share bolt beam)
	KK 03 27 75	Hex screw M16 x 75 mm w/nut (for ploughs w/A-beam)
105	KK 01 33 46	Cone screw M14 x 45 mm w/flange nut (for ploughs w/E-saddle) (Before 01.03.00)
	KK 01 33 61	Cone screw M14 x 60 mm w/flange nut (for ploughs w/E-saddle) (From 01.03.00)
	KK 01 33 85	Cone screw M14 x 85 mm w/flange nut (for ploughs w/share bolt beam and A-beam)
106	KK 01 60 15	Flange nut M14
107	KK 01 29 29	Washer (for ploughs w/E-saddle) (From 01.03.00)







26	KK 03 30 04	Oval screw M10 x 20 mm w/nut
27	KK 07 33 50	Trashboard plastic, R
	KK 07 33 51	Trashboard plastic, L
28	KK 07 33 52	Support, R
	KK 07 33 53	Support, L
29	KK 05 33 87	Mouldboard extension, R
	KK 06 33 88	Mouldboard extension, L
31	KK 03 27 30	Hex screw M16 x 13 mm w/nut
32	KK 06 20 25	Nut M16 mm
33	KK 07 30 88	Landside knife w/nuts, R
	KK 07 30 89	Landside knife w/nuts, L
34	KK 03 32 51	Screw M16 x 50 mm w/nut (for E-sad- dle) (Before 01.02.00)
	KK 03 32 56	Screw M16 x 55 mm w/nut (for E-sad- dle) (From 01.02.00)
	KK 03 32 86	Screw M16 x 85 mm w/nut (for A-sad- dle) (Before 01.02.00)
	KK 03 32 95	Screw M16 x 95 mm w/nut (for A-sad- dle) (From 01.02.00)
35	KK 03 31 74	Screw M14 x 45 mm w/nut



1	KK 01 33 32	Cone screw M14 x 34 mm w/nut	21	KK 07 33 03	Bracket, R	KK 07 30 89	Landside knife w/nut, L	
2	KK 07 30 54	Share 14", R		KK 07 33 04	Bracket, L	44	KK 01 29 22	Washer 17 x 40 x 4.58 mm
	KK 07 30 55	Share 14", L	22	KK 01 29 19	Washer 12.5 x 23 x 3.2 mm	45	KK 03 31 75	Screw M14 x 50 mm w/nut
	KK 07 30 56	Share 16", R	23	KK 03 27 40	Hex screw M16 x 40 mm w/nut	46	KK 03 32 51	Screw M16 x 50 mm w/nut (for E-saddle)
	KK 07 30 57	Share 16", L	24	KK 07 36 08	Landside, short, R + L		KK 03 32 86	Screw M16 x 85 mm w/nut (for A-saddle)
	KK 07 30 80	Share 18", R	25	KK 07 36 09	Landside, long, R + L	47	KK 06 36 07	Plate (For On-land ploughs only)
	KK 07 30 81	Share 18", L	26	KK 07 38 22	Stay front (for E-saddle)		KK 07 36 07	Plate cpl. (For On-land ploughs only)
3	KK 05 30 90	Reversible point, R		KK 07 38 16	Stay front (for A-saddle)	48	KK 01 33 46	Screw M14 x 45 mm w/nut
	KK 06 30 90	Reversible point, L	27	KK 01 58 30	Nut M20 mm (Before 01.06.93)	50	KK 07 36 14	Wearing plate
4	KK 07 32 45	Mouldboard, R	28	KK 07 38 17	Stay (Before 01.06.93)	51	KK 01 33 32	Cone screw M14 x 34 mm
	KK 07 32 46	Mouldboard, L	29	KK 07 38 15	Stay, rear (for A-saddle) (Before 01.06.93)			
5	KK 03 31 73	Oval screw M14 x 38 mm w/nut		KK 07 38 20	Stay, R cpl. (for E-saddle) (Before 01.06.93)			
7	KK 01 32 28	Cone screw M12 x 34 mm w/nut		KK 07 38 21	Stay, L cpl. (for E-saddle) (Before 01.06.93)			
8	KK 01 32 34	Cone screw M12 x 38 mm w/nut		KK 07 38 10	Stay, R cpl. (for A-saddle) (Before 01.06.93)			
9	KK 07 30 91	Share knife, R		KK 07 38 11	Stay, L cpl (for A-saddle) (Before 01.06.93)			
	KK 07 30 92	Share knife, L						
	KK 06 30 91	Share knife, R (for Sweden)						
	KK 06 30 92	Share knife, L (for Sweden)						
10	KK 07 34 70	Saddle, R (for E-saddle)	31	KK 07 15 00	Spacer			
	KK 07 34 71	Saddle, L (for E-saddle)	32	KK 03 31 81	Oval screw M14 x 85 mm w/nut			
	KK 07 34 64	Saddle, R (for A-saddle)	33	KK 07 36 15	Furrow widener, R			
	KK 07 34 65	Saddle, L (for A-saddle)		KK 07 30 16	Furrow widener, L			
11	KK 03 31 00	Oval screw M12 x 30 mm w/nut	34	KK 07 30 62	Share 14", R			
12	KK 07 32 72	Shinpiece, R		KK 07 30 63	Share 14", L			
	KK 07 32 73	Shinpiece, L		KK 07 30 64	Share 16", R			
13	KK 03 31 08	Oval screw M12 x 40 mm w/nut		KK 07 30 65	Share 16", L			
14	KK 03 27 30	Hex screw M16 x 30 mm w/nut	35	KK 07 38 05	Stay (for E-saddle) (From 01.06.93)			
16	KK 03 31 75	Oval screw M14 x 50 mm w/nut		KK 07 38 03	Stay (for A-saddle) (From 01.06.93)			
17	KK 07 32 75	Connecting piece, R	36	KK 07 38 34	Bracket for stay, R+L			
	KK 07 32 76	Connecting piece, L	37	KK 07 38 35	Spacing tube 27 x 20.5 x 80 mm			
18	KK 03 31 07	Oval screw M12 x 35 mm w/nut	38	KK 07 38 36	Spacing tube 27 x 20.5 x 69 mm			
19	KK 07 33 00	Trashboard, R	39	KK 07 38 12	Bracket for stay, R			
	KK 07 33 01	Trashboard, L		KK 07 38 13	Bracket for stay, L			
	KK 07 02 92	Trashboard, R cpl.	40	KK 01 30 01	Washer 14 x 30 x 7.5 mm			
	KK 07 02 93	Trashboard, L cpl.	41	KK 01 58 34	Nut M20 mm			
	KK 07 02 94	Trashboard, R + L cpl.	42	KK 03 31 85	Oval screw M14 x 130 mm w/flangenut			
20	KK 07 33 32	Mouldboard extension, R (extra)	43	KK 07 30 88	Landside knife w/nut, R			
	KK 07 33 33	Mouldboard extension,, L (extra)						




1	KK 07 33 00	Trashboard, R	15	KK 08 34 15	Saddle R, A-saddle (for body no. 29)	KK 03 30 16	Oval screw M10 x 30 mm (for body no. 30)
	KK 07 33 01	Trashboard, L		KK 08 34 16	Saddle L, A-saddle (for body no. 29)		
2	KK 08 33 00	Bracket, R		KK 08 34 06	Saddle R, A-saddle (for body no. 30)	KK 01 58 13	Nut M10
	KK 08 33 01	Bracket, L		KK 08 34 07	Saddle L, A-saddle (for body no. 30)	23	KK 07 30 62 Share 14", R (for body no. 30)
3	KK 07 36 15	Furrow widener, R	16	KK 05 30 90	Reversible point, R		KK 07 30 63 Share 14", L (for body no. 30)
	KK 07 36 16	Furrow widener, L		KK 06 30 90	Reversible point, L		KK 07 30 64 Share 16", R (for body no. 30)
4	KK 01 33 32	Cone screw M14 x 34 mm	17	KK 01 32 28	Cone screw M12 x 34 mm		KK 07 30 65 Share 16", L (for body no. 30)
	KK 01 60 13	Flange nut M14		KK 01 58 17	Nut M12	24	KK 08 32 11 Slat no 1, R
5	KK 07 36 09	Landside, long R + L	18	KK 07 30 91	Share knife, R		KK 08 32 21 Slat no 1, L
6	KK 08 34 17	Saddle R, E-saddle (for body no. 29)		KK 07 30 92	Share knife, L	25	KK 08 32 12 Slat no 2, R
	KK 08 34 18	Saddle L, E-saddle (for body no. 29)		KK 06 30 91	Share knife, R (for Sweeden)		KK 08 32 22 Slat no 2, L
	KK 08 34 08	Saddle R, E-saddle (for body no. 30)		KK 06 30 92	Share knife, L (for Sweeden)	26	KK 08 32 13 Slat no 3, R
	KK 08 34 09	Saddle L, E-saddle (for body no. 30)	19	KK 07 30 02	Share 14", R (for body no. 29)		KK 08 32 23 Slat no 3, L
7	KK 03 31 16	Oval screw M12 x 35 mm (for body no. 29 and 30)		KK 07 30 03	Share 14", L (for body no. 29)	27	KK 08 32 14 Slat no 4, R
	KK 01 58 17	Nut M12		KK 07 30 54	Share 14", R (for body no. 30)		KK 08 32 24 Slat no 4, L
	KK 03 31 07	Oval screw M12 x 35 mm (for body no. 30) (Before 01.01.01)		KK 07 30 55	Share 14", L (for body no. 30)	28	KK 07 30 88 Landside knife, R
	KK 01 58 17	Nut M12		KK 07 30 04	Share 16", R (for body no. 29)		KK 07 30 89 Landside knife, L
8	KK 03 31 17	Oval screw M12 x 45 mm (for body no. 29 and 30)		KK 07 30 05	Share 16", L (for body no. 29)	29	KK 03 31 75 Screw M14 x 50 mm
	KK 01 58 17	Nut M12		KK 07 30 56	Share 16", R (for body no. 30)		KK 01 60 15 Flange nut M14
	KK 03 31 11	Oval screw M12 x 45 mm (for body no. 30) (Before 01.01.01)		KK 07 30 57	Share 16", L (for body no. 30)	30	KK 03 32 51 Screw M16 x 50 mm (for E-saddle) (Before 01.02.00)
	KK 01 58 17	Nut M12		KK 07 30 06	Share 18", R (for body no. 29)		KK 03 32 56 Screw M16 x 56 mm (for E-saddle) (From 01.02.00)
	KK 03 31 11	Oval screw M12 x 45 mm (for body no. 30) (Before 01.01.01)		KK 07 30 07	Share 18", L (for body no. 29)		KK 01 58 25 Nut M16
	KK 01 58 17	Nut M12		KK 07 30 80	Share 18", R (for body no. 30)		KK 03 32 86 Screw M16 x 85 mm (for A-saddle) (Before 01.02.00)
9	KK 08 32 10	Slat support, R	20	KK 08 32 15	Connecting piece, plastic (for slat 1-2)		KK 03 32 95 Screw M16 x 95 mm (for A-saddle) (From 01.02.00)
	KK 08 32 20	Slat support, L		KK 08 32 18	Connecting piece, plastic (for slat 2) (for body no. 29)		KK 01 58 25 Nut M16
10	KK 08 38 03	Stay		KK 08 32 16	Connecting piece, plastic (for slat 2-3) (for body no. 30)	31	KK 01 29 22 Washer 17 x 40 x 4.58 mm
11	KK 08 38 05	Stay 1, saddle A (for body no. 29)			Connecting piece, plastic (for slat 3-4)	32	KK 07 30 42 Flush fit share 14", R (for body no. 29)
	KK 08 38 06	Stay 2, saddle A (for body no. 29)		KK 08 32 17	Connecting piece, plastic (for slat 3-4)		KK 07 30 43 Flush fit share 14", L (for body no. 29)
	KK 08 38 02	Stay, saddle A (for body no. 30)	21	KK 07 32 56	Shinpiece, R (for body no. 29)		KK 07 30 44 Flush fit share 16", R (for body no. 29)
	KK 08 38 07	Stay 1, saddle E (for body no. 29)		KK 07 32 57	Shinpiece, L (for body no. 29)		KK 07 30 45 Flush fit share 16", L (for body no. 29)
	KK 08 38 08	Stay 2, saddle E (for body no. 29)		KK 07 32 30	Shinpiece, R (for body no. 30)	33	KK 07 30 30 Flush fit point, R
	KK 08 38 04	Stay, saddle E (for body no. 30)		KK 07 32 31	Shinpiece, L (for body no. 30)		KK 07 30 31 Flush fit point, L
12	KK 07 36 08	Landside, short R + L	22	KK 03 30 06	Oval screw M10 x 30 mm (for body no. 29)	34	KK 08 32 35 Mouldboard knife R and L (From 01.12.01)
13	KK 03 27 50	Hex screw M16 x 50 mm		KK 01 58 13	Nut M10		
	KK 01 58 25	Nut M16					
14	KK 07 36 14	Wearing plate					



Pos. 100 - 107 Eco-share from 01.04.00		
100	KK 05 30 90	Reversible point, R
	KK 06 30 90	Reversible point, L
101	KK 01 32 28	Cone screw M12 x 34 mm
	KK 01 58 17	Nut M12
102	KK 07 36 34	Eco-share, R
	KK 07 36 35	Eco-share, L
103	KK 01 01 55	Bushing (for ploughs w/share bolt beam)
	KK 01 01 56	Bushing (for ploughs w/A-beam)
104	KK 03 27 40	Hex screw M16 x 40 (for ploughs w/E-saddle) (Before 01.03.00)
	KK 03 27 50	Hex screw M16 x 50 mm (for ploughs w/E-saddle) (From 01.03.00)
	KK 01 58 25	Nut M16
	KK 03 27 65	Hex screw M16 x 65 mm w/nut (for ploughs w/share bolt beam)
	KK 01 58 25	Nut M16
	KK 03 27 75	Hex screw M16 x 75 mm w/nut (for ploughs w/A-beam)
	KK 01 58 25	Nut ;16
105	KK 01 33 46	Cone screw M14 x 45 mm (for ploughs w/E-saddle) (Before 01.03.00)
	KK 01 33 61	Cone screw M14 x 60 mm (for ploughs w/E-saddle) (From 01.03.00)
	KK 01 33 85	Cone screw M14 x 85 mm (for ploughs w/share bolt beam and A-beam)
106	KK 01 60 15	Flange nut M14
107	KK 01 29 29	Washer (for ploughs w/E-saddle) (From 01.03.00)



Замовлення запчастин
(050)-407-68-47
(050)-407-68-45



1	KK 03 26 65	Hex screw M12 x 65 mm			
2	KK 02 97 27	Roll pin D5 x 32 mm	Not ill.	KK 05 07 06	Leaf spring std. cpl.
3	KK 05 70 89	Bolt		KK 06 07 03	Leaf spring HD cpl.
4	KK 05 70 63	Main blade		KK 07 70 00	Adjustable holder for leaf spring cpl. (pos. 12 - 17)
5	KK 05 70 64	Blade no. 1		KK 07 70 05	Holder, front for leaf spring cpl. (pos. 25 - 28 and 30)
6	KK 05 70 65	Blade no. 2			
7	KK 05 70 66	Blade no. 3			
8	KK 05 70 67	Blade no. 4			
9	KK 05 70 68	Blade no. 5			
10	KK 03 50 21	Bolt M10 x 30.5 mm			
11	KK 03 50 20	Bolt M10 x 34 mm			
12	KK 06 70 64	Plate L, rear			
13	KK 07 70 12	Spacing tube			
14	KK 06 70 42	Adjustment screw M20 x 75 mm			
15	KK 06 70 63	Plate R, rear			
16	KK 03 26 50	Hex screw M12 x 50 mm			
17	KK 07 70 11	Threaded piece			
18	KK 03 27 70	Hex screw M16 x 70 mm			
19	KK 07 12 40	Beam			
20	KK 06 15 40	Plate			
21	KK 03 27 74	Hex screw M16 x 70 mm			
22	KK 02 99 18	Grease nipple			
23	KK 01 60 01	Nut M24			
24	KK 07 70 20	Bolt			
25	KK 06 70 07	Plate R, front			
26	KK 06 70 08	Plate L, front			
27	KK 03 36 20	Hex screw M12 x 20 mm			
28	KK 03 28 80	Hex screw M20 x 80 mm			
29	KK 03 28 90	Hex screw M20 x 90 mm			
30	KK 07 70 01	Spacing tube			
31	KK 07 15 04	Excenter			
32	KK 07 15 07	Spacer			
33	KK 07 15 00	Bushing			
34	KK 01 58 25	Nut M16			
35	KK 01 58 30	Nut M20			
36	KK 01 58 17	Nut M12			
37	KK 01 60 07	Flange nut M10			





1	KK 03 13 40	Hex screw M8 x 40 mm
2	KK 05 61 56	Cap
3	KK 01 07 75	O-ring D54.5 x 3 mm
4	KK 05 61 12	Disc 18"
	KK 05 61 15	Disc 18" Notched
5	KK 05 61 14	Disc 20"
	KK 05 61 16	Disc 20" Notched
6	KK 06 61 02	Hub w/needles
7	KK 01 07 72	Seal ring
8	KK 01 07 60	Circlip
9	KK 06 61 08	Axle D30
10	KK 02 99 20	Grease nipple
11	KK 06 06 10	Disc coulters arm 18"
	KK 06 06 17	Disc coulters arm 20"
12	KK 05 61 90	Stop collar
13	KK 05 60 03	Stem (for disc coulters Europe)
	KK 05 60 02	Stem (for disc coulters Canada and USA)
14	KK 07 61 21	Bracket
15	KK 03 27 02	Hex screw M16 x 110 mm w/nut
16	KK 07 61 20	Holder
17	KK 03 27 65	Hex screw M16 x 65 mm w/nut
18	KK 01 12 72	Circlip
19	KK 01 04 85	Axle
20	KK 03 26 70	Hex screw M12 x 70 mm w/nut
21	KK 01 12 66	Circlip
22	KK 01 12 92	Washer D30 x 45 x 2.5 mm
Not ill.	KK 06 06 24	Hub cpl.
	KK 07 06 26	Holder cpl.





1	KK 07 64 06	Disc coulters 18"
	KK 07 64 07	Disc coulters 20"
2	KK 07 64 09	Disc coulters, notched 18"
	KK 07 64 10	Disc coulters, notched 20"
3	KK 07 64 99	Plate
4	KK 03 51 14	Screw M10 x 40 mm w/lock nut
5	KK 01 17 50	O-ring 124,5 x 3 mm
6	KK 01 18 66	O-ring 67 x 3 mm
7	KK 01 12 59	Circlip I 62 x 2 mm
8	KK 01 12 66	Circlip A 30 x 1,5 mm
9	KK 01 05 72	Bearing
10	KK 01 05 32	Gasket ring
11	KK 08 60 90	Bearing housing cpl. (ill. no. 4, 5, 6, 8 and 12)
12	KK 08 61 01	Axle
	KK 08 60 86	Disc coulters arm w/bearing, A- and 3D-saddle
	KK 08 60 87	Disc coulters bearing cpl. (ill. no. 7, 9, 10 and 11)
13	KK 07 65 75	Arm
14	KK 07 64 00	Support
15	KK 03 27 02	Hex screw M16 x 110 mm w/nut
16	KK 02 99 20	Grease nipple
17	KK 08 61 02	Stem
18	KK 07 61 21	Bracket
19	KK 07 61 20	Holder
20	KK 01 04 85	Pin
21	KK 01 12 72	Circlip
22	KK 03 27 65	Hex screw M16 x 65 mm w/nut
Not ill.	KK 08 60 89	Hub without axle cpl.






1	KK 03 13 40	Hex screw M8 x 40 mm	KK 07 06 26	Holder for disc coulters cpl.
2	KK 05 61 56	Cap	KK 06 06 26	Spring loaded disc coulters 18" cpl.
3	KK 01 07 75	O-ring	KK 06 06 27	Spring loaded disc coulters 20" cpl.
4	KK 05 61 12	Disc 18"	KK 07 00 41	Spring loaded disc coulters 18", notched cpl.
5	KK 05 61 14	Disc 20"	KK 07 00 43	Spring loaded disc coulters 20", notched cpl.
6	KK 06 61 02	Bearing housing w/bearing		
7	KK 01 07 72	Gasket ring		
8	KK 01 07 60	Circlip		
9	KK 06 61 08	Axle w/circlip and washer		
10	KK 02 99 20	Grease nipple		
11	KK 01 58 35	Nut M20		
12	KK 09 63 05	Arm		
13	KK 09 63 10	Tube		
14	KK 09 63 18	Bolt		
15	KK 09 63 20	Spring		
16	KK 09 63 15	Rod for spring		
17	KK 05 61 90	Stop		
18	KK 03 26 70	Hex screw M12 x 70 mm w/nut		
19	KK 05 60 03	Axle for disc coulters		
20	KK 07 61 20	Holder for axle		
21	KK 07 61 21	Piece for holder		
22	KK 03 27 02	Hex screw M16 x 110 mm w/nut		
23	KK 03 27 65	Hex screw M16 x 65 mm w/nut		
24	KK 01 04 85	Axle		
25	KK 01 12 72	Circlip		
26	KK 09 63 22	Bushing		
27	KK 01 12 66	Circlip		
28	KK 01 12 92	Washer		
29	KK 06 61 67	U-bolt M16 x 120 x 90 mm		
30	KK 07 61 68	Angular disc coulters bracket		
31	KK 07 61 69	Angular clamp bracket		


Not ill.	KK 05 61 15	Disc 18", notched
	KK 05 61 16	Disc 20", notched
	KK 06 06 24	Bearing cpl.
	KK 09 06 06	Arm w/spring cpl.






1	KK 07 64 06	Disc coulters 18"
	KK 07 64 07	Disc coulters 20"
2	KK 07 64 09	Disc coulters, notched 18"
	KK 07 64 10	Disc coulters, notched 20"
3	KK 07 64 99	Plate
4	KK 03 25 40	Screw M10 x 40 mm w/nut
5	KK 01 17 50	O-ring 124,5 x 3 mm
6	KK 01 18 66	O-ring 67 x 3 mm
7	KK 01 12 59	Circlip I 62 x 2 mm
8	KK 01 12 66	Circlip A 30 x 1,5 mm
9	KK 01 05 72	Bearing
10	KK 01 05 32	Gasket ring
11	KK 08 61 00	Bearing housing
12	KK 08 61 01	Axle
	KK 08 60 88	Disc coulters arm w/bearing, A-saddle
	KK 08 60 87	Disc coulters bearing cpl.
13	KK 09 63 05	Arm
14	KK 09 63 10	Tube
15	KK 09 63 20	Spring
16	KK 09 63 15	Rod for spring
17	KK 09 63 22	Bushing
18	KK 09 63 18	Bolt
19	KK 01 58 30	Nut M16
20	KK 05 61 90	Stop
21	KK 03 26 70	Hex screw M12 x 70 mm w/nut
22	KK 05 60 02	Stem (Before 15.11.99)
	KK 05 60 03	Stem (From 15.11.99)
23	KK 01 07 60	Circlip
24	KK 07 61 69	Angular clamp bracket
25	KK 07 61 68	Angular disc coulters bracket
26	KK 06 61 67	U-bolt M16 x 120 x 90 mm
27	KK 01 58 25	Nut M16






1	KK 07 68 12	Mouldboard maize R	11	KK 06 68 11	Arm R, H = 700 mm for HD beam and std. beam H700
	KK 07 68 13	Mouldboard maize L		KK 07 68 58	Arm R, H = 750 mm for std. beam H800 (From 01.12.00)
2	KK 06 68 80	Mouldboard R	16	KK 07 06 53	Fixing bracket with screw and nut (for beam 071240 and 071241)
	KK 07 69 43	Mouldboard R, plastic	17	KK 03 44 46	Setscrew M24 x 53 mm
	KK 06 68 81	Mouldboard L	18	KK 01 58 41	Nut M24
	KK 07 69 44	Mouldboard L, plastic	19	KK 01 58 16	Nut M10
3	KK 03 30 06	Oval screw M10 x 30 mm	20	KK 08 50 76	Clevis
4	KK 05 68 73	Share, short R	21	KK 06 68 61	Bracket HD beam
	KK 06 68 73	Share, short L			
5	KK 06 68 68	Share, long R			
	KK 06 68 69	Share, long L			
6	KK 01 29 06	Washer 10.5 x 25 x 3.4			
7	KK 01 58 25	Nut M16			
22	KK 08 68 01	Skimmer extension			
23	KK 03 30 07	Oval screw M10 x 35 mm			
for all turnable ploughs with Auto Reset beams:					
8	KK 03 27 95	Hex screw M16 x 95 mm			
9	KK 03 42 28	Setscrew M16 x 32 mm			
10	KK 06 06 57	Bracket cpl.			
11	KK 06 68 11	Arm R, H = 700 mm			
	KK 07 68 58	Arm R, H = 750 mm (From 01.12.00)			
	KK 06 68 12	Arm L, H = 700 mm			
	KK 07 68 59	Arm L, H = 750 mm (From 01.12.00)			
for all turnable ploughs with Shear Bolt beams:					
12	KK 07 06 39	Bracket with screws (for LB, LD, RB, RS, RX)			
	KK 07 68 72	Bracket (for LM, LS, RG, RL, RM, VD)			
13	KK 03 42 25	Setscrew M16 x 25 mm			
14	KK 03 42 50	Setscrew M16 x 50 mm			
15	KK 07 68 17	Arm R, H = 700 mm			
	KK 07 68 18	Arm L, H = 700 mm			
	KK 07 68 25	Arm R, H = 800 mm			
	KK 07 68 26	Arm L, H = 800 mm			
	KK 07 68 33	Arm R, H = 700 mm (for VD plough only) (Before 15.03.98)			
	KK 07 68 34	Arm L, H = 700 mm (for VD plough only) (Before 15.03.98)			
for beams on conventional ploughs:					





1	KK 07 17 97	Plate
2	KK 01 10 19	Roll pin D10 x 50 mm
3	KK 01 29 65	Washer
4	KK 07 14 27	Rod for AD-85
	KK 07 14 58	Rod for AD-100
5	KK 03 28 55	Hex screw M20 x 55 mm w/nut
6	KK 07 17 76	Plate
7	KK 06 43 43	Spacer
8	KK 01 08 51	Pin
9	KK 01 07 00	Pin (Before 01.08.97)
	KK 01 10 20	Roll pin D12 x 40 mm (From 01.08.97)
10	KK 01 03 43	Bolt w/handle
11	KK 07 43 80	Cross shaft, Cat II long
	KK 07 43 81	Cross shaft, Cat III
	KK 07 43 71	Cross shaft, Cat II
12	KK 07 17 93	Spacer
13	KK 06 70 39	Screw M24 x 90 mm
14	KK 07 18 99	Contra nut M24
15	KK 07 17 99	Stop
16	KK 07 17 79	Plate
17	KK 01 03 32	Bolt w/head D25.3 x 85 mm
18	KK 03 28 15	Hex screw M20 x 140 mm w/nut
19	KK 03 28 08	Hex screw M20 x 160 mm w/nut
20	KK 03 28 95	Hex screw M20 x 95 mm w/nut
21	KK 03 28 24	Hex screw M20 x 105 mm w/nut
22	KK 03 28 13	Hex screw M20 x 170 mm w/nut
23	KK 07 43 88	Bolt w/head D25.3 x 75 mm
24	KK 07 50 33	Screen
Not ill.	KK 36 11 16	Turnbuckle cpl. (520 - 720)






1	KK 03 28 65	Hex screw M20 x 65 mm w/nut
2	KK 07 17 94	Bolt
3	KK 07 47 21	Slide plate (Before 01.06.00)
	KK 07 28 66	Slide plate (From 01.06.00)
4	KK 01 07 00	Pin (Before 01.08.97)
	KK 01 10 20	Roll pin D12 x 40 mm (From 01.08.97)
5	KK 01 03 43	Bolt w/handle D28 x 100 mm
	KK 01 03 45	Bolt w/handle D36.6 x 100 mm
6	KK 07 17 93	Spacer
7	KK 07 47 07	Slide plate
8	KK 07 47 29	Cross shaft, Cat II
	KK 07 47 27	Cross shaft, Cat III
9	KK 07 47 05	Plate, lower
10	KK 03 28 95	Hex screw M20 x 95 mm w/nut
11	KK 07 17 68	Tube
12	KK 01 12 62	Circlip
13	KK 07 47 04	Fix for cylinder
14	KK 03 28 03	Hex screw M20 x 110 mm w/nut
15	KK 01 10 48	Roll pin D12 x 60 mm
16	KK 01 29 51	Washer
Not ill.	KK 36 11 16	Turnbuckle cpl.




Замовлення запчастин
(050)-407-68-47
(050)-407-68-45




1	KK 07 10 36	Tube for -85
	KK 07 10 37	Tube for -100
	KK 07 20 34	Tube for -115 (LB only)
2	KK 03 28 50	Hex screw M20 x 50 mm w/nut
3	KK 07 10 45	Plate, outer
4	KK 07 10 47	Plate, inner
5	KK 07 11 58	Connecting piece
	KK 07 10 48	Connecting piece (for AB & AD only)
6	KK 03 27 02	Hex screw M16 x 110 mm w/nut
	KK 03 27 55	Hex screw M16 x 55 mm w/nut (for AB & AD only)
7	KK 07 11 72	Parallel rod for -85
	KK 07 10 64	Parallel rod (for AB & AD-85 only)
	KK 07 11 73	Parallel rod for -100
	KK 07 10 65	Parallel rod (for AB & AD-100 only)
	KK 07 20 35	Parallel rod for -115 (LB only)




Замовлення запчастин
(050)-407-68-47
(050)-407-68-45



1	KK 07 17 10	Fix for machine stand	25	KK 07 18 53	Indicator	59	KK 07 14 04	Tube
2	KK 07 17 13	Bolt	26	KK 03 28 35	Hex screw M20 x 35 mm w/nut	60	KK 01 29 40	Washer
3	KK 03 27 02	Hex screw M16 x 110 mm w/nut	27	KK 07 14 91	U-bolt	61	KK 01 10 18	Pin D10 x 40 mm
4	KK 07 17 12	Bolt w/nut for machine stand	28	KK 07 14 94	Indicator	62	KK 03 50 25	Cylinder screw M10 x 30 mm (From 01.05.99)
5	KK 07 17 11	Spring	29	KK 35 11 74	Screw, R	63	KK 01 60 06	Lock nut M10 (From 01.05.99)
6	KK 07 17 14	Bolt	30	KK 02 99 20	Grease nipple	64	KK 12 30 05	Bolt w/head D25.3 x 50 mm
7	KK 01 60 13	Nut M14	31	KK 01 07 00	Pin (Before 01.08.97)	65	KK 07 16 72	Rear orvel
8	KK 07 17 15	Machine stand for beam H = 700 (Before 01.08.01)		KK 01 10 20	Roll pin D12 x 40 mm (From 01.08.97)			
	KK 07 15 24	Machine stand for beam H = 800 (Before 01.08.01)	32	KK 07 17 35	Axle	Not ill.	KK 07 14 12	Tube cpl.
	KK 08 16 24	Tube for machine stand (From 01.08.01)	33	KK 03 28 16	Hex screw M20 x 150 mm w/nut		KK 07 08 05	Turnbuckle cpl. (ill. no 29 and 49)
9	KK 08 16 22	Adjustable machine stand (From 01.08.01)	34	KK 01 16 83	Bushing		KK 08 01 87	Machine stand cpl. (From 01.08.01)
10	KK 03 27 60	Hex screw M16 x 60 mm (From 01.08.01)	35	KK 07 02 06	Support w/bushings			
11	KK 07 43 19	Bushing (From 01.08.01)	36	KK 07 14 03	Bushing			
12	KK 01 58 25	Nut M16 (From 01.08.01)	37	KK 07 14 10	Tube			
13	KK 07 17 56	Fix for turnbuckle	38	KK 07 14 11	Tube			
14	KK 03 27 75	Hex screw M16 x 75 mm	39	KK 07 14 22	Plate			
15	KK 01 60 25	Lock nut M16	40	KK 03 29 26	Hex screw M24 x 265 mm w/nut			
16	KK 07 10 58	Adjustment rod, 3 furrow (for AD-85)	41	KK 07 14 20	Plate			
	KK 07 10 59	Adjustment rod, 4 furrow (for AD-85)	42	KK 07 17 50	Rod (for AD-85) (Before 01.01.00)			
	KK 07 10 60	Adjustment rod, 5 furrow (for AD-85)		KK 07 14 27	Rod w/cut (for AD-85) (From 01.01.00)			
	KK 07 10 61	Adjustment rod, 3 furrow (for AD-100)		KK 07 17 52	Rod (for AD-100) (Before 01.01.00)			
	KK 07 10 62	Adjustment rod, 4 furrow (for AD-100)		KK 07 14 58	Rod w/cut (for AD-100) (From 01.01.00)			
	KK 07 10 63	Adjustment rod, 5 furrow (for AD-100)	43	KK 07 17 48	Fix for rod AD-85			
17	KK 01 60 38	Flange nut M20	44	KK 07 17 47	Fix for cylinder AD-85			
18	KK 07 14 13	Bushing	45	KK 07 17 44	Fix for tie rod			
19	KK 07 17 45	Support, rear	46	KK 01 29 66	Washer			
20	KK 03 27 40	Hex screw M16 x 40 mm w/nut	47	KK 07 18 29	Axle			
21	KK 07 40 50	Holder for depth wheel	48	KK 01 12 77	Circlip			
22	KK 03 29 29	Hex screw M24 x 290 mm w/nut	49	KK 07 18 36	Tube			
23	KK 07 10 30	Tube, 3 furrow (for AD-85)	50	KK 07 17 49	Fix for arm (for AD-100)			
	KK 07 10 31	Tube, 4 furrow (for AD-85)	51	KK 01 12 62	Circlip			
	KK 07 10 32	Tube, 5 furrow (for AD-85)	52	KK 07 17 68	Tube			
	KK 07 10 33	Tube, 3 furrow (for AD-100)	53	KK 07 17 69	Stop for beam			
	KK 07 10 34	Tube, 4 furrow (for AD-100)	54	KK 03 28 08	Hex screw M20 x 160 mm w/nut			
	KK 07 10 35	Tube, 5 furrow (for AD-100)	55	KK 02 99 22	Grease nipple			
24	KK 01 58 17	Nut M12	56	KK 07 14 17	Supporting tube (From 01.05.96)			
			57	KK 01 09 10	Cover			
			58	KK 01 29 22	Washer			



1	KK 07 17 01	Front plate, AD-85 (Before 01.06.00)	28	KK 07 17 00	Headstock	44	KK 01 60 34	Nut M24
	KK 07 28 60	Front plate, AD-85 (From 01.06.00)	29	KK 01 03 21	Bolt		KK 01 60 54	Nut M30, Cat III (From 01.10.95)
	KK 07 17 08	Front plate, AD-100 (Before 01.06.00)	30	KK 03 28 75	Hex screw M20 x 75 mm w/nut	45	KK 07 17 80	Holder for cross shaft, 3 - 4 furrow (Before 01.06.00)
	KK 07 28 61	Front plate, AD-100 (From 01.06.00)	31	KK 01 10 19	Roll pin D10 x 50 mm		KK 07 28 62	Holder for cross shaft, 3 - 4 furrow (From 01.06.00)
2	KK 07 17 37	Axle	32	KK 01 29 65	Washer			
3	KK 07 17 34	Spacer	33	KK 03 28 55	Hex screw M20 x 55 mm w/nut (Before 01.06.00)	46	KK 01 12 62	Circlip
4	KK 03 27 45	Hex screw M16 x 45 mm w/nut		KK 03 29 60	Hex screw M24 x 60 mm w/nut (From 01.06.00)	47	KK 07 17 68	Tube
5	KK 02 99 20	Grease nipple				48	KK 01 15 65	Gasket ring 1/2" (Before 01.07.97)
6	KK 01 07 00	Pin (Before 01.08.97)	34	KK 07 17 20	Holder for cross shaft, 5 furrow (Before 01.06.00)		KK 01 15 85	Gasket ring 3/8" (From 01.07.97)
	KK 01 10 20	Roll pin D12 x 40 mm (From 01.08.97)		KK 07 28 64	Holder for cross shaft, 5 furrow (From 01.06.00)	49	KK 01 21 77	Gasket ring 1/2" (Before 01.07.97)
7	KK 01 06 06	Spanner NV 19-27					KK 01 15 85	Gasket ring 3/8" (From 01.07.97)
8	KK 01 60 50	Spanner NV 27-36	35	KK 07 43 02	Cross shaft, L = 825 mm Cat II cpl.	50	KK 01 21 46	Banjo bolt 1/2" w/1 mm choke (Before 01.07.97)
9	KK 07 17 26	Spanner holder		KK 07 43 04	Cross shaft, L = 920 mm Cat II cpl.		KK 01 20 81	Banjo bolt 3/8" w/1 mm choke (From 01.07.97)
10	KK 03 28 16	Hex screw M20 x 150 mm w/nut		KK 07 43 06	Cross shaft, L = 965 mm Cat III cpl. (Before 01.10.95)			
11	KK 07 17 39	Fix for stay		KK 07 43 94	Cross shaft, L = 965 mm Cat III cpl. (From 01.10.95)	51	KK 01 21 80	Banjo cpl. (Before 01.07.97)
12	KK 01 03 15	Bolt		KK 07 43 08	Cross shaft, L = 720 mm Cat II cpl.		KK 01 25 48	Adjustable banjo 3/8" (From 01.07.97)
13	KK 35 11 39	Screw, R	36	KK 07 43 17	Extension plate, L	52	KK 01 21 47	Banjo bolt 1/2" w/1.4 mm choke (Before 01.07.97)
14	KK 35 11 48	Contra nut	37	KK 07 43 16	Extension plate, R		KK 01 20 82	Banjo bolt 3/8" w/1.4 mm choke (From 01.07.97)
15	KK 35 11 44	Tube	38	KK 07 43 19	Spacer			
16	KK 35 11 40	Screw, L	39	KK 03 27 70	Hex screw M16 x 70 mm w/nut	53	KK 01 15 92	Lock valve 1/2" (Before 01.07.97)
17	KK 06 19 42	Holder for hose	40	KK 03 27 35	Hex screw M16 x 35 mm w/nut		KK 01 25 08	Lock valve 3/8" (From 01.07.97)
18	KK 03 35 45	Hex screw M10 x 45 mm w/nut	41	KK 35 23 52	Cylinder D50 x 200 mm cpl. (see plate no. 225) (Before 01.08.96)	54	KK 01 20 60	Threaded coupling 3/8" - 1/2" (Before 01.07.97)
19	KK 35 23 73	Cylinder without lock valve D75 x 200 mm cpl. (see plate no. 568) (Before 01.08.96)		KK 35 37 03	Cylinder D50 x 200 mm cpl. (see plate no. 525) (From 01.08.96) (Before 01.04.01)		KK 01 22 61	Threaded coupling 3/8" - 3/8" (From 01.07.97)
	KK 35 37 06	Cylinder D75 x 200 mm cpl. (see plate no. 890) (From 01.08.96) (Before 01.04.01)				55	KK 01 21 14	Quick coupling
	KK 35 39 06	Hydraulic cylinder D75 x 200 mm w/90° twisted end cap cpl. (see plate no. 1195) (From 01.04.01)		KK 35 39 03	Hydraulic cylinder D50 x 200 mm w/90° twisted end cap cpl. (see plate no. 1192) (From 01.04.01)	56	KK 01 20 62	Banjo 3/8"
20	KK 01 03 28	Bolt w/head D25.3 x 78 mm				Not ill.	KK 36 11 16	Turnbuckle cpl. (520 - 720)
21	KK 01 15 31	Hose 3/8", L = 2000 mm	42	KK 01 22 27	Hose 3/8", L = 1600 mm (Before 01.07.97)		KK 36 11 19	Turnbuckle cpl., 5 furrow
22	KK 35 11 75	Screw, L		KK 01 22 19	Hose 3/8", L = 1600 mm (From 01.07.97)		KK 35 25 08	Hydraulics for front furrow adj. cpl.
23	KK 35 11 66	Tube					KK 35 19 75	Hydraulics for working width adjustment cpl.
24	KK 35 11 74	Screw, R	43	KK 07 43 29	Bolt for Cat II			
25	KK 07 17 03	Bolt		KK 07 43 30	Bolt for Cat III (Before 01.10.95)			
26	KK 07 17 02	Hinge for headstock		KK 07 43 92	Bolt for Cat III (From 01.10.95)			
27	KK 07 02 15	Spacer						



1	KK 01 19 15	Packing (Before 01.11.90)
	KK 01 19 59	Packing (From 01.11.90)
2	KK 35 22 66	Piston rod w/piston (From 01.11.90)
3	KK 35 22 60	Rod clevis
4	KK 03 25 50	Hex screw M10 x 50 mm w/nut
5	KK 01 20 60	Threaded coupling
6	KK 01 15 65	Gasket ring 1/2"
7	KK 01 18 10	O-ring D44 x 3 mm
8	KK 35 22 80	Cylinder tube
9	KK 35 22 52	Clevis cap
10	KK 01 15 94	Plug
11	KK 35 22 90	Tie rod w/nut
12	KK 35 22 58	Rod cap
13	KK 01 19 52	Packing
14	KK 01 19 09	Scraper
Not ill.	KK 35 23 50	Cylinder D50 x 200 mm without threaded coupling cpl.
	KK 35 23 52	Cylinder D50 x 200 mm w/twisted end cap cpl.
	KK 01 19 69	Packings cpl. (From 01.11.90)
	KK 01 19 75	Seal kit cpl. (Before 01.11.90)



Замовлення запчастин
(050)-407-68-47
(050)-407-68-45



1	KK 35 37 30	Cylinder tube (for cylinder KK 35 37 01 and KK 35 37 02)
	KK 35 37 31	Cylinder tube (for cylinder KK 35 37 03)
2	KK 03 20 02	Screw M6 x 10 mm
3	KK 35 37 21	Piston
4	KK 01 17 30	Piston packing
5	KK 01 17 29	O-ring
6	KK 35 37 40	Piston rod (for cylinder KK 35 37 01 and KK 35 37 03)
	KK 35 37 41	Piston rod (for cylinder KK 35 37 02)
7	KK 01 17 98	O-ring
8	KK 01 17 99	Support ring
9	KK 01 17 33	Ring (Before 15.03.99)
	KK 35 37 92	Lock spring (From 15.03.99)
10	KK 35 37 20	Packing seal
11	KK 01 17 31	Piston rod packing
12	KK 01 17 32	Scraper
13	KK 03 20 16	Screw M10 x 45 mm
14	KK 35 37 22	Clevis

Not ill.	KK 35 37 42	Stop (for cylinder KK 35 37 02)
	KK 35 37 25	Packings cpl.
	KK 35 37 01	Hydraulic cylinder for furrow with adjustment D50 x 200 mm cpl.
	KK 35 37 02	Hydraulic cylinder D50 x 200 mm w/stop cpl.
	KK 35 37 03	Hydraulic cylinder D50 x 200 mm w/90° twisted end cap cpl.





1	KK 35 39 34	Cylinder tube (for cylinder KK 35 39 01 and KK 35 39 02)
	KK 35 39 35	Cylinder tube (for cylinder KK 35 39 03)
2	KK 01 03 90	Piston packing
3	KK 35 39 36	Piston rod (for cylinder KK 35 39 01 and KK 35 39 03)
	KK 35 39 37	Piston rod (for cylinder KK 35 39 02)
4	KK 01 65 17	O-ring D42 x 4 mm
5	KK 03 33 06	Hex screw M6 x 8 mm
6	KK 35 39 26	Packing seal
7	KK 01 30 91	Piston rod packing
8	KK 01 30 89	Scraper
9	KK 03 21 10	Set screw M8 x 8 mm
10	KK 35 39 46	Pin for stop (for cylinder KK 35 39 02)
11	KK 35 39 44	Stop (for cylinder KK 35 39 02)
12	UH 82 56 40	Cylinder screw M12 x 40 mm (for cylinder KK 35 39 02)
13	KK 35 39 22	Clevis
Not ill.	KK 01 30 86	Packings cpl.
	KK 35 39 01	Hydraulic cylinder D50 x 200 mm cpl.
	KK 35 39 02	Hydraulic cylinder D50 x 200 mm w/stop cpl.
	KK 35 39 03	Hydraulic cylinder D50 x 200 mm w/90° twisted end cap cpl.




Замовлення запчастин
(050)-407-68-47
(050)-407-68-45




1	KK 35 21 66	Cylinder tube D75 mm
2	KK 01 18 02	O-ring D70 x 3 mm
3	KK 35 21 61	End cap
4	KK 01 15 65	Gasket ring 1/2"
5	KK 01 15 94	Plug
6	KK 01 58 18	Nut M12
7	KK 35 21 64	Tie rod
8	KK 01 19 06	Piston packing
9	KK 35 21 69	Piston rod w/piston
10	KK 01 19 50	Packing for piston rod D36/D44 x 6 mm
11	KK 35 21 72	Clevis cap w/packings
12	KK 01 19 11	Scraper packing D36/D45 x 7/10 mm
13	KK 01 60 40	Nut R1"
14	KK 35 21 75	Clevis (Before 01.09.98)
	KK 35 21 97	Clevis (From 01.09.98)
Not ill.	KK 01 19 40	Packings cpl.
	KK 35 23 72	Cylinder D75 x 200 mm
	KK 35 23 73	Cylinder D75 x 200 mm w/twisted end cap



Замовлення запчастин
(050)-407-68-47
(050)-407-68-45




1	KK 35 37 32	Cylinder tube for art.no 353704 (cylinder D75 x 200 mm without stop) and 353705 (cylinder D75 x 200 mm w/stop)
	KK 35 37 35	Cylinder tube for art.no 353706 (cylinder D75 x 200 mm w/90° twisted end cap)
	KK 35 37 36	Cylinder tube for art.no 353707 (cylinder D75 x 400 mm w/90° twisted end cap)
2	KK 03 20 06	Screw w/inner hex M6 x 20 mm
3	KK 35 37 27	Piston
4	KK 01 17 36	Piston packing
5	KK 01 17 37	O-ring
6	KK 35 37 44	Piston rod for art.no 353705 (cylinder D75 x 200 mm w/stop)
	KK 35 37 43	Piston rod for art.no 353704 and 353706 (cylinders D75 x 200 mm without stop)
	KK 35 37 46	Piston rod for art.no 353707 (cylinder D75 x 400 mm w/twisted end cap)
7	KK 01 17 38	O-ring
8	KK 01 17 43	Ring
9	KK 01 17 46	Ring (Before 15.03.99)
	KK 35 37 93	Lock spring (From 15.03.99)
10	KK 35 37 26	Packing seal
11	KK 01 17 44	Piston rod packing
12	KK 01 17 45	Scraper
13	KK 35 37 45	Stop for art.no 353705 (cylinder D75 x 200 mm w/stop)
14	KK 03 20 16	Screw w/inner hex M10 x 45 mm
15	KK 35 37 28	Clevis
Not ill.	KK 35 37 29	Packings cpl.
	KK 35 37 04	Cylinder D75 x 200 mm without stop, cpl.
	KK 35 37 05	Cylinder D75 x 200 mm w/stop, cpl.
	KK 35 37 06	Cylinder D75 x 200 mm w/90° twisted end cap, cpl.
	KK 35 37 07	Cylinder D75 x 400 mm w/90° twisted end cap, cpl.



Замовлення запчастин

(050)-407-68-47

(050)-407-68-45



1	KK 35 39 38	Cylinder tube (for cylinder KK 35 39 04 and KK 35 39 05)
	KK 35 39 39	Cylinder tube (for cylinder KK 35 39 06)
2	KK 35 39 40	Piston rod (for cylinder KK 35 39 04 and KK 35 39 06)
	KK 35 39 41	Piston rod (for cylinder KK 35 39 05)
3	KK 01 30 93	Piston packing
4	KK 01 30 96	O-ring D67 x 4 mm
5	KK 01 30 95	Support ring
6	KK 03 33 06	Hex screw M6 x 8 mm
7	KK 35 39 27	Packing seal
8	KK 01 30 94	Piston rod packing
9	KK 01 30 92	Scraper
10	KK 03 21 10	Set screw M8 x 8 mm (for cylinder KK 35 39 05)
11	KK 35 39 46	Pin for stop (for cylinder KK 35 39 05)
12	KK 35 39 45	Stop (for cylinder KK 35 39 05)
13	UH 82 56 40	Cylinder screw M12 x 40 mm
14	KK 35 39 23	Clevis


Not ill.	KK 01 30 87	Packings cpl.
	KK 35 39 04	Hydraulic cylinder D75 x 200 mm cpl.
	KK 35 39 05	Hydraulic cylinder D75 x 200 mm w/stop cpl.
	KK 35 39 06	Hydraulic cylinder D75 x 200 mm w/90° twisted end cap cpl.





1	KK 02 99 20	Grease nipple
2	KK 06 41 18	Spindle w/bearing
3	KK 06 41 17	Threaded piece
4	KK 06 40 21	Holder for spindle
5	KK 03 26 45	Hex screw M12 x 45 mm
6	KK 03 27 40	Hex screw M16 x 40 mm
7	KK 06 40 26	Fixing bracket
8	KK 01 10 05	Roll pin D10 x 70 mm
9	KK 06 41 30	Arm for depth wheel w/axle
10	KK 03 36 30	Hex screw M12 x 30 mm
11	KK 07 40 53	Axle
12	KK 07 40 52	Wheel, steel
13	KK 09 42 06	Tyre 6.00 x 9
	KK 01 13 78	Rim
	KK 09 42 07	Inner tube
14	KK 01 08 06	Packing
15	KK 01 12 00	Bearing
16	KK 01 00 96	Spacing tube
17	KK 01 12 31	Bearing
18	KK 01 29 22	Washer
19	KK 01 29 40	Washer
20	KK 01 60 22	Nut M30
21	KK 07 17 40	Holder for scraper
22	KK 07 17 29	Scraper for 6.00 x 9, rubber wheel
	KK 07 40 54	Scraper for 500 x 165, steel wheel
23	KK 01 29 19	Washer
24	KK 01 60 10	Lock nut M16
25	KK 01 11 67	End cap
26	KK 01 14 00	Cover kit 6.00 x 9 cpl.
27	KK 01 58 17	Nut M12
28	KK 01 58 25	Nut M16
Not ill.	KK 07 04 59	Wheel w/axle 500 x 165 cpl.
	KK 07 04 94	Wheel w/axle and tyre 6.00 x 9 cpl.
	KK 06 04 49	Depth wheel, steel 500 x 165 cpl.
	KK 06 04 68	Depth wheel, rubber 6.00 x 9 cpl.





1	KK 70 95 70	Kverneland AD-85
2	KK 70 95 71	Kverneland AD-100
3	KK 70 97 37	Arrow
4	KK 70 94 79	Info., nuts
5	KK 70 98 43	Safety sign, parking support
6	KK 70 98 44	Safety sign, read instruction manual
7	KK 70 98 41	Safety sign, danger, tractor/implement
8	KK 70 98 23	Safety sign, crush danger
9	KK 70 94 44	Info. for turnbuckle
Not ill.	KK 70 98 47	Patent label
	KK 70 91 24	Oil manual



Замовлення запчастин
(050)-407-68-47
(050)-407-68-45

Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page
KK 01 00 96	55	KK 01 08 51	33	KK 01 15 92	41	KK 01 20 81	41	KK 01 30 01	15	KK 01 33 46	7	KK 01 58 32	5	KK 03 20 06	51
KK 01 01 55	11	KK 01 09 10	39	KK 01 15 94	43	KK 01 20 82	41	KK 01 30 86	47	KK 01 33 46	9	KK 01 58 34	13	KK 03 20 16	45
KK 01 01 55	13	KK 01 10 05	55	KK 01 15 94	49	KK 01 21 14	41	KK 01 30 87	53	KK 01 33 61	11	KK 01 58 34	15	KK 03 20 16	51
KK 01 01 55	19	KK 01 10 18	39	KK 01 16 83	39	KK 01 21 46	41	KK 01 30 89	47	KK 01 33 61	13	KK 01 58 34	9	KK 03 21 10	47
KK 01 01 55	7	KK 01 10 19	33	KK 01 17 29	45	KK 01 21 47	41	KK 01 30 91	47	KK 01 33 61	19	KK 01 58 35	27	KK 03 21 10	53
KK 01 01 56	11	KK 01 10 19	41	KK 01 17 30	45	KK 01 21 77	41	KK 01 30 92	53	KK 01 33 61	7	KK 01 58 41	31	KK 03 25 40	29
KK 01 01 56	13	KK 01 10 20	33	KK 01 17 31	45	KK 01 21 80	41	KK 01 30 93	53	KK 01 33 85	11	KK 01 60 01	21	KK 03 25 50	43
KK 01 01 56	19	KK 01 10 20	35	KK 01 17 32	45	KK 01 22 19	41	KK 01 30 94	53	KK 01 33 85	13	KK 01 60 06	39	KK 03 26 45	55
KK 01 01 56	7	KK 01 10 20	39	KK 01 17 33	45	KK 01 22 27	41	KK 01 30 95	53	KK 01 33 85	19	KK 01 60 07	21	KK 03 26 50	21
KK 01 03 15	41	KK 01 10 20	41	KK 01 17 36	51	KK 01 22 61	41	KK 01 30 96	53	KK 01 33 85	7	KK 01 60 10	55	KK 03 26 65	21
KK 01 03 21	41	KK 01 10 48	35	KK 01 17 37	51	KK 01 25 08	41	KK 01 32 28	11	KK 01 58 13	17	KK 01 60 13	17	KK 03 26 70	23
KK 01 03 28	41	KK 01 11 67	55	KK 01 17 38	51	KK 01 25 48	41	KK 01 32 28	13	KK 01 58 13	17	KK 01 60 13	39	KK 03 26 70	27
KK 01 03 32	33	KK 01 12 00	55	KK 01 17 43	51	KK 01 29 06	31	KK 01 32 28	13	KK 01 58 16	31	KK 01 60 15	11	KK 03 26 70	29
KK 01 03 43	33	KK 01 12 31	55	KK 01 17 44	51	KK 01 29 19	13	KK 01 32 28	15	KK 01 58 17	17	KK 01 60 15	13	KK 03 27 02	23
KK 01 03 43	35	KK 01 12 59	25	KK 01 17 45	51	KK 01 29 19	15	KK 01 32 28	17	KK 01 58 17	17	KK 01 60 15	17	KK 03 27 02	25
KK 01 03 45	35	KK 01 12 59	29	KK 01 17 46	51	KK 01 29 19	5	KK 01 32 28	19	KK 01 58 17	17	KK 01 60 15	19	KK 03 27 02	27
KK 01 03 90	47	KK 01 12 62	35	KK 01 17 50	25	KK 01 29 19	55	KK 01 32 28	7	KK 01 58 17	17	KK 01 60 15	7	KK 03 27 02	37
KK 01 04 85	23	KK 01 12 62	39	KK 01 17 50	29	KK 01 29 19	9	KK 01 32 28	9	KK 01 58 17	17	KK 01 60 22	55	KK 03 27 02	39
KK 01 04 85	25	KK 01 12 62	41	KK 01 17 98	45	KK 01 29 22	13	KK 01 32 34	13	KK 01 58 17	19	KK 01 60 25	39	KK 03 27 25	5
KK 01 04 85	27	KK 01 12 66	23	KK 01 17 99	45	KK 01 29 22	15	KK 01 32 34	15	KK 01 58 17	21	KK 01 60 34	41	KK 03 27 25	9
KK 01 05 32	25	KK 01 12 66	25	KK 01 18 02	49	KK 01 29 22	17	KK 01 32 34	5	KK 01 58 17	39	KK 01 60 38	39	KK 03 27 30	13
KK 01 05 32	29	KK 01 12 66	27	KK 01 18 10	43	KK 01 29 22	39	KK 01 32 34	9	KK 01 58 17	55	KK 01 60 40	49	KK 03 27 30	15
KK 01 05 72	25	KK 01 12 66	29	KK 01 18 66	25	KK 01 29 22	5	KK 01 33 32	13	KK 01 58 18	49	KK 01 60 50	41	KK 03 27 35	13
KK 01 05 72	29	KK 01 12 72	23	KK 01 18 66	29	KK 01 29 22	55	KK 01 33 32	15	KK 01 58 25	17	KK 01 60 54	41	KK 03 27 35	41
KK 01 06 06	41	KK 01 12 72	25	KK 01 19 06	49	KK 01 29 22	9	KK 01 33 32	15	KK 01 58 25	17	KK 01 65 17	47	KK 03 27 35	5
KK 01 07 00	33	KK 01 12 72	27	KK 01 19 09	43	KK 01 29 27	5	KK 01 33 32	17	KK 01 58 25	17	KK 02 97 27	21	KK 03 27 35	9
KK 01 07 00	35	KK 01 12 77	39	KK 01 19 11	49	KK 01 29 27	9	KK 01 33 32	5	KK 01 58 25	19	KK 02 99 18	21	KK 03 27 40	11
KK 01 07 00	39	KK 01 12 92	23	KK 01 19 15	43	KK 01 29 29	11	KK 01 33 32	9	KK 01 58 25	19	KK 02 99 20	23	KK 03 27 40	13
KK 01 07 00	41	KK 01 12 92	27	KK 01 19 40	49	KK 01 29 29	13	KK 01 33 32	9	KK 01 58 25	19	KK 02 99 20	25	KK 03 27 40	15
KK 01 07 60	23	KK 01 13 78	55	KK 01 19 50	49	KK 01 29 29	19	KK 01 33 33	13	KK 01 58 25	21	KK 02 99 20	27	KK 03 27 40	19
KK 01 07 60	27	KK 01 14 00	55	KK 01 19 52	43	KK 01 29 29	7	KK 01 33 33	7	KK 01 58 25	29	KK 02 99 20	39	KK 03 27 40	39
KK 01 07 60	29	KK 01 15 31	41	KK 01 19 59	43	KK 01 29 40	39	KK 01 33 33	9	KK 01 58 25	31	KK 02 99 20	41	KK 03 27 40	55
KK 01 07 72	23	KK 01 15 65	41	KK 01 19 69	43	KK 01 29 40	55	KK 01 33 46	11	KK 01 58 25	39	KK 02 99 20	55	KK 03 27 40	7
KK 01 07 72	27	KK 01 15 65	43	KK 01 19 75	43	KK 01 29 51	35	KK 01 33 46	13	KK 01 58 25	55	KK 02 99 22	39	KK 03 27 45	41
KK 01 07 75	23	KK 01 15 65	49	KK 01 20 60	41	KK 01 29 65	33	KK 01 33 46	15	KK 01 58 30	15	KK 03 13 40	23	KK 03 27 50	11
KK 01 07 75	27	KK 01 15 85	41	KK 01 20 60	43	KK 01 29 65	41	KK 01 33 46	19	KK 01 58 30	21	KK 03 13 40	27	KK 03 27 50	13
KK 01 08 06	55	KK 01 15 85	41	KK 01 20 62	41	KK 01 29 66	39	KK 01 33 46	7	KK 01 58 30	29	KK 03 20 02	45	KK 03 27 50	17

Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page
KK 03 27 50	19	KK 03 28 95	33	KK 03 32 51	5	KK 05 30 90	7	KK 06 06 26	27	KK 06 61 02	23	KK 07 03 97	9	KK 07 11 73	37
KK 03 27 50	7	KK 03 28 95	35	KK 03 32 51	9	KK 05 30 90	9	KK 06 06 27	27	KK 06 61 02	27	KK 07 03 98	9	KK 07 12 40	21
KK 03 27 50	9	KK 03 29 26	39	KK 03 32 56	13	KK 05 33 87	13	KK 06 06 57	31	KK 06 61 08	23	KK 07 03 99	9	KK 07 14 03	39
KK 03 27 55	37	KK 03 29 29	39	KK 03 32 56	17	KK 05 33 87	5	KK 06 07 03	21	KK 06 61 08	27	KK 07 04 59	55	KK 07 14 04	39
KK 03 27 60	39	KK 03 29 60	41	KK 03 32 56	5	KK 05 33 87	9	KK 06 15 40	21	KK 06 61 67	27	KK 07 04 94	55	KK 07 14 10	39
KK 03 27 65	11	KK 03 30 04	13	KK 03 32 56	9	KK 05 60 02	23	KK 06 19 42	41	KK 06 61 67	29	KK 07 06 26	23	KK 07 14 11	39
KK 03 27 65	13	KK 03 30 06	17	KK 03 32 86	13	KK 05 60 02	29	KK 06 20 25	13	KK 06 68 11	31	KK 07 06 26	27	KK 07 14 12	39
KK 03 27 65	19	KK 03 30 06	31	KK 03 32 86	15	KK 05 60 03	23	KK 06 20 25	9	KK 06 68 11	31	KK 07 06 39	31	KK 07 14 13	39
KK 03 27 65	23	KK 03 30 07	31	KK 03 32 86	17	KK 05 60 03	27	KK 06 30 90	11	KK 06 68 12	31	KK 07 06 40	5	KK 07 14 17	39
KK 03 27 65	25	KK 03 30 16	17	KK 03 32 86	5	KK 05 60 03	29	KK 06 30 90	13	KK 06 68 61	31	KK 07 06 40	9	KK 07 14 20	39
KK 03 27 65	27	KK 03 31 00	13	KK 03 32 86	9	KK 05 61 12	23	KK 06 30 90	13	KK 06 68 68	31	KK 07 06 41	5	KK 07 14 22	39
KK 03 27 65	7	KK 03 31 00	15	KK 03 32 95	13	KK 05 61 12	27	KK 06 30 90	15	KK 06 68 69	31	KK 07 06 41	9	KK 07 14 27	33
KK 03 27 70	21	KK 03 31 00	5	KK 03 32 95	17	KK 05 61 14	23	KK 06 30 90	17	KK 06 68 73	31	KK 07 06 42	5	KK 07 14 27	39
KK 03 27 70	41	KK 03 31 00	9	KK 03 32 95	5	KK 05 61 14	27	KK 06 30 90	19	KK 06 68 80	31	KK 07 06 42	9	KK 07 14 58	33
KK 03 27 74	21	KK 03 31 07	15	KK 03 32 95	9	KK 05 61 15	23	KK 06 30 90	5	KK 06 68 81	31	KK 07 06 53	31	KK 07 14 58	39
KK 03 27 75	11	KK 03 31 07	17	KK 03 33 06	47	KK 05 61 15	27	KK 06 30 90	7	KK 06 70 07	21	KK 07 08 05	39	KK 07 14 91	39
KK 03 27 75	13	KK 03 31 07	5	KK 03 33 06	53	KK 05 61 16	23	KK 06 30 90	9	KK 06 70 08	21	KK 07 10 30	39	KK 07 14 94	39
KK 03 27 75	19	KK 03 31 07	9	KK 03 33 32	5	KK 05 61 16	27	KK 06 30 91	15	KK 06 70 39	33	KK 07 10 31	39	KK 07 15 00	15
KK 03 27 75	39	KK 03 31 07	9	KK 03 35 45	41	KK 05 61 56	23	KK 06 30 91	17	KK 06 70 42	21	KK 07 10 32	39	KK 07 15 00	21
KK 03 27 75	7	KK 03 31 08	15	KK 03 36 20	21	KK 05 61 56	27	KK 06 30 91	5	KK 06 70 63	21	KK 07 10 33	39	KK 07 15 04	21
KK 03 27 95	31	KK 03 31 11	17	KK 03 36 30	55	KK 05 61 90	23	KK 06 30 92	15	KK 06 70 64	21	KK 07 10 34	39	KK 07 15 07	21
KK 03 28 03	35	KK 03 31 16	17	KK 03 42 25	31	KK 05 61 90	27	KK 06 30 92	17	KK 07 00 41	27	KK 07 10 35	39	KK 07 15 24	39
KK 03 28 08	33	KK 03 31 17	17	KK 03 42 28	31	KK 05 61 90	29	KK 06 30 92	5	KK 07 00 43	27	KK 07 10 36	37	KK 07 16 72	39
KK 03 28 08	39	KK 03 31 18	13	KK 03 42 50	31	KK 05 68 73	31	KK 06 33 88	13	KK 07 02 06	39	KK 07 10 37	37	KK 07 17 00	41
KK 03 28 13	33	KK 03 31 19	13	KK 03 44 46	31	KK 05 70 63	21	KK 06 33 88	5	KK 07 02 15	41	KK 07 10 45	37	KK 07 17 01	41
KK 03 28 15	33	KK 03 31 73	15	KK 03 50 20	21	KK 05 70 64	21	KK 06 33 88	9	KK 07 02 92	15	KK 07 10 47	37	KK 07 17 02	41
KK 03 28 16	39	KK 03 31 74	13	KK 03 50 21	21	KK 05 70 65	21	KK 06 36 07	15	KK 07 02 93	15	KK 07 10 48	37	KK 07 17 03	41
KK 03 28 16	41	KK 03 31 75	15	KK 03 50 25	39	KK 05 70 66	21	KK 06 36 07	7	KK 07 02 94	15	KK 07 10 58	39	KK 07 17 08	41
KK 03 28 24	33	KK 03 31 75	15	KK 03 51 14	25	KK 05 70 67	21	KK 06 36 07	9	KK 07 03 88	9	KK 07 10 59	39	KK 07 17 10	39
KK 03 28 35	39	KK 03 31 75	17	KK 05 07 06	21	KK 05 70 68	21	KK 06 38 01	5	KK 07 03 89	9	KK 07 10 60	39	KK 07 17 11	39
KK 03 28 50	37	KK 03 31 75	5	KK 05 30 90	11	KK 05 70 89	21	KK 06 38 01	5	KK 07 03 90	5	KK 07 10 61	39	KK 07 17 12	39
KK 03 28 55	33	KK 03 31 75	9	KK 05 30 90	13	KK 06 04 49	55	KK 06 40 21	55	KK 07 03 91	5	KK 07 10 62	39	KK 07 17 13	39
KK 03 28 55	41	KK 03 31 81	15	KK 05 30 90	13	KK 06 04 68	55	KK 06 40 26	55	KK 07 03 92	9	KK 07 10 63	39	KK 07 17 14	39
KK 03 28 65	35	KK 03 31 85	15	KK 05 30 90	15	KK 06 06 10	23	KK 06 41 17	55	KK 07 03 93	9	KK 07 10 64	37	KK 07 17 15	39
KK 03 28 75	41	KK 03 32 51	13	KK 05 30 90	17	KK 06 06 17	23	KK 06 41 18	55	KK 07 03 94	5	KK 07 10 65	37	KK 07 17 20	41
KK 03 28 80	21	KK 03 32 51	15	KK 05 30 90	19	KK 06 06 24	23	KK 06 41 30	55	KK 07 03 95	5	KK 07 11 58	37	KK 07 17 26	41
KK 03 28 90	21	KK 03 32 51	17	KK 05 30 90	5	KK 06 06 24	27	KK 06 43 43	33	KK 07 03 96	9	KK 07 11 72	37	KK 07 17 29	55

Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page
KK 07 17 34	41	KK 07 30 01	5	KK 07 30 55	9	KK 07 30 88	9	KK 07 32 57	5	KK 07 33 10	5	KK 07 36 07	9	KK 07 38 01	5
KK 07 17 35	39	KK 07 30 02	17	KK 07 30 56	13	KK 07 30 89	13	KK 07 32 60	5	KK 07 33 10	9	KK 07 36 08	13	KK 07 38 01	9
KK 07 17 37	41	KK 07 30 02	5	KK 07 30 56	15	KK 07 30 89	15	KK 07 32 61	5	KK 07 33 11	5	KK 07 36 08	15	KK 07 38 03	15
KK 07 17 39	41	KK 07 30 03	17	KK 07 30 56	17	KK 07 30 89	17	KK 07 32 63	5	KK 07 33 11	9	KK 07 36 08	17	KK 07 38 03	5
KK 07 17 40	55	KK 07 30 03	5	KK 07 30 56	9	KK 07 30 89	5	KK 07 32 64	5	KK 07 33 28	13	KK 07 36 08	5	KK 07 38 03	5
KK 07 17 44	39	KK 07 30 04	17	KK 07 30 57	13	KK 07 30 89	9	KK 07 32 66	5	KK 07 33 29	13	KK 07 36 08	9	KK 07 38 04	9
KK 07 17 45	39	KK 07 30 04	5	KK 07 30 57	15	KK 07 30 91	13	KK 07 32 66	9	KK 07 33 32	15	KK 07 36 09	13	KK 07 38 04	9
KK 07 17 47	39	KK 07 30 05	17	KK 07 30 57	17	KK 07 30 91	15	KK 07 32 67	5	KK 07 33 33	15	KK 07 36 09	15	KK 07 38 05	15
KK 07 17 48	39	KK 07 30 05	5	KK 07 30 57	9	KK 07 30 91	17	KK 07 32 67	9	KK 07 33 38	13	KK 07 36 09	17	KK 07 38 05	9
KK 07 17 49	39	KK 07 30 06	17	KK 07 30 62	13	KK 07 30 91	5	KK 07 32 72	13	KK 07 33 39	13	KK 07 36 09	5	KK 07 38 07	5
KK 07 17 50	39	KK 07 30 06	5	KK 07 30 62	15	KK 07 30 91	9	KK 07 32 72	15	KK 07 33 50	13	KK 07 36 09	9	KK 07 38 08	5
KK 07 17 52	39	KK 07 30 07	17	KK 07 30 62	17	KK 07 30 92	13	KK 07 32 73	13	KK 07 33 51	13	KK 07 36 14	13	KK 07 38 10	15
KK 07 17 56	39	KK 07 30 07	5	KK 07 30 62	9	KK 07 30 92	15	KK 07 32 73	15	KK 07 33 52	13	KK 07 36 14	15	KK 07 38 11	15
KK 07 17 68	35	KK 07 30 08	5	KK 07 30 63	13	KK 07 30 92	17	KK 07 32 75	13	KK 07 33 53	13	KK 07 36 14	17	KK 07 38 12	15
KK 07 17 68	39	KK 07 30 09	5	KK 07 30 63	15	KK 07 30 92	5	KK 07 32 75	15	KK 07 33 54	13	KK 07 36 14	7	KK 07 38 13	15
KK 07 17 68	41	KK 07 30 16	15	KK 07 30 63	17	KK 07 30 92	9	KK 07 32 76	13	KK 07 34 06	5	KK 07 36 14	9	KK 07 38 15	15
KK 07 17 69	39	KK 07 30 30	17	KK 07 30 63	9	KK 07 32 24	9	KK 07 32 76	15	KK 07 34 07	5	KK 07 36 15	13	KK 07 38 16	15
KK 07 17 76	33	KK 07 30 30	5	KK 07 30 64	13	KK 07 32 25	9	KK 07 32 78	13	KK 07 34 11	5	KK 07 36 15	15	KK 07 38 17	15
KK 07 17 79	33	KK 07 30 31	17	KK 07 30 64	15	KK 07 32 27	9	KK 07 32 79	13	KK 07 34 12	5	KK 07 36 15	17	KK 07 38 20	15
KK 07 17 80	41	KK 07 30 31	5	KK 07 30 64	17	KK 07 32 28	9	KK 07 32 80	5	KK 07 34 14	5	KK 07 36 15	5	KK 07 38 21	15
KK 07 17 93	33	KK 07 30 40	5	KK 07 30 64	9	KK 07 32 30	17	KK 07 32 81	5	KK 07 34 15	5	KK 07 36 15	9	KK 07 38 22	15
KK 07 17 93	35	KK 07 30 41	5	KK 07 30 65	13	KK 07 32 30	9	KK 07 32 86	5	KK 07 34 17	9	KK 07 36 16	13	KK 07 38 26	13
KK 07 17 94	35	KK 07 30 42	17	KK 07 30 65	15	KK 07 32 31	17	KK 07 32 87	5	KK 07 34 18	9	KK 07 36 16	17	KK 07 38 26	9
KK 07 17 97	33	KK 07 30 42	5	KK 07 30 65	17	KK 07 32 31	9	KK 07 32 90	5	KK 07 34 35	9	KK 07 36 16	5	KK 07 38 26	9
KK 07 17 99	33	KK 07 30 43	17	KK 07 30 65	9	KK 07 32 36	9	KK 07 32 90	9	KK 07 34 36	9	KK 07 36 16	9	KK 07 38 29	13
KK 07 18 29	39	KK 07 30 43	5	KK 07 30 80	13	KK 07 32 37	9	KK 07 32 91	5	KK 07 34 40	9	KK 07 36 34	11	KK 07 38 29	9
KK 07 18 36	39	KK 07 30 44	17	KK 07 30 80	15	KK 07 32 39	9	KK 07 32 91	9	KK 07 34 41	9	KK 07 36 34	13	KK 07 38 30	5
KK 07 18 53	39	KK 07 30 44	5	KK 07 30 80	17	KK 07 32 40	9	KK 07 33 00	15	KK 07 34 64	13	KK 07 36 34	19	KK 07 38 31	5
KK 07 18 99	33	KK 07 30 45	17	KK 07 30 80	9	KK 07 32 41	9	KK 07 33 00	17	KK 07 34 64	15	KK 07 36 34	7	KK 07 38 31	9
KK 07 20 34	37	KK 07 30 45	5	KK 07 30 81	13	KK 07 32 42	9	KK 07 33 00	5	KK 07 34 65	13	KK 07 36 35	11	KK 07 38 34	15
KK 07 20 35	37	KK 07 30 54	13	KK 07 30 81	15	KK 07 32 45	15	KK 07 33 00	9	KK 07 34 65	15	KK 07 36 35	13	KK 07 38 35	15
KK 07 28 60	41	KK 07 30 54	15	KK 07 30 81	17	KK 07 32 46	15	KK 07 33 01	15	KK 07 34 70	13	KK 07 36 35	19	KK 07 38 36	15
KK 07 28 61	41	KK 07 30 54	17	KK 07 30 81	9	KK 07 32 50	5	KK 07 33 01	17	KK 07 34 70	15	KK 07 36 35	7	KK 07 38 42	9
KK 07 28 62	41	KK 07 30 54	9	KK 07 30 88	13	KK 07 32 51	5	KK 07 33 01	5	KK 07 34 71	13	KK 07 38 00	13	KK 07 40 50	39
KK 07 28 64	41	KK 07 30 55	13	KK 07 30 88	15	KK 07 32 56	17	KK 07 33 01	9	KK 07 34 71	15	KK 07 38 00	5	KK 07 40 52	55
KK 07 28 66	35	KK 07 30 55	15	KK 07 30 88	17	KK 07 32 56	5	KK 07 33 03	15	KK 07 36 07	15	KK 07 38 00	9	KK 07 40 53	55
KK 07 30 00	5	KK 07 30 55	17	KK 07 30 88	5	KK 07 32 57	17	KK 07 33 04	15	KK 07 36 07	7	KK 07 38 01	13	KK 07 40 54	55

Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page
KK 07 43 02 41		KK 07 61 68 29		KK 07 70 01 21		KK 08 34 08 17		KK 09 63 05 27		KK 35 22 58 43		KK 35 37 31 45		KK 35 39 39 53	
KK 07 43 04 41		KK 07 61 69 27		KK 07 70 05 21		KK 08 34 09 17		KK 09 63 05 29		KK 35 22 60 43		KK 35 37 32 51		KK 35 39 40 53	
KK 07 43 06 41		KK 07 61 69 29		KK 07 70 11 21		KK 08 34 15 17		KK 09 63 10 27		KK 35 22 66 43		KK 35 37 35 51		KK 35 39 41 53	
KK 07 43 08 41		KK 07 64 00 25		KK 07 70 12 21		KK 08 34 16 17		KK 09 63 10 29		KK 35 22 80 43		KK 35 37 36 51		KK 35 39 44 47	
KK 07 43 16 41		KK 07 64 06 25		KK 07 70 20 21		KK 08 34 17 17		KK 09 63 15 27		KK 35 22 90 43		KK 35 37 40 45		KK 35 39 45 53	
KK 07 43 17 41		KK 07 64 06 29		KK 08 01 87 39		KK 08 34 18 17		KK 09 63 15 29		KK 35 23 50 43		KK 35 37 41 45		KK 35 39 46 47	
KK 07 43 19 39		KK 07 64 07 25		KK 08 16 22 39		KK 08 38 02 17		KK 09 63 18 27		KK 35 23 52 41		KK 35 37 42 45		KK 35 39 46 53	
KK 07 43 19 41		KK 07 64 07 29		KK 08 16 24 39		KK 08 38 03 17		KK 09 63 18 29		KK 35 23 52 43		KK 35 37 43 51		KK 36 11 16 33	
KK 07 43 29 41		KK 07 64 09 25		KK 08 32 10 17		KK 08 38 04 17		KK 09 63 20 27		KK 35 23 72 49		KK 35 37 44 51		KK 36 11 16 41	
KK 07 43 30 41		KK 07 64 09 29		KK 08 32 11 17		KK 08 38 05 17		KK 09 63 20 29		KK 35 23 73 41		KK 35 37 45 51		KK 36 11 19 41	
KK 07 43 71 33		KK 07 64 10 25		KK 08 32 12 17		KK 08 38 06 17		KK 09 63 22 27		KK 35 23 73 49		KK 35 37 46 51		KK 70 91 24 57	
KK 07 43 80 33		KK 07 64 10 29		KK 08 32 13 17		KK 08 38 07 17		KK 09 63 22 29		KK 35 25 08 41		KK 35 37 92 45		KK 70 94 44 57	
KK 07 43 81 33		KK 07 64 99 25		KK 08 32 14 17		KK 08 38 08 17		KK 12 30 05 39		KK 35 37 01 45		KK 35 37 93 51		KK 70 94 79 57	
KK 07 43 88 33		KK 07 64 99 29		KK 08 32 15 17		KK 08 38 09 5		KK 35 11 39 41		KK 35 37 02 45		KK 35 39 01 47		KK 70 95 70 57	
KK 07 43 92 41		KK 07 65 75 25		KK 08 32 16 17		KK 08 38 10 5		KK 35 11 40 41		KK 35 37 03 41		KK 35 39 02 47		KK 70 95 71 57	
KK 07 43 94 41		KK 07 68 12 31		KK 08 32 17 17		KK 08 50 76 31		KK 35 11 44 41		KK 35 37 03 45		KK 35 39 03 41		KK 70 97 37 57	
KK 07 47 04 35		KK 07 68 13 31		KK 08 32 18 17		KK 08 60 86 25		KK 35 11 48 41		KK 35 37 04 51		KK 35 39 03 47		KK 70 98 23 57	
KK 07 47 05 35		KK 07 68 17 31		KK 08 32 20 17		KK 08 60 87 25		KK 35 11 66 41		KK 35 37 05 51		KK 35 39 04 53		KK 70 98 41 57	
KK 07 47 07 35		KK 07 68 18 31		KK 08 32 21 17		KK 08 60 87 29		KK 35 11 74 39		KK 35 37 06 41		KK 35 39 05 53		KK 70 98 43 57	
KK 07 47 21 35		KK 07 68 25 31		KK 08 32 22 17		KK 08 60 88 29		KK 35 11 74 41		KK 35 37 06 51		KK 35 39 06 41		KK 70 98 44 57	
KK 07 47 27 35		KK 07 68 26 31		KK 08 32 23 17		KK 08 60 89 25		KK 35 11 75 41		KK 35 37 07 51		KK 35 39 06 53		KK 70 98 47 57	
KK 07 47 29 35		KK 07 68 33 31		KK 08 32 24 17		KK 08 60 90 25		KK 35 19 75 41		KK 35 37 20 45		KK 35 39 22 47		UH 82 56 40 47	
KK 07 50 33 33		KK 07 68 34 31		KK 08 32 28 5		KK 08 61 00 29		KK 35 21 61 49		KK 35 37 21 45		KK 35 39 23 53		UH 82 56 40 53	
KK 07 61 20 23		KK 07 68 58 31		KK 08 32 29 5		KK 08 61 01 25		KK 35 21 64 49		KK 35 37 22 45		KK 35 39 26 47			
KK 07 61 20 25		KK 07 68 58 31		KK 08 32 35 17		KK 08 61 01 29		KK 35 21 66 49		KK 35 37 25 45		KK 35 39 27 53			
KK 07 61 20 27		KK 07 68 59 31		KK 08 32 35 7		KK 08 61 02 25		KK 35 21 69 49		KK 35 37 26 51		KK 35 39 34 47			
KK 07 61 21 23		KK 07 68 72 31		KK 08 33 00 17		KK 08 68 01 31		KK 35 21 72 49		KK 35 37 27 51		KK 35 39 35 47			
KK 07 61 21 25		KK 07 69 43 31		KK 08 33 01 17		KK 09 06 06 27		KK 35 21 75 49		KK 35 37 28 51		KK 35 39 36 47			
KK 07 61 21 27		KK 07 69 44 31		KK 08 34 06 17		KK 09 42 06 55		KK 35 21 97 49		KK 35 37 29 51		KK 35 39 37 47			
KK 07 61 68 27		KK 07 70 00 21		KK 08 34 07 17		KK 09 42 07 55		KK 35 22 52 43		KK 35 37 30 45		KK 35 39 38 53			