

Spare Parts List

Model EM/LM

Mounted plough

No 733025

Hannover
Agro

Замовлення запчастин


(050)-407-68-47

(050)-407-68-45



Notes

GB Model	GB Interbody clearance	GB Headstock
D Modell	D Körperlängsabstand	D Drehwerk
F Modèle	F Dégagement sous age	F Type de tête
E Modelo	E Separación entre cuerpos	E Tipo de cabezal



GB Serial number	Type of beam:	GB Type of body
D Seriennummer	Heavy Duty	D Körperform
F Numéro de série	Vibromat	F Type de corps
E Numero de serie	On-land	E Tipo de cuerpo

Замовлення запчастин

(GB) Complete model code and serial number must be stated to avoid mistakes when ordering spare parts and misunderstandings regarding service consultations. The identification plate is located on the headstock.

(F) Le code complet et le numéro de série doivent être indiqués pour éviter des erreurs lors de la commande de pièces de rechange et des malentendus concernant des demandes de Service-Après-Vente. La plaque d'identité est située sur la tête.

(D) Um bei Ersatzteilbestellungen und Serviceleistungen Fehler und Mißverständnisse zu vermeiden ist es erforderlich, daß die genaue Bezeichnung und die Seriennummer angegeben werden. Die Plakette befindet sich am Drehwerk.

(E) Debe figura el código completo del modelo y el número de serie para evitar errores al pedir las piezas de recambio y al hacer consultas técnicas. La placa de identificación esta situada en el cabezal.

Plate		Page
244	Bodies no 6, 7, 8, 9 and 28.....	4
367	Bodies no 12, 15 and 19.....	8
414	Body no 20 (Finger Body) (Before 01.03.99)	12
1089	Bodies no. 29 and no. 30	14
494	Body no 14 (Plastic mouldboard)	18
458	Auto Reset Beam.....	20
1009	Beam (Shear bolt).....	22
1073	Disc coulter 18" and 20", E-saddle (From 01.01.99).....	24
1007	Disc coulter for shear bolt beam	26
341	Manure skimmer / Maize skimmer	28
495	Turnable cross shaft mod. 110 - 160	30
1103	Cross shafts for headstock mod. 200.....	32
380	Turn-over device mod. 110	34
355	Turn-over device mod. 160	36
1102	Turn-over device mod. 200	38
330	Turn-over device mod. 240	40
1075	Frame for EM/LM for headstock 110/160/240 (Before 01.01.02)	42
1151	Frame for EM/LM for headstock 200 (Before 01.01.02)	46
1171	Frame for EM/LM for headstock 110 and 200 (From 01.01.02)	48
360	Hydraulic layout for headstock 80, 110 and 160 (for 80 and 110 from 01.06.94)	50
1107	Hydraulic layout for headstock mod. 200 EM/LM (From 01.01.00)	52
578	Hydraulic layout for mod. 240	54
1063	Turn-over cylinder D90 x 150 mm for mod. 160(From 01.12.98)	56
1037	Turn-over cylinder D80 x 130 mm mod. 80 and 110 (From 01.04.98)	58
525	Hydraulic cylinder D50 x 200 mm (353701 - 353703) (From 01.08.96) (Before 01.04.01)	60
1192	Hydraulic cylinder D50 x 200 mm (353901 - 353903) (From 01.04.01)	62
890	Hydraulic cylinder D75 x 200 mm (353704 - 353707) (From 01.08.96) (Before 01.04.01)	64
1195	Hydraulic cylinder D75 x 200 mm (353904 - 353906) (From 01.04.01)	66
1005	Turn-over cylinder D75 x 420 mm for mod. 240 (From 01.07.97)	68
1111	Turn-over cylinder D80 x 300 mm	70
1114	Front furrow adjustment cylinder D50 x 200 mm	72
188	Depth wheel for mod. 80 - 110 - 160 - 200	74
299	Depth wheel 200 x 14.5 (Before 01.06.99)	76
418	Depth wheel with shock absorber	78
340	Depth/transport wheel 87	80
514	Depth/transport wheel 93 (Before 01.06.99)	84
1088	Depth/transport wheel 99 (From 01.06.99)	86
1228	Bracket for depth/ transport wheel 99 (From 01.06.99)	92
1076	Transfers for EM/LM	94
	Index	96




1	KK 07 30 00	Share 12" R (30 cm)	KK 07 38 03	Stay R + L for body no. 6, 7 and 8 A - saddle, L = 560 (And no. 9 before 01.12.95)	KK 07 06 41	Trashboard, L cpl.		
	KK 07 30 01	Share 12" L (30 cm)			KK 07 06 42	Trashboard, R + L cpl.		
	KK 07 30 02	Share 14" R (35 cm)	KK 07 38 31	Stay R + L for body no. 9 E - saddle, L = 725 (From 01.12.95)	17	KK 03 33 32	Cone screw M14 x 34 mm w/nut	
	KK 07 30 03	Share 14" L (35 cm)			18	KK 03 27 25	Hex screw M16 x 27 mm w/nut	
	KK 07 30 04	Share 16" R (40 cm)	KK 07 38 30	Stay R + L for body no. 9 A - saddle, L = 710 (From 01.12.95)	19	KK 03 31 07	Oval screw M12 x 35 mm w/nut	
	KK 07 30 05	Share 16" L (40 cm)			20	KK 01 32 34	Cone screw M12 x 38 mm w/nut	
	KK 07 30 06	Share 18" R (45 cm)	KK 06 38 01	Extra stay R + L, no. 9 E - saddle L = 550 (From 01.12.95)	21	KK 07 30 91	Share knife, R	
	KK 07 30 07	Share 18" L (45 cm)				KK 07 30 92	Share knife, L	
	KK 07 30 08	Share 20" R (50 cm)	KK 07 03 94	Extra stay R for body no. 9 E - saddle, cpl. w. bracket (pos. 12) (From 01.12.95)		KK 06 30 91	Share knife, R (for Sweden)	
	KK 07 30 09	Share 20" L (50 cm)	KK 07 03 95	Extra stay L for body no. 9 E - saddle, cpl. w. bracket (pos. 12) (From 01.12.95)		KK 06 30 92	Share knife, L (for Sweden)	
2	KK 05 30 90	Reversible point, R			23	KK 07 36 09	Landside, long R + L	
	KK 06 30 90	Reversible point, L	KK 07 38 03	Extra stay R + L, no. 9 A - saddle L = 560 (From 01.12.95)	24	KK 07 32 66	Bracket for stay, body no. 6 and 9, R	
3	KK 07 34 06	Saddle, R (for E-saddle)				KK 07 32 67	Bracket for stay, body no. 6 and 9, L	
	KK 07 34 07	Saddle, L (for E-saddle)	KK 07 03 90	Extra stay R for body no. 9 A - saddle, cpl. w. bracket (pos. 12) (From 01.12.95)	25	KK 07 34 14	Connecting plate, 16" - 20", R	
	KK 07 34 11	Saddle, R (for A-saddle)				KK 07 34 15	Connecting plate, 16" - 20", L	
	KK 07 34 12	Saddle, L (for A-saddle)	KK 07 03 91	Extra stay L for body no. 9 A - saddle, cpl. w. bracket (pos. 12) (From 01.12.95)	26	KK 07 30 40	Flush fit share 12", R	
4	KK 01 33 32	Cone screw M14 x 34 mm w/nut				KK 07 30 41	Flush fit share 12", L	
5	KK 03 31 00	Oval screw M12 x 30 mm w/nut	KK 08 38 09	Stay R + L for body no. 28 A - saddle (From 01.03.03)		KK 07 30 42	Flush fit share 14", R	
6	KK 07 32 60	Mouldboard 12" - 16" no. 6, R	KK 08 38 10	Stay R + L for body no. 28 E - saddle (From 01.03.03)		KK 07 30 43	Flush fit share 14", L	
	KK 07 32 61	Mouldboard 12" - 16" no. 6, L				KK 07 30 44	Flush fit share 16", R	
	KK 07 32 63	Mouldboard 12" - 14" no. 7, R	10	KK 07 36 08	Landside, R and L, short		KK 07 30 45	Flush fit share 16", L
	KK 07 32 64	Mouldboard 12" - 14" no. 7, L	11	KK 01 58 32	Nut M20 mm	27	KK 07 30 30	Flush point, R
	KK 07 32 80	Mouldboard 12" no. 8, R	12	KK 07 38 00	Bracket for stay, R for body no. 6, 7, 8 (And no. 9 before 01.12.95)		KK 07 30 31	Flush point, L
	KK 07 32 81	Mouldboard 12" no. 8, L				28	KK 01 29 27	Washer 17 x 30 x 3 mm (for use with two stays)
	KK 07 32 86	Mouldboard 14" - 18" no. 8, R	KK 07 38 01	Bracket for stay, L for body no. 6, 7, 8 (And no. 9 before 01.12.95)	30	KK 07 36 15	Furrow widener, R	
	KK 07 32 87	Mouldboard 14" - 18" no. 8, L				KK 07 36 16	Furrow widener, L	
	KK 07 32 90	Mouldboard 14" - 20" no. 9, R	KK 07 38 07	Bracket for stay, R for body no. 9 (From 01.12.95)	31	KK 07 30 88	Landside knife w/screw, R	
	KK 07 32 91	Mouldboard 14" - 20" no. 9, L				KK 07 30 89	Landside knife w/screw, L	
	KK 08 32 28	Mouldboard no. 28, R (From 01.03.03)	KK 07 38 08	Bracket for stay, L for body no. 9 (From 01.12.95)	32	KK 03 32 51	Screw M16 x 50 mm w/nut (for E-saddle) (Before 01.02.00)	
	KK 08 32 29	Mouldboard no. 28, L (From 01.03.03)				KK 03 32 56	Screw M16 x 55 mm w/ nut (for E-saddle) (From 01.02.00)	
7	KK 07 32 50	Shinpiece for no. 8, R	13	KK 01 29 19	Washer 12.5 x 23 x 3.2 mm		KK 03 32 86	Screw M16 x 85 mm w/nut (for A-saddle) (Before 01.02.00)
	KK 07 32 51	Shinpiece for no. 8, L	14	KK 05 33 87	Mouldboard extension, R		KK 03 32 95	Screw M16 x 95 mm w/nut (for A-saddle) (From 01.02.00)
	KK 07 32 56	Shinpiece for no. 6 and 9, R		KK 06 33 88	Mouldboard extension, L			
	KK 07 32 57	Shinpiece for no. 6 and 9, L	15	KK 07 33 10	Bracket for trashboard, R			
8	KK 03 27 35	Hex screw M16 x 35 mm w/nut		KK 07 33 11	Bracket for trashboard, L			
9	KK 06 38 01	Stay R + L for body no. 6, 7 and 8 E - saddle, L = 550 (And no. 9 before 01.12.95)	16	KK 07 33 00	Trashboard, R			
				KK 07 33 01	Trashboard L			
				KK 07 06 40	Trashboard, R cpl.	33	KK 03 31 75	Screw M14 x 50 mm w/nut
						34	KK 01 29 22	Washer 17 x 40 x 4.58 mm




35	KK 06 36 07	Plate
	KK 07 36 07	Plate cpl.
36	KK 01 33 46	Screw M14 x 45 mm w/nut
37	KK 07 36 14	Wearing plate
38	KK 01 33 33	Cone screw M14 x 34 mm
39	KK 08 32 35	Mouldboard knife R and L (From 01.12.01)
Pos. 100 - 107 Eco-share from 01.04.00		
100	KK 05 30 90	Reversible point, R
	KK 06 30 90	Reversible point, L
101	KK 01 32 28	Cone screw M12 x 34 mm w/nut
102	KK 07 36 34	Eco-share, R
	KK 07 36 35	Eco-share, L
103	KK 01 01 55	Bushing (for ploughs w/share bolt beam)
	KK 01 01 56	Bushing (for ploughs w/A-beam)
104	KK 03 27 40	Hex screw M16 x 40 mm w/nut (for ploughs w/E-saddle) (Before 01.03.00)
	KK 03 27 50	Hex screw M16 x 50 mm w/nut (for ploughs w/E-saddle) (From 01.03.00)
	KK 03 27 65	Hex screw M16 x 65 mm w/nut (for ploughs w/share bolt beam)
	KK 03 27 75	Hex screw M16 x 75 mm w/nut (for ploughs w/A-beam)
105	KK 01 33 46	Cone screw M14 x 45 mm w/flange nut (for ploughs w/E-saddle) (Before 01.03.00)
	KK 01 33 61	Cone screw M14 x 60 mm w/flange nut (for ploughs w/E-saddle) (From 01.03.00)
	KK 01 33 85	Cone screw M14 x 85 mm w/flange nut (for ploughs w/share bolt beam and A-beam)
106	KK 01 60 15	Flange nut M14
107	KK 01 29 29	Washer (for ploughs w/E-saddle) (From 01.03.00)





1	KK 01 29 19	Washer		KK 07 32 31	Shinpiece no. 19, L		KK 07 03 93	Extra stay L for body no. 19 A - saddle cpl.
2	KK 07 33 00	Trashboard, R	16	KK 07 32 39	Connecting piece no. 12 and 15, R			w. bracket (pos. 6) (From 01.12.95)
	KK 07 33 01	Trashboard, L		KK 07 32 40	Connecting piece no. 12 and 15, L	20	KK 07 36 09	Landside, long, R + L
	KK 07 06 40	Trashboard, R cpl.		KK 07 32 66	Connecting piece no. 19, R	21	KK 07 36 08	Landside, short, R + L
	KK 07 06 41	Trashboard, L cpl.		KK 07 32 67	Connecting piece no. 19, L	22	KK 03 27 25	Hex screw M16 x 27 mm
	KK 07 06 42	Trashboard, R + L cpl.	17	KK 03 27 50	Hex screw M16 x 50 mm w/nut (for use with two stays)	23	KK 01 32 34	Cone screw M12 x 38 mm w/nut
3	KK 07 33 10	Bracket, R		KK 03 27 35	Hex screw M16 x 35 mm w/nut (for use with one stay only)	24	KK 01 32 28	Cone screw M12 x 34 mm w/nut
	KK 07 33 11	Bracket, L				25	KK 05 30 90	Reversible point, R
4	KK 03 31 00	Oval screw M12 x 30 mm w/nut					KK 06 30 90	Reversible point, L
5	KK 01 58 34	Nut M20 mm	18	KK 01 29 27	Washer 17 x 30 x 3 mm (for use with two stays)	26	KK 07 30 54	Share 14", R
6	KK 07 38 00	Bracket, R					KK 07 30 55	Share 14", L
	KK 07 38 01	Bracket, L	19	KK 07 38 05	Stay R + L for body no. 12 and 15 E - saddle, L = 540 (And no. 19 before 12.01.95)		KK 07 30 56	Share 16", R
7	KK 05 33 87	Mouldboard extention, R		KK 07 38 31	Stay R + L for body no. 19 E - saddle, L = 730 (From 12.01.95)		KK 07 30 57	Share 16", L
	KK 06 33 88	Mouldboard extention, L		KK 07 38 04	Stay R + L for body no. 12 and 15 A - saddle, L = 550 (And no. 19 before 12.01.95)		KK 07 30 80	Share 18", R
8	KK 07 32 36	Mouldboard no. 12, R		KK 07 38 26	Stay R + L for body no. 19 A - saddle, L = 770 (From 12.01.95)	27	KK 07 30 81	Share 18", L
	KK 07 32 37	Mouldboard no. 12, L		KK 07 38 26	Extra stay R + L, no. 15 E - saddle L = 770 (From 01.12.96)		KK 07 30 91	Share knife, R
	KK 07 32 24	Mouldboard no. 15, R		KK 07 03 88	Extra stay R for body no. 15 E - saddle cpl. w. bracket (pos. 6) (From 01.12.96)	28	KK 07 30 92	Share knife, L
	KK 07 32 25	Mouldboard no. 15, L		KK 07 03 89	Extra stay L for body no. 15 E - saddle cpl. w. bracket (pos. 6) (From 01.12.96)	29	KK 07 30 88	Landside knife, R w/nuts
	KK 07 32 90	Mouldboard no. 19, R		KK 07 38 29	Extra stay R + L, no. 15 A - saddle L = 785 (From 01.12.96)		KK 07 30 89	Landside knife, L w/nuts
	KK 07 32 91	Mouldboard no. 19, L		KK 07 03 98	Extra stay R for body no. 15 A - saddle cpl. w. bracket (pos. 6) (From 01.12.96)	30	KK 07 36 15	Furrow widener, R
9	KK 01 33 32	Cone screw M14 x 34 mm w/nut		KK 07 03 99	Extra stay L for body no. 15 A - saddle cpl. w. bracket (pos. 6) (From 01.12.96)	31	KK 07 36 16	Furrow widener, L
10	KK 03 31 07	Oval screw M12 x 35 mm w/nut		KK 07 38 42	Extra stay R + L, no. 19 E - saddle L = 570 (From 01.12.95)		KK 03 31 75	Screw M14 x 50 mm w/nut
11	KK 07 30 62	Share 14", R		KK 07 03 96	Extra stay R for body no. 19 E - saddle cpl. w. bracket (pos. 6) (From 01.12.95)		KK 03 32 51	Screw M16 x 50 mm w/nut (for E-saddle) (Before 01.02.00)
	KK 07 30 63	Share 14", L		KK 07 03 97	Extra stay L for body no. 19 E - saddle cpl. w. bracket (pos. 6) (From 01.12.95)		KK 03 32 56	Screw M16 x 56 mm w/nut (for E-saddle) (From 01.02.00)
	KK 07 30 64	Share 16", R		KK 07 38 04	Extra stay R + L, no. 19 A - saddle L = 550 (From 01.12.95)		KK 03 32 86	Screw M16 x 85 mm w/nut (for A-saddle) (Before 01.02.00)
	KK 07 30 65	Share 16", L		KK 07 03 92	Extra stay R for body no. 19 A - saddle cpl. w. bracket (pos. 6) (From 01.12.95)		KK 03 32 95	Screw M16 x 95 mm w/nut (for A-saddle) (From 01.02.00)
12	KK 06 20 25	Nut M16 mm				32	KK 01 29 22	Washer 17 x 40 x 4.58 mm
13	KK 07 34 35	Saddle, R (for E-saddle)				34	KK 01 33 33	Cone screw M14 x 34 mm w/nut
	KK 07 34 36	Saddle, L (for E-saddle)				35	KK 06 36 07	Plate for On-Land ploughs
	KK 07 34 40	Saddle, R (for A-saddle)					KK 07 36 07	Plate for On-Land ploughs cpl.
	KK 07 34 41	Saddle, L (for A-saddle)				36	KK 01 33 46	Screw M14 x 45 mm w/nut
14	KK 07 34 17	Connecting plate no. 12 and 15, R				37	KK 03 31 07	Oval screw M12 x 35 mm
	KK 07 34 18	Connecting plate no. 12 and 15, L				38	KK 07 36 14	Wearing plate
15	KK 07 32 41	Shinpiece no. 12, R				39	KK 01 33 32	Cone screw M14 x 34 mm
	KK 07 32 42	Shinpiece no. 12, L						
	KK 07 32 27	Shinpiece no. 15, R						
	KK 07 32 28	Shinpiece no. 15, L						
	KK 07 32 30	Shinpiece no. 19, R						




40	KK 08 32 35	Mouldboard knife R and L (From 01.12.01)
Pos. 100 - 107 Eco-share from 01.04.00		
100	KK 05 30 90	Reversible point, R
	KK 06 30 90	Reversible point, L
101	KK 01 32 28	Cone screw M12 x 34 mm w/nut
102	KK 07 36 34	Eco-share, R
	KK 07 36 35	Eco-share, L
103	KK 01 01 55	Bushing (for ploughs w/share bolt beam)
	KK 01 01 56	Bushing (for ploughs w/A-beam)
104	KK 03 27 40	Hex screw M16 x 40 mm w/nut (for ploughs w/E-saddle) (Before 01.03.00)
	KK 03 27 50	Hex screw M16 x 50 mm w/nut (for ploughs w/E-saddle) (From 01.03.00)
	KK 03 27 65	Hex screw M16 x 65 mm w/nut (for ploughs w/share bolt beam)
	KK 03 27 75	Hex screw M16 x 75 mm w/nut (for ploughs w/A-beam)
105	KK 01 33 46	Cone screw M14 x 45 mm w/flange nut (for ploughs w/E-saddle) (Before 01.03.00)
	KK 01 33 61	Cone screw M14 x 60 mm w/flange nut (for ploughs w/E-saddle) (From 01.03.00)
	KK 01 33 85	Cone screw M14 x 85 mm w/flange nut (for ploughs w/share bolt beam and A-beam)
106	KK 01 60 15	Flange nut M14
107	KK 01 29 29	Washer (for ploughs w/E-saddle) (From 01.03.00)






1	KK 01 33 32	Cone screw M14 x 34 mm w/nut	21	KK 07 33 03	Bracket, R		KK 07 30 89	Landside knife w/nut, L
2	KK 07 30 54	Share 14", R		KK 07 33 04	Bracket, L	44	KK 01 29 22	Washer 17 x 40 x 4.58 mm
	KK 07 30 55	Share 14", L	22	KK 01 29 19	Washer 12.5 x 23 x 3.2 mm	45	KK 03 31 75	Screw M14 x 50 mm w/nut
	KK 07 30 56	Share 16", R	23	KK 03 27 40	Hex screw M16 x 40 mm w/nut	46	KK 03 32 51	Screw M16 x 50 mm w/nut (for E-saddle)
	KK 07 30 57	Share 16", L	24	KK 07 36 08	Landside, short, R + L		KK 03 32 86	Screw M16 x 85 mm w/nut (for A-saddle)
	KK 07 30 80	Share 18", R	25	KK 07 36 09	Landside, long, R + L	47	KK 06 36 07	Plate (For On-land ploughs only)
	KK 07 30 81	Share 18", L	26	KK 07 38 22	Stay front (for E-saddle)		KK 07 36 07	Plate cpl. (For On-land ploughs only)
3	KK 05 30 90	Reversible point, R		KK 07 38 16	Stay front (for A-saddle)	48	KK 01 33 46	Screw M14 x 45 mm w/nut
	KK 06 30 90	Reversible point, L	27	KK 01 58 30	Nut M20 mm (Before 01.06.93)	50	KK 07 36 14	Wearing plate
4	KK 07 32 45	Mouldboard, R	28	KK 07 38 17	Stay (Before 01.06.93)	51	KK 01 33 32	Cone screw M14 x 34 mm
	KK 07 32 46	Mouldboard, L	29	KK 07 38 15	Stay, rear (for A-saddle) (Before 01.06.93)			
5	KK 03 31 73	Oval screw M14 x 38 mm w/nut		KK 07 38 20	Stay, R cpl. (for E-saddle) (Before 01.06.93)			
7	KK 01 32 28	Cone screw M12 x 34 mm w/nut		KK 07 38 21	Stay, L cpl. (for E-saddle) (Before 01.06.93)			
8	KK 01 32 34	Cone screw M12 x 38 mm w/nut		KK 07 38 10	Stay, R cpl. (for A-saddle) (Before 01.06.93)			
9	KK 07 30 91	Share knife, R		KK 07 38 11	Stay, L cpl (for A-saddle) (Before 01.06.93)			
	KK 07 30 92	Share knife, L						
	KK 06 30 91	Share knife, R (for Sweden)						
	KK 06 30 92	Share knife, L (for Sweden)						
10	KK 07 34 70	Saddle, R (for E-saddle)	31	KK 07 15 00	Spacer			
	KK 07 34 71	Saddle, L (for E-saddle)	32	KK 03 31 81	Oval screw M14 x 85 mm w/nut			
	KK 07 34 64	Saddle, R (for A-saddle)	33	KK 07 36 15	Furrow widener, R			
	KK 07 34 65	Saddle, L (for A-saddle)		KK 07 30 16	Furrow widener, L			
11	KK 03 31 00	Oval screw M12 x 30 mm w/nut	34	KK 07 30 62	Share 14", R			
12	KK 07 32 72	Shinpiece, R		KK 07 30 63	Share 14", L			
	KK 07 32 73	Shinpiece, L		KK 07 30 64	Share 16", R			
13	KK 03 31 08	Oval screw M12 x 40 mm w/nut		KK 07 30 65	Share 16", L			
14	KK 03 27 30	Hex screw M16 x 30 mm w/nut	35	KK 07 38 05	Stay (for E-saddle) (From 01.06.93)			
16	KK 03 31 75	Oval screw M14 x 50 mm w/nut		KK 07 38 03	Stay (for A-saddle) (From 01.06.93)			
17	KK 07 32 75	Connecting piece, R	36	KK 07 38 34	Bracket for stay, R+L			
	KK 07 32 76	Connecting piece, L	37	KK 07 38 35	Spacing tube 27 x 20.5 x 80 mm			
18	KK 03 31 07	Oval screw M12 x 35 mm w/nut	38	KK 07 38 36	Spacing tube 27 x 20.5 x 69 mm			
19	KK 07 33 00	Trashboard, R	39	KK 07 38 12	Bracket for stay, R			
	KK 07 33 01	Trashboard, L		KK 07 38 13	Bracket for stay, L			
	KK 07 02 92	Trashboard, R cpl.	40	KK 01 30 01	Washer 14 x 30 x 7.5 mm			
	KK 07 02 93	Trashboard, L cpl.	41	KK 01 58 34	Nut M20 mm			
	KK 07 02 94	Trashboard, R + L cpl.	42	KK 03 31 85	Oval screw M14 x 130 mm w/flangenut			
20	KK 07 33 32	Mouldboard extension, R (extra)	43	KK 07 30 88	Landside knife w/nut, R			
	KK 07 33 33	Mouldboard extension,, L (extra)						



1	KK 07 33 00	Trashboard, R	15	KK 08 34 15	Saddle R, A-saddle (for body no. 29)	KK 03 30 16	Oval screw M10 x 30 mm (for body no. 30)
	KK 07 33 01	Trashboard, L		KK 08 34 16	Saddle L, A-saddle (for body no. 29)		
2	KK 08 33 00	Bracket, R		KK 08 34 06	Saddle R, A-saddle (for body no. 30)	KK 01 58 13	Nut M10
	KK 08 33 01	Bracket, L		KK 08 34 07	Saddle L, A-saddle (for body no. 30)	23	KK 07 30 62 Share 14", R (for body no. 30)
3	KK 07 36 15	Furrow widener, R	16	KK 05 30 90	Reversible point, R		KK 07 30 63 Share 14", L (for body no. 30)
	KK 07 36 16	Furrow widener, L		KK 06 30 90	Reversible point, L		KK 07 30 64 Share 16", R (for body no. 30)
4	KK 01 33 32	Cone screw M14 x 34 mm	17	KK 01 32 28	Cone screw M12 x 34 mm		KK 07 30 65 Share 16", L (for body no. 30)
	KK 01 60 13	Flange nut M14		KK 01 58 17	Nut M12	24	KK 08 32 11 Slat no 1, R
5	KK 07 36 09	Landside, long R + L	18	KK 07 30 91	Share knife, R		KK 08 32 21 Slat no 1, L
6	KK 08 34 17	Saddle R, E-saddle (for body no. 29)		KK 07 30 92	Share knife, L	25	KK 08 32 12 Slat no 2, R
	KK 08 34 18	Saddle L, E-saddle (for body no. 29)		KK 06 30 91	Share knife, R (for Sweeden)		KK 08 32 22 Slat no 2, L
	KK 08 34 08	Saddle R, E-saddle (for body no. 30)		KK 06 30 92	Share knife, L (for Sweeden)	26	KK 08 32 13 Slat no 3, R
	KK 08 34 09	Saddle L, E-saddle (for body no. 30)	19	KK 07 30 02	Share 14", R (for body no. 29)		KK 08 32 23 Slat no 3, L
7	KK 03 31 16	Oval screw M12 x 35 mm (for body no. 29 and 30)		KK 07 30 03	Share 14", L (for body no. 29)	27	KK 08 32 14 Slat no 4, R
	KK 01 58 17	Nut M12		KK 07 30 54	Share 14", R (for body no. 30)		KK 08 32 24 Slat no 4, L
	KK 03 31 07	Oval screw M12 x 35 mm (for body no. 30) (Before 01.01.01)		KK 07 30 55	Share 14", L (for body no. 30)	28	KK 07 30 88 Landside knife, R
	KK 01 58 17	Nut M12		KK 07 30 04	Share 16", R (for body no. 29)		KK 07 30 89 Landside knife, L
8	KK 03 31 17	Oval screw M12 x 45 mm (for body no. 29 and 30)		KK 07 30 05	Share 16", L (for body no. 29)	29	KK 03 31 75 Screw M14 x 50 mm
	KK 01 58 17	Nut M12		KK 07 30 56	Share 16", R (for body no. 30)		KK 01 60 15 Flange nut M14
	KK 03 31 11	Oval screw M12 x 45 mm (for body no. 30) (Before 01.01.01)		KK 07 30 57	Share 16", L (for body no. 30)	30	KK 03 32 51 Screw M16 x 50 mm (for E-saddle) (Before 01.02.00)
	KK 01 58 17	Nut M12		KK 07 30 06	Share 18", R (for body no. 29)		KK 03 32 56 Screw M16 x 56 mm (for E-saddle) (From 01.02.00)
	KK 03 31 11	Oval screw M12 x 45 mm (for body no. 30) (Before 01.01.01)		KK 07 30 07	Share 18", L (for body no. 29)		KK 01 58 25 Nut M16
	KK 01 58 17	Nut M12		KK 07 30 80	Share 18", R (for body no. 30)		KK 03 32 86 Screw M16 x 85 mm (for A-saddle) (Before 01.02.00)
9	KK 08 32 10	Slat support, R	20	KK 08 32 15	Connecting piece, plastic (for slat 1-2)		KK 03 32 95 Screw M16 x 95 mm (for A-saddle) (From 01.02.00)
	KK 08 32 20	Slat support, L		KK 08 32 18	Connecting piece, plastic (for slat 2) (for body no. 29)		KK 01 58 25 Nut M16
10	KK 08 38 03	Stay		KK 08 32 16	Connecting piece, plastic (for slat 2-3) (for body no. 30)	31	KK 01 29 22 Washer 17 x 40 x 4.58 mm
11	KK 08 38 05	Stay 1, saddle A (for body no. 29)			Connecting piece, plastic (for slat 3-4)	32	KK 07 30 42 Flush fit share 14", R (for body no. 29)
	KK 08 38 06	Stay 2, saddle A (for body no. 29)		KK 08 32 17	Connecting piece, plastic (for slat 3-4)		KK 07 30 43 Flush fit share 14", L (for body no. 29)
	KK 08 38 02	Stay, saddle A (for body no. 30)	21	KK 07 32 56	Shinpiece, R (for body no. 29)		KK 07 30 44 Flush fit share 16", R (for body no. 29)
	KK 08 38 07	Stay 1, saddle E (for body no. 29)		KK 07 32 57	Shinpiece, L (for body no. 29)		KK 07 30 45 Flush fit share 16", L (for body no. 29)
	KK 08 38 08	Stay 2, saddle E (for body no. 29)		KK 07 32 30	Shinpiece, R (for body no. 30)	33	KK 07 30 30 Flush fit point, R
	KK 08 38 04	Stay, saddle E (for body no. 30)		KK 07 32 31	Shinpiece, L (for body no. 30)		KK 07 30 31 Flush fit point, L
12	KK 07 36 08	Landside, short R + L	22	KK 03 30 06	Oval screw M10 x 30 mm (for body no. 29)	34	KK 08 32 35 Mouldboard knife R and L (From 01.12.01)
13	KK 03 27 50	Hex screw M16 x 50 mm					
	KK 01 58 25	Nut M16		KK 01 58 13	Nut M10		
14	KK 07 36 14	Wearing plate					




Pos. 100 - 107 Eco-share from 01.04.00		
100	KK 05 30 90	Reversible point, R
	KK 06 30 90	Reversible point, L
101	KK 01 32 28	Cone screw M12 x 34 mm
	KK 01 58 17	Nut M12
102	KK 07 36 34	Eco-share, R
	KK 07 36 35	Eco-share, L
103	KK 01 01 55	Bushing (for ploughs w/share bolt beam)
	KK 01 01 56	Bushing (for ploughs w/A-beam)
104	KK 03 27 40	Hex screw M16 x 40 (for ploughs w/E-saddle) (Before 01.03.00)
	KK 03 27 50	Hex screw M16 x 50 mm (for ploughs w/E-saddle) (From 01.03.00)
	KK 01 58 25	Nut M16
	KK 03 27 65	Hex screw M16 x 65 mm w/nut (for ploughs w/share bolt beam)
	KK 01 58 25	Nut M16
	KK 03 27 75	Hex screw M16 x 75 mm w/nut (for ploughs w/A-beam)
	KK 01 58 25	Nut ;16
105	KK 01 33 46	Cone screw M14 x 45 mm (for ploughs w/E-saddle) (Before 01.03.00)
	KK 01 33 61	Cone screw M14 x 60 mm (for ploughs w/E-saddle) (From 01.03.00)
	KK 01 33 85	Cone screw M14 x 85 mm (for ploughs w/share bolt beam and A-beam)
106	KK 01 60 15	Flange nut M14
107	KK 01 29 29	Washer (for ploughs w/E-saddle) (From 01.03.00)



Замовлення запчастин
(050)-407-68-47
(050)-407-68-45



26	KK 03 30 04	Oval screw M10 x 20 mm w/nut
27	KK 07 33 50	Trashboard plastic, R
	KK 07 33 51	Trashboard plastic, L
28	KK 07 33 52	Support, R
	KK 07 33 53	Support, L
29	KK 05 33 87	Mouldboard extension, R
	KK 06 33 88	Mouldboard extension, L
31	KK 03 27 30	Hex screw M16 x 13 mm w/nut
32	KK 06 20 25	Nut M16 mm
33	KK 07 30 88	Landside knife w/nuts, R
	KK 07 30 89	Landside knife w/nuts, L
34	KK 03 32 51	Screw M16 x 50 mm w/nut (for E-sad- dle) (Before 01.02.00)
	KK 03 32 56	Screw M16 x 55 mm w/nut (for E-sad- dle) (From 01.02.00)
	KK 03 32 86	Screw M16 x 85 mm w/nut (for A-sad- dle) (Before 01.02.00)
	KK 03 32 95	Screw M16 x 95 mm w/nut (for A-sad- dle) (From 01.02.00)
35	KK 03 31 74	Screw M14 x 45 mm w/nut



1	KK 05 70 67	Blade no 4	33	KK 03 26 55	Hex screw M12 x 55 mm w/nut (for extra additional leaf spring cpl.)
2	KK 03 50 20	Hex screw w/flange M10 x 34 mm w/nut	34	KK 06 70 77	Bushing (for extra additional leaf spring cpl.)
3	KK 05 70 66	Blade no 3	35	KK 06 70 75	Linkage (for extra additional leaf spring cpl.)
4	KK 02 99 20	Grease nipple M8 x 1	36	KK 06 70 76	Bolt D15.7 (for extra additional leaf spring cpl.)
5	KK 06 70 59	Bolt	37	KK 02 97 27	Split pin D5 x 32 mm (for extra additional leaf spring cpl.)
6	KK 01 10 37	Roll pin D10 x 40 mm	38	KK 06 12 91	Threaded piece
7	KK 06 70 57	Bolt (Before 01.08.02)			
	KK 06 70 16	Bolt (From 01.08.02)	Not ill.	KK 05 07 06	Leaf spring cpl. (1 x ill. no. 3, 13, 14, 16, 17 and 22 + 2 x ill. no. 1, 2, 20 and 29)
8	KK 03 28 60	Hex screw M20 x 60 mm w/nut		KK 06 07 03	Leaf spring HD cpl. (1 x ill. no 3, 16, 17 22 and 32 + 2 x ill. no. 1, 2, 20, 23 and 29)
9	KK 06 70 51	Adjustment screw w/threaded piece		KK 06 01 19	Spacer kit w/ hex screws R & L cpl.
10	KK 06 70 40	Holder (Before 01.08.02)			
	KK 06 70 25	Holder (From 01.08.02)			
11	KK 06 70 68	Bracket (Before 01.08.02)			
	KK 06 70 92	Bracket (From 01.08.02)			
12	KK 06 70 39	Adjustment screw M24 x 90 mm			
13	KK 05 70 89	Bolt			
14	KK 02 97 27	Split pin D5 x 32 mm			
15	KK 06 70 80	Spring arm			
16	KK 03 26 65	Hex screw M12 x 65 mm w/nut			
17	KK 05 70 63	Main blade			
18	KK 06 70 60	Regulator (Before 01.08.02)			
	KK 06 70 90	Regulator (From 01.08.02)			
19	KK 06 70 70	Tie rod (Before 01.08.02)			
	KK 06 70 26	Tie rod (From 01.08.02)			
20	KK 05 70 64	Blade no 1			
21	KK 06 70 31	Axle D22 x 53 mm			
22	KK 05 70 65	Blade no 2			
23	KK 05 70 68	Blade no 5			
24	KK 06 12 80	Beam			
25	KK 03 52 09	Hex screw M20 x 50 mm w/threaded piece			
26	KK 03 28 40	Hex screw M20 x 40 mm w/nut			
27	KK 06 01 08	Spacer cpl. w/hex screws R			
	KK 06 01 09	Spacer cpl. w/hex screws L			
28	KK 03 51 65	Hex screw M20 x 50 mm w/flange nut			
29	KK 03 50 21	Hex screw w/flange M10 x 30.5 mm w/nut			
30	KK 01 10 42	Roll pin D6 x 40 mm (to be mounted into roll pin 011037)			
31	KK 03 28 55	Hex screw M20 x 55 mm			
32	KK 01 29 13	Washer			



For LS, RL, LM, RM and RG ploughs

For LD, LO, RS, RX, LB, and RB ploughs




1	KK 07 12 08	Beam, R (Before 15.08.01)		KK 03 28 60	Hex screw M20 x 60 mm (for LB, LO and RB only) (From 01.04.02)
	KK 07 12 72	Beam, R (From 15.08.01)	23	KK 01 60 49	Lock nut M20 (From 01.04.02)
2	KK 07 12 09	Beam, L (Before 15.08.01)			
	KK 07 12 73	Beam, L (From 15.08.01)	Not ill.	KK 07 12 11	Beam, H = 700 mm cpl. (ill. no. 1, 2, 3 and 5 - 8) (Before 15.08.01)
3	KK 07 12 28	Support, H = 700 mm (Before 15.08.01)		KK 07 12 80	Beam, H = 700 mm cpl. (ill. no. 1, 2, 3 and 5 - 8) (From 15.08.01)
	KK 07 12 71	Support, H = 700 mm (From 15.08.01)		KK 07 12 12	Beam, H = 800 mm cpl. (ill. no. 1, 2, 4 and 5 - 8) (Before 15.08.01)
4	KK 07 12 07	Support, H = 800 mm (Before 15.08.01)		KK 07 12 81	Beam, H = 800 mm cpl. (ill. no. 1, 2, 4 and 5 - 8) (From 15.08.01)
	KK 07 12 70	Support, H = 800 mm (From 15.08.01)			
5	KK 07 70 24	Main bolt M30 x 72 mm, L (Before 15.08.01)			
	KK 07 12 75	Main bolt M30 x 84 mm, L (From 15.08.01)			
6	KK 07 70 23	Main bolt M30 x 72 mm, R (Before 15.08.01)			
	KK 07 12 74	Main bolt M30 x 84 mm, R (From 15.08.01)			
7	KK 01 60 22	Nut M30, R			
8	KK 01 60 45	Nut M30, L			
9	KK 07 49 10	Plate for support, H = 700 mm (for LS, RL, LM, RM and RG ploughs only)			
10	KK 07 49 11	Plate for support, H = 800 mm (for LS, RL, LM, RM and RG ploughs only)			
11	KK 06 15 15	Bushing D28 x D20.5 x 35.2 mm			
12	KK 03 28 40	Hex screw M20 x 40 mm w/nut (Before 01.04.02)			
	KK 03 28 45	Hex screw M20 x 45 mm (From 01.04.02)			
	KK 03 28 50	Hex screw M20 x 50 mm w/nut (for disc coulter, for front piece and rear beam)			
	KK 03 28 60	Hex screw M20 x 60 mm w/nut (for front piece w/disc coulter)			
13	KK 03 28 65	Hex screw M20 x 65 mm w/nut			
14	KK 03 52 15	Hex screw M20 x 80 mm w/flange nut qual. 12.9			
	KK 03 52 16	Hex screw M20 x 90 mm w/flange nut qual. 12.9 (for RL/ LB/ LO/ RB ploughs front section, rear leg only)			
15	KK 03 28 07	Hex screw M20 x 100 mm			
	KK 03 28 03	Hex screw M20 x 110 mm (for LB, LO and RB only) (From 01.04.02)			
	KK 03 28 24	Hex screw M20 x 105 mm (when using fixing device KK 07 72 95 for RL plough) (From 01.04.02)			
16	KK 06 20 20	Washer			
17	KK 03 50 60	Shear bolt M20 x 62 mm w/nut (for support H = 800 mm) (Before 15.08.01)			
	KK 03 50 48	Shear bolt M20 x 72 mm w/nut (for support H = 800 mm) (From 15.08.01)			
18	KK 03 50 72	Shear bolt M20 x 81 mm w/nut (for support H = 700 mm)			
19	KK 07 15 08	Plate for support H = 700 mm (for LD, LO, RS, RX, LB and RB ploughs only)			
20	KK 07 15 29	Plate for support H = 800 mm (for LD, LO, RS, RX, LB and RB ploughs only)			
21	KK 03 27 62	Hex screw M16 x 60 w/nut qual. 12.9			
22	KK 03 28 40	Hex screw M20 x 40 mm w/nut (Before 01.04.02)			
	KK 03 28 45	Hex screw M20 x 45mm (From 01.04.02)			



1	KK 07 64 06	Disc coulters 18"	22	KK 03 28 30	Hex screw M20 x 30 mm
	KK 07 64 07	Disc coulters 20"		KK 01 58 30	Nut M20
2	KK 07 64 09	Disc coulters, notched 18"	23	KK 03 28 40	Hex screw M20 x 40 mm
	KK 07 64 10	Disc coulters, notched 20"		KK 01 58 30	Nut M20
3	KK 07 64 99	Plate	24	KK 01 60 31	Cone nut M16
4	KK 03 35 40	Screw M10 x 40 mm			
	KK 01 60 04	Lock nut M10			
5	KK 01 17 50	O-ring 124,5 x 4 mm			
6	KK 01 18 66	O-ring 67 x 3 mm			
7	KK 01 12 59	Circlip I 62 x 2 mm			
8	KK 01 12 66	Circlip A 30 x 1,5 mm			
9	KK 01 05 72	Bearing			
10	KK 01 05 32	Gasket ring			
11	KK 08 60 89	Bearing housing cpl. (ill. 3 - 11)			
	KK 08 60 90	Bearing housing cpl. w/axle			
12	KK 08 61 01	Axle			
	KK 08 60 80	Disc coulters arm w/bearing 18", R			
	KK 08 60 81	Disc coulters arm w/bearing 18", L			
	KK 08 60 82	Disc coulters arm w/bearing 20", R			
	KK 08 60 83	Disc coulters arm w/bearing 20", L			
	KK 08 60 84	Disc coulters arm w/bearing 20", lowered R			
	KK 08 60 85	Disc coulters arm w/bearing 20", lowered L			
13	KK 08 61 10	Arm 18", R			
	KK 08 61 12	Arm 20", R			
	KK 08 61 14	Arm 20", lowered R			
14	KK 08 61 11	Arm 18", L			
	KK 08 61 13	Arm 20", L			
	KK 08 61 15	Arm 20", lowered L			
15	KK 06 61 70	Bracket			
16	KK 02 99 20	Grease nipple			
17	KK 06 61 90	Clip			
18	KK 03 50 31	Hex screw M12 x 45 mm			
	KK 01 58 17	Nut M12			
19	KK 06 61 89	Bracket 18"			
	KK 06 61 82	Bracket 20"			
20	KK 06 61 78	Eccentric			
21	KK 06 61 75	U-bolt			




Замовлення запчастин
(050)-407-68-47
(050)-407-68-45




1	KK 07 64 06	Disc coulters 18"
	KK 07 64 07	Disc coulters 20"
2	KK 01 17 50	O-ring
3	KK 01 18 66	O-ring
4	KK 01 12 59	Circlip
5	KK 01 12 66	Circlip
6	KK 01 05 72	Ball bearing
7	KK 01 08 18	Rubber ring (Before 01.01.99)
	KK 01 05 32	Gasket ring (From 01.01.99)
8	KK 08 60 90	Bearing housing cpl. (ill. no. 2-3-4-5-6-7-8-10) (Before 01.01.99)
	KK 08 60 89	Bearing housing cpl. (ill. no. 2-3-4-5-6-7-8) (From 01.01.99)
9	KK 07 60 76	Axle (Before 01.01.99)
	KK 08 61 01	Axle (From 01.01.99)
	KK 08 60 86	Disc coulters arm w/bearing (From 01.01.99)
	KK 08 60 87	Disc coulters bearing cpl. (ill. no. 4-6-7-8) (From 01.01.99)
10	KK 02 99 20	Grease nipple
11	KK 07 65 75	Arm
12	KK 07 64 00	Support
13	KK 07 65 27	Axle
14	KK 03 27 02	Hex screw M16 x 110 mm w/nut
15	KK 03 10 30	Hex screw M10 x 30 mm
16	KK 07 64 09	Disc coulters 18" notched
	KK 07 64 10	Disc coulters 20" notched
17	KK 03 28 50	Hex screw M20 x 50 mm
18	KK 03 28 40	Hex screw M20 x 40 mm
19	KK 06 61 78	Eccentric for bracket
20	KK 07 49 31	Bracket
21	KK 01 29 60	Washer 20.5 x 40 x 3.4 mm
22	KK 07 49 36	Plate w/threads
23	KK 07 49 30	Tube
24	KK 03 27 75	Hex screw M16 x 75 mm w/nut
25	KK 07 65 15	Supporting piece for tube
26	KK 07 49 39	Extended tube
27	KK 03 27 85	Hex screw M16 x 85 mm w/nut
28	KK 07 49 38	Support
29	KK 07 49 37	Support
30	KK 07 64 99	Plate





1	KK 07 68 12	Mouldboard maize R	11	KK 06 68 11	Arm R, H = 700 mm for HD beam and std. beam H700
	KK 07 68 13	Mouldboard maize L		KK 07 68 58	Arm R, H = 750 mm for std. beam H800 (From 01.12.00)
2	KK 06 68 80	Mouldboard R	16	KK 07 06 53	Fixing bracket with screw and nut (for beam 071240 and 071241)
	KK 07 69 43	Mouldboard R, plastic	17	KK 03 44 46	Setscrew M24 x 53 mm
	KK 06 68 81	Mouldboard L	18	KK 01 58 41	Nut M24
	KK 07 69 44	Mouldboard L, plastic	19	KK 01 58 16	Nut M10
3	KK 03 30 06	Oval screw M10 x 30 mm	20	KK 08 50 76	Clevis
4	KK 05 68 73	Share, short R	21	KK 06 68 61	Bracket HD beam
	KK 06 68 73	Share, short L			
5	KK 06 68 68	Share, long R			
	KK 06 68 69	Share, long L			
6	KK 01 29 06	Washer 10.5 x 25 x 3.4			
7	KK 01 58 25	Nut M16			
22	KK 08 68 01	Skimmer extension			
23	KK 03 30 07	Oval screw M10 x 35 mm			
for all turnable ploughs with Auto Reset beams:					
8	KK 03 27 95	Hex screw M16 x 95 mm			
9	KK 03 42 28	Setscrew M16 x 32 mm			
10	KK 06 06 57	Bracket cpl.			
11	KK 06 68 11	Arm R, H = 700 mm			
	KK 07 68 58	Arm R, H = 750 mm (From 01.12.00)			
	KK 06 68 12	Arm L, H = 700 mm			
	KK 07 68 59	Arm L, H = 750 mm (From 01.12.00)			
for all turnable ploughs with Shear Bolt beams:					
12	KK 07 06 39	Bracket with screws (for LB, LD, RB, RS, RX)			
	KK 07 68 72	Bracket (for LM, LS, RG, RL, RM, VD)			
13	KK 03 42 25	Setscrew M16 x 25 mm			
14	KK 03 42 50	Setscrew M16 x 50 mm			
15	KK 07 68 17	Arm R, H = 700 mm			
	KK 07 68 18	Arm L, H = 700 mm			
	KK 07 68 25	Arm R, H = 800 mm			
	KK 07 68 26	Arm L, H = 800 mm			
	KK 07 68 33	Arm R, H = 700 mm (for VD plough only) (Before 15.03.98)			
	KK 07 68 34	Arm L, H = 700 mm (for VD plough only) (Before 15.03.98)			
for beams on conventional ploughs:					






1	KK 07 19 13	Plate R, mod. 160
2	KK 07 19 14	Plate L, mod. 160
3	KK 07 22 80	Plate R, mod. 110
4	KK 07 22 81	Plate L, mod. 110
5	KK 01 02 78	Pin 19 x 93 mm cat II
	KK 01 02 82	Pin 19 x 110 mm cat III
6	KK 07 17 94	Pin 35 x 90 mm cat II
	KK 07 43 79	Pin 35 x 105 mm cat III
7	KK 07 19 12	Plate
8	KK 07 43 32	Cross shaft cat II, 110 and 160
	KK 07 43 77	Cross shaft cat III, 160
9	KK 06 43 43	Spacing tube cat II
	KK 07 43 78	Spacing tube cat III
10	KK 01 29 51	Washer
11	KK 01 07 00	Pin
12	KK 03 28 24	Hex screw M20 x 105 mm w/nut
	KK 03 28 11	Hex screw M20 x 130 mm w/nut




Замовлення запчастин
(050)-407-68-47
(050)-407-68-45




1	KK 03 28 24	Hex screw M20 x 105 mm w/lock nut (for cross shaft cat. II, L = 852 mm)	KK 06 43 20	Cross shaft cat. II, L = 935 mm D60
	KK 03 28 11	Hex screw M20 x 130 mm w/lock nut (for cross shaft cat. III, L = 965 mm)	KK 06 43 23	Cross shaft cat. III, L = 860 mm D60
2	KK 03 29 56	Hex screw M24 x 55 mm	KK 06 43 21	Cross shaft cat. III, L = 965 mm D60
3	KK 08 15 81	Plate mod. 200, R	KK 07 43 96	Cross shaft cat. III, L = 860 mm D70
4	KK 01 02 78	Bolt w/head D19 x 93 mm (for cross shaft cat. II, L = 852 mm)	KK 07 43 95	Cross shaft cat. III, L = 965 mm D70
	KK 01 02 82	Bolt w/head D19 x 110 mm (for cross shaft cat. III, L = 965 mm)		
5	KK 07 17 94	Bolt w/head D35 x 90 mm (for cross shaft cat. II, L = 852 mm)		
	KK 07 43 79	Bolt w/head D35 x 105 mm (for cross shaft cat. III, L = 965 mm)		
6	KK 08 15 80	Plate, upper and lower		
7	KK 07 43 32	Cross shaft cat. II, L = 825 mm		
	KK 07 43 77	Cross shaft cat. III, L = 965 mm		
8	KK 06 43 43	Bushing D38 x D20,5 x 41 mm (for cross shaft cat. II, L = 852 mm)		
	KK 07 43 78	Bushing D38 x D20,5 x 61 mm (for cross shaft cat. III, L = 965 mm)		
9	KK 01 29 51	Washer D65 x D36 x 3 mm		
10	KK 01 07 00	Pin D12		
11	KK 01 02 88	Bolt w/handle D19 x 93 mm, D60		
	KK 01 02 91	Bolt w/handle D19 x 110 mm, D70		
12	KK 07 43 54	Collar, D60		
	KK 07 26 34	Collar, D70		
13	KK 08 15 50	Holder for quick coupling, D60		
	KK 08 15 52	Holder for lower quick coupling, D60		
	KK 08 15 60	Holder for quick coupling, D70		
	KK 08 15 62	Holder for lower quick coupling, D70		
14	KK 06 43 23	Cross shaft cat. III, L = 860 mm D60 (for quick coupling and lower quick coupling)		
	KK 06 43 20	Cross shaft cat. II , L = 935 mm D60 (for quick coupling and lower quick coupling)		
	KK 06 43 21	Cross shaft cat. III, L = 965 mm D60 (for quick coupling and lower quick coupling)		
	KK 07 43 96	Cross shaft cat. III, L = 860 mm D70 (for quick coupling and lower quick coupling)		
	KK 07 43 95	Cross shaft cat. III, L = 965 mm D70 (for quick coupling and lower quick coupling)		
15	KK 08 15 83	Plate mod. 200, L		
16	KK 06 43 60	Collar, D60 w/hex screw KK 03 27 50 w/nut (M16 x 50 mm) (for cross shaft D60)		
	KK 07 43 97	Collar, D70 w/hex screw KK 03 28 70 w/nut (M20 x 70 mm) (for cross shaft D70)		
17	KK 08 15 54	Holder (for cross shaft D60) (Before 01.03.02)		
	KK 08 15 34	Holder (for cross shaft D60) (From 01.03.02)		
	KK 08 15 37	Holder (for cross shaft D70) (Before 01.03.02)		
	KK 08 15 35	Holder (for cross shaft D70) (From 01.03.02)		
18	KK 06 43 19	Cross shaft cat. II, L = 825 mm D60		




1	KK 07 25 21	Slide H = 200 mm	36	KK 07 22 79	Collar, D50	KK 01 01 52	Bushing (for LD and VD) (From 01.11.01)	
2	KK 07 19 26	Cylinder bracket (Before 01.11.01)	37	KK 03 36 30	Hex screw M12 x 30 mm w/nut	KK 01 01 53	Bushing (for LD-HD) (From 01.11.01)	
3	KK 03 28 45	Hex screw M20 x 45 mm	38	KK 01 03 32	Bolt D25, 3 x 85 mm	60	KK 12 60 95	Bolt w/head D25 x 212 mm (for EM/ LM and ES/LS) (From 01.11.01)
4	KK 01 60 12	Flange nut M20	39	KK 01 27 26	Hose holder	KK 01 03 38	Bolt w/head D25 x 190 mm (for LD and VD) (From 01.11.01)	
5	KK 07 22 68	Spanner holder	40	KK 07 22 92	Tube	KK 01 03 37	Bolt w/head D25 x 180 mm (for LD-HD) (From 01.11.01)	
6	KK 03 36 25	Hex screw M12 x 25 mm	41	KK 07 19 17	Plate R	61	KK 01 10 16	Roll pin D8 x 45
7	KK 07 22 50	Headstock mod. 110	42	KK 07 19 18	Plate L	62	KK 03 28 65	Hex screw M20 x 65 mm
8	KK 01 18 97	O-ring		KK 07 22 93	Extended bracket cpl.			
9	KK 07 22 70	Ring	43	KK 07 25 34	Holder for quick coupling (From 01/01/96)			
10	KK 01 18 98	O-ring		KK 07 25 35	Holder, extended for lower quick coupling (From 11/01/96)	Not ill.	KK 07 22 95	Turn-over device w/regular cross shaft cpl.
11	KK 01 05 71	Bearing	44	KK 03 28 50	Hex screw M20 x 50 mm w/nut	KK 07 22 99	Turn-over device w/quick coupling cpl.	
12	KK 07 22 71	Washer	45	KK 01 02 88	Bolt 19 x 93 mm w/handle	KK 07 22 97	Turn-over device w/pivotal cross shaft cpl.	
13	KK 02 99 20	Grease nipple	46	KK 07 19 34	Bracket	KK 07 41 74	Quick coupling cpl, (From 01/01/96, supply for previously delivered ploughs)	
14	KK 01 18 96	O-ring	47	KK 01 29 31	Washer d20,5 - D40 x 3,4	KK 07 41 83	Extended lower quick-coupling cpl. (From 11/01/96, supply for previously delivered ploughs)	
15	KK 07 22 64	Plate w/shaft	48	KK 01 03 19	Bolt w/head D25.3 x 120 mm (for LS and VD only) (Before 01.11.01)	KK 08 15 90	Adjustable screw cpl. (From 01.11.01)	
16	KK 03 28 70	Hex screw M20 x 70 mm	49	KK 36 11 16	Turnbuckle cpl. (520 - 720) (Before 01.11.01)			
17	KK 07 22 69	Bracket for cross-shaft	50	KK 07 49 14	Cylinder bracket (for LS and VD only) (From 01.11.01 also for EM/LM, ES and LD)			
18	KK 03 28 40	Hex screw M20 x 40 mm w/nut						
19	KK 03 27 60	Hex screw M16 x 60 mm w/nut						
20	KK 07 22 72	Collar, D50						
21	KK 07 22 91	Cross-shaft cat II, L = 720 mm						
	KK 07 22 74	Cross-shaft cat II, L = 825 mm						
	KK 07 22 75	Cross-shaft cat II, L = 935 mm						
22	KK 07 22 65	Eccentric shaft	51	KK 01 00 08	Spacing tube D35 x D26 x 10 mm (For LS and VD only) (Before 01.11.01)			
23	KK 07 22 83	Tube	52	KK 03 27 35	Hex screw M16 x 35 mm (From 01.11.01)			
24	KK 01 10 20	Roll pin D12 x 40 mm (Before 01.11.01)	53	KK 07 25 19	Lock plate (From 01.08.00)			
25	KK 01 06 56	Spanner for turning cylinder	54	KK 07 43 19	Bushing (From 01.11.01)			
26	KK 03 27 85	Hex screw M16 x 86 mm w/nut	55	KK 08 15 45	Bracket for adjustable screw (From 01.11.01)			
27	KK 07 19 35	Bracket	56	KK 08 15 88	Adjustable screw (From 01.11.01)			
28	KK 01 06 50	Spanner 27 - 36	57	KK 35 11 48	Stop for adjustable screw (From 01.11.01)			
29	KK 01 06 06	Spanner 19 - 27	58	KK 08 15 87	Bushing for adjustable screw (From 01.11.01)			
30	KK 01 03 15	Bolt D25,3 x 60 mm (Before 01.11.01)	59	KK 01 00 42	Bushing (for EM/LM and ES/LS) (From 01.11.01)			
31	KK 35 11 72	Screw R (Before 01.11.01)						
32	KK 35 11 48	Lock nut (Before 01.11.01)						
33	KK 35 11 70	Tube (Before 01.11.01)						
34	KK 35 11 73	Screw L (Before 01.11.01)						
35	KK 01 07 00	Pin D12 mm						



1	KK 07 19 30	Main shaft, H = 200 mm (Before 01.10.97)	29	KK 01 03 15	Bolt D25.3 x 60 mm	54	KK 07 45 76	Handle
	KK 07 24 21	Main shaft w/cross track H = 200 mm (From 01.10.97)		KK 01 03 18	Bolt D25.3 x 100 mm (for ES only)	55	KK 02 99 20	Grease nipple M8
2	KK 03 28 60	Hex screw M20 x 60 mm w/nut	30	KK 12 60 95	Bolt D25.3 x 212 mm (for LS only)	56	KK 03 28 65	Hex screw M20 x 65 mm
3	KK 03 28 55	Hex screw M20 x 55 mm w/nut	31	KK 35 11 39	Screw R	57	KK 07 25 26	Lock washer
4	KK 07 19 26	Cylinder bracket	32	KK 35 11 48	Nut	58	KK 01 02 88	Bolt D19 x 93 mm w/handle for D60
5	KK 07 19 00	Headstock mod. 160	33	KK 35 11 44	Tube		KK 01 02 91	Bolt D19 x 110 for D70
6	KK 02 99 20	Grease nipple	34	KK 35 11 40	Screw L	59	KK 01 10 20	Roll pin D12 x 40 mm (for EM, LM and LS)
7	KK 03 28 07	Hex screw M20 x 100 mm w/nut	35	KK 01 60 12	Flange nut	60	KK 01 03 19	Bolt w/head D25.3 x 120 mm (for EM, LM and LS)
8	KK 07 19 35	Bracket	36	KK 01 06 55	Spanner for hydraulic cylinder			
9	KK 07 19 24	Shaft		KK 07 25 36	Holder for quick coupling (From 01.01.96)	61	KK 36 11 16	Turnbuckle cpl. (520 - 720)
10	KK 01 10 21	Roll pin D12 x 50 mm		KK 07 25 37	Holder, extended for lower quick coupling (From 03.01.96)	62	KK 07 49 14	Cylinder bracket (for EM, LM and LS)
11	KK 07 19 25	Tube		KK 07 26 27	Holder for quick coupling D70 mm	63	KK 01 00 08	Wahser D35 x D26 x 10 mm for EM, LM and LS)
12	KK 03 09 70	Hex screw M24 x 70 mm		KK 07 26 32	Holder for lower quick coupling D70 mm	64	KK 07 59 15	Cylinder bracket (ES plough only)
13	KK 03 09 60	Hex screw M24 x 60 mm	37	KK 07 43 54	Collare D60 mm	65	KK 12 60 95	Bolt D25.3 x 212 mm (for EM, LM and LS)
14	KK 07 19 38	Plate w/notch for transport lock		KK 07 26 34	Collar for quick coupling D70 mm	66	KK 07 58 61	Bracket (From 01.03.99)
15	KK 01 18 95	O-ring	38	KK 03 26 30	Hex screw M12 x 30 mm w/nut	67	KK 01 09 58	Bushing
16	KK 01 05 66	Bearing	39	KK 03 26 40	Hex screw M12 x 40 mm w/nut	68	KK 01 00 42	Bushing (for EM, LM and LS)
17	KK 06 12 91	Threaded piece	40	KK 07 22 68	Spanner holder			
18	KK 01 29 79	Washer	41	KK 01 27 26	Hose holder	Not ill.	KK 01 12 52	Circlip
19	KK 01 18 90	O-ring	42	KK 07 19 17	Side plate R		KK 07 45 70	Lock for transport wheel, cpl.
20	KK 07 19 04	Ring	43	KK 07 19 18	Side plate L		KK 07 01 63	Turn-over device w/regular cross shaft cpl.
21	KK 01 18 91	O-ring		KK 07 22 93	Fixing plate cpl.		KK 07 01 64	Turn-over device w/pivotal cross shaft cpl.
22	KK 03 28 45	Hex screw M20 x 45 mm w/nut	44	KK 01 03 32	Bolt w/head		KK 07 01 65	Turn-over device w/quick coupling cpl.
23	KK 07 19 10	Bracket for cross shaft	45	KK 07 22 92	Bush		KK 07 41 73	Quick coupling cpl.
	KK 07 25 39	Bracket for D70 mm cross shaft	46	KK 01 07 00	Pin D12 (Before 01.08.97)		KK 07 41 84	Extended lower quick coupling
	KK 07 25 27	Bracket for cross shaft, extended		KK 01 10 20	Roll pin D12 x 40 mm (From 01.08.97)		KK 07 25 08	Cross shaft assembly w/eccentric adjustment cpl.
24	KK 06 43 19	Cross shaft cat. II, L = 825 mm		III. 47 - 59	Lock for transport wheel			
	KK 06 43 20	Cross shaft cat. II, L = 935 mm			From 07.01.93		KK 07 58 60	Bracket for electric valve (From 01.04.99)
	KK 06 43 21	Cross shaft cat. III, L = 965 mm	47	KK 07 45 71	Plate for locking			
	KK 06 43 23	Cross shaft cat. III, L = 860 mm		KK 07 45 80	Plate for locking, quick coupling (Before 01.01.96)			
	KK 07 43 95	Cross shaft D70 mm cat. III, L = 965 mm	48	KK 35 60 42	Spring			
	KK 07 43 96	Cross shaft D70 mm cat. III, L = 860 mm	49	KK 02 97 70	Pin D4			
25	KK 06 43 60	Collar D60 mm	50	KK 06 86 40	Pin for lock			
	KK 07 43 97	Collar D70 mm	51	KK 01 10 02	Roll pin D5 x 36 mm			
26	KK 03 27 60	Hex screw M16 x 60 mm w/nut	52	KK 01 10 09	Roll pin D10 x 36 mm			
27	KK 01 06 50	Spanner 27 - 36	53	KK 03 24 40	Hex screw M8 x 40 mm			
28	KK 01 06 06	Spanner 19 - 27						




1	KK 08 15 29	Cylinder bracket	36	KK 08 14 57	Bracket	59	KK 03 24 70	Hex screw M8 x 70 mm (Before 01.02.01)
2	KK 01 29 70	Washer	37	KK 06 70 31	Bolt		KK 03 24 40	Hex screw M8 x 40 mm (From 01.02.01)
3	KK 03 28 30	Hex screw M20 x 30 mm	38	KK 08 15 31	Lever arm			
4	KK 08 15 55	Bolt	39	KK 03 27 35	Hex screw M16 x 35 mm	60	KK 01 60 05	Lock nut M8
	KK 08 15 56	Bolt (for headstock slide R, turning with bodies over the frame)	40	KK 01 60 22	Flange nut M30	61	KK 08 15 17	Cylinder bracket (when using 2 cylinders) (From 01.09.00)
5	KK 03 20 50	Unbraco screw M16 x 45 mm	41	KK 08 14 79	Nut w/spring clamp	62	KK 01 02 93	Top link
6	KK 08 15 27	Main shaft	42	KK 08 14 58	Adjustable screw	63	KK 01 01 58	Bushing
7	KK 01 18 91	O-ring D150	43	KK 03 24 40	Hex screw M8 x 40 mm	64	KK 03 36 30	Hex screw M12 x 30 mm w/nut for extra hole (From 01.01.02)
8	KK 07 19 04	Gasket ring	44	KK 01 60 05	Lock nut M8	65	KK 08 14 50	Washer
9	KK 01 18 90	O-ring D120	45	KK 08 15 65	Bracket for hoses	66	KK 08 14 78	Stop for adjustable screw (Before 01.07.01)
10	KK 01 05 66	Bearing	46	KK 08 15 47	Bracket (From 01.02.01)		KK 35 11 48	Stop for adjustable screw (From 01.07.01)
11	KK 01 29 79	Washer	47	KK 01 06 06	Spanner 19 - 27, L = 450 mm	67	KK 08 14 71	Adjustable screw (Before 01.07.01)
12	KK 08 15 20	Headstock mod. 200	48	KK 01 07 00	Ring pin D12		KK 08 15 88	Adjustable screw (From 01.07.01)
13	KK 01 30 10	Washer	49	KK 07 43 19	Bushing	68	KK 03 24 70	Hex screw M8 x 70 mm (From 01.02.01)
14	KK 08 15 32	Axle	50	KK 08 14 73	Bushing for adjustable screw (Before 01.07.01)	69	KK 01 10 16	Roll pin D8 x 45 mm (From 01.12.01)
15	KK 01 30 64	O-ring D112		KK 08 15 87	Bushing for adjustable screw (From 01.07.01)	70	KK 02 99 20	Grease nipple (From 01.07.01)
16	KK 01 30 62	O-ring D153		KK 08 15 82	Bracket for adjustable screw (Before 01.07.01)			
17	KK 08 15 36	Cover	51	KK 08 15 45	Bracket for adjustable screw (From 01.12.01)			
18	KK 03 20 51	Unbraco screw M20 x 50 mm		KK 01 00 42	Bushing (for EM/LM and ES/LS)	Not ill.	KK 08 15 43	Transport lock cpl.
19	KK 03 36 30	Hex screw M12 x 30 mm	52	KK 01 01 52	Bushing (for EG, LB, LD and VX)		KK 08 14 70	Adjustable screw cpl. (Before 01.07.01)
20	KK 08 15 57	Bracket and cover for turn-over valve		KK 01 01 53	Bushing (for ED and LD-HD)		KK 08 15 90	Adjustable screw cpl. (From 01.07.01)
21	KK 08 15 30	Axle for cylinder bracket	53	KK 12 60 95	Bolt w/head D25 x 212 mm (for ES/LS and EM/LM)			
22	KK 03 28 07	Hex screw M20 x 100 w/lock nut		KK 01 03 37	Bolt w/head D25 x 180 mm (for ED, EG, LB and LD-HD)			
23	KK 08 15 33	Key holder		KK 01 03 38	Bolt w/head D25 x 190 mm (for LD and VX)			
24	KK 08 15 70	Pin for lock						
25	KK 35 60 42	Spring	54	KK 01 29 36	Washer (for mechanical adjustment only) (Before 01.07.01)			
26	KK 01 09 58	Bushing, bronze	55	KK 02 99 22	Grease nipple (Before 01.07.01)			
27	KK 01 12 52	Locking plate	56	KK 01 29 78	Washer			
28	KK 03 37 41	Hex screw M16 x 40 mm w/nut	57	KK 01 12 62	Lock ring			
29	KK 02 99 20	Grease nipple	58	KK 08 15 67	Cover for hoses (Before 01.01.01)			
30	KK 08 15 74	Bolt (Before 01.01.01)		KK 08 15 39	Cover for hoses (From 01.01.01)			
	KK 08 15 69	Handle (From 01.01.01)						
31	KK 08 15 40	Lock linkage						
32	KK 08 15 71	Eccentric for lock linkage						
33	KK 01 10 01	Pin						
34	KK 08 15 72	Washer						
35	KK 03 34 16	Hex screw M8 x 16 mm w/nut						




1	KK 06 21 53	Headstock	33	KK 07 28 11	Extended top link bracket, R (From 07.07.99)
2	KK 03 28 75	Hex screw M20 x 75 mm w/nut	34	KK 07 28 13	Bushing D51 x D33 x 24 mm (From 07.07.99)
3	KK 01 06 06	Spanner 19-27			
4	KK 01 06 50	Spanner 27-36	Not ill.	KK 06 02 39	Lock for transport wheel cpl.
5	KK 01 07 00	Pin D12		KK 36 11 16	Turnbuckle cpl. (520 - 720)
6	KK 01 03 15	Bolt D25.3 x 60 mm		KK 07 04 58	Lower cross shaft, kit cpl. (ill. no. 12-15)
7	KK 35 11 40	Screw L			
8	KK 35 11 44	Tube			
9	KK 35 11 48	Nut			
10	KK 35 11 39	Screw R			
11	KK 07 18 80	Main shaft (For turning w/bodies under the main frame)			
	KK 07 26 36	Main shaft (For turning w/bodies under the main frame, for EM/LM only)			
	KK 07 25 28	Main shaft (For turning w/bodies over the main frame)			
	KK 07 14 96	Main shaft for wide wheel setting (For turning w/bodies under the main frame)			
12	KK 07 43 40	Bracket for lower cross shaft			
13	KK 07 43 41	Bushing			
14	KK 07 43 42	Bolt			
15	KK 01 58 30	Nut			
16	KK 06 43 19	Cross shaft cat. II L=825 mm			
	KK 06 43 20	Cross shaft cat. II L=935 mm			
	KK 06 43 23	Cross shaft cat. III L=860 mm			
	KK 06 43 21	Cross shaft cat. III L=965 mm			
17	KK 06 43 60	Collar, D60			
18	KK 06 43 17	Bushing			
19	KK 03 28 60	Hex screw M20 x 60 mm w/nut			
20	KK 07 14 83	Screw adj.			
21	KK 07 14 80	Turn-over device			
22	KK 07 16 52	Ring			
23	KK 06 02 52	Pivot pin w/bearing and packing			
24	KK 03 27 25	Hex screw M16 x 27 mm			
25	KK 02 99 20	Grease nipple			
26	KK 01 10 20	Roll pin D12 x 40 mm			
27	KK 01 29 78	Washer			
28	KK 01 12 62	Circlip			
29	KK 07 17 65	Bushing			
30	KK 01 03 32	Bolt w/head D25.3 x 85 mm (From 07.07.99)			
31	KK 01 03 30	Bolt w/head D31.75 x 103 mm (From 07.07.99)			
32	KK 07 28 12	Extended top link bracket, L (From 07.07.99)			






1	KK 08 13 16	Main tube, L = 1088 mm for EM/LM-85 (2 furrow)	14	KK 07 17 13	Bolt	KK 08 13 76	Beam support, rear for LM85-14" andLM100 - 16" (From 15.08.00)	
	KK 08 13 10	Main tube, L = 1938 mm for EM/LM-85 (3 furrow)	15	KK 03 27 45	Hex screw M16 x 45 mm w/nut	KK 08 12 96	Beam support, rear for LM85- 6" and LM100-18" (Before 01.06.99)	
	KK 08 13 11	Main tube, L = 2788 mm for EM/LM-85 (4 furrow)	16	KK 07 17 10	Fixing plate for machine stand	KK 08 16 21	Beam support, rear for LM85-16" and LM100-18" (From 01.06.99)	
	KK 08 13 12	Main tube, L = 3638 mm for EM/LM-85 (5 furrow)	17	KK 01 60 13	Flange nut M14	KK 08 13 77	Beam support, rear for LM85-16" and LM100-18" (From 15.08.00)	
	KK 08 13 17	Main tube, L = 1238 mm for EM/LM-100 (2 furrow)	18	KK 01 58 30	Nut M20	KK 08 12 93	Beam support, rear for LM100-14" (From 15.08.00)	
	KK 08 13 13	Main tube, L = 2238 mm for EM/LM-100 (3 furrow)	19	KK 08 13 42	Connecting plate (for headstock 240)	29	KK 03 28 50	Hex screw M20 x 50 mm w/nut
	KK 08 13 14	Main tube, L = 3238 mm for EM/LM-100 (4 furrow)	20	KK 08 13 90	Beam support w/balls for EM85-14" and EM100-16"	30	KK 03 28 90	Hex screw M20 x 90 mm w/nut (for headstock 160)
	KK 08 13 15	Main tube, L = 4238 mm for EM/LM-100 (5 furrow)		KK 08 13 95	Beam support w/balls for EM85-16" and EM100-18"	KK 03 28 40	Hex screw M20 x 40 mm w/nut (for headstock 240)	
2	KK 08 13 18	Extension tube EM/LM-85	21	KK 08 13 91	Beam support w/balls, rear for EM85-14" and EM100- 6" (Before 01.06.99)	31	KK 01 10 18	Roll pin D10 x 40 mm
	KK 08 13 19	Estension tube EM/LM-100		KK 08 13 92	Beam support w/balls, rear for EM85-4" and EM100-16" (From 01.06.99)	32	KK 07 15 69	Fixing for cylinder (for headstock 240)
3	KK 08 13 40	Threaded plate for extension kit		KK 08 17 83	Beam support w/balls, rear for EM85-14" and EM100-16" (From 01.11.00)	33	KK 01 10 20	Roll pin D12 x 40 mm
4	KK 07 58 89	Bushing (Before 01.09.99)		KK 08 13 96	Beam support w/balls, rear for EM85-16" and EM100-18" (Before 01.06.99)	34	KK 12 60 95	Bolt D25.3 x 212 mm
5	KK 08 13 20	Main support for EM85-14" and EM100-16"		KK 08 13 97	Beam support w/balls, rear for EM85-16" and EM100-18" (From 01.06.99)	35	KK 01 00 42	Bushing
	KK 08 13 25	Main support for EM85-16" and EM100-18"		KK 08 17 88	Beam support w/balls, rear for EM8-16" and EM100-18" (From 01.11.00)	36	KK 07 26 06	Slide rail, inner (for headstock 240)
	KK 08 13 60	Main support for EM100 - 14" (From 01.11.00)		KK 08 13 59	Beam support w/balls, rear for EM100-14" (From 01.11.00)	37	KK 07 26 07	Slide rail, outer (for headstock 240)
	KK 08 13 30	Main support for LM85-14" and LM100-16"				38	KK 03 28 80	Hex screw M20 x 80 mm w/nut
	KK 08 13 35	Main support for LM85-16" and LM100-18"				39	KK 03 28 95	Hex screw M20 x 95 mm w/nut
	KK 08 13 70	Main support for LM100 - 14" (From 15.08.00)	22	KK 03 28 45	Hex screw M20 x 45 mm w/nut	40	KK 03 50 25	Cylinder screw M10 x 30 mm (From 01.05.99)
6	KK 08 13 41	Threaded plate for main support	23	KK 03 28 22	Hex screw M20 x 190 mm w/nut	41	KK 01 60 06	Lock nut M10 (From 01.05.99)
7	KK 07 26 21	Slide rail inner, EM/LM-110	24	KK 06 16 37	Plate	42	KK 06 19 70	Fix for hose (for EM plough only)
	KK 07 26 17	Slide rail inner, EM/LM-160	25	KK 07 12 55	Ball	43	KK 06 19 74	Fix for hose
8	KK 07 26 06	Slide rail outer, EM/LM-110	26	KK 03 27 52	Hex screw M16 x 50 mm w/nut	44	KK 06 19 73	Fix for hose (for LM plough only)
	KK 07 19 40	Slide rail outer, EM/LM-160	27	KK 08 12 90	Beam support for LM85-14" and LM100-16"		KK 06 19 70	Fix for hose (for EM plough only)
9	KK 07 15 24	Machine stand (Before 01.08.01)		KK 08 12 95	Beam support for LM85-16" and LM100-18"	46	KK 08 13 68	Support for machine stand
	KK 08 16 24	Tube for machine stand (From 01.08.01)		KK 08 12 92	Beam support for LM100-14" (From 15.08.00)	47	KK 03 27 45	Hex screw M16 x 45 mm w/nut
10	KK 07 17 14	Bolt	28	KK 08 12 91	Beam support, rear for LM85-14" and LM100-16" (Before 01.06.99)	48	KK 03 28 22	Hex screw M20 x 190 mm w/nut (Before 01.09.99)
11	KK 07 17 11	Spring				KK 03 28 45	Hex screw M20 x 45 mm w/nut (From 01.09.99)	
12	KK 07 17 12	Bolt		KK 08 16 20	Beam support, rear for LM85-14" and LM100-16" (From 01.06.99)	49	KK 03 28 30	Hex screw M20 x 30 mm w/nut
13	KK 01 09 09	Plastic cover				50	KK 08 12 14	Plate (From 01.09.99)




51	KK 08 13 69	Plate for wheel support (From 15.08.00)
52	KK 08 16 22	Adjustable machine stand (From 01.08.01)
53	KK 03 27 60	Hex screw M16 x 60 mm (From 01.08.01)
54	KK 07 43 19	Bushing (From 01.08.01)
55	KK 01 58 25	Nut M16 (From 01.08.01)
56	KK 07 14 04	Bushing
57	KK 03 27 92	Hex screw M16 x 90 mm w/ nut
Not ill.	KK 08 01 87	Machine stand cpl. (From 01.08.01)




Замовлення запчастин
(050)-407-68-47
(050)-407-68-45




1	KK 08 13 16	Main tube, L = 1088 mm for EM/LM-85 (2 furrow)	15	KK 08 13 68	Support for machine stand	KK 08 13 77	Beam support, rear LM85 - 16" and LM100 - 18"	
	KK 08 13 10	Main tube, L = 1938 mm for EM/LM-85 (3 furrow)	16	KK 07 15 24	Machine stand (Before 01.08.01)	KK 08 12 93	Beam support, rear LM100 - 14"	
	KK 08 13 11	Main tube, L = 2788 mm for EM/LM-85 (4 furrow)	17	KK 07 17 14	Bolt	41	KK 08 12 90	Beam support, LM85 - 14" and LM100 - 16"
	KK 08 13 12	Main tube, L = 3638 mm for EM/LM-85 (5 furrow)	18	KK 07 17 11	Spring		KK 08 12 95	Beam support, LM85 - 16" and LM100 - 18"
	KK 08 13 17	Main tube, L = 1238 mm for EM/LM-100 (2 furrow)	19	KK 07 17 12	Bolt		KK 08 12 92	Beam support, LM100 - 14"
	KK 08 13 13	Main tube, L = 2238 mm for EM/LM-100 (3 furrow)	20	KK 01 09 09	Plastic cover	42	KK 03 28 30	Hex screw M20 x 30 mm w/nut
	KK 08 13 14	Main tube, L = 3238 mm for EM/LM-100 (4 furrow)	21	KK 07 17 13	Bolt	43	KK 08 12 14	Plate (Before 01.09.99)
	KK 08 13 15	Main tube, L = 4238 mm for EM/LM-100 (5 furrow)	22	KK 03 27 45	Hex screw M16 x 45 mm w/nut	44	KK 01 06 50	Spanner
2	KK 08 13 18	Extension tube EM/LM-85	23	KK 07 17 10	Fixing plate for machine stand	45	KK 08 16 22	Adjustable machine stand (From 01.08.01)
	KK 08 13 19	Estension tube EM/LM-100	24	KK 01 60 13	Flange nut M14	46	KK 03 27 60	Hex screw M16 x 60 mm (From 01.08.01)
3	KK 08 13 40	Threaded plate for extension kit	25	KK 01 58 30	Nut M20	47	KK 07 43 19	Bushing (From 01.08.01)
4	KK 07 58 89	Bushing (Before 01.09.99)	26	KK 01 60 06	Lock nut M10	48	KK 01 58 25	Nut M16 (From 01.08.01)
5	KK 08 13 20	Main support for EM85 - 14" and EM100 - 16"	27	KK 01 10 18	Roll pin D10 x 40 mm	49	KK 08 15 18	Slide rail, inner w/cylinder bracket (for front furrow adjustment w/2 cylinders) (From 01.01.02)
	KK 08 13 25	Main support for EM85 - 16" and EM100 - 18"	28	KK 03 50 25	Cylinder screw M10 x 30 mm			
	KK 08 13 60	Main support for EM100 - 14"	29	KK 01 07 00	Ring pin D12	50	KK 07 58 89	Bushing (From 01.05.00)
	KK 08 13 30	Main support for LM85 - 14" and LM100 - 16"	30	KK 08 15 75	Spanner holder	51	KK 07 14 04	Bushing
	KK 08 13 35	Main support for LM85 - 16" and LM100 - 18"	31	KK 08 13 90	Beam support w/balls EM85 - 14" and EM100 - 16"	52	KK 03 27 92	Hex screw M16 x 90 mm w/ nut
	KK 08 13 70	Main support for LM100 - 14"		KK 08 45 38	Beam support w/balls EM85 - 16" and EM100 - 18"	Not ill.	KK 08 01 87	Machine stand cpl. (From 01.08.01)
6	KK 08 13 41	Threaded plate for main support		KK 08 13 58	Beam support w/balls EM100 - 14"			
7	KK 07 26 17	Slide rail, inner	32	KK 08 17 83	Beam support w/balls, rear EM85 - 14" and EM100 - 16"			
8	KK 07 19 40	Slide rail, outer		KK 08 17 88	Beam support w/balls, rear EM85 - 16" and EM100 - 18"			
9	KK 02 99 27	Grease nipple 45°		KK 08 13 59	Beam support w/balls, rear EM100 - 14"			
10	KK 06 19 72	Fix for hose (only when using support for packer)	33	KK 03 28 22	Hex screw M20 x 190 mm w/nut (Before 01.09.99)			
				KK 03 28 45	Hex screw M20 x 45 mm w/nut (From 01.09.99)			
11	KK 03 28 90	Hex screw M20 x 90 mm w/nut	34	KK 03 28 20	Hex screw M20 x 200 mm w/nut			
12	KK 03 28 85	Hex screw M20 x 85 mm w/nut	35	KK 06 16 37	Plate			
13	KK 03 28 50	Hex screw M20 x 50 mm w/nut	36	KK 07 12 56	2 balls w/bolt M16 x 50 mm and locktite			
14	KK 03 27 45	Hex screw M16 x 45 mm w/nut	37	KK 03 27 52	Hex screw M16 x 50 mm (12.9)			
			38	KK 03 28 45	Hex screw M20 x 45 mm w/nut			
			39	KK 08 13 69	Plate for wheel support			
			40	KK 08 13 76	Beam support, rear LM85 - 14" and LM100 - 16"			



1	KK 08 24 80	Main tube for EM/LM-85 (2 furrow)	KK 08 13 67	Support for machine stand (From 01.03.02)	KK 08 24 97	Beam support, LM85 - 14" and LM100 - 16"		
	KK 08 24 81	Main tube for EM/LM-85 (3 furrow)	16	KK 08 16 24	Tube for machine stand	KK 08 24 98	Beam support, LM85 - 16" and LM100 - 18"	
	KK 08 24 82	Main tube for EM/LM-85 (4 furrow)	17	KK 07 17 14	Bolt	42	KK 03 28 30	Hex screw M20 x 30 mm w/nut
	KK 08 24 83	Main tube for EM/LM-85 (5 furrow)	18	KK 07 17 11	Spring	43	KK 01 58 25	Nut M16
	KK 08 24 84	Main tube for EM/LM-100 (2 furrow)	19	KK 07 17 12	Bolt	44	KK 01 06 50	Spanner
	KK 08 24 85	Main tube for EM/LM-100 (3 furrow)	20	KK 01 09 09	Plastic cover	45	KK 08 16 22	Adjustable machine stand
	KK 08 24 86	Main tube for EM/LM-100 (4 furrow)	21	KK 07 17 13	Bolt	46	KK 03 27 60	Hex screw M16 x 60 mm
	KK 08 24 87	Main tube for EM/LM-100 (5 furrow)	22	KK 03 27 45	Hex screw M16 x 45 mm w/nut	47	KK 07 43 19	Bushing
2	KK 08 13 18	Extension tube EM/LM-85	23	KK 07 17 10	Fixing plate for machine stand	48	KK 08 12 14	Plate
	KK 08 13 19	Estension tube EM/LM-100	24	KK 01 60 13	Flange nut M14	49	KK 07 14 04	Bushing
3	KK 08 13 40	Threaded plate for extension kit	25	KK 01 58 30	Nut M20	50	KK 03 27 92	Hex screw M16 x 90 mm w/ nut
4	KK 07 58 89	Bushing	26	KK 01 60 06	Lock nut M10			
5	KK 08 24 70	Main support for EM100 - 14"	27	KK 01 10 18	Roll pin D10 x 40 mm	Not ill.	KK 08 01 87	Machine stand cpl.
	KK 08 24 71	Main support for EM85 - 14" and EM100 - 16"	28	KK 03 50 25	Cylinder screw M10 x 30 mm			
	KK 08 24 72	Main support for EM85 - 16" and EM100 - 18"	29	KK 01 07 00	Ring pin D12			
	KK 08 24 65	Main support for LM100 - 14"	30	KK 08 15 75	Spanner holder			
	KK 08 24 66	Main support for LM85 - 14" and LM100 - 16"	31	KK 08 45 36	Beam support w/balls EM100 - 14"			
	KK 08 24 67	Main support for LM85 - 16" and LM100 - 18"		KK 08 45 37	Beam support w/balls EM85 - 14" and EM100 - 16"			
				KK 08 45 38	Beam support w/balls EM85 - 16" and EM100 - 18"			
6	KK 03 28 21	Hex screw M20 x 210 mm w/flange nut	32	KK 08 13 59	Beam support w/balls, rear EM100 - 14"			
7	KK 07 26 17	Slide rail, inner		KK 08 17 83	Beam support w/balls, rear EM85 - 14" and EM100 - 16"			
8	KK 07 19 40	Slide rail, outer		KK 08 17 88	Beam support w/balls, rear EM85 - 16" and EM100 - 18"			
9	KK 02 99 27	Grease nipple 45°						
10	KK 06 19 72	Fix for hose (only when using support for packer)	33	KK 03 28 45	Hex screw M20 x 45 mm w/nut			
			34	KK 03 28 22	Hex screw M20 x 190 mm w/nut			
11	KK 03 28 90	Hex screw M20 x 90 mm w/nut	35	KK 06 16 37	Plate			
12	KK 03 28 85	Hex screw M20 x 85 mm w/nut	36	KK 07 12 56	2 balls w/bolt M16 x 50 mm and locktite			
13	KK 08 15 18	Slide rail, inner w/cylinder bracket (for front furrow adjustment w/2 cylinders) (Before 15.03.02)	37	KK 03 27 52	Hex screw M16 x 50 mm (12.9)			
	KK 08 15 92	Slide rail, inner (for front furrow adjustment w/2 cylinders) (From 15.03.02)	38	KK 03 28 50	Hex screw M20 x 50 mm w/nut			
			39	KK 08 13 69	Plate for wheel support			
			40	KK 08 13 76	Beam support, rear LM85 - 14" and LM100 - 16"			
14	KK 03 27 45	Hex screw M16 x 45 mm w/nut		KK 08 13 77	Beam support, rear LM85 - 16" and LM100 - 18"			
15	KK 08 13 68	Support for machine stand (Before 01.03.02)		KK 08 12 93	Beam support, rear LM100 - 14"			
			41	KK 08 24 96	Beam support, LM100 - 14"			




1	KK 03 35 16	Hex screw M10 x 16 mm	25	KK 01 20 56	Angle
	KK 03 50 10	Cylinder screw M8 x 90 mm w/nut	26	KK 01 27 32	Fixing device (for headstock 160)
2	KK 01 22 61	Threaded coupling 3/8" - 3/8" without choke		KK 01 27 25	Fixing device (for headstock 80 and 110)
3	KK 01 15 85	Gasket ring 3/8"	27	KK 01 20 77	Threaded coupling 3/8" - 3/8" w/1.7 mm choke (For turning w/bodies over the main frame. For headstock 80 and 110)
4	KK 01 27 40	Valve		KK 01 21 04	Threaded coupling 3/8" - 1/2" w/2.0 mm choke (for headstock 160) (Before 01.12.98)
5	KK 01 22 09	Hose 3/8", L = 600 mm		KK 01 20 78	Threaded coupling 3/8" - 3/8" w/2.0 mm choke (for headstock 160) (From 01.12.98)
6	KK 01 22 08	Hose 3/8", L = 500 mm	28	KK 01 20 78	Threaded coupling 3/8" - 3/8" w/2.0 mm choke (For turning w/bodies under the main frame. For headstock 80 and 110)
7	KK 35 24 02	Turn-over cylinder D90 x 150 mm (for headstock 160) (see plate no. 1033) (Before 01.12.98)		KK 01 20 70	Threaded coupling 3/8" - 1/2" w/1.7 mm choke (for headstock 160) (Before 01.12.98)
	KK 35 35 80	Turn-over cylinder D90 x 150 mm (for headstock 160) (see plate no. 1063) (From 01.12.98)		KK 01 20 77	Threaded coupling 3/8" - 3/8" w/1.7 mm choke (for headstock 160) (From 01.12.98)
	KK 35 27 50	Turn-over cylinder D80 x 130 mm (for headstock 80 and 110) (see plate no. 357)	29	KK 06 19 42	Clamp for 2 hoses
	KK 35 38 02	Turn-over cylinder D80 x 130 mm (for headstock 110 only, from 01.08.96) (see plate on. 1037) (Before 01.01.00)	30	KK 03 35 25	Hex screw M10 x 25 mm w/nut
	KK 35 36 32	Turn-over cylinder D80 x 130 mm (see plate no. 1146) (From 01.01.01)	31	KK 01 21 02	Threaded coupling 3/8" - 1/2" w/1.0 mm choke (Before 01.08.96)
8	KK 01 27 88	Hose 3/8", L = 1500 mm		KK 01 20 75	Threaded coupling 3/8" - 3/8" w/1.0 mm choke (From 01.08.96)
9	KK 35 23 50	Cylinder D50 x 200 mm (see plate no. 473) (Before 01.08.96)		KK 01 21 03	Threaded coupling 3/8" - 1/2" w/1.4 mm choke (Before 01.08.96)
	KK 35 37 01	Hydraulic cylinder D50 x 200 mm cpl. (see plate no. 525) (From 01.08.96) (Before 01.04.01)		KK 01 20 76	Threaded coupling 3/8" - 3/8" w/1.4 mm choke (From 01.08.96)
	KK 35 39 01	Hydraulic cylinder D50 x 200 mm cpl. (see plate no. 1192) (From 01.04.01) (when using headstock 110, before 01.11.01)	32	KK 01 15 65	Gasket ring 1/2" (Before 01.08.96)
10	KK 01 03 28	Bolt D25.3 x 78 mm		KK 01 15 85	Gasket ring 3/8" (From 01.08.96)
	KK 01 03 19	Bolt D25.3 x 120 mm (for EM, LM and LS)	33	KK 35 36 81	Hydraulic cylinder D50 x 200 mm cpl. (see plate no. 1114) (when using headstock 110, from 01.11.01)
	KK 12 60 95	Bolt D25.3 x 212 mm (for EM, LM and LS)	34	KK 01 03 19	Bolt w/head D25.3 x 120 mm (when using headstock 110, from 01.11.01)
11	KK 03 33 25	Hex screw M6 x 25 mm w/nut	35	KK 01 00 08	Bushing D35 x d26 x 10 mm (when using headstock 110, from 01.11.01)
12	KK 01 25 20	Hose holder	36	KK 01 20 62	Banjo 3/8", H = 17 (when using headstock 110, from 01.11.01)
13	KK 01 07 00	Pin D12 mm (Before 01.08.96)	37	KK 01 20 59	Banjo bolt 3/8" x 31 (when using headstock 110, from 01.11.01)
	KK 01 10 20	Roll pin D12 x 40 mm (From 01.06.96)	38	KK 01 27 86	Hose 1/4", L = 3000 mm (when using headstock 110, from 01.11.01)
14	KK 01 15 96	Hose wrapper	39	KK 01 27 10	Clamp for 6 hoses
15	KK 01 27 04	Hose assembly coil	40	KK 06 19 41	Hose bracket for 6 hoses, H = 70 mm
16	KK 01 27 02	U-bolt	41	KK 06 19 40	Hose bracket for 6 hoses, H = 55 mm
17	KK 01 58 99	Wing nut M6	42	KK 35 36 80	Hydraulic cylinder D63 x 200 mm cpl. (see plate no. 1123) (From 01.07.02)
18	KK 01 27 01	Hose holder			
19	KK 01 58 17	Nut M12			
20	KK 06 19 43	Bracket for 3 hoses			
21	KK 01 27 59	Hose 1/4", L = 2750 mm			
22	KK 01 21 14	Quick coupling			
23	KK 01 15 65	Gasket ring 1/2"			
24	KK 01 20 60	Threaded coupling 3/8" - 1/2"			




1	KK 35 36 64	Turn-over cylinder D80 x 300 mm cpl. (see plate no. 1111)
2	KK 01 15 85	Gasket ring 3/8"
3	KK 01 22 61	Threaded coupling 3/8" - 3/8"
4	KK 01 20 80	Threaded coupling 3/8", D3.0 mm choke (Before 01.04.02)
	KK 01 20 78	Threaded coupling 3/8" - 3/8", D2.0 mm choke (From 01.04.02)
5	KK 01 20 56	Angular coupling 3/8", 90 °
6	KK 01 15 41	Hose 3/8", L = 700 mm
7	KK 01 27 40	Turn-over valve 3/8"
8	KK 03 35 12	Hex screw M10 x 12 mm
9	KK 01 22 12	Hose 3/8", L = 900 mm
10	KK 01 00 08	Bushing
11	KK 01 35 01	Hydraulic hose holder, L = 400 mm
12	KK 01 15 96	Hydraulic hose holder, L = 250 mm
13	KK 35 36 81	Front furrow adjustment cylinder D50 x 200 mm cpl. (see plate no. 1114)
14	KK 01 03 19	Bolt w/head D25.3 x 120 mm
15	KK 01 10 20	Pin D12 x 40 mm
16	KK 01 27 85	Hose 1/4", L = 2250 mm
17	KK 01 20 59	Banjo bolt 3/8" x 31
18	KK 01 20 62	Banjo 3/8", H = 17
19	KK 01 21 58	Quick coupling 1/2" - 3/8"
20	KK 01 03 28	Bolt w/head D25.3 x 78 mm
21	KK 01 35 00	Hydraulic hose holder D32 x 250 mm
22	KK 01 26 70	Hose 1/4", L = 500 mm
23	KK 01 23 07	Catridge 3/8" x 31
24	KK 35 36 09	Rod bracket extension
25	KK 01 03 28	Bolt w/head D25.3 x 78 mm (Before 15.03.02)
	KK 01 03 18	Bolt w/head D25.3 x 103 mm (From 15.03.02)





1	KK 35 24 01	Turn-over cylinder D75 x 400 mm (see plate no. 369) (Before 01.07.97)	20	KK 35 23 72	Hydraulic cylinder for furrow width adjustment D75 x 200 mm (see plate no. 568) (Before 01.08.96)
	KK 35 37 08	Turn-over cylinder D75 x 400 mm (see plate no. 1005) (From 01.07.97)		KK 35 37 04	Hydraulic cylinder for furrow width adjustment D75 x 200 mm (see plate no. 890) (From 01.08.96) (Before 01.04.01)
2	KK 01 03 28	Bolt w/head 25.3 x 78 mm		KK 35 39 04	Hydraulic cylinder for furrow width adjustment D75 x 200 mm (see plate no. 1195) (From 01.04.01)
3	KK 01 15 65	Gasket ring 1/4" (Before 01.07.97)			
	KK 01 15 85	Gasket ring 3/8" (From 01.07.97)	21	KK 07 21 77	Bracket for cylinder
4	KK 01 20 60	Threaded coupling 3/8" - 1/2" (for turning w/bodies under the frame) (Before 01.07.97)	22	KK 01 03 18	Bolt w/head 25.3 x 100 mm
	KK 01 22 61	Threaded coupling 3/8" - 3/8" (for turning w/bodies under the frame) (From 01.07.97)	23	KK 06 19 43	Holder for three hoses (For turning w/bodies over the frame)
	KK 01 21 04	Threaded coupling 3/8" - 1/2" w/2.0 mm choke (for turning w/bodies over the frame) (Before 01.07.97)	24	KK 03 27 25	Hex screw M16 x 27 mm (For turning w/bodies over the frame)
	KK 01 20 78	Threaded coupling 3/8" - 1/2" w/2.0 mm choke (for turning w/bodies over the frame) (From 01.07.97)	25	KK 03 27 75	Hex screw M16 x 75 mm w/nut (For turning w/bodies over the frame)
5	KK 01 22 12	Hose 3/8" L=900 mm	26	KK 03 27 90	Hex screw M16 x 90 mm w/nut (For turning w/bodies over the frame)
6	KK 01 22 09	Hose 3/8" L=600 mm	27	KK 06 19 45	Extension for hose holder (For turning w/bodies over the frame)
7	KK 01 21 04	Threaded coupling 3/8" - 1/2" w/2.0 mm choke (For turning w/bodies under the frame) (Before 01.07.97)	28	KK 01 25 20	Clamp for three hoses (For turning w/bodies over the frame)
	KK 01 20 78	Threaded coupling 3/8" - 3/8" w/2.0 mm choke (For turning w/bodies under the frame) (From 01.07.97)	29	KK 03 33 25	Hex screw M6 x 25 mm (For turning w/bodies over the frame)
	KK 01 20 60	Threaded coupling 3/8" - 1/2" (For turning w/bodies over the frame) (Before 01.07.97)	30	KK 01 21 14	Quick coupling plug
	KK 01 22 61	Threaded coupling 3/8" - 3/8" (For turning w/bodies over the frame) (From 01.07.97)	31	KK 01 58 17	Nut M12
8	KK 01 27 40	Turn-over valve 3/8"	32	KK 01 27 01	Hose holder
9	KK 07 16 97	Holder for turn-over valve	33	KK 01 58 99	Wing nut M6
10	KK 03 35 16	Hex screw M10 x 16 mm	34	KK 01 27 02	Clamp for hose holder
11	KK 01 27 88	Hose 3/8" L=1500 mm	35	KK 01 27 04	Hose assembly coil 30 x 1300 mm
12	KK 01 21 48	Banjo bolt 1/2" w/2.0 mm choke (Before 01.07.97)	36	KK 01 15 96	Hose wrapper 12.5 x 250 mm
	KK 01 20 84	Banjo bolt 3/8" w/2.0 mm choke (From 01.07.97)	37	KK 01 21 44	Banjobolt 1/2" (Before 01.07.97)
13	KK 01 21 77	Gasket ring		KK 01 20 59	Banjobolt 3/8" (From 01.07.97)
14	KK 01 25 48	Banjo 3/8"	38	KK 01 27 28	Banjo 1/2" (Before 01.07.97)
15	KK 01 25 08	Lock valve		KK 01 25 48	Banjo 3/8" (From 01.07.97)
16	KK 01 20 60	Threaded coupling 3/8" - 1/2" (Before 01.07.97)	39	KK 01 25 77	Threaded coupling 3/8" outer - 3/8" inner
	KK 01 22 61	Threaded coupling 3/8" - 3/8" (From 01.07.97)	40	KK 01 15 85	Gasket ring 3/8"
17	KK 01 20 56	Angle 3/8"	41	KK 01 27 23	Valve w/handle 3/8"
18	KK 01 27 76	Hose 1/4" L = 2750 mm (for turning w/bodies under the frame)	42	KK 01 20 62	Banjo 3/8"
	KK 01 27 52	Hose 1/4" L=3500 mm (for turning w/bodies over the frame)	43	KK 01 20 59	Banjobolt 3/8" x 31
19	KK 01 07 00	Pin D12 (Before 01.08.97)			
	KK 01 10 20	Roll pin D12 x 40 mm (From 01.08.97)			



1	KK 01 12 61	Circlip
2	KK 01 12 23	Bearing
3	KK 35 35 96	Rod head
4	KK 03 20 02	Screw M6 x 10 mm
5	KK 01 65 22	Scraper
6	KK 01 65 23	Packing for piston rod
7	KK 35 35 97	Collar
8	KK 03 20 07	Screw M5 x 6 mm
9	KK 35 35 93	Rod cap
10	KK 01 65 25	Support ring
11	KK 01 65 24	O-ring D79.2 x D5.7
12	KK 01 17 37	O-ring D35 x D3
13	KK 35 35 95	Piston rod
14	KK 01 65 26	O-ring D28 x D3
15	KK 35 35 94	Piston
16	KK 01 65 27	Packing
17	KK 35 35 92	Cylinder tube
18	KK 02 99 18	Grease nipple
19	KK 35 36 77	Scraper plastic ring
Not ill.	KK 01 36 02	Packings cpl.
	KK 35 35 80	Turn-over cylinder D90 x 150 mm



Замовлення запчастин
(050)-407-68-47
(050)-407-68-45



1	KK 01 12 76	Circlip
2	KK 01 05 09	Bearing
3	KK 02 99 20	Grease nipple
4	KK 03 20 01	Cylinder screw M6 x 6 mm
5	KK 35 37 64	Clevis D80/D35 mm
6	KK 01 65 16	Ring D45 x 2.5 mm
7	KK 01 65 17	O-ring D42 x 4 mm
8	KK 35 37 65	Stop
9	KK 35 37 66	Rod cap
10	KK 01 65 08	Aluminium ring D95 x 1.2 mm
11	KK 01 65 12	Support ring
12	KK 01 65 11	O-ring
13	KK 01 17 45	Scraper
14	KK 01 17 44	Seal for piston rod
15	KK 35 37 63	Piston rod
16	KK 01 65 69	O-ring
17	KK 03 20 06	Cylinder screw M6 x 20 mm
18	KK 35 37 67	Piston
19	KK 01 65 09	Packing set
20	KK 35 37 62	Cylinder tube D80/D35 mm
Not ill.	KK 35 37 68	Packings D80/D35 mm cpl.
	KK 35 38 02	Turn-over cylinder D80 x 130 mm cpl.





1	KK 35 37 30	Cylinder tube (for cylinder KK 35 37 01 and KK 35 37 02)
	KK 35 37 31	Cylinder tube (for cylinder KK 35 37 03)
2	KK 03 20 02	Screw M6 x 10 mm
3	KK 35 37 21	Piston
4	KK 01 17 30	Piston packing
5	KK 01 17 29	O-ring
6	KK 35 37 40	Piston rod (for cylinder KK 35 37 01 and KK 35 37 03)
	KK 35 37 41	Piston rod (for cylinder KK 35 37 02)
7	KK 01 17 98	O-ring
8	KK 01 17 99	Support ring
9	KK 01 17 33	Ring (Before 15.03.99)
	KK 35 37 92	Lock spring (From 15.03.99)
10	KK 35 37 20	Packing seal
11	KK 01 17 31	Piston rod packing
12	KK 01 17 32	Scraper
13	KK 03 20 16	Screw M10 x 45 mm
14	KK 35 37 22	Clevis

Not ill.	KK 35 37 42	Stop (for cylinder KK 35 37 02)
	KK 35 37 25	Packings cpl.
	KK 35 37 01	Hydraulic cylinder for furrow with adjustment D50 x 200 mm cpl.
	KK 35 37 02	Hydraulic cylinder D50 x 200 mm w/stop cpl.
	KK 35 37 03	Hydraulic cylinder D50 x 200 mm w/90° twisted end cap cpl.







1	KK 35 39 34	Cylinder tube (for cylinder KK 35 39 01 and KK 35 39 02)
	KK 35 39 35	Cylinder tube (for cylinder KK 35 39 03)
2	KK 01 03 90	Piston packing
3	KK 35 39 36	Piston rod (for cylinder KK 35 39 01 and KK 35 39 03)
	KK 35 39 37	Piston rod (for cylinder KK 35 39 02)
4	KK 01 65 17	O-ring D42 x 4 mm
5	KK 03 33 06	Hex screw M6 x 8 mm
6	KK 35 39 26	Packing seal
7	KK 01 30 91	Piston rod packing
8	KK 01 30 89	Scraper
9	KK 03 21 10	Set screw M8 x 8 mm
10	KK 35 39 46	Pin for stop (for cylinder KK 35 39 02)
11	KK 35 39 44	Stop (for cylinder KK 35 39 02)
12	UH 82 56 40	Cylinder screw M12 x 40 mm (for cylinder KK 35 39 02)
13	KK 35 39 22	Clevis
Not ill.	KK 01 30 86	Packings cpl.
	KK 35 39 01	Hydraulic cylinder D50 x 200 mm cpl.
	KK 35 39 02	Hydraulic cylinder D50 x 200 mm w/stop cpl.
	KK 35 39 03	Hydraulic cylinder D50 x 200 mm w/90° twisted end cap cpl.



Замовлення запчастин
(050)-407-68-47
(050)-407-68-45




1	KK 35 37 32	Cylinder tube for art.no 353704 (cylinder D75 x 200 mm without stop) and 353705 (cylinder D75 x 200 mm w/stop)
	KK 35 37 35	Cylinder tube for art.no 353706 (cylinder D75 x 200 mm w/90° twisted end cap)
	KK 35 37 36	Cylinder tube for art.no 353707 (cylinder D75 x 400 mm w/90° twisted end cap)
2	KK 03 20 06	Screw w/inner hex M6 x 20 mm
3	KK 35 37 27	Piston
4	KK 01 17 36	Piston packing
5	KK 01 17 37	O-ring
6	KK 35 37 44	Piston rod for art.no 353705 (cylinder D75 x 200 mm w/stop)
	KK 35 37 43	Piston rod for art.no 353704 and 353706 (cylinders D75 x 200 mm without stop)
	KK 35 37 46	Piston rod for art.no 353707 (cylinder D75 x 400 mm w/twisted end cap)
7	KK 01 17 38	O-ring
8	KK 01 17 43	Ring
9	KK 01 17 46	Ring (Before 15.03.99)
	KK 35 37 93	Lock spring (From 15.03.99)
10	KK 35 37 26	Packing seal
11	KK 01 17 44	Piston rod packing
12	KK 01 17 45	Scraper
13	KK 35 37 45	Stop for art.no 353705 (cylinder D75 x 200 mm w/stop)
14	KK 03 20 16	Screw w/inner hex M10 x 45 mm
15	KK 35 37 28	Clevis
Not ill.	KK 35 37 29	Packings cpl.
	KK 35 37 04	Cylinder D75 x 200 mm without stop, cpl.
	KK 35 37 05	Cylinder D75 x 200 mm w/stop, cpl.
	KK 35 37 06	Cylinder D75 x 200 mm w/90° twisted end cap, cpl.
	KK 35 37 07	Cylinder D75 x 400 mm w/90° twisted end cap, cpl.



Замовлення запчастин

(050)-407-68-47


(050)-407-68-45



1	KK 35 39 38	Cylinder tube (for cylinder KK 35 39 04 and KK 35 39 05)
	KK 35 39 39	Cylinder tube (for cylinder KK 35 39 06)
2	KK 35 39 40	Piston rod (for cylinder KK 35 39 04 and KK 35 39 06)
	KK 35 39 41	Piston rod (for cylinder KK 35 39 05)
3	KK 01 30 93	Piston packing
4	KK 01 30 96	O-ring D67 x 4 mm
5	KK 01 30 95	Support ring
6	KK 03 33 06	Hex screw M6 x 8 mm
7	KK 35 39 27	Packing seal
8	KK 01 30 94	Piston rod packing
9	KK 01 30 92	Scraper
10	KK 03 21 10	Set screw M8 x 8 mm (for cylinder KK 35 39 05)
11	KK 35 39 46	Pin for stop (for cylinder KK 35 39 05)
12	KK 35 39 45	Stop (for cylinder KK 35 39 05)
13	UH 82 56 40	Cylinder screw M12 x 40 mm
14	KK 35 39 23	Clevis

Not ill.	KK 01 30 87	Packings cpl.
	KK 35 39 04	Hydraulic cylinder D75 x 200 mm cpl.
	KK 35 39 05	Hydraulic cylinder D75 x 200 mm w/stop cpl.
	KK 35 39 06	Hydraulic cylinder D75 x 200 mm w/90° twisted end cap cpl.






1	KK 35 21 53	Rod head
2	KK 02 99 20	Grease nipple
3	KK 01 17 45	Scraper 35 x 43 mm
4	KK 01 17 44	Seal for piston rod
5	KK 35 37 26	Rod cap
6	KK 01 17 46	Ring (Before 15.03.99)
	KK 35 37 93	Lock ring (From 15.03.99)
7	KK 01 17 43	Support ring
8	KK 01 17 38	O-ring
9	KK 35 37 47	Piston rod
10	KK 35 37 37	Cylinder tube
11	KK 01 17 36	Packing
12	KK 03 20 06	Cylinder screw M6 x 20 mm
13	KK 35 37 27	Piston D75/35
14	KK 01 17 37	O-ring
15	KK 03 50 15	Cylinder screw M8 x 25 mm
16	KK 01 12 61	Circlip
17	KK 01 12 23	Bearing

Not ill.	KK 35 37 29	Packings set D75 mm cpl. (ill. no. 3, 4, 7, 8, 11 and 14)
	KK 35 37 08	Hydraulic cylinder D75 x 420 mm cpl. (ill. no. 1 - 17)



Замовлення запчастин
(050)-407-68-47
(050)-407-68-45



1	KK 35 36 71	Cylinder tube (for turn-over cylinder KK 35 36 64)
	KK 35 36 78	Cylinder tube (for turn-over cylinder KK 35 36 65)
2	KK 35 36 72	Piston rod w/piston (for turn-over cylinder KK 35 36 64)
	KK 35 36 79	Piston rod w/piston (for turn-over cylinder KK 35 36 65)
3	KK 03 20 01	Set screw M6 x 6 mm
4	KK 01 19 18	Piston packing
5	KK 01 18 24	O-ring D74.5
6	KK 01 18 76	Support ring
7	KK 35 36 75	Rod cap
8	KK 03 20 08	Set screw M5 x 8 mm
9	KK 01 19 51	Rod packing
10	KK 01 19 12	Scraper
11	KK 02 99 18	Grease nipple M6
12	KK 35 36 73	Rod bearing
13	KK 01 12 61	Circlip
14	KK 01 12 23	Spherical ball bearing
Not ill.	KK 01 30 66	Packing set cpl.
	KK 35 36 64	Turn-over cylinder D80 x 300 mm cpl. (for headstock mod. 200)
	KK 35 36 65	Turn-over cylinder D80 x 375 mm cpl. (for headstock mod. 300)



Замовлення запчастин
(050)-407-68-47
(050)-407-68-45




1	KK 35 36 82	Cylinder tube D50
2	KK 35 36 84	Piston
3	KK 01 30 69	Piston packing
4	KK 01 30 70	O-ring D23
5	KK 35 36 83	Piston rod
6	KK 01 17 69	O-ring D44.5
7	KK 35 36 85	Rod cap
8	KK 01 26 32	Support ring
9	KK 01 30 68	Seal for piston rod
10	KK 01 19 62	Scraper
11	KK 03 21 06	Pin M6 x 12 mm
12	KK 35 36 76	Clevis


Not ill.	KK 01 30 67	Packing set cpl.
	KK 35 36 81	Front furrow adjustment cylinder D50 x 200 mm cpl.




Замовлення запчастин
(050)-407-68-47
(050)-407-68-45




1	KK 06 40 30	Clevis	34	KK 07 17 40	Scraper holder
2	KK 01 58 34	Nut M20	35	KK 07 40 54	Scraper for steel wheel
3	KK 06 40 24	Stop screw		KK 07 17 29	Scraper for rubber wheel
	KK 06 40 47	Clevis cpl. (ill. 1 - 3)	36	KK 01 14 00	Cover kit cpl. 6,00 x 9
4	KK 02 99 20	Grease nipple	37	KK 01 29 22	Washer
5	KK 03 27 50	Hex screw M16 x 50 mm w/nut (Before 01.06.99)	38	KK 01 10 61	Roll pin D6 x 22 mm (From 18.05.99)
	KK 03 28 50	Hex screw M20 x 50 mm w/nut (From 01.06.99)	39	KK 01 16 36	Bushing (From 01.06.99)
6	KK 01 12 72	Circlip	40	KK 01 58 17	Nut M12
7	KK 01 04 61	Axle 16 x 47 mm (Before 18.05.99)	41	KK 01 58 25	Nut M16
	KK 01 02 55	Bolt w/head D16 x 51 mm (From 18.05.99)	42	KK 01 58 30	Nut M20
8	KK 06 40 75	Support (Before 01.06.99)			
	KK 07 47 74	Support (From 01.06.99)	Not ill.	KK 06 04 49	Depth wheel, steel 500 x 165 cpl. (Before 01.06.99)
9	KK 06 40 87	Silent block		KK 07 47 90	Depth wheel, steel 500 x 165 for beam H = 700 mm cpl. (From 01.06.99)
10	KK 06 40 78	Holder for silent block		KK 07 47 91	Depth wheel, steel 500 x 165 for beam H = 800 mm cpl. (From 01.06.99)
11	KK 03 27 40	Hex screw M16 x 40 mm w/nut		KK 06 04 69	Depth wheel, rubber 6.00 x 9 cpl. (Before 01.06.99)
12	KK 06 40 86	Lock for cushion		KK 07 47 94	Depth wheel, 6.00 x 9 for beam H = 700 mm cpl. (From 01.06.99)
13	KK 06 40 55	Wheel arm H = 700 mm		KK 07 47 95	Depth wheel, 6.00 x 9 for beam H = 800 mm cpl. (From 01.06.99)
	KK 07 40 55	Wheel arm H = 800 mm		KK 07 47 99	Screw and bushing set cpl. (From 01.06.99)
14	KK 06 40 89	Spring			
15	KK 06 40 88	Bracket for spring			
16	KK 01 29 19	Washer			
17	KK 03 36 70	Hex screw, wholly threaded M12 x 70 mm			
18	KK 03 15 30	Hex screw M12 x 30 mm			
23	KK 01 11 67	End cap			
24	KK 01 60 10	Lock nut M16			
25	KK 01 12 31	Bearing			
26	KK 01 00 96	Spacing tube			
27	KK 01 12 00	Bearing			
28	KK 01 08 06	2 packing sets			
29	KK 07 40 52	Wheel, steel			
	KK 07 04 59	Wheel cpl. w/ axle, steel			
30	KK 07 40 53	Axle			
31	KK 01 29 40	Washer			
32	KK 01 60 22	Flange nut M30			
33	KK 09 42 06	Tyre 6,00 x 9			
	KK 01 13 78	Rim			
	KK 09 42 07	Inner tube			
	KK 07 04 94	Wheel w/axle and tyre cpl.			



 Hannover
 Agro
 Замовлення запчастин
 (050)-407-68-47
 (050)-407-68-45




1	KK 01 11 57	End cap		KK 07 46 24	Scraper for wheel 26 x 12-12	
2	KK 01 60 10	Nut M16		KK 07 46 17	Scraper for wheel 26 x 12-12 cpl.	
3	KK 01 29 27	Washer		29	KK 01 14 01	Cover kit 200 x 14,5 cpl.
4	KK 01 12 00	Bearing			KK 01 14 02	Cover kit 26 x 12-12 cpl.
5	KK 01 00 31	Spacing tube for wheel 200 x 14.5		30	KK 35 35 40	Shock absorber
	KK 01 00 67	Spacing tube for wheel 26 x 12-12		31	KK 07 48 06	Bushing for shock absorber
6	KK 01 12 31	Bearing		32	KK 01 10 42	Roll pin for shock absorber
7	KK 01 08 06	Packing		33	KK 07 48 10	Bracket for wheelarm (for hydraulic shock absorber)
8	KK 01 13 03	Tyre 200 x 14.5		34	KK 07 40 48	Fixing for scraper
	KK 01 13 05	Inner tube for 200 x 14.5		35	KK 01 13 46	Tyre for wheel 26 x 12-12
	KK 01 13 31	Rim w/bearinga for 200 x 14.5			KK 01 13 49	Inner tube for wheel 26 x 12-12
9	KK 06 42 22	Axle for wheel LP-200 x 14,5		36	KK 01 14 19	Rim w/bearings for 26 x 12-12
	KK 06 42 23	Axle for wheel LP-26 x 12-12		37	KK 01 16 36	Bushing (From 01.06.99)
10	KK 01 60 37	Cone nut M30				
11	KK 02 99 20	Grease nipple	Not ill.	KK 03 26 95	Hex screw M12 x 95 mm w/nut (for scraper fixing)	
12	KK 01 02 55	Bolt w/ head		KK 03 26 85	Hex screw M12 x 85 mm w/nut (for scraper fixing)	
13	KK 01 10 61	Roll pin		KK 07 47 99	Screw and bushing set cpl. (From 01.06.99)	
14	KK 06 40 30	Clevis		KK 07 48 17	Rubber wheel 200 x 14 .5, H = 700 cpl.	
15	KK 01 58 32	Nut M20		KK 07 48 18	Rubber wheel 200 x 14 .5, H = 800 cpl.	
16	KK 06 40 36	Stop screw		KK 07 48 19	Rubber wheel 26 x 12 - 12, H = 700 cpl.	
	KK 06 40 39	Clevis cpl.		KK 07 48 20	Rubber wheel 26 x 12 - 12, H = 800 cpl.	
17	KK 06 40 75	Support				
18	KK 06 40 86	Protection for damper block				
19	KK 06 40 87	Damper block				
20	KK 06 40 78	Holder for damper block				
21	KK 03 27 40	Hex screw M16 x 40 mm w/nut				
	KK 03 27 60	Hex screw M16 x 60 mm w/nut (for hydraulic shock absorber)				
22	KK 06 40 81	Wheel arm H = 700 mm				
	KK 07 48 01	Wheel arm for hydr. shock absorber H = 700 mm				
	KK 06 40 74	Wheel arm H = 800 mm				
	KK 07 48 02	Wheel arm for hydr. shock absorber H = 800 mm				
23	KK 06 40 73	Tube				
24	KK 03 36 70	Hex screw M12 x 70 mm				
25	KK 01 29 19	Washer				
26	KK 06 40 89	Spring				
27	KK 03 27 50	Hex screw M16 x 50 mm w/nut				
28	KK 07 40 47	Scraper blade for wheel 200 x 14.5				
	KK 07 40 49	Scraper for wheel 200 x 14.5 cpl.				



1	KK 06 40 30	Clevis	32	KK 07 28 09	Wheel support (Before 01.06.99)
2	KK 01 58 30	Nut		KK 07 47 70	Wheel support (From 01.06.99)
3	KK 06 40 24	Stop screw	34	KK 01 16 36	Bushing (From 01.06.99)
	KK 06 40 47	Stop clevis cpl (ill. 1 - 3)	35	KK 01 02 55	Bolt w/head D16 x 51 mm (From 01.06.99)
4	KK 01 10 48	Roll pin	36	KK 01 10 61	Roll pin D6 x 22 mm (From 01.06.99)
5	KK 07 27 18	Bracket for shock absorber w/M16 axle			
6	KK 35 35 41	Shock absorber (as spare part, 072810 rebuilding part will be delivered)	Not ill.	KK 07 24 54	Depth wheel 500 x 165 w/shock absorber cpl. (Before 01.06.99)
7	KK 02 97 15	Split pin		KK 07 47 92	Depth wheel 500 x 165 w/shock absorber for beam H = 700 mm cpl. (From 01.06.99)
8	KK 07 27 17	Axle M16		KK 07 25 89	Depth wheel 6.00 x 9 cpl. (Before 01.06.99)
9	KK 02 99 20	Grease nipple		KK 07 47 93	Depth wheel 6.00 x 9 for beam H = 700 mm cpl. (From 01.06.99)
10	KK 01 58 25	Nut M16		KK 07 47 99	Screw and bushing set cpl. (From 01.06.99)
11	KK 01 12 72	Circlip (Before 01.06.99)			
12	KK 01 04 61	Axle (Before 01.06.99)			
13	KK 01 10 20	Roll pin (Before 01.06.99)			
14	KK 07 46 95	Wheel support			
15	KK 03 27 45	Hex screw M16 x 45 mm w/nut (Before 01.06.99)			
	KK 03 28 45	Hex screw M20 x 45 mm w/nut (From 01.06.99)			
16	KK 07 46 23	Cross shaft			
17	KK 07 24 68	Wheel arm			
18	KK 07 46 96	U-bolt M24			
19	KK 03 27 75	Hex screw M16 x 75 mm w/nut (without scraper)			
	KK 03 27 85	Hex screw M16 x 85 mm w/nut (with scraper)			
20	KK 03 36 30	Hex screw M12 x 30 mm w/nut			
21	KK 01 29 19	Washer			
22	KK 07 24 69	Bracket			
23	KK 07 40 54	Scraper blade steel wheel 500 x 165			
	KK 07 17 29	Scraper blade rubber wheel 6.00 x 9			
24	KK 07 24 58	Axle pin for wheel 072455 and 072588			
25	KK 07 40 52	Wheel 500 x 165			
	KK 07 24 55	Wheel 500 x 165 w/axle			
	KK 07 25 88	Wheel, rubber 6.00 x 9 w/axle			
26	KK 01 10 11	Roll pin D5 x 26 mm (From 01.04.99)			
27	KK 07 28 06	Bolt w/head D12 x 67 mm (From 01.04.99)			
28	KK 07 28 01	Crank (From 01.04.99)			
29	KK 01 29 31	Washer (From 01.04.99)			
30	KK 01 10 35	Roll pin D6 x 30 mm (From 01.04.99)			
31	KK 35 35 77	Shock absorber (From 01.04.99)			
	KK 35 39 20	Shock absorber (From 01.01.01)			




1	KK 01 11 57	End cap (Before 21.05.02)	27	KK 07 40 65	Lock bolt	44	KK 07 40 42	Plate for wheel 200 x 14.5 (Replaces 068578 from 03.01.92, Serial no. LB2320, LD5916 and EG4925)
2	KK 01 60 00	Lock nut M20 (Before 21.05.02)	28	KK 03 27 35	Hex screw M16 x 35 mm w/nut		KK 07 40 43	Plate for wheel 26 x 12-12 (Replaces 068578 from 03.01.92, Serial no. LB2320, LD5916 and EG4925)
3	KK 01 29 34	Washer (Before 21.05.02)	29	KK 01 29 24	Washer			
4	KK 01 12 00	Bearing (Before 21.05.02)	30	KK 06 82 51	Thrustwasher			
5	KK 01 13 79	Rim 200 x 14.5 (Before 21.05.02)	31	KK 07 40 70	Depth/transport wheelarm w/bushing			
	KK 08 41 06	Rim 200 x 14.5 (From 21.05.02)	32	KK 01 07 49	Bearing	45	KK 03 27 60	Hex screw M16 x 60 mm w/nut (Before 04.01.96, Serial no. LB3311)
6	KK 01 05 17	Bearing(Before 21.05.02)	33	KK 07 86 08	Axle D50 x 284 mm		KK 03 27 02	Hex screw M16 x 100 mm w/nut (From 04.01.96, Serial no. LB3311)
7	KK 01 11 68	Packing(Before 21.05.02)	34	KK 01 29 55	Washer		KK 03 28 07	Hex screw M20 x 100 mm w/nut (From 01.06.99)
8	KK 01 13 03	Tyre 200 x 14.5	35	KK 03 27 80	Hex screw M16 x 80 mm w/nut (Before serial no. ES1700)			
	KK 01 13 05	Inner tube 200 x 14.5	36	KK 01 14 01	Cover kit cpl.	46	KK 01 14 19	Rim 26 x 12-12 (Before 27.05.02)
9	KK 07 40 80	Axle 200 x 14.5 (Before 21.05.02)	37	KK 01 16 52	Bushing		KK 08 41 07	Rim 26 x 12-12 (From 27.05.02)
	KK 08 41 10	Axle 200 x 14.5 (From 21.05.02)	38	KK 07 58 47	Plate for wheel (for ES only) (From serial no. ES1700)	47	KK 01 13 46	Tyre 26 x 12-12 (Before 27.05.02)
10	KK 03 51 78	Hex screw M20 x 110 mm w/nut		KK 07 47 84	Plate for wheel (for ES only) (From 01.06.99) (Before 01.11.00)		KK 01 35 00	Tyre 26 x 12-12 (From 27.05.02)
11	KK 07 40 79	Wheel arm		KK 07 49 61	Plate for wheel (for LS only) (Before 01.06.99)	48	KK 01 13 49	Inner tube 26 x 12-12
12	KK 02 99 20	Grease nipple		KK 07 47 86	Plate for wheel (for LS only) (From 01.06.99)		KK 07 40 93	Axle 26 x 12-12 (Before 27.05.02)
13	KK 03 27 50	Hex screw M16 x 50 mm w/nut (Before serial no. ES1700)				49	KK 08 41 11	Axle 26 x 12-12 (From 27.05.02)
14	KK 03 27 65	Hex screw M16 x 65 mm w/nut (Before serial no. ES1700)	39	KK 07 58 49	Plate for wheel (for ES only) (From serial no. ES1700)	50	KK 01 16 13	Bushing D16/D20 x 17 mm w/flange
15	KK 06 40 30	Clevis		KK 07 47 85	Plate for wheel (for ES only) (From 01.06.99)		KK 07 40 42	Tube (Before 01.04.96)
16	KK 01 58 34	Nut M20		KK 07 49 64	Plate for wheel (for LS only) (Before 01.06.99)		KK 07 46 90	Tube (E/F, ED, EG, LB, LD only for) (From 01.04.96)
17	KK 06 40 36	Stop screw		KK 07 47 87	Plate for wheel (for LS only) (From 01.06.99) (Before 15.08.00)		KK 07 47 80	Tube (LB and LD only for wheel 200 x 14.5) (From 01.06.99)
	KK 06 40 39	Clevis cpl.					KK 07 40 43	Tube (Before 01.04.96)
18	KK 35 21 45	Shock absorber (Before 01.08.98)	40	KK 03 27 70	Hex screw M16 x 70 mm w/nut (From serial no.ES1700 and LS plough)		KK 07 46 93	Tube (E/F, ED, EG, LB, LD only for wheel 26 x 12-12) (From 01.04.96)
	KK 35 35 77	Shock absorber (From 01.08.98)		KK 03 28 70	Hex screw M20 x 70 mm w/nut (From 01.06.99)		KK 07 47 82	Tube (ED, EG, LB, LD only for wheel 26 x 12 - 12) (From 01.06.99)
	KK 35 39 20	Shock absorber (From 01.01.01)				51	KK 07 40 37	Scraper bracket (for wheel 200 x 14.5)
19	KK 01 04 64	Axle	41	KK 03 27 45	Hex screw M16 x 45 mm w/nut (From serial no.ES1700 and LS plough)		KK 07 39 91	Scraper bracket (for wheel 26 x 12 - 12)
20	KK 01 12 72	Circlip		KK 03 28 45	Hex screw M20 x 45 mm w/nut (From 01.06.99)	52	KK 07 40 47	Scraper (for wheel 200 x 14.5)
21	KK 02 99 20	Grease nipple					KK 07 46 24	Scraper (for wheel 26 x 12 - 12)
22	KK 01 04 61	Axle (Before 18.05.99)	42	KK 07 58 42	Plate for wheel (Before serial no. ES1700)	53	KK 01 10 61	Roll pin D6 x 22 mm (From 18.05.99)
	KK 01 02 55	Bolt w/head D16 x 51 mm (From 18.05.99)				54	KK 03 34 30	Lock screw M12 x 30 mm
23	KK 07 40 60	Support (Before 01.06.99)	43	KK 07 58 45	Plate for wheel (Before serial no. ES1700)	55	KK 01 29 19	Washer
	KK 07 47 72	Support (From 01.06.99)				56	KK 01 16 36	Bushing (From 01.06.99)
24	KK 07 40 78	Lock piece						
	KK 07 40 36	Lock piece for wheel w/scraper						
25	KK 03 27 60	Hex screw M16 x 60 mm w/nut						
26	KK 01 07 00	Pin M12						




57	KK 08 13 78	Plate for wheel (for LS and LM only) (From 15.08.00)	KK 07 04 91	Depth/transport wheel 200 x 14.5 cpl. (Before 01.06.99)
	KK 08 13 78	Plate for wheel (for ES and EM only) (From 01.11.00) (For LB, LD and EG, from 18.06.01)	KK 07 47 96	Depth/transport wheel 200 x 14.5 for beam H = 700/800 mm cpl. (From 01.06.99)
	KK 07 47 53	Plate for wheel 200 x 14.5 (for LB and LD only) (Before 18.06.01)	KK 01 19 39	Packing for shock absorber for part no. 35 21 45 and 35 27 77
	KK 07 22 40	Plate for wheel 26 x 12 - 12 (for ED, EG, LB and LD)	KK 07 48 40	Scraper for depth/transport wheel 200 x 14.5 cpl.
58	KK 01 10 35	Pin D6 x 30 mm	KK 07 47 99	Screw and bushing set cpl. (From 01.06.99)
59	KK 01 31 06	Z-lamell (From 21.05.02)		
60	KK 01 12 15	Conical bearing (From 21.05.02)		
61	KK 01 05 91	Conical bearing (From 21.05.02)		
62	KK 01 31 02	Washer MK6 (From 21.05.02)		
63	KK 01 31 04	Washer D42 x d30 x 3 (From 21.05.02)		
64	KK 01 31 03	Lock nut M30		
65	KK 01 31 05	Hub cap (From 21.05.02)		
Not ill.	KK 01 14 18	Wheel w/axle 26 x 12-12 (Before 21.05.02)		
	KK 08 41 01	Wheel w/axle 26 x 12-12 (From 27.05.02)		
	KK 07 04 93	Wheel w/axle 200 x 14.5 (Before 27.05.02)		
	KK 08 41 00	Wheel w/axle 200 x 14.5 (From 27.05.02)		
	KK 07 40 41	Depth/transport wheel 26 x 12-12 cpl. (Before 01.06.99)		
	KK 07 47 97	Depth/transport wheel 26 x 12-12 for beam H = 700/800 mm cpl. (From 01.06.99)		



Замовлення запчастин
(050)-407-68-47
(050)-407-68-45



1	KK 03 50 40	Hex screw w/cone M14 x 35 mm	30	KK 07 46 55	Wheel arm H=700 mm (From 01/01/95, serial no E41970, F17952, EG6271 and LB3033)	53	KK 01 29 94	Washer 8.4 x 16 x 1.5
2	KK 07 46 78	Plate (From 02/01/95, serial no EG6310, E41999, F18020, LB3045)				54	KK 03 27 90	Hex screw M16 x 90 mm w/nut
	KK 07 45 88	Plate (Before 02/01/95, serial no EG6310, E41999, F18020, LB3045)		KK 07 46 52	Wheel arm H=800 mm (From 01/01/95, serial no E41970, F17952, EG6271 and LB3033)	55	KK 07 46 48	Plate for rear mounted wheel (for LB plough)
3	KK 01 29 56	Washer 60 x 85 x 1 mm		KK 07 45 08	Wheel arm H=700 mm (Before 01/01/95, serial no E41970, F17952, EG6271 and LB3033)	56	KK 03 27 50	Hex screw M16 x 50 mm w/nut (for LB plough)
4	KK 03 27 95	Hex screw M16 x 95 mm w/nut				57	KK 07 59 08	Plate (Before serial no. ES1700)
5	KK 03 27 02	Hex screw M16 x 110 mm w/nut				58	KK 03 27 55	Hex screw M16 x 55 mm w/nut
6	KK 07 45 07	Bracket w/axle				59	KK 03 27 65	Hex screw M16 x 65 mm (for ES and LS plough, before 01.08.98) (for ED and LD plough, from 01.08.98)
7	KK 07 45 27	Cone bolt	31	KK 01 58 34	Nut M20		KK 07 58 97	Plate (From serial no. ES1700)
8	KK 01 10 16	Roll pin 8 x 45 mm	32	KK 06 70 49	Adjustment screw M20 x 110 mm		KK 07 46 45	Plate (for ED and LD plough) (From 01.08.98)
9	KK 07 45 18	Cone nut	33	KK 03 26 50	Hex screw M12 x 50 mm w/nut	60		
10	KK 07 45 49	Bolt D35 mm		KK 03 26 55	Hex screw M12 x 55 mm w/nut (w/scrapper)			
11	KK 07 45 35	Bracket	34	KK 01 29 55	Washer 50 x 70 x 1 mm	61	KK 01 14 19	Rim w/bearing for 26 x 12-12
	KK 07 46 40	Bracket (for VD plough only) (150 x 150)	35	KK 07 45 87	Stretching screw	62	KK 01 13 46	Tyre 26 x 12-12
12	KK 07 45 33	Plate for bracket	36	KK 07 45 94	Spring D26 x 76 mm		KK 01 13 49	Inner tube 26 x 12-12
	KK 07 46 44	Plate for bracket (for VD plough only) (150 x 150)	37	KK 07 46 77	Pin (From 02/01/95, serial no EG6310, E41999, F18020, LB3045)	63	KK 07 40 93	Axle 26 x 12-12
13	KK 03 28 75	Hex screw M20 x 75 mm w/nut		KK 07 45 86	Pin (Before 02/01/95, serial no EG6310, E41999, F18020, LB3045)	64	KK 07 46 13	Leaf spring (From 01.04.97)
	KK 03 28 24	Hex screw M20 x 105 mm w/nut (for VD plough only) (150 x 150)				65	KK 03 27 65	Hex screw M16 x 65 mm (for ES and LS plough) (From 01.08.98)
14	KK 02 97 70	Pin	38	KK 07 45 92	Ball D30	66	KK 03 27 45	Hex screw M16 x 45 mm (for ES and LS plough) (From 01.08.98)
15	KK 07 45 40	Cover	39	KK 07 40 47	Scraper		KK 03 27 50	Hex screw M16 x 50 mm (for LS plough) (From 01.08.98)
16	KK 01 16 66	Slidebearing		KK 07 46 24	Scraper (for wheel 26 x 12 - 12)			
17	KK 07 45 48	Bolt	40	KK 03 51 78	Hex screw M20 x 110 mm w/lock nut			
18	KK 07 45 93	Spring for bolt	41	KK 07 40 80	Axle for 200 x 14.5	68	KK 01 29 19	Washer (w/scrapper)
19	KK 07 45 01	Main bearinghouse	42	KK 01 11 68	Z - lamell	69	KK 03 35 16	Hex screw M10 x 16 mm w/nut (From 01.04.97.)
20	KK 02 99 20	Greasenipple M8 x 1	43	KK 01 05 17	Bearing			
21	KK 07 45 90	Pawl	44	KK 01 13 03	Tyre 200 x 14.5			
22	KK 07 45 89	Slidecover		KK 01 13 05	Inne tube 200 x 14.5	Not ill.	KK 07 46 37	Combi wheel cpl. 200 x 14.5 (H=700 mm)
23	KK 03 20 10	Umbrakoscrew M8 x 20 mm	45	KK 01 13 79	Rim w/bearing for 200 x 14.5		KK 07 46 39	Combi wheel cpl. 26 x 12-12 (H=700 mm)
24	KK 03 20 13	Umbrakoscrew M8 x 15 mm	46	KK 01 12 00	Ball bearing 6206		KK 07 46 66	Combi wheel cpl. 200 x 14.5 (H=800 mm)
25	KK 03 20 03	Umbrakoscrew M6 x 12 mm	47	KK 01 29 34	Washer 20.5 x 40 x 3.4 mm		KK 07 46 68	Combi wheel cpl. 26 x 12-12 (H=800 mm)
26	KK 07 45 21	Plate	48	KK 01 60 00	Lock nut		KK 07 46 14	Scraper for wheel 26 x 12-12 cpl.
27	KK 01 28 70	Discspring	49	KK 01 11 57	Cap		KK 07 48 40	Scraper for wheel 200 x 14.5 cpl.
28	KK 07 45 24	Spacing tube for discspring	50	KK 01 14 01	Cover cpl. 200 x 14.5			
29	KK 01 10 00	Roll pin 8 x 80 mm	51	KK 07 45 95	Bracket, rear			
			52	KK 07 46 51	Tube for rear mounted wheel (for EG plough)			



1	KK 07 48 56	Axle w/bearing cpl. (for depth/transport wheel)	28	KK 02 99 32	Grease nipple	50	KK 07 48 73	Axle
2	KK 07 48 75	Axle	29	KK 01 60 00	Lock nut M20 (Before 01.01.02)	51	KK 01 37 00	Spring
3	KK 07 48 93	Axle		KK 01 31 03	Lock nut KM6 M30 (Rebuilding kit EO/LO. Check dimension !)	52	KK 01 29 16	Washer
4	KK 01 10 48	Roll pin D12 x 60 mm		KK 01 31 09	Lock nut KM7 M35 (From 21.05.02)	53	KK 07 48 76	Lock
5	KK 01 07 00	Pin D12	30	KK 01 29 34	Lock washer (Before 21.05.02)	54	KK 06 40 86	Protection for damper block (From 01.05.00)
6	KK 07 48 64	Switch bracket		KK 01 31 04	Lock washer D42 x d30 x 3 (Rebuilding kit EO/LO. Check dimension !)	55	KK 06 40 79	Holder for damper block (From 01.05.00)
7	KK 07 48 65	Wheel arm (for depth/transport wheel)		KK 01 31 08	Lock washer D58 x d35 x 2,5 (From 21.05.02)	56	KK 01 30 04	Washer
8	KK 03 29 80	Hex screw M24 x 80 mm w/nut		KK 01 31 02	Washer MB6 (Rebuilding kit EO/LO. Check dimension !)	57	KK 01 29 56	Washer
9	KK 03 27 65	Hex screw M16 x 65 mm w/nut (From 01.04.01)	31	KK 01 31 10	Washer MB7 (From 21.05.02)	58	KK 07 48 41	Axle w/short bracket shaft cpl. (for depth wheel 200 x 14.5)
10	KK 07 48 44	Bracket for scraper (From 01.04.01)		KK 01 12 00	Bearing (Before 21.05.02)	59	KK 07 48 62	Axle w/bracket shaft cpl. (for depth wheel 26 x 12-12)
11	KK 07 48 38	Scraper (for wheel 200 x 14.5)	32	KK 01 05 91	Conical bearing (From 21.05.02)	60	KK 03 27 40	Hex screw M16 x 40 mm w/nut (From 01.05.00)
	KK 07 48 43	Scraper (for wheel 26 x 12-12) (Before 01.01.02)	33	KK 01 05 17	Bearing (Before 21.05.02)	61	KK 01 02 55	Bolt D16 x 51 mm
	KK 07 46 24	Scraper (for wheel 26 x 12-12) (From 01.01.02)	34	KK 01 12 15	Conical bearing (From 21.05.02)	62	KK 01 16 36	Bushing D20 x D16 x 10 mm
12	KK 03 26 40	Hex screw M12 x 40 mm w/nut	35	KK 01 11 68	Z - lamell	63	KK 07 48 50	Wheel bracket, rear mounted depth wheel
13	KK 01 60 38	Flange nut M12 (From 01.04.01)		KK 01 13 03	Tyre 200 x 14.5		KK 07 48 39	Wheel bracket, rear mounted depth wheel w/bearing
14	KK 03 28 07	Hex screw M20 x 100 mm w/nut		KK 01 13 05	Inner tube 200 x 14.5			
15	KK 01 60 12	Flange nut M20	36	KK 07 40 80	Axle 200 x 14.5 (Before 21.05.02)	64	KK 02 99 20	Grease nipple
16	KK 03 27 70	Hex screw M16 x 70 mm w/nut (for depth/transport wheel) (Before 01.04.01)	37	KK 08 41 10	Axle 200 x 14.5 (From 21.05.02)	65	KK 03 28 50	Hex screw M20 x 50 mm w/nut
	KK 03 27 75	Hex screw M16 x 75 mm w/nut (for depth wheel) (Before 01.04.01)	38	KK 07 40 93	Axle 26 x 12-12 (Before 27.05.02)	66	KK 03 23 90	Hex screw M6 x 90 mm
				KK 08 41 11	Axle 26 x 12-12 (From 27.05.02)	67	KK 01 29 55	Washer
				KK 01 13 46	Tyre 26 x 12-12 (Before 27.05.02)	68	KK 03 27 45	Hex screw M16 x 45 mm w/nut
				KK 01 31 00	Tyre 26 x 12-12 (From 27.05.02)	69	KK 01 10 52	Roll pin D12 x 80 mm
				KK 01 13 49	Inner tube 26 x 12-12	70	KK 07 48 67	Crank for shock absorber
17	KK 07 48 35	Clamp bracket (Before 01.04.01)	39	KK 01 14 02	Cover kit cpl.	71	KK 08 40 40	Rotation bolt (From 01.05.00)
18	KK 07 48 36	Bracket for scraper (Before 01.04.01)	40	KK 06 40 89	Spring (From 01.05.00)	72	KK 06 40 97	Crank screw cpl.
19	KK 10 68 63	Bushing (Before 01.04.01)	41	KK 03 26 65	Hex screw M12 x 60 mm (From 01.05.00)	73	KK 06 40 24	Stop screw
20	KK 01 29 19	Washer (Before 01.04.01)	42	KK 08 40 43	Crank (From 01.05.00)	74	KK 06 40 30	Clevis
21	KK 01 29 11	Washer 6,4 x 12,5 x 1,5 mm	43	KK 01 60 18	Lock nut M6	75	KK 01 13 79	Rim 200 x 14.5 (Before 21.05.02)
22	KK 03 28 90	Hex screw M20 x 90 mm w/nut	44	KK 01 29 31	Washer		KK 08 41 06	Rim 200 x 14.5 (From 21.05.02)
23	KK 07 48 66	Wheel arm (for depth wheel)	45	KK 35 36 30	Shock absorber	76	KK 01 14 19	Rim 26 x 12-12 (Before 27.05.02)
24	KK 03 29 80	Hex screw M24 x 80 mm w/nut	46	KK 01 10 35	Roll pin D6 x 30 mm		KK 08 41 07	Rim 26 x 12-12 (From 27.05.02)
25	KK 07 90 63	Washer	47	KK 07 48 70	Bracket arm for shock absorber		KK 07 48 86	Clamp w/fixing lug (200 mm tube)
26	KK 01 14 01	Cover kit cpl.	48	KK 35 60 42	Spring	77	KK 01 60 01	Lock nut M24
27	KK 01 11 57	Hub cap (Before 01.01.02)	49	KK 07 48 74	Handle			
	KK 01 31 05	Hub cap (From 21.05.02)						



Not ill.	KK 06 40 47	Stop cpl.
	KK 08 40 00	Depth wheel 200 x 14.5 rear mounted without shock absorber cpl.
	KK 08 40 01	Depth wheel 200 x 14.5 rear mounted w/shock absorber cpl.
	KK 08 40 02	Depth wheel 26 x 12-12 rear mounted w/shock absorber cpl.
	KK 08 40 03	Depth wheel 200 x 14.5 frame mounted without shock absorber cpl.
	KK 08 40 10	Depth/transport wheel 200 x 14.5 rear mounted without shock absorber cpl.
	KK 08 40 11	Depth/transport wheel 200 x 14.5 rear mounted w/shock absorber cpl.
	KK 08 40 12	Depth/transport wheel 26 x 12-12 rear mounted w/shock absorber cpl.
	KK 08 40 13	Depth/transport wheel 200 x 14.5 frame mounted without shock absorber cpl.
	KK 08 41 00	Wheel 200 x 14.5 cpl. w/axle (From 21.05.02)
	KK 08 41 01	Wheel 26 x 12-12 cpl. w/axle (From 27.05.02)



Замовлення запчастин
(050)-407-68-47
(050)-407-68-45



Замовлення запчастин

(050)-407-68-47

(050)-407-68-45



Замовлення запчастин

(050)-407-68-47

(050)-407-68-45



1	KK 03 27 16	Hex screw M16 x 140 mm w/nut (VD, VX, ED and LD plough)	24	KK 07 48 90	Clamp (150 mm tube)
	KK 03 27 19	Hex screw M16 x 190 mm w/nut (EM/LM plough)		KK 07 48 87	Clamp (200 mm tube)
	KK 03 27 27	Hex screw M16 x 160 mm w/nut (ED/LD-HD plough)	25	KK 07 48 89	Clamp w/fixing lug (150 mm tube)
				KK 07 48 86	Clamp w/fixing lug (200 mm tube)
2	KK 01 03 15	Bolt D25.3 x 60 mm	26	KK 07 48 81	Plate, over (for ES and LS plough)
3	KK 07 08 05	Adjustable stay			
4	KK 01 10 20	Roll pin D12 x 40 mm			
5	KK 07 48 80	Wheel bracket, frame mounted wheel			
6	KK 07 48 85	Plate, lower (ED and LD plough)			
	KK 07 49 71	Plate, lower (ED/LD-HD, 200 tube)			
7	KK 07 48 84	Plate, upper (ED and LD plough)			
	KK 07 49 70	Plate, upper (ED/LD-HD, 200 tube)			
8	KK 07 48 88	Plate (for VD and VX plough)			
9	KK 07 48 91	Plate (for EM/LM plough)			
10	KK 07 48 82	Plate, under (for ES and LS plough)			
11	KK 01 30 05	Washer			
12	KK 01 16 14	Bushing D30 x D16 x 28 mm			
13	KK 03 27 65	Hex screw M16 x 65 mm w/nut			
14	KK 01 16 15	Bushing D40 x D24 x 15.5 mm			
15	KK 03 29 25	Hex screw M24 x 250 mm w/nut			
16	KK 03 29 20	Hex screw M24 x 200 mm w/nut			
17	KK 03 28 22	Hex screw M20 x 190 mm w/nut			
18	KK 03 28 36	Hex screw M20 x 240 mm w/nut			
19	KK 08 40 42	Pin (From 01.05.00)			
20	KK 06 82 51	Washer			
21	KK 08 40 84	Stop screw (for ES/LS ploughs only) (From 01.04.01)			
22	KK 07 48 46	Transportation support (for ES/LS ploughs only) (From 01.04.01)			
23	KK 06 18 99	Contra nut M24 (for ES/LS ploughs only) (From 01.04.01)			








Замовлення запчастин
(050)-407-68-47
(050)-407-68-45

 **Kverneland**
EM/LM 85

 **Kverneland**
EM/LM 100

30



1	KK 70 99 68	Kverneland EM-85
	KK 70 99 70	Kverneland LM-85
2	KK 70 99 69	Kverneland EM-100
	KK 70 99 71	Kverneland LM-100
3	KK 70 97 37	Arrow
4	KK 70 94 79	Info., nuts
5	KK 70 98 33	Info., hoses
6	KK 70 97 81	Info., speed limit 30 km/h
7	KK 70 92 34	Info., leaf spring
8	KK 70 98 31	Kverneland w/arrow
9	KK 70 98 43	Safety sign, parking support
10	KK 70 98 95	Safety sign, sharp edges
11	KK 70 98 23	Safety sign, crush danger
12	KK 70 98 42	Safety sign, reversible plough
13	KK 70 98 44	Safety sign, read instruction manual
14	KK 70 98 41	Safety sign, danger, tractor/implement
Not ill.	KK 70 98 47	Patent label
	KK 70 99 80	Triangular reflexive foil
	KK 70 99 81	Rectangular reflexive foil



Замовлення запчастин
(050)-407-68-47
(050)-407-68-45

Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page
KK 01 00 08 35		KK 01 02 91 37		KK 01 05 66 37		KK 01 09 58 37		KK 01 11 57 77		KK 01 13 03 85		KK 01 15 96 51		KK 01 17 98 61	
KK 01 00 08 37		KK 01 02 93 39		KK 01 05 66 39		KK 01 09 58 39		KK 01 11 57 81		KK 01 13 03 87		KK 01 15 96 53		KK 01 17 99 61	
KK 01 00 08 51		KK 01 03 15 35		KK 01 05 71 35		KK 01 10 00 85		KK 01 11 57 85		KK 01 13 05 77		KK 01 15 96 55		KK 01 18 24 71	
KK 01 00 08 53		KK 01 03 15 37		KK 01 05 72 25		KK 01 10 01 39		KK 01 11 57 87		KK 01 13 05 81		KK 01 16 14 93		KK 01 18 66 25	
KK 01 00 31 77		KK 01 03 15 41		KK 01 05 72 27		KK 01 10 02 37		KK 01 11 67 75		KK 01 13 05 85		KK 01 16 15 93		KK 01 18 66 27	
KK 01 00 42 35		KK 01 03 15 93		KK 01 05 91 83		KK 01 10 09 37		KK 01 11 68 81		KK 01 13 05 87		KK 01 16 36 75		KK 01 18 76 71	
KK 01 00 42 37		KK 01 03 18 37		KK 01 05 91 87		KK 01 10 11 79		KK 01 11 68 85		KK 01 13 31 77		KK 01 16 36 77		KK 01 18 90 37	
KK 01 00 42 39		KK 01 03 18 53		KK 01 06 06 35		KK 01 10 16 35		KK 01 11 68 87		KK 01 13 46 77		KK 01 16 36 79		KK 01 18 90 39	
KK 01 00 42 43		KK 01 03 18 55		KK 01 06 06 37		KK 01 10 16 39		KK 01 12 00 75		KK 01 13 46 85		KK 01 16 36 81		KK 01 18 91 37	
KK 01 00 67 77		KK 01 03 19 35		KK 01 06 06 39		KK 01 10 16 85		KK 01 12 00 77		KK 01 13 46 87		KK 01 16 36 87		KK 01 18 91 39	
KK 01 00 96 75		KK 01 03 19 37		KK 01 06 06 41		KK 01 10 18 43		KK 01 12 00 81		KK 01 13 49 77		KK 01 16 52 81		KK 01 18 95 37	
KK 01 01 52 35		KK 01 03 19 51		KK 01 06 50 35		KK 01 10 18 47		KK 01 12 00 85		KK 01 13 49 85		KK 01 16 66 85		KK 01 18 96 35	
KK 01 01 52 39		KK 01 03 19 51		KK 01 06 50 37		KK 01 10 18 49		KK 01 12 00 87		KK 01 13 49 87		KK 01 17 29 61		KK 01 18 97 35	
KK 01 01 53 35		KK 01 03 19 53		KK 01 06 50 41		KK 01 10 20 35		KK 01 12 15 83		KK 01 13 78 75		KK 01 17 30 61		KK 01 18 98 35	
KK 01 01 53 39		KK 01 03 28 51		KK 01 06 50 47		KK 01 10 20 37		KK 01 12 15 87		KK 01 13 79 81		KK 01 17 31 61		KK 01 19 12 71	
KK 01 01 55 11		KK 01 03 28 53		KK 01 06 50 49		KK 01 10 20 37		KK 01 12 23 57		KK 01 13 79 85		KK 01 17 32 61		KK 01 19 18 71	
KK 01 01 55 17		KK 01 03 28 53		KK 01 06 55 37		KK 01 10 20 41		KK 01 12 23 69		KK 01 13 79 87		KK 01 17 33 61		KK 01 19 39 83	
KK 01 01 55 19		KK 01 03 28 55		KK 01 06 56 35		KK 01 10 20 43		KK 01 12 23 71		KK 01 14 00 75		KK 01 17 36 65		KK 01 19 51 71	
KK 01 01 55 7		KK 01 03 30 41		KK 01 07 00 31		KK 01 10 20 51		KK 01 12 31 75		KK 01 14 01 77		KK 01 17 36 69		KK 01 19 62 73	
KK 01 01 56 11		KK 01 03 32 35		KK 01 07 00 33		KK 01 10 20 53		KK 01 12 31 77		KK 01 14 01 81		KK 01 17 37 57		KK 01 20 56 51	
KK 01 01 56 17		KK 01 03 32 37		KK 01 07 00 35		KK 01 10 20 55		KK 01 12 52 37		KK 01 14 01 85		KK 01 17 37 65		KK 01 20 56 53	
KK 01 01 56 19		KK 01 03 32 41		KK 01 07 00 37		KK 01 10 20 79		KK 01 12 52 39		KK 01 14 01 87		KK 01 17 37 69		KK 01 20 56 55	
KK 01 01 56 7		KK 01 03 37 35		KK 01 07 00 39		KK 01 10 20 93		KK 01 12 59 25		KK 01 14 02 77		KK 01 17 38 65		KK 01 20 59 51	
KK 01 01 58 39		KK 01 03 37 39		KK 01 07 00 41		KK 01 10 21 37		KK 01 12 59 27		KK 01 14 02 87		KK 01 17 38 69		KK 01 20 59 53	
KK 01 02 55 75		KK 01 03 38 35		KK 01 07 00 47		KK 01 10 35 79		KK 01 12 61 57		KK 01 14 18 83		KK 01 17 43 65		KK 01 20 59 55	
KK 01 02 55 77		KK 01 03 38 39		KK 01 07 00 49		KK 01 10 35 83		KK 01 12 61 69		KK 01 14 19 77		KK 01 17 43 69		KK 01 20 59 55	
KK 01 02 55 79		KK 01 03 90 63		KK 01 07 00 51		KK 01 10 35 87		KK 01 12 61 71		KK 01 14 19 85		KK 01 17 44 59		KK 01 20 60 51	
KK 01 02 55 81		KK 01 04 61 75		KK 01 07 00 55		KK 01 10 37 21		KK 01 12 62 39		KK 01 14 19 87		KK 01 17 44 65		KK 01 20 60 55	
KK 01 02 55 87		KK 01 04 61 79		KK 01 07 00 81		KK 01 10 42 21		KK 01 12 62 41		KK 01 15 41 53		KK 01 17 44 69		KK 01 20 60 55	
KK 01 02 78 31		KK 01 04 61 81		KK 01 07 00 87		KK 01 10 42 77		KK 01 12 66 25		KK 01 15 65 51		KK 01 17 45 59		KK 01 20 60 55	
KK 01 02 78 33		KK 01 04 64 81		KK 01 07 49 81		KK 01 10 48 79		KK 01 12 66 27		KK 01 15 65 51		KK 01 17 45 65		KK 01 20 62 51	
KK 01 02 82 31		KK 01 05 09 59		KK 01 08 06 75		KK 01 10 48 87		KK 01 12 72 75		KK 01 15 65 55		KK 01 17 45 69		KK 01 20 62 53	
KK 01 02 82 33		KK 01 05 17 81		KK 01 08 06 77		KK 01 10 52 87		KK 01 12 72 79		KK 01 15 85 51		KK 01 17 46 65		KK 01 20 62 55	
KK 01 02 88 33		KK 01 05 17 85		KK 01 08 18 27		KK 01 10 61 75		KK 01 12 72 81		KK 01 15 85 51		KK 01 17 46 69		KK 01 20 70 51	
KK 01 02 88 35		KK 01 05 17 87		KK 01 09 09 43		KK 01 10 61 77		KK 01 12 76 59		KK 01 15 85 53		KK 01 17 50 25		KK 01 20 75 51	
KK 01 02 88 37		KK 01 05 32 25		KK 01 09 09 47		KK 01 10 61 79		KK 01 13 03 77		KK 01 15 85 55		KK 01 17 50 27		KK 01 20 76 51	
KK 01 02 91 33		KK 01 05 32 27		KK 01 09 09 49		KK 01 10 61 81		KK 01 13 03 81		KK 01 15 85 55		KK 01 17 69 73		KK 01 20 77 51	

Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page
KK 01 20 77	51	KK 01 26 70	53	KK 01 29 19	87	KK 01 29 94	85	KK 01 32 28	17	KK 01 37 00	87	KK 01 58 34	13	KK 01 60 31	25
KK 01 20 78	51	KK 01 27 01	51	KK 01 29 19	9	KK 01 30 01	13	KK 01 32 28	19	KK 01 58 13	15	KK 01 58 34	19	KK 01 60 37	77
KK 01 20 78	51	KK 01 27 01	55	KK 01 29 22	13	KK 01 30 04	87	KK 01 32 28	19	KK 01 58 13	15	KK 01 58 34	75	KK 01 60 38	87
KK 01 20 78	53	KK 01 27 02	51	KK 01 29 22	15	KK 01 30 05	93	KK 01 32 28	7	KK 01 58 16	29	KK 01 58 34	81	KK 01 60 45	23
KK 01 20 78	55	KK 01 27 02	55	KK 01 29 22	19	KK 01 30 10	39	KK 01 32 28	9	KK 01 58 17	15	KK 01 58 34	85	KK 01 60 49	23
KK 01 20 78	55	KK 01 27 04	51	KK 01 29 22	5	KK 01 30 62	39	KK 01 32 34	13	KK 01 58 17	15	KK 01 58 34	9	KK 01 65 08	59
KK 01 20 80	53	KK 01 27 04	55	KK 01 29 22	75	KK 01 30 64	39	KK 01 32 34	19	KK 01 58 17	15	KK 01 58 41	29	KK 01 65 09	59
KK 01 20 84	55	KK 01 27 10	51	KK 01 29 22	9	KK 01 30 66	71	KK 01 32 34	5	KK 01 58 17	15	KK 01 58 99	51	KK 01 65 11	59
KK 01 21 02	51	KK 01 27 23	55	KK 01 29 24	81	KK 01 30 67	73	KK 01 32 34	9	KK 01 58 17	15	KK 01 58 99	55	KK 01 65 12	59
KK 01 21 03	51	KK 01 27 25	51	KK 01 29 27	5	KK 01 30 68	73	KK 01 33 32	13	KK 01 58 17	17	KK 01 60 00	81	KK 01 65 16	59
KK 01 21 04	51	KK 01 27 26	35	KK 01 29 27	77	KK 01 30 69	73	KK 01 33 32	13	KK 01 58 17	25	KK 01 60 00	85	KK 01 65 17	59
KK 01 21 04	55	KK 01 27 26	37	KK 01 29 27	9	KK 01 30 70	73	KK 01 33 32	15	KK 01 58 17	51	KK 01 60 00	87	KK 01 65 17	63
KK 01 21 04	55	KK 01 27 28	55	KK 01 29 29	11	KK 01 30 86	63	KK 01 33 32	19	KK 01 58 17	55	KK 01 60 01	87	KK 01 65 22	57
KK 01 21 14	51	KK 01 27 32	51	KK 01 29 29	17	KK 01 30 87	67	KK 01 33 32	5	KK 01 58 17	75	KK 01 60 04	25	KK 01 65 23	57
KK 01 21 14	55	KK 01 27 40	51	KK 01 29 29	19	KK 01 30 89	63	KK 01 33 32	9	KK 01 58 25	15	KK 01 60 05	39	KK 01 65 24	57
KK 01 21 44	55	KK 01 27 40	53	KK 01 29 29	7	KK 01 30 91	63	KK 01 33 32	9	KK 01 58 25	15	KK 01 60 05	39	KK 01 65 25	57
KK 01 21 48	55	KK 01 27 40	55	KK 01 29 31	35	KK 01 30 92	67	KK 01 33 33	19	KK 01 58 25	15	KK 01 60 06	43	KK 01 65 26	57
KK 01 21 58	53	KK 01 27 52	55	KK 01 29 31	79	KK 01 30 93	67	KK 01 33 33	7	KK 01 58 25	17	KK 01 60 06	47	KK 01 65 27	57
KK 01 21 77	55	KK 01 27 59	51	KK 01 29 31	87	KK 01 30 94	67	KK 01 33 33	9	KK 01 58 25	17	KK 01 60 06	49	KK 01 65 69	59
KK 01 22 08	51	KK 01 27 76	55	KK 01 29 34	81	KK 01 30 95	67	KK 01 33 46	11	KK 01 58 25	17	KK 01 60 10	75	KK 02 97 15	79
KK 01 22 09	51	KK 01 27 85	53	KK 01 29 34	85	KK 01 30 96	67	KK 01 33 46	13	KK 01 58 25	29	KK 01 60 10	77	KK 02 97 27	21
KK 01 22 09	55	KK 01 27 86	51	KK 01 29 34	87	KK 01 31 00	87	KK 01 33 46	17	KK 01 58 25	45	KK 01 60 12	35	KK 02 97 27	21
KK 01 22 12	53	KK 01 27 88	51	KK 01 29 36	39	KK 01 31 02	83	KK 01 33 46	19	KK 01 58 25	47	KK 01 60 12	37	KK 02 97 70	37
KK 01 22 12	55	KK 01 27 88	55	KK 01 29 40	75	KK 01 31 02	87	KK 01 33 46	7	KK 01 58 25	49	KK 01 60 12	87	KK 02 97 70	85
KK 01 22 61	51	KK 01 28 70	85	KK 01 29 51	31	KK 01 31 03	83	KK 01 33 46	7	KK 01 58 25	75	KK 01 60 13	15	KK 02 99 18	57
KK 01 22 61	53	KK 01 29 06	29	KK 01 29 51	33	KK 01 31 03	87	KK 01 33 46	9	KK 01 58 25	79	KK 01 60 13	43	KK 02 99 18	71
KK 01 22 61	55	KK 01 29 11	87	KK 01 29 55	81	KK 01 31 04	83	KK 01 33 61	11	KK 01 58 30	13	KK 01 60 13	47	KK 02 99 20	21
KK 01 22 61	55	KK 01 29 13	21	KK 01 29 55	85	KK 01 31 04	87	KK 01 33 61	17	KK 01 58 30	25	KK 01 60 13	49	KK 02 99 20	25
KK 01 22 61	55	KK 01 29 16	87	KK 01 29 55	87	KK 01 31 05	83	KK 01 33 61	19	KK 01 58 30	25	KK 01 60 15	11	KK 02 99 20	27
KK 01 23 07	53	KK 01 29 19	13	KK 01 29 56	85	KK 01 31 05	87	KK 01 33 61	7	KK 01 58 30	41	KK 01 60 15	15	KK 02 99 20	35
KK 01 25 08	55	KK 01 29 19	19	KK 01 29 56	87	KK 01 31 06	83	KK 01 33 85	11	KK 01 58 30	43	KK 01 60 15	17	KK 02 99 20	37
KK 01 25 20	51	KK 01 29 19	5	KK 01 29 60	27	KK 01 31 08	87	KK 01 33 85	17	KK 01 58 30	47	KK 01 60 15	19	KK 02 99 20	37
KK 01 25 20	55	KK 01 29 19	75	KK 01 29 70	39	KK 01 31 09	87	KK 01 33 85	19	KK 01 58 30	49	KK 01 60 15	7	KK 02 99 20	39
KK 01 25 48	55	KK 01 29 19	77	KK 01 29 78	39	KK 01 31 10	87	KK 01 33 85	7	KK 01 58 30	75	KK 01 60 18	87	KK 02 99 20	39
KK 01 25 48	55	KK 01 29 19	79	KK 01 29 78	41	KK 01 32 28	11	KK 01 35 00	53	KK 01 58 30	79	KK 01 60 22	23	KK 02 99 20	41
KK 01 25 77	55	KK 01 29 19	81	KK 01 29 79	37	KK 01 32 28	13	KK 01 35 01	53	KK 01 58 32	5	KK 01 60 22	39	KK 02 99 20	59
KK 01 26 32	73	KK 01 29 19	85	KK 01 29 79	39	KK 01 32 28	15	KK 01 36 02	57	KK 01 58 32	77	KK 01 60 22	75	KK 02 99 20	69

Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page
KK 02 99 20 75		KK 03 24 40 39		KK 03 27 40 87		KK 03 27 65 81		KK 03 28 22 49		KK 03 28 55 21		KK 03 31 07 5		KK 03 33 06 67	
KK 02 99 20 77		KK 03 24 70 39		KK 03 27 45 43		KK 03 27 65 85		KK 03 28 22 93		KK 03 28 55 37		KK 03 31 07 9		KK 03 33 25 51	
KK 02 99 20 79		KK 03 24 70 39		KK 03 27 45 43		KK 03 27 65 85		KK 03 28 24 23		KK 03 28 60 21		KK 03 31 07 9		KK 03 33 25 55	
KK 02 99 20 81		KK 03 26 30 37		KK 03 27 45 47		KK 03 27 65 87		KK 03 28 24 31		KK 03 28 60 23		KK 03 31 08 13		KK 03 33 32 5	
KK 02 99 20 81		KK 03 26 40 37		KK 03 27 45 47		KK 03 27 65 93		KK 03 28 24 33		KK 03 28 60 23		KK 03 31 11 15		KK 03 34 16 39	
KK 02 99 20 85		KK 03 26 40 87		KK 03 27 45 49		KK 03 27 70 87		KK 03 28 24 85		KK 03 28 60 37		KK 03 31 16 15		KK 03 34 30 81	
KK 02 99 20 87		KK 03 26 50 85		KK 03 27 45 49		KK 03 27 75 11		KK 03 28 30 25		KK 03 28 60 41		KK 03 31 17 15		KK 03 35 12 53	
KK 02 99 22 39		KK 03 26 55 21		KK 03 27 45 79		KK 03 27 75 17		KK 03 28 30 39		KK 03 28 65 23		KK 03 31 18 19		KK 03 35 16 51	
KK 02 99 27 47		KK 03 26 55 85		KK 03 27 45 85		KK 03 27 75 19		KK 03 28 30 43		KK 03 28 65 35		KK 03 31 19 19		KK 03 35 16 55	
KK 02 99 27 49		KK 03 26 65 21		KK 03 27 45 87		KK 03 27 75 27		KK 03 28 30 47		KK 03 28 65 37		KK 03 31 73 13		KK 03 35 16 85	
KK 02 99 32 87		KK 03 26 65 87		KK 03 27 50 11		KK 03 27 75 55		KK 03 28 30 49		KK 03 28 70 35		KK 03 31 74 19		KK 03 35 25 51	
KK 03 09 60 37		KK 03 26 85 77		KK 03 27 50 15		KK 03 27 75 7		KK 03 28 36 93		KK 03 28 75 41		KK 03 31 75 13		KK 03 35 40 25	
KK 03 09 70 37		KK 03 26 95 77		KK 03 27 50 17		KK 03 27 75 79		KK 03 28 40 21		KK 03 28 75 85		KK 03 31 75 13		KK 03 36 25 35	
KK 03 10 30 27		KK 03 27 02 27		KK 03 27 50 19		KK 03 27 75 87		KK 03 28 40 23		KK 03 28 80 43		KK 03 31 75 15		KK 03 36 30 35	
KK 03 15 30 75		KK 03 27 02 85		KK 03 27 50 7		KK 03 27 80 81		KK 03 28 40 23		KK 03 28 85 47		KK 03 31 75 5		KK 03 36 30 39	
KK 03 20 01 59		KK 03 27 16 93		KK 03 27 50 75		KK 03 27 85 27		KK 03 28 40 25		KK 03 28 85 49		KK 03 31 75 9		KK 03 36 30 39	
KK 03 20 01 71		KK 03 27 19 93		KK 03 27 50 77		KK 03 27 85 35		KK 03 28 40 27		KK 03 28 90 43		KK 03 31 81 13		KK 03 36 30 79	
KK 03 20 02 57		KK 03 27 25 41		KK 03 27 50 81		KK 03 27 85 79		KK 03 28 40 35		KK 03 28 90 47		KK 03 31 85 13		KK 03 36 70 75	
KK 03 20 02 61		KK 03 27 25 5		KK 03 27 50 85		KK 03 27 90 55		KK 03 28 40 43		KK 03 28 90 49		KK 03 32 51 13		KK 03 36 70 77	
KK 03 20 03 85		KK 03 27 25 55		KK 03 27 50 85		KK 03 27 90 85		KK 03 28 45 23		KK 03 28 90 87		KK 03 32 51 15		KK 03 37 41 39	
KK 03 20 06 59		KK 03 27 25 9		KK 03 27 50 9		KK 03 27 92 45		KK 03 28 45 23		KK 03 28 95 43		KK 03 32 51 19		KK 03 42 25 29	
KK 03 20 06 65		KK 03 27 27 93		KK 03 27 52 43		KK 03 27 92 47		KK 03 28 45 35		KK 03 29 20 93		KK 03 32 51 5		KK 03 42 28 29	
KK 03 20 06 69		KK 03 27 30 13		KK 03 27 52 47		KK 03 27 92 49		KK 03 28 45 37		KK 03 29 25 93		KK 03 32 51 9		KK 03 42 50 29	
KK 03 20 07 57		KK 03 27 30 19		KK 03 27 52 49		KK 03 27 95 29		KK 03 28 45 43		KK 03 29 56 33		KK 03 32 56 15		KK 03 44 46 29	
KK 03 20 08 71		KK 03 27 35 19		KK 03 27 55 85		KK 03 27 95 85		KK 03 28 45 43		KK 03 29 80 87		KK 03 32 56 19		KK 03 50 10 51	
KK 03 20 10 85		KK 03 27 35 35		KK 03 27 60 35		KK 03 28 03 23		KK 03 28 45 47		KK 03 29 80 87		KK 03 32 56 5		KK 03 50 15 69	
KK 03 20 13 85		KK 03 27 35 39		KK 03 27 60 37		KK 03 28 07 23		KK 03 28 45 47		KK 03 30 04 19		KK 03 32 56 9		KK 03 50 20 21	
KK 03 20 16 61		KK 03 27 35 5		KK 03 27 60 45		KK 03 28 07 37		KK 03 28 45 49		KK 03 30 06 15		KK 03 32 86 13		KK 03 50 21 21	
KK 03 20 16 65		KK 03 27 35 81		KK 03 27 60 47		KK 03 28 07 39		KK 03 28 45 79		KK 03 30 06 29		KK 03 32 86 15		KK 03 50 25 43	
KK 03 20 50 39		KK 03 27 35 9		KK 03 27 60 49		KK 03 28 07 87		KK 03 28 50 23		KK 03 30 07 29		KK 03 32 86 19		KK 03 50 25 47	
KK 03 20 51 39		KK 03 27 40 11		KK 03 27 60 77		KK 03 28 11 31		KK 03 28 50 27		KK 03 30 16 15		KK 03 32 86 5		KK 03 50 25 49	
KK 03 21 06 73		KK 03 27 40 13		KK 03 27 60 81		KK 03 28 11 33		KK 03 28 50 35		KK 03 31 00 13		KK 03 32 86 9		KK 03 50 31 25	
KK 03 21 10 63		KK 03 27 40 17		KK 03 27 62 23		KK 03 28 20 47		KK 03 28 50 43		KK 03 31 00 19		KK 03 32 95 15		KK 03 50 40 85	
KK 03 21 10 67		KK 03 27 40 19		KK 03 27 65 11		KK 03 28 21 49		KK 03 28 50 47		KK 03 31 00 5		KK 03 32 95 19		KK 03 50 48 23	
KK 03 23 90 87		KK 03 27 40 7		KK 03 27 65 17		KK 03 28 22 43		KK 03 28 50 49		KK 03 31 00 9		KK 03 32 95 5		KK 03 50 60 23	
KK 03 24 40 37		KK 03 27 40 75		KK 03 27 65 19		KK 03 28 22 43		KK 03 28 50 75		KK 03 31 07 13		KK 03 32 95 9		KK 03 50 72 23	
KK 03 24 40 39		KK 03 27 40 77		KK 03 27 65 7		KK 03 28 22 47		KK 03 28 50 87		KK 03 31 07 15		KK 03 33 06 63		KK 03 51 65 21	

Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page
KK 03 51 78 81		KK 06 12 91 37		KK 06 33 88 19		KK 06 40 88 75		KK 06 68 12 29		KK 07 03 89 9		KK 07 12 73 23		KK 07 17 65 41	
KK 03 51 78 85		KK 06 15 15 23		KK 06 33 88 5		KK 06 40 89 75		KK 06 68 61 29		KK 07 03 90 5		KK 07 12 74 23		KK 07 17 94 31	
KK 03 52 09 21		KK 06 16 37 43		KK 06 33 88 9		KK 06 40 89 77		KK 06 68 68 29		KK 07 03 91 5		KK 07 12 75 23		KK 07 17 94 33	
KK 03 52 15 23		KK 06 16 37 47		KK 06 36 07 13		KK 06 40 89 87		KK 06 68 69 29		KK 07 03 92 9		KK 07 12 80 23		KK 07 18 80 41	
KK 03 52 16 23		KK 06 16 37 49		KK 06 36 07 7		KK 06 40 97 87		KK 06 68 73 29		KK 07 03 93 9		KK 07 12 81 23		KK 07 19 00 37	
KK 05 07 06 21		KK 06 18 99 93		KK 06 36 07 9		KK 06 42 22 77		KK 06 68 80 29		KK 07 03 94 5		KK 07 14 04 45		KK 07 19 04 37	
KK 05 30 90 11		KK 06 19 40 51		KK 06 38 01 5		KK 06 42 23 77		KK 06 68 81 29		KK 07 03 95 5		KK 07 14 04 47		KK 07 19 04 39	
KK 05 30 90 13		KK 06 19 41 51		KK 06 38 01 5		KK 06 43 17 41		KK 06 70 16 21		KK 07 03 96 9		KK 07 14 04 49		KK 07 19 10 37	
KK 05 30 90 15		KK 06 19 42 51		KK 06 40 24 75		KK 06 43 19 33		KK 06 70 25 21		KK 07 03 97 9		KK 07 14 80 41		KK 07 19 12 31	
KK 05 30 90 17		KK 06 19 43 51		KK 06 40 24 79		KK 06 43 19 37		KK 06 70 26 21		KK 07 03 98 9		KK 07 14 83 41		KK 07 19 13 31	
KK 05 30 90 19		KK 06 19 43 55		KK 06 40 24 87		KK 06 43 19 41		KK 06 70 31 21		KK 07 03 99 9		KK 07 14 96 41		KK 07 19 14 31	
KK 05 30 90 19		KK 06 19 45 55		KK 06 40 30 75		KK 06 43 20 33		KK 06 70 31 39		KK 07 04 58 41		KK 07 15 00 13		KK 07 19 17 35	
KK 05 30 90 5		KK 06 19 70 43		KK 06 40 30 77		KK 06 43 20 33		KK 06 70 39 21		KK 07 04 59 75		KK 07 15 08 23		KK 07 19 17 37	
KK 05 30 90 7		KK 06 19 70 43		KK 06 40 30 79		KK 06 43 20 37		KK 06 70 40 21		KK 07 04 91 83		KK 07 15 24 43		KK 07 19 18 35	
KK 05 30 90 9		KK 06 19 72 47		KK 06 40 30 81		KK 06 43 20 41		KK 06 70 49 85		KK 07 04 93 83		KK 07 15 24 47		KK 07 19 18 37	
KK 05 33 87 19		KK 06 19 72 49		KK 06 40 30 87		KK 06 43 21 33		KK 06 70 51 21		KK 07 04 94 75		KK 07 15 29 23		KK 07 19 24 37	
KK 05 33 87 5		KK 06 19 73 43		KK 06 40 36 77		KK 06 43 21 33		KK 06 70 57 21		KK 07 06 39 29		KK 07 15 69 43		KK 07 19 25 37	
KK 05 33 87 9		KK 06 19 74 43		KK 06 40 36 81		KK 06 43 21 37		KK 06 70 59 21		KK 07 06 40 5		KK 07 16 52 41		KK 07 19 26 35	
KK 05 68 73 29		KK 06 20 20 23		KK 06 40 39 77		KK 06 43 21 41		KK 06 70 60 21		KK 07 06 40 9		KK 07 16 97 55		KK 07 19 26 37	
KK 05 70 63 21		KK 06 20 25 19		KK 06 40 39 81		KK 06 43 23 33		KK 06 70 68 21		KK 07 06 41 5		KK 07 17 10 43		KK 07 19 30 37	
KK 05 70 64 21		KK 06 20 25 9		KK 06 40 47 75		KK 06 43 23 33		KK 06 70 70 21		KK 07 06 41 9		KK 07 17 10 47		KK 07 19 34 35	
KK 05 70 65 21		KK 06 21 53 41		KK 06 40 47 79		KK 06 43 23 37		KK 06 70 75 21		KK 07 06 42 5		KK 07 17 10 49		KK 07 19 35 35	
KK 05 70 66 21		KK 06 30 90 11		KK 06 40 47 89		KK 06 43 23 41		KK 06 70 76 21		KK 07 06 42 9		KK 07 17 11 43		KK 07 19 35 37	
KK 05 70 67 21		KK 06 30 90 13		KK 06 40 55 75		KK 06 43 43 31		KK 06 70 77 21		KK 07 06 53 29		KK 07 17 11 47		KK 07 19 38 37	
KK 05 70 68 21		KK 06 30 90 15		KK 06 40 73 77		KK 06 43 43 33		KK 06 70 80 21		KK 07 08 05 93		KK 07 17 11 49		KK 07 19 40 43	
KK 05 70 89 21		KK 06 30 90 17		KK 06 40 74 77		KK 06 43 60 33		KK 06 70 90 21		KK 07 12 07 23		KK 07 17 12 43		KK 07 19 40 47	
KK 06 01 08 21		KK 06 30 90 19		KK 06 40 75 75		KK 06 43 60 37		KK 06 70 92 21		KK 07 12 08 23		KK 07 17 12 47		KK 07 19 40 49	
KK 06 01 09 21		KK 06 30 90 19		KK 06 40 75 77		KK 06 43 60 41		KK 06 82 51 81		KK 07 12 09 23		KK 07 17 12 49		KK 07 21 77 55	
KK 06 01 19 21		KK 06 30 90 5		KK 06 40 78 75		KK 06 61 70 25		KK 06 82 51 93		KK 07 12 11 23		KK 07 17 13 43		KK 07 22 40 83	
KK 06 02 39 41		KK 06 30 90 7		KK 06 40 78 77		KK 06 61 75 25		KK 06 86 40 37		KK 07 12 12 23		KK 07 17 13 47		KK 07 22 50 35	
KK 06 02 52 41		KK 06 30 90 9		KK 06 40 79 87		KK 06 61 78 25		KK 07 01 63 37		KK 07 12 28 23		KK 07 17 13 49		KK 07 22 64 35	
KK 06 04 49 75		KK 06 30 91 13		KK 06 40 81 77		KK 06 61 78 27		KK 07 01 64 37		KK 07 12 55 43		KK 07 17 14 43		KK 07 22 65 35	
KK 06 04 69 75		KK 06 30 91 15		KK 06 40 86 75		KK 06 61 82 25		KK 07 01 65 37		KK 07 12 56 47		KK 07 17 14 47		KK 07 22 68 35	
KK 06 06 57 29		KK 06 30 91 5		KK 06 40 86 77		KK 06 61 89 25		KK 07 02 92 13		KK 07 12 56 49		KK 07 17 14 49		KK 07 22 68 37	
KK 06 07 03 21		KK 06 30 92 13		KK 06 40 86 87		KK 06 61 90 25		KK 07 02 93 13		KK 07 12 70 23		KK 07 17 29 75		KK 07 22 69 35	
KK 06 12 80 21		KK 06 30 92 15		KK 06 40 87 75		KK 06 68 11 29		KK 07 02 94 13		KK 07 12 71 23		KK 07 17 29 79		KK 07 22 70 35	
KK 06 12 91 21		KK 06 30 92 5		KK 06 40 87 77		KK 06 68 11 29		KK 07 03 88 9		KK 07 12 72 23		KK 07 17 40 75		KK 07 22 71 35	

Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page
KK 07 22 72	35	KK 07 26 17	43	KK 07 30 31	5	KK 07 30 64	19	KK 07 32 28	9	KK 07 32 80	5	KK 07 34 14	5	KK 07 36 15	5
KK 07 22 74	35	KK 07 26 17	47	KK 07 30 40	5	KK 07 30 64	9	KK 07 32 30	15	KK 07 32 81	5	KK 07 34 15	5	KK 07 36 15	9
KK 07 22 75	35	KK 07 26 17	49	KK 07 30 41	5	KK 07 30 65	13	KK 07 32 30	9	KK 07 32 86	5	KK 07 34 17	9	KK 07 36 16	15
KK 07 22 79	35	KK 07 26 21	43	KK 07 30 42	15	KK 07 30 65	15	KK 07 32 31	15	KK 07 32 87	5	KK 07 34 18	9	KK 07 36 16	19
KK 07 22 80	31	KK 07 26 27	37	KK 07 30 42	5	KK 07 30 65	19	KK 07 32 31	9	KK 07 32 90	5	KK 07 34 35	9	KK 07 36 16	5
KK 07 22 81	31	KK 07 26 32	37	KK 07 30 43	15	KK 07 30 65	9	KK 07 32 36	9	KK 07 32 90	9	KK 07 34 36	9	KK 07 36 16	9
KK 07 22 83	35	KK 07 26 34	33	KK 07 30 43	5	KK 07 30 80	13	KK 07 32 37	9	KK 07 32 91	5	KK 07 34 40	9	KK 07 36 34	11
KK 07 22 91	35	KK 07 26 34	37	KK 07 30 44	15	KK 07 30 80	15	KK 07 32 39	9	KK 07 32 91	9	KK 07 34 41	9	KK 07 36 34	17
KK 07 22 92	35	KK 07 26 36	41	KK 07 30 44	5	KK 07 30 80	19	KK 07 32 40	9	KK 07 33 00	13	KK 07 34 64	13	KK 07 36 34	19
KK 07 22 92	37	KK 07 27 17	79	KK 07 30 45	15	KK 07 30 80	9	KK 07 32 41	9	KK 07 33 00	15	KK 07 34 64	19	KK 07 36 34	7
KK 07 22 93	35	KK 07 27 18	79	KK 07 30 45	5	KK 07 30 81	13	KK 07 32 42	9	KK 07 33 00	5	KK 07 34 65	13	KK 07 36 35	11
KK 07 22 93	37	KK 07 28 01	79	KK 07 30 54	13	KK 07 30 81	15	KK 07 32 45	13	KK 07 33 00	9	KK 07 34 65	19	KK 07 36 35	17
KK 07 22 95	35	KK 07 28 06	79	KK 07 30 54	15	KK 07 30 81	19	KK 07 32 46	13	KK 07 33 01	13	KK 07 34 70	13	KK 07 36 35	19
KK 07 22 97	35	KK 07 28 09	79	KK 07 30 54	19	KK 07 30 81	9	KK 07 32 50	5	KK 07 33 01	15	KK 07 34 70	19	KK 07 36 35	7
KK 07 22 99	35	KK 07 28 11	41	KK 07 30 54	9	KK 07 30 88	13	KK 07 32 51	5	KK 07 33 01	5	KK 07 34 71	13	KK 07 38 00	19
KK 07 24 21	37	KK 07 28 12	41	KK 07 30 55	13	KK 07 30 88	15	KK 07 32 56	15	KK 07 33 01	9	KK 07 34 71	19	KK 07 38 00	5
KK 07 24 54	79	KK 07 28 13	41	KK 07 30 55	15	KK 07 30 88	19	KK 07 32 56	5	KK 07 33 03	13	KK 07 36 07	13	KK 07 38 00	9
KK 07 24 55	79	KK 07 30 00	5	KK 07 30 55	19	KK 07 30 88	5	KK 07 32 57	15	KK 07 33 04	13	KK 07 36 07	7	KK 07 38 01	19
KK 07 24 58	79	KK 07 30 01	5	KK 07 30 55	9	KK 07 30 88	9	KK 07 32 57	5	KK 07 33 10	5	KK 07 36 07	9	KK 07 38 01	5
KK 07 24 68	79	KK 07 30 02	15	KK 07 30 56	13	KK 07 30 89	13	KK 07 32 60	5	KK 07 33 10	9	KK 07 36 08	13	KK 07 38 01	9
KK 07 24 69	79	KK 07 30 02	5	KK 07 30 56	15	KK 07 30 89	15	KK 07 32 61	5	KK 07 33 11	5	KK 07 36 08	15	KK 07 38 03	13
KK 07 25 08	37	KK 07 30 03	15	KK 07 30 56	19	KK 07 30 89	19	KK 07 32 63	5	KK 07 33 11	9	KK 07 36 08	19	KK 07 38 03	5
KK 07 25 19	35	KK 07 30 03	5	KK 07 30 56	9	KK 07 30 89	5	KK 07 32 64	5	KK 07 33 28	19	KK 07 36 08	5	KK 07 38 03	5
KK 07 25 21	35	KK 07 30 04	15	KK 07 30 57	13	KK 07 30 89	9	KK 07 32 66	5	KK 07 33 29	19	KK 07 36 08	9	KK 07 38 04	9
KK 07 25 26	37	KK 07 30 04	5	KK 07 30 57	15	KK 07 30 91	13	KK 07 32 66	9	KK 07 33 32	13	KK 07 36 09	13	KK 07 38 04	9
KK 07 25 27	37	KK 07 30 05	15	KK 07 30 57	19	KK 07 30 91	15	KK 07 32 67	5	KK 07 33 33	13	KK 07 36 09	15	KK 07 38 05	13
KK 07 25 28	41	KK 07 30 05	5	KK 07 30 57	9	KK 07 30 91	19	KK 07 32 67	9	KK 07 33 38	19	KK 07 36 09	19	KK 07 38 05	9
KK 07 25 34	35	KK 07 30 06	15	KK 07 30 62	13	KK 07 30 91	5	KK 07 32 72	13	KK 07 33 39	19	KK 07 36 09	5	KK 07 38 07	5
KK 07 25 35	35	KK 07 30 06	5	KK 07 30 62	15	KK 07 30 91	9	KK 07 32 72	19	KK 07 33 50	19	KK 07 36 09	9	KK 07 38 08	5
KK 07 25 36	37	KK 07 30 07	15	KK 07 30 62	19	KK 07 30 92	13	KK 07 32 73	13	KK 07 33 51	19	KK 07 36 14	13	KK 07 38 10	13
KK 07 25 37	37	KK 07 30 07	5	KK 07 30 62	9	KK 07 30 92	15	KK 07 32 73	19	KK 07 33 52	19	KK 07 36 14	15	KK 07 38 11	13
KK 07 25 39	37	KK 07 30 08	5	KK 07 30 63	13	KK 07 30 92	19	KK 07 32 75	13	KK 07 33 53	19	KK 07 36 14	19	KK 07 38 12	13
KK 07 25 88	79	KK 07 30 09	5	KK 07 30 63	15	KK 07 30 92	5	KK 07 32 75	19	KK 07 33 54	19	KK 07 36 14	7	KK 07 38 13	13
KK 07 25 89	79	KK 07 30 16	13	KK 07 30 63	19	KK 07 30 92	9	KK 07 32 76	13	KK 07 34 06	5	KK 07 36 14	9	KK 07 38 15	13
KK 07 26 06	43	KK 07 30 30	15	KK 07 30 63	9	KK 07 32 24	9	KK 07 32 76	19	KK 07 34 07	5	KK 07 36 15	13	KK 07 38 16	13
KK 07 26 06	43	KK 07 30 30	5	KK 07 30 64	13	KK 07 32 25	9	KK 07 32 78	19	KK 07 34 11	5	KK 07 36 15	15	KK 07 38 17	13
KK 07 26 07	43	KK 07 30 31	15	KK 07 30 64	15	KK 07 32 27	9	KK 07 32 79	19	KK 07 34 12	5	KK 07 36 15	19	KK 07 38 20	13

Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page
KK 07 38 21	13	KK 07 40 80	85	KK 07 45 18	85	KK 07 46 52	85	KK 07 48 18	77	KK 07 48 93	87	KK 07 64 99	27	KK 08 12 95	47
KK 07 38 22	13	KK 07 40 80	87	KK 07 45 21	85	KK 07 46 55	85	KK 07 48 19	77	KK 07 49 10	23	KK 07 65 15	27	KK 08 12 96	43
KK 07 38 26	19	KK 07 40 93	85	KK 07 45 24	85	KK 07 46 66	85	KK 07 48 20	77	KK 07 49 11	23	KK 07 65 27	27	KK 08 13 10	43
KK 07 38 26	9	KK 07 40 93	87	KK 07 45 27	85	KK 07 46 68	85	KK 07 48 35	87	KK 07 49 14	35	KK 07 65 75	27	KK 08 13 10	47
KK 07 38 26	9	KK 07 41 73	37	KK 07 45 33	85	KK 07 46 77	85	KK 07 48 36	87	KK 07 49 14	37	KK 07 68 12	29	KK 08 13 11	43
KK 07 38 29	19	KK 07 41 74	35	KK 07 45 35	85	KK 07 46 78	85	KK 07 48 38	87	KK 07 49 30	27	KK 07 68 13	29	KK 08 13 11	47
KK 07 38 29	9	KK 07 41 83	35	KK 07 45 40	85	KK 07 46 90	81	KK 07 48 39	87	KK 07 49 31	27	KK 07 68 17	29	KK 08 13 12	43
KK 07 38 30	5	KK 07 41 84	37	KK 07 45 48	85	KK 07 46 93	81	KK 07 48 40	83	KK 07 49 36	27	KK 07 68 18	29	KK 08 13 12	47
KK 07 38 31	5	KK 07 43 19	35	KK 07 45 49	85	KK 07 46 95	79	KK 07 48 40	85	KK 07 49 37	27	KK 07 68 25	29	KK 08 13 13	43
KK 07 38 31	9	KK 07 43 19	39	KK 07 45 70	37	KK 07 46 96	79	KK 07 48 41	87	KK 07 49 38	27	KK 07 68 26	29	KK 08 13 13	47
KK 07 38 34	13	KK 07 43 19	45	KK 07 45 71	37	KK 07 47 53	83	KK 07 48 43	87	KK 07 49 39	27	KK 07 68 33	29	KK 08 13 14	43
KK 07 38 35	13	KK 07 43 19	47	KK 07 45 76	37	KK 07 47 70	79	KK 07 48 44	87	KK 07 49 61	81	KK 07 68 34	29	KK 08 13 14	47
KK 07 38 36	13	KK 07 43 19	49	KK 07 45 80	37	KK 07 47 72	81	KK 07 48 46	93	KK 07 49 64	81	KK 07 68 58	29	KK 08 13 15	43
KK 07 38 42	9	KK 07 43 32	31	KK 07 45 86	85	KK 07 47 74	75	KK 07 48 50	87	KK 07 49 70	93	KK 07 68 58	29	KK 08 13 15	47
KK 07 39 91	81	KK 07 43 32	33	KK 07 45 87	85	KK 07 47 80	81	KK 07 48 56	87	KK 07 49 71	93	KK 07 68 59	29	KK 08 13 16	43
KK 07 40 36	81	KK 07 43 40	41	KK 07 45 88	85	KK 07 47 82	81	KK 07 48 62	87	KK 07 58 47	81	KK 07 68 72	29	KK 08 13 16	47
KK 07 40 37	81	KK 07 43 41	41	KK 07 45 89	85	KK 07 47 84	81	KK 07 48 64	87	KK 07 58 49	81	KK 07 69 43	29	KK 08 13 17	43
KK 07 40 41	83	KK 07 43 42	41	KK 07 45 90	85	KK 07 47 85	81	KK 07 48 65	87	KK 07 58 60	37	KK 07 69 44	29	KK 08 13 17	47
KK 07 40 42	81	KK 07 43 54	33	KK 07 45 92	85	KK 07 47 86	81	KK 07 48 66	87	KK 07 58 61	37	KK 07 70 23	23	KK 08 13 18	43
KK 07 40 43	81	KK 07 43 54	37	KK 07 45 93	85	KK 07 47 87	81	KK 07 48 67	87	KK 07 58 89	43	KK 07 70 24	23	KK 08 13 18	47
KK 07 40 47	77	KK 07 43 77	31	KK 07 45 94	85	KK 07 47 90	75	KK 07 48 70	87	KK 07 58 89	47	KK 07 86 08	81	KK 08 13 18	49
KK 07 40 47	81	KK 07 43 77	33	KK 07 45 95	85	KK 07 47 91	75	KK 07 48 73	87	KK 07 58 89	47	KK 07 90 63	87	KK 08 13 19	43
KK 07 40 47	85	KK 07 43 78	31	KK 07 46 13	85	KK 07 47 92	79	KK 07 48 74	87	KK 07 58 89	49	KK 08 01 87	45	KK 08 13 19	47
KK 07 40 48	77	KK 07 43 78	33	KK 07 46 14	85	KK 07 47 93	79	KK 07 48 75	87	KK 07 58 97	85	KK 08 01 87	47	KK 08 13 19	49
KK 07 40 49	77	KK 07 43 79	31	KK 07 46 17	77	KK 07 47 94	75	KK 07 48 76	87	KK 07 59 08	85	KK 08 01 87	49	KK 08 13 20	43
KK 07 40 52	75	KK 07 43 79	33	KK 07 46 23	79	KK 07 47 95	75	KK 07 48 80	93	KK 07 59 15	37	KK 08 12 14	43	KK 08 13 20	47
KK 07 40 52	79	KK 07 43 95	33	KK 07 46 24	77	KK 07 47 96	83	KK 07 48 81	93	KK 07 60 76	27	KK 08 12 14	47	KK 08 13 25	43
KK 07 40 53	75	KK 07 43 95	33	KK 07 46 24	81	KK 07 47 97	83	KK 07 48 82	93	KK 07 64 00	27	KK 08 12 14	49	KK 08 13 25	47
KK 07 40 54	75	KK 07 43 95	37	KK 07 46 24	85	KK 07 47 99	75	KK 07 48 84	93	KK 07 64 06	25	KK 08 12 90	43	KK 08 13 30	43
KK 07 40 54	79	KK 07 43 96	33	KK 07 46 24	87	KK 07 47 99	77	KK 07 48 85	93	KK 07 64 06	27	KK 08 12 90	47	KK 08 13 30	47
KK 07 40 55	75	KK 07 43 96	33	KK 07 46 37	85	KK 07 47 99	79	KK 07 48 86	87	KK 07 64 07	25	KK 08 12 91	43	KK 08 13 35	43
KK 07 40 60	81	KK 07 43 96	37	KK 07 46 39	85	KK 07 47 99	83	KK 07 48 86	93	KK 07 64 07	27	KK 08 12 92	43	KK 08 13 35	47
KK 07 40 65	81	KK 07 43 97	33	KK 07 46 40	85	KK 07 48 01	77	KK 07 48 87	93	KK 07 64 09	25	KK 08 12 92	47	KK 08 13 40	43
KK 07 40 70	81	KK 07 43 97	37	KK 07 46 44	85	KK 07 48 02	77	KK 07 48 88	93	KK 07 64 09	27	KK 08 12 93	43	KK 08 13 40	47
KK 07 40 78	81	KK 07 45 01	85	KK 07 46 45	85	KK 07 48 06	77	KK 07 48 89	93	KK 07 64 10	25	KK 08 12 93	47	KK 08 13 40	49
KK 07 40 79	81	KK 07 45 07	85	KK 07 46 48	85	KK 07 48 10	77	KK 07 48 90	93	KK 07 64 10	27	KK 08 12 93	49	KK 08 13 41	43
KK 07 40 80	81	KK 07 45 08	85	KK 07 46 51	85	KK 07 48 17	77	KK 07 48 91	93	KK 07 64 99	25	KK 08 12 95	43	KK 08 13 41	47

Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page
KK 08 13 42 43		KK 08 14 73 39		KK 08 15 74 39		KK 08 24 83 49		KK 08 38 03 15		KK 08 60 82 25		KK 35 11 48 39		KK 35 36 79 71	
KK 08 13 58 43		KK 08 14 78 39		KK 08 15 75 47		KK 08 24 84 49		KK 08 38 04 15		KK 08 60 83 25		KK 35 11 48 41		KK 35 36 80 51	
KK 08 13 58 47		KK 08 14 79 39		KK 08 15 75 49		KK 08 24 85 49		KK 08 38 05 15		KK 08 60 84 25		KK 35 11 70 35		KK 35 36 81 51	
KK 08 13 59 43		KK 08 15 17 39		KK 08 15 80 33		KK 08 24 86 49		KK 08 38 06 15		KK 08 60 85 25		KK 35 11 72 35		KK 35 36 81 53	
KK 08 13 59 47		KK 08 15 18 47		KK 08 15 81 33		KK 08 24 87 49		KK 08 38 07 15		KK 08 60 86 27		KK 35 11 73 35		KK 35 36 81 73	
KK 08 13 59 49		KK 08 15 18 49		KK 08 15 82 39		KK 08 24 96 49		KK 08 38 08 15		KK 08 60 87 27		KK 35 21 45 81		KK 35 36 82 73	
KK 08 13 60 43		KK 08 15 20 39		KK 08 15 83 33		KK 08 24 97 49		KK 08 38 09 5		KK 08 60 89 25		KK 35 21 53 69		KK 35 36 83 73	
KK 08 13 60 47		KK 08 15 27 39		KK 08 15 87 35		KK 08 24 98 49		KK 08 38 10 5		KK 08 60 89 27		KK 35 23 50 51		KK 35 36 84 73	
KK 08 13 67 49		KK 08 15 29 39		KK 08 15 87 39		KK 08 32 10 15		KK 08 40 00 89		KK 08 60 90 25		KK 35 23 72 55		KK 35 36 85 73	
KK 08 13 68 43		KK 08 15 30 39		KK 08 15 88 35		KK 08 32 11 15		KK 08 40 01 89		KK 08 60 90 27		KK 35 24 01 55		KK 35 37 01 51	
KK 08 13 68 47		KK 08 15 31 39		KK 08 15 88 39		KK 08 32 12 15		KK 08 40 02 89		KK 08 61 01 25		KK 35 24 02 51		KK 35 37 01 61	
KK 08 13 68 49		KK 08 15 32 39		KK 08 15 90 35		KK 08 32 13 15		KK 08 40 03 89		KK 08 61 01 27		KK 35 27 50 51		KK 35 37 02 61	
KK 08 13 69 45		KK 08 15 33 39		KK 08 15 90 39		KK 08 32 14 15		KK 08 40 10 89		KK 08 61 10 25		KK 35 35 40 77		KK 35 37 03 61	
KK 08 13 69 47		KK 08 15 34 33		KK 08 15 92 49		KK 08 32 15 15		KK 08 40 11 89		KK 08 61 11 25		KK 35 35 41 79		KK 35 37 04 55	
KK 08 13 69 49		KK 08 15 35 33		KK 08 16 20 43		KK 08 32 16 15		KK 08 40 12 89		KK 08 61 12 25		KK 35 35 77 79		KK 35 37 04 65	
KK 08 13 70 43		KK 08 15 36 39		KK 08 16 21 43		KK 08 32 17 15		KK 08 40 13 89		KK 08 61 13 25		KK 35 35 77 81		KK 35 37 05 65	
KK 08 13 70 47		KK 08 15 37 33		KK 08 16 22 45		KK 08 32 18 15		KK 08 40 40 87		KK 08 61 14 25		KK 35 35 80 51		KK 35 37 06 65	
KK 08 13 76 43		KK 08 15 39 39		KK 08 16 22 47		KK 08 32 20 15		KK 08 40 42 93		KK 08 61 15 25		KK 35 35 80 57		KK 35 37 07 65	
KK 08 13 76 47		KK 08 15 40 39		KK 08 16 22 49		KK 08 32 21 15		KK 08 40 43 87		KK 08 68 01 29		KK 35 35 92 57		KK 35 37 08 55	
KK 08 13 76 49		KK 08 15 43 39		KK 08 16 24 43		KK 08 32 22 15		KK 08 40 84 93		KK 09 42 06 75		KK 35 35 93 57		KK 35 37 08 69	
KK 08 13 77 43		KK 08 15 45 35		KK 08 16 24 47		KK 08 32 23 15		KK 08 41 00 83		KK 09 42 07 75		KK 35 35 94 57		KK 35 37 20 61	
KK 08 13 77 47		KK 08 15 45 39		KK 08 16 24 49		KK 08 32 24 15		KK 08 41 00 89		KK 10 68 63 87		KK 35 35 95 57		KK 35 37 21 61	
KK 08 13 77 49		KK 08 15 47 39		KK 08 17 83 43		KK 08 32 28 5		KK 08 41 01 83		KK 12 60 95 35		KK 35 35 96 57		KK 35 37 22 61	
KK 08 13 78 83		KK 08 15 50 33		KK 08 17 83 47		KK 08 32 29 5		KK 08 41 01 89		KK 12 60 95 37		KK 35 35 97 57		KK 35 37 25 61	
KK 08 13 78 83		KK 08 15 52 33		KK 08 17 83 49		KK 08 32 35 15		KK 08 41 06 81		KK 12 60 95 37		KK 35 36 09 53		KK 35 37 26 65	
KK 08 13 90 43		KK 08 15 54 33		KK 08 17 88 43		KK 08 32 35 7		KK 08 41 06 87		KK 12 60 95 39		KK 35 36 30 87		KK 35 37 26 69	
KK 08 13 90 47		KK 08 15 55 39		KK 08 17 88 47		KK 08 33 00 15		KK 08 41 07 87		KK 12 60 95 43		KK 35 36 32 51		KK 35 37 27 65	
KK 08 13 91 43		KK 08 15 56 39		KK 08 17 88 49		KK 08 33 01 15		KK 08 41 10 81		KK 12 60 95 51		KK 35 36 64 53		KK 35 37 27 69	
KK 08 13 92 43		KK 08 15 57 39		KK 08 24 65 49		KK 08 34 06 15		KK 08 41 10 87		KK 35 11 39 37		KK 35 36 64 71		KK 35 37 28 65	
KK 08 13 95 43		KK 08 15 60 33		KK 08 24 66 49		KK 08 34 07 15		KK 08 41 11 87		KK 35 11 39 41		KK 35 36 65 71		KK 35 37 29 65	
KK 08 13 96 43		KK 08 15 62 33		KK 08 24 67 49		KK 08 34 08 15		KK 08 45 36 49		KK 35 11 40 37		KK 35 36 71 71		KK 35 37 29 69	
KK 08 13 97 43		KK 08 15 65 39		KK 08 24 70 49		KK 08 34 09 15		KK 08 45 37 49		KK 35 11 40 41		KK 35 36 72 71		KK 35 37 30 61	
KK 08 14 50 39		KK 08 15 67 39		KK 08 24 71 49		KK 08 34 15 15		KK 08 45 38 47		KK 35 11 44 37		KK 35 36 73 71		KK 35 37 31 61	
KK 08 14 57 39		KK 08 15 69 39		KK 08 24 72 49		KK 08 34 16 15		KK 08 45 38 49		KK 35 11 44 41		KK 35 36 75 71		KK 35 37 32 65	
KK 08 14 58 39		KK 08 15 70 39		KK 08 24 80 49		KK 08 34 17 15		KK 08 50 76 29		KK 35 11 48 35		KK 35 36 76 73		KK 35 37 35 65	
KK 08 14 70 39		KK 08 15 71 39		KK 08 24 81 49		KK 08 34 18 15		KK 08 60 80 25		KK 35 11 48 35		KK 35 36 77 57		KK 35 37 36 65	
KK 08 14 71 39		KK 08 15 72 39		KK 08 24 82 49		KK 08 38 02 15		KK 08 60 81 25		KK 35 11 48 37		KK 35 36 78 71		KK 35 37 37 69	

Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page
KK 35 37 40 61		KK 35 37 64 59		KK 35 39 01 51		KK 35 39 22 63		KK 35 39 40 67		KK 36 11 16 37		KK 70 98 42 95		KK 70 99 81 95	
KK 35 37 41 61		KK 35 37 65 59		KK 35 39 01 63		KK 35 39 23 67		KK 35 39 41 67		KK 36 11 16 41		KK 70 98 43 95		UH 82 56 40 63	
KK 35 37 42 61		KK 35 37 66 59		KK 35 39 02 63		KK 35 39 26 63		KK 35 39 44 63		KK 70 92 34 95		KK 70 98 44 95		UH 82 56 40 67	
KK 35 37 43 65		KK 35 37 67 59		KK 35 39 03 63		KK 35 39 27 67		KK 35 39 45 67		KK 70 94 79 95		KK 70 98 47 95			
KK 35 37 44 65		KK 35 37 68 59		KK 35 39 04 55		KK 35 39 34 63		KK 35 39 46 63		KK 70 97 37 95		KK 70 98 95 95			
KK 35 37 45 65		KK 35 37 92 61		KK 35 39 04 67		KK 35 39 35 63		KK 35 39 46 67		KK 70 97 81 95		KK 70 99 68 95			
KK 35 37 46 65		KK 35 37 93 65		KK 35 39 05 67		KK 35 39 36 63		KK 35 60 42 37		KK 70 98 23 95		KK 70 99 69 95			
KK 35 37 47 69		KK 35 37 93 69		KK 35 39 06 67		KK 35 39 37 63		KK 35 60 42 39		KK 70 98 31 95		KK 70 99 70 95			
KK 35 37 62 59		KK 35 38 02 51		KK 35 39 20 79		KK 35 39 38 67		KK 35 60 42 87		KK 70 98 33 95		KK 70 99 71 95			
KK 35 37 63 59		KK 35 38 02 59		KK 35 39 20 81		KK 35 39 39 67		KK 36 11 16 35		KK 70 98 41 95		KK 70 99 80 95			



Замовлення запчастин
(050)-407-68-47
(050)-407-68-45