

Spare Parts List

Model EO/LO


Mounted Reversible Plough

No 733037



Notes

GB Model	GB Interbody clearance	GB Headstock
D Modell	D Körperlängsabstand	D Drehwerk
F Modèle	F Dégagement sous age	F Type de tête
E Modelo	E Separación entre cuerpos	E Tipo de cabezal



GB Serial number	Type: HD=Heavy Duty SL=Vibromat OL=On-land	GB Body no.
D Seriennummer		D Körper no.
F Numéro de série		F Type no.
E Numero de serie		E Tipo no.

Замовлення запчастин

- (GB)** Complete model code and serial number must be stated to avoid mistakes when ordering spare parts and misunderstandings regarding service consultations. The identification plate is located on the headstock.
- (F)** Le code complet et le numéro de série doivent être indiqués pour éviter des erreurs lors de la commande de pièces de rechange et des malentendus concernant des demandes de Service-Après-Vente. La plaque d'identité est située sur la tête.
- (D)** Um bei Ersatzteilbestellungen und Serviceleistungen Fehler und Mißverständnisse zu vermeiden ist es erforderlich, daß die genaue Bezeichnung und die Seriennummer angegeben werden. Die Plakette befindet sich am Drehwerk.
- (E)** Debe figura el código completo del modelo y el número de serie para evitar errores al pedir las piezas de recambio y al hacer consultas técnicas. La placa de identificación esta situada en el cabezal.

Plate		Page
244	Bodies no 6, 7, 8, 9 and 28	4
367	Bodies no 12, 15 and 19	8
494	Body no 14 (Plastic mouldboard)	12
1089	Bodies no. 29 and no. 30.....	14
458	Auto Reset Beam.....	18
1009	Beam (Shear bolt)	20
1073	Disc coultter 18” and 20”, E-saddle (From 01.01.99)	22
1044	Disc coultter LD, LO, SL, RB, RS, RT (rear frame) and RX	24
	(RS, RX from 15.09.99, RB from 01.05.01)	24
341	Manure skimmer / Maize skimmer	26
1122	Cross shafts for headstock mod. 300	28
1183	Turn-over device	30
1164	Frame, EO/LO	32
1165	Hydraulic layout w/turn-over valve, EO/LO	36
1226	Hydraulic layout w/sequence valve, EO/LO	38
1111	Turn-over cylinder D80 x 300 mm	40
1180	Hydraulic cylinder D110 x 1010 mm.....	42
1181	Hydraulic cylinder D90 x 520 mm.....	44
1166	Depth wheel double.....	46
1088	Depth/transport wheel 99 (From 01.06.99)	48
1228	Bracket for depth/ transport wheel 99 (From 01.06.99)	52
1167	Transfers, EO/LO.....	54
	Index.....	56




KK 06 38 01	Extra stay R + L, no. 9 E - saddle L = 550 (From 01.12.95)
KK 07 03 94	Extra stay R for body no. 9 E - saddle, w. bracket (pos. 12) (From 01.12.95)
KK 07 03 95	Extra stay L for body no. 9 E - saddle, cpl. w. bracket (pos. 12) (From 01.12.95)
KK 07 38 03	Extra stay R + L, no. 9 A - saddle L = 560 (From 01.12.95)
KK 07 03 90	Extra stay R for body no. 9 A - saddle, cpl. w. bracket (pos. 12) (From 01.12.95)
KK 07 03 91	Extra stay L for body no. 9 A - saddle, cpl. w. bracket (pos. 12) (From 01.12.95)
KK 08 38 09	Stay R + L for body no. 28 A - saddle (From 01.03.03)
KK 08 38 10	Stay R + L for body no. 28 E - saddle (From 01.03.03)
10 KK 07 36 08	Landside, R and L, short
11 KK 01 58 32	Nut M20 mm
12 KK 07 38 00	Bracket for stay, R for body no. 6, 7, 8 (And no. 9 before 01.12.95)
KK 07 38 01	Bracket for stay, L for body no. 6, 7, 8 (And no. 9 before 01.12.95)
KK 07 38 07	Bracket for stay, R for body no. 9




35	KK 06 36 07	Plate
	KK 07 36 07	Plate cpl.
36	KK 01 33 46	Screw M14 x 45 mm w/nut
37	KK 07 36 14	Wearing plate
38	KK 01 33 33	Cone screw M14 x 34 mm
39	KK 08 32 35	Mouldboard knife R and L (From 01.12.01)
Pos. 100 - 107 Eco-share from 01.04.00		
100	KK 05 30 90	Reversible point, R
	KK 06 30 90	Reversible point, L
101	KK 01 32 28	Cone screw M12 x 34 mm w/nut
102	KK 07 36 34	Eco-share, R
	KK 07 36 35	Eco-share, L
103	KK 01 01 55	Bushing (for ploughs w/share bolt beam)
	KK 01 01 56	Bushing (for ploughs w/A-beam)
104	KK 03 27 40	Hex screw M16 x 40 mm w/nut (for ploughs w/E-saddle) (Before 01.03.00)
	KK 03 27 50	Hex screw M16 x 50 mm w/nut (for ploughs w/E-saddle) (From 01.03.00)
	KK 03 27 65	Hex screw M16 x 65 mm w/nut (for ploughs w/share bolt beam)
	KK 03 27 75	Hex screw M16 x 75 mm w/nut (for ploughs w/A-beam)
105	KK 01 33 46	Cone screw M14 x 45 mm w/flange nut (for ploughs w/E-saddle) (Before 01.03.00)
	KK 01 33 61	Cone screw M14 x 60 mm w/flange nut (for ploughs w/E-saddle) (From 01.03.00)
	KK 01 33 85	Cone screw M14 x 85 mm w/flange nut (for ploughs w/share bolt beam and A-beam)
106	KK 01 60 15	Flange nut M14
107	KK 01 29 29	Washer (for ploughs w/E-saddle) (From 01.03.00)





1	KK 01 29 19	Washer	KK 07 32 31	Shinpiece no. 19, L	KK 07 03 93	Extra stay L for body no. 19 A - saddle cpl.		
2	KK 07 33 00	Trashboard, R	16	KK 07 32 39	Connecting piece no. 12 and 15, R	w. bracket (pos. 6) (From 01.12.95)		
	KK 07 33 01	Trashboard, L		KK 07 32 40	Connecting piece no. 12 and 15, L	20	KK 07 36 09	Landside, long, R + L
	KK 07 06 40	Trashboard, R cpl.		KK 07 32 66	Connecting piece no. 19, R	21	KK 07 36 08	Landside, short, R + L
	KK 07 06 41	Trashboard, L cpl.		KK 07 32 67	Connecting piece no. 19, L	22	KK 03 27 25	Hex screw M16 x 27 mm
	KK 07 06 42	Trashboard, R + L cpl.	17	KK 03 27 50	Hex screw M16 x 50 mm w/nut (for use with two stays)	23	KK 01 32 34	Cone screw M12 x 38 mm w/nut
3	KK 07 33 10	Bracket, R		KK 03 27 35	Hex screw M16 x 35 mm w/nut (for use with one stay only)	24	KK 01 32 28	Cone screw M12 x 34 mm w/nut
	KK 07 33 11	Bracket, L				25	KK 05 30 90	Reversible point, R
4	KK 03 31 00	Oval screw M12 x 30 mm w/nut					KK 06 30 90	Reversible point, L
5	KK 01 58 34	Nut M20 mm	18	KK 01 29 27	Washer 17 x 30 x 3 mm (for use with two stays)	26	KK 07 30 54	Share 14", R
6	KK 07 38 00	Bracket, R					KK 07 30 55	Share 14", L
	KK 07 38 01	Bracket, L	19	KK 07 38 05	Stay R + L for body no. 12 and 15 E - saddle, L = 540 (And no. 19 before 12.01.95)		KK 07 30 56	Share 16", R
7	KK 05 33 87	Mouldboard extention, R		KK 07 38 31	Stay R + L for body no. 19 E - saddle, L = 730 (From 12.01.95)		KK 07 30 57	Share 16", L
	KK 06 33 88	Mouldboard extention, L		KK 07 38 04	Stay R + L for body no. 12 and 15 A - saddle, L = 550 (And no. 19 before 12.01.95)		KK 07 30 80	Share 18", R
8	KK 07 32 36	Mouldboard no. 12, R		KK 07 38 26	Stay R + L for body no. 19 A - saddle, L = 770 (From 12.01.95)	27	KK 07 30 81	Share 18", L
	KK 07 32 37	Mouldboard no. 12, L		KK 07 38 26	Extra stay R + L, no. 15 E - saddle L = 770 (From 01.12.96)		KK 07 30 91	Share knife, R
	KK 07 32 24	Mouldboard no. 15, R		KK 07 38 26	Extra stay R + L, no. 15 E - saddle L = 770 (From 01.12.96)	28	KK 07 30 92	Share knife, L
	KK 07 32 25	Mouldboard no. 15, L		KK 07 03 88	Extra stay R for body no. 15 E - saddle cpl. w. bracket (pos. 6) (From 01.12.96)	29	KK 07 30 88	Landside knife, R w/nuts
	KK 07 32 90	Mouldboard no. 19, R		KK 07 03 89	Extra stay L for body no. 15 E - saddle cpl. w. bracket (pos. 6) (From 01.12.96)		KK 07 30 89	Landside knife, L w/nuts
	KK 07 32 91	Mouldboard no. 19, L		KK 07 38 29	Extra stay R + L, no. 15 A - saddle L = 785 (From 01.12.96)	30	KK 07 36 15	Furrow widener, R
9	KK 01 33 32	Cone screw M14 x 34 mm w/nut		KK 07 03 98	Extra stay R for body no. 15 A - saddle cpl. w. bracket (pos. 6) (From 01.12.96)	31	KK 07 36 16	Furrow widener, L
10	KK 03 31 07	Oval screw M12 x 35 mm w/nut		KK 07 03 99	Extra stay L for body no. 15 A - saddle cpl. w. bracket (pos. 6) (From 01.12.96)		KK 03 31 75	Screw M14 x 50 mm w/nut
11	KK 07 30 62	Share 14", R		KK 07 38 42	Extra stay R + L, no. 19 E - saddle L = 570 (From 01.12.95)	31	KK 03 32 51	Screw M16 x 50 mm w/nut (for E-saddle) (Before 01.02.00)
	KK 07 30 63	Share 14", L		KK 07 03 96	Extra stay R for body no. 19 E - saddle cpl. w. bracket (pos. 6) (From 01.12.95)		KK 03 32 56	Screw M16 x 56 mm w/nut (for E-saddle) (From 01.02.00)
	KK 07 30 64	Share 16", R		KK 07 03 97	Extra stay L for body no. 19 E - saddle cpl. w. bracket (pos. 6) (From 01.12.95)		KK 03 32 86	Screw M16 x 85 mm w/nut (for A-saddle) (Before 01.02.00)
	KK 07 30 65	Share 16", L		KK 07 38 04	Extra stay R + L, no. 19 A - saddle L = 550 (From 01.12.95)		KK 03 32 95	Screw M16 x 95 mm w/nut (for A-saddle) (From 01.02.00)
12	KK 06 20 25	Nut M16 mm		KK 07 03 92	Extra stay R for body no. 19 A - saddle cpl. w. bracket (pos. 6) (From 01.12.95)	32	KK 01 29 22	Washer 17 x 40 x 4.58 mm
13	KK 07 34 35	Saddle, R (for E-saddle)				34	KK 01 33 33	Cone screw M14 x 34 mm w/nut
	KK 07 34 36	Saddle, L (for E-saddle)				35	KK 06 36 07	Plate for On-Land ploughs
	KK 07 34 40	Saddle, R (for A-saddle)					KK 07 36 07	Plate for On-Land ploughs cpl.
	KK 07 34 41	Saddle, L (for A-saddle)				36	KK 01 33 46	Screw M14 x 45 mm w/nut
14	KK 07 34 17	Connecting plate no. 12 and 15, R				37	KK 03 31 07	Oval screw M12 x 35 mm
	KK 07 34 18	Connecting plate no. 12 and 15, L				38	KK 07 36 14	Wearing plate
15	KK 07 32 41	Shinpiece no. 12, R				39	KK 01 33 32	Cone screw M14 x 34 mm
	KK 07 32 42	Shinpiece no. 12, L						
	KK 07 32 27	Shinpiece no. 15, R						
	KK 07 32 28	Shinpiece no. 15, L						
	KK 07 32 30	Shinpiece no. 19, R						




40	KK 08 32 35	Mouldboard knife R and L (From 01.12.01)
Pos. 100 - 107 Eco-share from 01.04.00		
100	KK 05 30 90	Reversible point, R
	KK 06 30 90	Reversible point, L
101	KK 01 32 28	Cone screw M12 x 34 mm w/nut
102	KK 07 36 34	Eco-share, R
	KK 07 36 35	Eco-share, L
103	KK 01 01 55	Bushing (for ploughs w/share bolt beam)
	KK 01 01 56	Bushing (for ploughs w/A-beam)
104	KK 03 27 40	Hex screw M16 x 40 mm w/nut (for ploughs w/E-saddle) (Before 01.03.00)
	KK 03 27 50	Hex screw M16 x 50 mm w/nut (for ploughs w/E-saddle) (From 01.03.00)
	KK 03 27 65	Hex screw M16 x 65 mm w/nut (for ploughs w/share bolt beam)
	KK 03 27 75	Hex screw M16 x 75 mm w/nut (for ploughs w/A-beam)
105	KK 01 33 46	Cone screw M14 x 45 mm w/flange nut (for ploughs w/E-saddle) (Before 01.03.00)
	KK 01 33 61	Cone screw M14 x 60 mm w/flange nut (for ploughs w/E-saddle) (From 01.03.00)
	KK 01 33 85	Cone screw M14 x 85 mm w/flange nut (for ploughs w/share bolt beam and A-beam)
106	KK 01 60 15	Flange nut M14
107	KK 01 29 29	Washer (for ploughs w/E-saddle) (From 01.03.00)






26	KK 03 30 04	Oval screw M10 x 20 mm w/nut
27	KK 07 33 50	Trashboard plastic, R
	KK 07 33 51	Trashboard plastic, L
28	KK 07 33 52	Support, R
	KK 07 33 53	Support, L
29	KK 05 33 87	Mouldboard extension, R
	KK 06 33 88	Mouldboard extension, L
31	KK 03 27 30	Hex screw M16 x 13 mm w/nut
32	KK 06 20 25	Nut M16 mm
33	KK 07 30 88	Landside knife w/nuts, R
	KK 07 30 89	Landside knife w/nuts, L
34	KK 03 32 51	Screw M16 x 50 mm w/nut (for E-sad- dle) (Before 01.02.00)
	KK 03 32 56	Screw M16 x 55 mm w/nut (for E-sad- dle) (From 01.02.00)
	KK 03 32 86	Screw M16 x 85 mm w/nut (for A-sad- dle) (Before 01.02.00)
	KK 03 32 95	Screw M16 x 95 mm w/nut (for A-sad- dle) (From 01.02.00)
35	KK 03 31 74	Screw M14 x 45 mm w/nut




1	KK 07 33 00	Trashboard, R	15	KK 08 34 15	Saddle R, A-saddle (for body no. 29)	KK 03 30 16	Oval screw M10 x 30 mm (for body no. 30)
	KK 07 33 01	Trashboard, L		KK 08 34 16	Saddle L, A-saddle (for body no. 29)		
2	KK 08 33 00	Bracket, R		KK 08 34 06	Saddle R, A-saddle (for body no. 30)	KK 01 58 13	Nut M10
	KK 08 33 01	Bracket, L		KK 08 34 07	Saddle L, A-saddle (for body no. 30)	23	KK 07 30 62 Share 14", R (for body no. 30)
3	KK 07 36 15	Furrow widener, R	16	KK 05 30 90	Reversible point, R		KK 07 30 63 Share 14", L (for body no. 30)
	KK 07 36 16	Furrow widener, L		KK 06 30 90	Reversible point, L		KK 07 30 64 Share 16", R (for body no. 30)
4	KK 01 33 32	Cone screw M14 x 34 mm	17	KK 01 32 28	Cone screw M12 x 34 mm		KK 07 30 65 Share 16", L (for body no. 30)
	KK 01 60 13	Flange nut M14		KK 01 58 17	Nut M12	24	KK 08 32 11 Slat no 1, R
5	KK 07 36 09	Landside, long R + L	18	KK 07 30 91	Share knife, R		KK 08 32 21 Slat no 1, L
6	KK 08 34 17	Saddle R, E-saddle (for body no. 29)		KK 07 30 92	Share knife, L	25	KK 08 32 12 Slat no 2, R
	KK 08 34 18	Saddle L, E-saddle (for body no. 29)		KK 06 30 91	Share knife, R (for Sweeden)		KK 08 32 22 Slat no 2, L
	KK 08 34 08	Saddle R, E-saddle (for body no. 30)		KK 06 30 92	Share knife, L (for Sweeden)	26	KK 08 32 13 Slat no 3, R
	KK 08 34 09	Saddle L, E-saddle (for body no. 30)	19	KK 07 30 02	Share 14", R (for body no. 29)		KK 08 32 23 Slat no 3, L
7	KK 03 31 16	Oval screw M12 x 35 mm (for body no. 29 and 30)		KK 07 30 03	Share 14", L (for body no. 29)	27	KK 08 32 14 Slat no 4, R
	KK 01 58 17	Nut M12		KK 07 30 54	Share 14", R (for body no. 30)		KK 08 32 24 Slat no 4, L
	KK 03 31 07	Oval screw M12 x 35 mm (for body no. 30) (Before 01.01.01)		KK 07 30 55	Share 14", L (for body no. 30)	28	KK 07 30 88 Landside knife, R
	KK 01 58 17	Nut M12		KK 07 30 04	Share 16", R (for body no. 29)		KK 07 30 89 Landside knife, L
8	KK 03 31 17	Oval screw M12 x 45 mm (for body no. 29 and 30)		KK 07 30 05	Share 16", L (for body no. 29)	29	KK 03 31 75 Screw M14 x 50 mm
	KK 01 58 17	Nut M12		KK 07 30 56	Share 16", R (for body no. 30)		KK 01 60 15 Flange nut M14
	KK 03 31 11	Oval screw M12 x 45 mm (for body no. 30) (Before 01.01.01)		KK 07 30 57	Share 16", L (for body no. 30)	30	KK 03 32 51 Screw M16 x 50 mm (for E-saddle) (Before 01.02.00)
	KK 01 58 17	Nut M12		KK 07 30 06	Share 18", R (for body no. 29)		KK 03 32 56 Screw M16 x 56 mm (for E-saddle) (From 01.02.00)
	KK 03 31 11	Oval screw M12 x 45 mm (for body no. 30) (Before 01.01.01)		KK 07 30 07	Share 18", L (for body no. 29)		KK 01 58 25 Nut M16
	KK 01 58 17	Nut M12		KK 07 30 80	Share 18", R (for body no. 30)		KK 03 32 86 Screw M16 x 85 mm (for A-saddle) (Before 01.02.00)
9	KK 08 32 10	Slat support, R	20	KK 08 32 15	Connecting piece, plastic (for slat 1-2)		KK 03 32 95 Screw M16 x 95 mm (for A-saddle) (From 01.02.00)
	KK 08 32 20	Slat support, L		KK 08 32 18	Connecting piece, plastic (for slat 2) (for body no. 29)		KK 01 58 25 Nut M16
10	KK 08 38 03	Stay		KK 08 32 16	Connecting piece, plastic (for slat 2-3) (for body no. 30)	31	KK 01 29 22 Washer 17 x 40 x 4.58 mm
11	KK 08 38 05	Stay 1, saddle A (for body no. 29)		KK 08 32 17	Connecting piece, plastic (for slat 3-4)	32	KK 07 30 42 Flush fit share 14", R (for body no. 29)
	KK 08 38 06	Stay 2, saddle A (for body no. 29)	21	KK 07 32 56	Shinpiece, R (for body no. 29)		KK 07 30 43 Flush fit share 14", L (for body no. 29)
	KK 08 38 02	Stay, saddle A (for body no. 30)		KK 07 32 57	Shinpiece, L (for body no. 29)		KK 07 30 44 Flush fit share 16", R (for body no. 29)
	KK 08 38 07	Stay 1, saddle E (for body no. 29)		KK 07 32 30	Shinpiece, R (for body no. 30)		KK 07 30 45 Flush fit share 16", L (for body no. 29)
	KK 08 38 08	Stay 2, saddle E (for body no. 29)		KK 07 32 31	Shinpiece, L (for body no. 30)	33	KK 07 30 30 Flush fit point, R
	KK 08 38 04	Stay, saddle E (for body no. 30)	22	KK 03 30 06	Oval screw M10 x 30 mm (for body no. 29)		KK 07 30 31 Flush fit point, L
12	KK 07 36 08	Landside, short R + L		KK 01 58 13	Nut M10	34	KK 08 32 35 Mouldboard knife R and L (From 01.12.01)
13	KK 03 27 50	Hex screw M16 x 50 mm					
	KK 01 58 25	Nut M16					
14	KK 07 36 14	Wearing plate					



Pos. 100 - 107 Eco-share from 01.04.00		
100	KK 05 30 90	Reversible point, R
	KK 06 30 90	Reversible point, L
101	KK 01 32 28	Cone screw M12 x 34 mm
	KK 01 58 17	Nut M12
102	KK 07 36 34	Eco-share, R
	KK 07 36 35	Eco-share, L
103	KK 01 01 55	Bushing (for ploughs w/share bolt beam)
	KK 01 01 56	Bushing (for ploughs w/A-beam)
104	KK 03 27 40	Hex screw M16 x 40 (for ploughs w/E-saddle) (Before 01.03.00)
	KK 03 27 50	Hex screw M16 x 50 mm (for ploughs w/E-saddle) (From 01.03.00)
	KK 01 58 25	Nut M16
	KK 03 27 65	Hex screw M16 x 65 mm w/nut (for ploughs w/share bolt beam)
	KK 01 58 25	Nut M16
	KK 03 27 75	Hex screw M16 x 75 mm w/nut (for ploughs w/A-beam)
	KK 01 58 25	Nut ;16
105	KK 01 33 46	Cone screw M14 x 45 mm (for ploughs w/E-saddle) (Before 01.03.00)
	KK 01 33 61	Cone screw M14 x 60 mm (for ploughs w/E-saddle) (From 01.03.00)
	KK 01 33 85	Cone screw M14 x 85 mm (for ploughs w/share bolt beam and A-beam)
106	KK 01 60 15	Flange nut M14
107	KK 01 29 29	Washer (for ploughs w/E-saddle) (From 01.03.00)



Замовлення запчастин
(050)-407-68-47
(050)-407-68-45



1	KK 05 70 67	Blade no 4	33	KK 03 26 55	Hex screw M12 x 55 mm w/nut (for extra additional leaf spring cpl.)
2	KK 03 50 20	Hex screw w/flange M10 x 34 mm w/nut	34	KK 06 70 77	Bushing (for extra additional leaf spring cpl.)
3	KK 05 70 66	Blade no 3	35	KK 06 70 75	Linkage (for extra additional leaf spring cpl.)
4	KK 02 99 20	Grease nipple M8 x 1	36	KK 06 70 76	Bolt D15.7 (for extra additional leaf spring cpl.)
5	KK 06 70 59	Bolt	37	KK 02 97 27	Split pin D5 x 32 mm (for extra additional leaf spring cpl.)
6	KK 01 10 37	Roll pin D10 x 40 mm	38	KK 06 12 91	Threaded piece
7	KK 06 70 57	Bolt (Before 01.08.02)			
	KK 06 70 16	Bolt (From 01.08.02)	Not ill.	KK 05 07 06	Leaf spring cpl. (1 x ill. no. 3, 13, 14, 16, 17 and 22 + 2 x ill. no. 1, 2, 20 and 29)
8	KK 03 28 60	Hex screw M20 x 60 mm w/nut		KK 06 07 03	Leaf spring HD cpl. (1 x ill. no 3, 16, 17 22 and 32 + 2 x ill. no. 1, 2, 20, 23 and 29)
9	KK 06 70 51	Adjustment screw w/threaded piece		KK 06 01 19	Spacer kit w/ hex screws R & L cpl.
10	KK 06 70 40	Holder (Before 01.08.02)			
	KK 06 70 25	Holder (From 01.08.02)			
11	KK 06 70 68	Bracket (Before 01.08.02)			
	KK 06 70 92	Bracket (From 01.08.02)			
12	KK 06 70 39	Adjustment screw M24 x 90 mm			
13	KK 05 70 89	Bolt			
14	KK 02 97 27	Split pin D5 x 32 mm			
15	KK 06 70 80	Spring arm			
16	KK 03 26 65	Hex screw M12 x 65 mm w/nut			
17	KK 05 70 63	Main blade			
18	KK 06 70 60	Regulator (Before 01.08.02)			
	KK 06 70 90	Regulator (From 01.08.02)			
19	KK 06 70 70	Tie rod (Before 01.08.02)			
	KK 06 70 26	Tie rod (From 01.08.02)			
20	KK 05 70 64	Blade no 1			
21	KK 06 70 31	Axle D22 x 53 mm			
22	KK 05 70 65	Blade no 2			
23	KK 05 70 68	Blade no 5			
24	KK 06 12 80	Beam			
25	KK 03 52 09	Hex screw M20 x 50 mm w/threaded piece			
26	KK 03 28 40	Hex screw M20 x 40 mm w/nut			
27	KK 06 01 08	Spacer cpl. w/hex screws R			
	KK 06 01 09	Spacer cpl. w/hex screws L			
28	KK 03 51 65	Hex screw M20 x 50 mm w/flange nut			
29	KK 03 50 21	Hex screw w/flange M10 x 30.5 mm w/nut			
30	KK 01 10 42	Roll pin D6 x 40 mm (to be mounted into roll pin 011037)			
31	KK 03 28 55	Hex screw M20 x 55 mm			
32	KK 01 29 13	Washer			



For LS, RL, LM, RM and RG ploughs

For LD, LO, RS, RX, LB, and RB ploughs



1	KK 07 12 08	Beam, R (Before 15.08.01)		KK 03 28 60	Hex screw M20 x 60 mm (for LB, LO and RB only) (From 01.04.02)
	KK 07 12 72	Beam, R (From 15.08.01)	23	KK 01 60 49	Lock nut M20 (From 01.04.02)
2	KK 07 12 09	Beam, L (Before 15.08.01)			
	KK 07 12 73	Beam, L (From 15.08.01)	Not ill.	KK 07 12 11	Beam, H = 700 mm cpl. (ill. no. 1, 2, 3 and 5 - 8) (Before 15.08.01)
3	KK 07 12 28	Support, H = 700 mm (Before 15.08.01)		KK 07 12 80	Beam, H = 700 mm cpl. (ill. no. 1, 2, 3 and 5 - 8) (From 15.08.01)
	KK 07 12 71	Support, H = 700 mm (From 15.08.01)		KK 07 12 12	Beam, H = 800 mm cpl. (ill. no. 1, 2, 4 and 5 - 8) (Before 15.08.01)
4	KK 07 12 07	Support, H = 800 mm (Before 15.08.01)		KK 07 12 81	Beam, H = 800 mm cpl. (ill. no. 1, 2, 4 and 5 - 8) (From 15.08.01)
	KK 07 12 70	Support, H = 800 mm (From 15.08.01)			
5	KK 07 70 24	Main bolt M30 x 72 mm, L (Before 15.08.01)			
	KK 07 12 75	Main bolt M30 x 84 mm, L (From 15.08.01)			
6	KK 07 70 23	Main bolt M30 x 72 mm, R (Before 15.08.01)			
	KK 07 12 74	Main bolt M30 x 84 mm, R (From 15.08.01)			
7	KK 01 60 22	Nut M30, R			
8	KK 01 60 45	Nut M30, L			
9	KK 07 49 10	Plate for support, H = 700 mm (for LS, RL, LM, RM and RG ploughs only)			
10	KK 07 49 11	Plate for support, H = 800 mm (for LS, RL, LM, RM and RG ploughs only)			
11	KK 06 15 15	Bushing D28 x D20.5 x 35.2 mm			
12	KK 03 28 40	Hex screw M20 x 40 mm w/nut (Before 01.04.02)			
	KK 03 28 45	Hex screw M20 x 45 mm (From 01.04.02)			
	KK 03 28 50	Hex screw M20 x 50 mm w/nut (for disc coultter, for front piece and rear beam)			
	KK 03 28 60	Hex screw M20 x 60 mm w/nut (for front piece w/disc coultter)			
13	KK 03 28 65	Hex screw M20 x 65 mm w/nut			
14	KK 03 52 15	Hex screw M20 x 80 mm w/flange nut qual. 12.9			
	KK 03 52 16	Hex screw M20 x 90 mm w/flange nut qual. 12.9 (for RL/ LB/ LO/ RB ploughs front section, rear leg only)			
15	KK 03 28 07	Hex screw M20 x 100 mm			
	KK 03 28 03	Hex screw M20 x 110 mm (for LB, LO and RB only) (From 01.04.02)			
	KK 03 28 24	Hex screw M20 x 105 mm (when using fixing device KK 07 72 95 for RL plough) (From 01.04.02)			
16	KK 06 20 20	Washer			
17	KK 03 50 60	Shear bolt M20 x 62 mm w/nut (for support H = 800 mm) (Before 15.08.01)			
	KK 03 50 48	Shear bolt M20 x 72 mm w/nut (for support H = 800 mm) (From 15.08.01)			
18	KK 03 50 72	Shear bolt M20 x 81 mm w/nut (for support H = 700 mm)			
19	KK 07 15 08	Plate for support H = 700 mm (for LD, LO, RS, RX, LB and RB ploughs only)			
20	KK 07 15 29	Plate for support H = 800 mm (for LD, LO, RS, RX, LB and RB ploughs only)			
21	KK 03 27 62	Hex screw M16 x 60 w/nut qual. 12.9			
22	KK 03 28 40	Hex screw M20 x 40 mm w/nut (Before 01.04.02)			
	KK 03 28 45	Hex screw M20 x 45mm (From 01.04.02)			




1	KK 07 64 06	Disc coulters 18"	22	KK 03 28 30	Hex screw M20 x 30 mm
	KK 07 64 07	Disc coulters 20"		KK 01 58 30	Nut M20
2	KK 07 64 09	Disc coulters, notched 18"	23	KK 03 28 40	Hex screw M20 x 40 mm
	KK 07 64 10	Disc coulters, notched 20"		KK 01 58 30	Nut M20
3	KK 07 64 99	Plate	24	KK 01 60 31	Cone nut M16
4	KK 03 35 40	Screw M10 x 40 mm			
	KK 01 60 04	Lock nut M10			
5	KK 01 17 50	O-ring 124,5 x 4 mm			
6	KK 01 18 66	O-ring 67 x 3 mm			
7	KK 01 12 59	Circlip I 62 x 2 mm			
8	KK 01 12 66	Circlip A 30 x 1,5 mm			
9	KK 01 05 72	Bearing			
10	KK 01 05 32	Gasket ring			
11	KK 08 60 89	Bearing housing cpl. (ill. 3 - 11)			
	KK 08 60 90	Bearing housing cpl. w/axle			
12	KK 08 61 01	Axle			
	KK 08 60 80	Disc coulters arm w/bearing 18", R			
	KK 08 60 81	Disc coulters arm w/bearing 18", L			
	KK 08 60 82	Disc coulters arm w/bearing 20", R			
	KK 08 60 83	Disc coulters arm w/bearing 20", L			
	KK 08 60 84	Disc coulters arm w/bearing 20", lowered R			
	KK 08 60 85	Disc coulters arm w/bearing 20", lowered L			
13	KK 08 61 10	Arm 18", R			
	KK 08 61 12	Arm 20", R			
	KK 08 61 14	Arm 20", lowered R			
14	KK 08 61 11	Arm 18", L			
	KK 08 61 13	Arm 20", L			
	KK 08 61 15	Arm 20", lowered L			
15	KK 06 61 70	Bracket			
16	KK 02 99 20	Grease nipple			
17	KK 06 61 90	Clip			
18	KK 03 50 31	Hex screw M12 x 45 mm			
	KK 01 58 17	Nut M12			
19	KK 06 61 89	Bracket 18"			
	KK 06 61 82	Bracket 20"			
20	KK 06 61 78	Eccentric			
21	KK 06 61 75	U-bolt			



Замовлення запчастин
(050)-407-68-47
(050)-407-68-45


1044 Disc coulters LD, LO, SL, RB, RS, RT (rear frame) and RX
(RS, RX from 15.09.99, RB from 01.05.01)



**1044 Disc coultter LD, LO, SL, RB, RS, RT (rear frame) and RX
(RS, RX from 15.09.99, RB from 01.05.01)**


1	KK 07 64 06	Disc coultter 18"		KK 08 61 01	Axle (From 01.01.99)
	KK 07 64 07	Disc coultter 20"		KK 08 60 86	Disc coultter arm w/bearing (From 01.01.99)
2	KK 07 64 09	Disc coultter 18" notched		KK 08 60 87	Disc coultter bearing cpl. (ill. no. 4-6-7-8) (From 01.01.99)
	KK 07 64 10	Disc coultter 20" notched	32	KK 01 29 60	Washer
3	KK 01 18 66	O-ring	33	KK 07 64 99	Plate
4	KK 01 12 59	Circlip			
5	KK 01 12 66	Circlip			
6	KK 01 05 72	Ball bearing			
7	KK 01 08 18	Rubber ring (Before 01.01.99)			
	KK 01 05 32	Gasket ring (From 01.01.99)			
8	KK 80 60 90	Bearing housing cpl. (ill. no. 2-3-4-5-6-7-8-9-15) (Before 01.01.99)			
	KK 08 61 00	Bearing housing cpl. (ill. no. 2-3-4-5-6-7-8-15) (From 01.01.99)			
9	KK 02 99 20	Grease nipple			
10	KK 07 65 75	Arm (From serial no. LD7112)			
11	KK 03 27 02	Hex screw M16 x 110 mm w/nut			
12	KK 07 64 00	Support			
13	KK 07 65 27	Axle			
14	KK 03 27 70	Hex screw M16 x 70 mm w/nut			
15	KK 07 64 27	Excenter			
16	KK 07 65 32	Tube R			
17	KK 07 65 33	Tube L			
18	KK 01 60 50	Excentric nut M16 (Before 01.09.98)			
	KK 01 60 58	Flange nut M16 (From 01.09.98)			
19	KK 03 29 34	Hex screw M24 x 325 mm w/nut for forward extended disc coultter)			
	KK 03 28 85	Hex screw M20 x 85 mm w/nut			
20	KK 07 65 17	Tube disc coultter (for SL)			
	KK 07 65 18	Tube for forward extended disc coultter (for SL)			
21	KK 03 10 30	Screw M10 x 30 mm			
22	KK 01 17 50	O-ring			
23	KK 01 09 09	Cover			
24	KK 03 27 50	Hex screw M16 x 50 mm			
25	KK 03 29 29	Hex screw M24 x 290 mm w/nut			
26	KK 03 27 75	Hex screw M16 x 75 mm w/nut			
27	KK 03 28 80	Hex screw M20 x 80 mm w/nut			
28	KK 07 65 37	Bushing D20 x D24 x 40 mm			
29	KK 07 65 77	Bracket for forward extended disc coultter			
30	KK 07 65 15	Supporting piece for tube			
31	KK 07 60 76	Bolt (Before 01.01.99)			





1	KK 07 68 12	Mouldboard maize R	11	KK 06 68 11	Arm R, H = 700 mm for HD beam and std. beam H700
	KK 07 68 13	Mouldboard maize L		KK 07 68 58	Arm R, H = 750 mm for std. beam H800 (From 01.12.00)
2	KK 06 68 80	Mouldboard R	16	KK 07 06 53	Fixing bracket with screw and nut (for beam 071240 and 071241)
	KK 07 69 43	Mouldboard R, plastic	17	KK 03 44 46	Setscrew M24 x 53 mm
	KK 06 68 81	Mouldboard L	18	KK 01 58 41	Nut M24
	KK 07 69 44	Mouldboard L, plastic	19	KK 01 58 16	Nut M10
3	KK 03 30 06	Oval screw M10 x 30 mm	20	KK 08 50 76	Clevis
4	KK 05 68 73	Share, short R	21	KK 06 68 61	Bracket HD beam
	KK 06 68 73	Share, short L			
5	KK 06 68 68	Share, long R			
	KK 06 68 69	Share, long L			
6	KK 01 29 06	Washer 10.5 x 25 x 3.4			
7	KK 01 58 25	Nut M16			
22	KK 08 68 01	Skimmer extension			
23	KK 03 30 07	Oval screw M10 x 35 mm			
for all turnable ploughs with Auto Reset beams:					
8	KK 03 27 95	Hex screw M16 x 95 mm			
9	KK 03 42 28	Setscrew M16 x 32 mm			
10	KK 06 06 57	Bracket cpl.			
11	KK 06 68 11	Arm R, H = 700 mm			
	KK 07 68 58	Arm R, H = 750 mm (From 01.12.00)			
	KK 06 68 12	Arm L, H = 700 mm			
	KK 07 68 59	Arm L, H = 750 mm (From 01.12.00)			
for all turnable ploughs with Shear Bolt beams:					
12	KK 07 06 39	Bracket with screws (for LB, LD, RB, RS, RX)			
	KK 07 68 72	Bracket (for LM, LS, RG, RL, RM, VD)			
13	KK 03 42 25	Setscrew M16 x 25 mm			
14	KK 03 42 50	Setscrew M16 x 50 mm			
15	KK 07 68 17	Arm R, H = 700 mm			
	KK 07 68 18	Arm L, H = 700 mm			
	KK 07 68 25	Arm R, H = 800 mm			
	KK 07 68 26	Arm L, H = 800 mm			
	KK 07 68 33	Arm R, H = 700 mm (for VD plough only) (Before 15.03.98)			
	KK 07 68 34	Arm L, H = 700 mm (for VD plough only) (Before 15.03.98)			
for beams on conventional ploughs:					







1	KK 07 43 95	Cross shaft cat. III, L = 965 mm D70
2	KK 08 14 61	Holder (for cross shaft D70)
3	KK 07 43 97	Stop ring D70
4	KK 03 28 70	Hex screw M20 x 70 mm w/nut
5	KK 03 29 56	Hex screw M24 x 55 mm
6	KK 08 14 39	Plate (From 01.10.00 - before plate no. 081442)
7	KK 03 28 55	Hex screw M20 x 55 mm w/nut
8	KK 01 07 00	Pin D12
9	KK 01 03 45	Bolt w/handle D36.6
10	KK 01 01 57	Bushing D50,6 x D37 x 59 mm
11	KK 08 14 43	Cross shaft cat. III/IV, L = 965 mm
12	KK 08 14 53	Lock plate (for cross shaft cat. IV)
13	KK 08 14 52	Plate (for cross shaft cat. IV)
14	KK 01 29 63	Washer
15	KK 08 14 42	Plate upper/lower
16	KK 07 17 93	Bushing D35 x D20.5 x 53 mm
17	KK 08 14 40	Plate
18	KK 07 17 94	Bolt w/head D35 x 90 mm
19	KK 03 28 05	Hex screw M20 x 120 mm w/nut
20	KK 03 28 07	Hex screw M20 x 100 mm w/nut
21	KK 01 08 51	Pin D10
22	KK 08 14 49	Bolt m/hull D20 x 180 mm




Замовлення запчастин
(050)-407-68-47
(050)-407-68-45




1	KK 01 16 41	Bushing	38	KK 01 09 58	Bushing, bronze (Before 15.08.01)
2	KK 01 16 97	Bushing	39	KK 01 12 52	Locking plate (Before 15.08.01)
3	KK 01 37 50	Edge list for cover	40	KK 07 48 74	Handle
4	KK 01 02 93	Pin	41	KK 07 45 73	Bushing (Before 15.08.01)
5	KK 01 01 58	Bushing	42	KK 02 99 20	Grease nipple
6	KK 01 07 00	Pin D12	43	KK 01 29 78	Washer
7	KK 08 14 37	Hose connection	44	KK 01 12 62	Circlip
8	KK 03 20 51	Umbraco screw M20 x 50 mm	45	KK 01 06 55	Spanner
9	KK 08 14 31	Cover	46	KK 03 36 30	Hex screw M12 x 30 mm w/nut for extra hole (From 01.01.02)
10	KK 01 03 73	O-ring D194.2 x 5.7 mm	47	KK 02 99 18	Grease nipple
11	KK 01 03 71	O-ring D136.12 x 3.53 mm	48	KK 08 14 95	Bushing for transport lock (From 15.08.01)
12	KK 01 05 88	Bearing	49	KK 08 14 99	Locking pin (From 15.08.01)
13	KK 08 14 32	Washer	50	KK 08 20 46	Plate for transport lock (From 15.08.01)
14	KK 01 03 72	O-ring D150 x 4.5 mm	51	KK 08 14 96	Guide lock (From 15.08.01)
15	KK 08 14 33	Gasket ring	52	KK 01 37 10	Tube pin D8 x 60 mm (From 15.08.01)
16	KK 03 28 40	Hex screw M20 x 40 mm	53	KK 01 11 22	Plastic cap (From 15.08.01)
17	KK 01 29 68	Washer			
18	KK 08 22 00	Turn-over support w/bushing, EO/LO-85/100	Not ill.	KK 08 20 09	Transport lock cpl. (pos. 36 - 41)
	KK 08 22 35	Turn-over support w/bushing, EO/LO-100 (Before 22.06.01)			
19	KK 08 14 30	Axle			
20	KK 03 27 25	Hex screw M16 x 25 mm w/nut			
21	KK 08 14 50	Washer			
22	KK 08 14 79	Nut w/spring clamp			
23	KK 08 14 10	Headstock mod. 300			
24	KK 08 15 33	Key holder			
25	KK 03 28 05	Hex screw M20 x 120 mm w/nut			
26	KK 08 14 34	Axle for cylinder bracket			
27	KK 08 14 58	Adjusting screw			
28	KK 08 14 59	Lever arm			
29	KK 06 70 31	Bolt			
30	KK 08 14 57	Bracket			
31	KK 08 14 80	Cover			
32	KK 08 14 67	Hose protector			
33	KK 03 26 02	Hex screw M12 x 110 mm w/nut			
34	KK 01 29 42	Washer			
35	KK 01 06 06	Spanner 19 - 27			
36	KK 08 14 55	Pin for lock (Before 15.08.01)			
37	KK 35 60 42	Spring			


 Hannover Agro
 Замоклення запчастин
 (050)-407-68-47
 (050)-407-68-45



1	KK 08 22 58	Additional tube for EO/LO-85 (Before 01.09.02)	11	KK 07 14 95	Scale holder	43	KK 08 22 39	Bracket for parallel rod
	KK 08 25 28	Additional tube for EO/LO-85 (From 01.09.02)	12	KK 07 14 92	U-bolt M12	44	KK 08 22 40	Bracket for parallel rod
	KK 08 22 59	Additional tube for EO/LO-100 (Before 01.09.02)	13	KK 07 14 17	Bushing (Before 01.06.02)		KK 08 22 42	Bracket for parallel rod
	KK 08 25 29	Additional tube for EO/LO-100 (From 01.09.02)		KK 08 22 56	Bushing (From 01.06.02)	45	KK 01 29 68	Washer
2	KK 08 22 57	Connecting piece	14	KK 07 16 70	Plate	46	KK 08 22 80	Coupling piece
3	KK 08 22 56	Bushing	15	KK 01 09 07	Plastic cover	47	KK 08 22 81	Coupling piece
4	KK 08 22 55	Main tube for EO/LO-100, 4 furrows (From 01.09.01) (Before 01.09.02)	16	KK 08 22 45	Indicator bracket	48	KK 08 22 68	Parallel rod for EO/LO-100, 4 furrows (From 01.09.01)
	KK 08 25 24	Main tube for EO/LO-100, 4 furrows (From 01.09.02)	17	KK 07 18 53	Indicator		KK 08 22 60	Parallel rod for EO/LO-85, 5 furrows
	KK 08 22 50	Main tube for EO/LO-85, 5 furrows (Before 01.09.02)	18	KK 08 22 95	Beam support w/bushing and balls (for EO plough)		KK 08 22 61	Parallel rod for EO/LO-100, 5 furrows
	KK 08 25 21	Main tube for EO/LO-85, 5 furrows (From 01.09.02)	19	KK 08 22 82	Beam support w/bushing, upper (for LO plough)		KK 08 22 62	Parallel rod for EO/LO-85, 6 furrows
	KK 08 22 51	Main tube for EO/LO-100, 5 furrows (Before 01.09.02)	20	KK 08 22 83	Beam support w/bushing, lower (for LO plough)		KK 08 22 63	Parallel rod for EO/LO-100, 6 furrows
	KK 08 25 25	Main tube for EO/LO-100, 5 furrows (From 01.09.02)	21	KK 08 22 96	Beam support w/bushing, rear (for EO plough)	49	KK 08 22 66	Connecting piece for parallel rod
	KK 08 22 52	Main tube for EO/LO-85, 6 furrows (Before 01.09.02)	22	KK 08 22 84	Beam support w/bushing, upper rear (for LO plough)	50	KK 08 22 64	Additional parallel rod for EO/LO-85
	KK 08 25 22	Main tube for EO/LO-85, 6 furrows (From 01.09.02)	23	KK 08 22 85	Beam support w/bushing, lower rear (for LO plough)		KK 08 22 65	Additional parallel rod for EO/LO-100
	KK 08 22 53	Main tube for EO/LO-100, 6 furrows (Before 01.09.02)	24	KK 06 16 99	Plate	51	KK 08 22 37	Parallel arm w/bushing for EO/LO-85/100
	KK 08 25 26	Main tube for EO/LO-100, 6 furrows (From 01.09.02)	25	KK 07 12 55	Ball		KK 08 22 38	Parallel arm w/bushing for EO/LO-100 (Before 22.06.01)
5	KK 07 16 72	Plate, rear	26	KK 03 27 52	Hex screw M16 x 50 mm	52	KK 01 16 97	Bushing
6	KK 08 22 36	Spacer	27	KK 03 27 45	Hex screw M16 x 45 mm w/nut	53	KK 08 22 11	Tie rod 140 x 80 mm
7	KK 08 22 28	Cylinder bracket, R for EO/LO-85	28	KK 31 00 75	Bushing	54	KK 08 22 13	Axle D70 x 525 mm
	KK 08 22 48	Cylinder bracket, R for EO/LO-100 (From 22.06.01)	29	KK 01 16 94	Bushing	55	KK 08 22 15	Cylinder bracket
8	KK 08 22 29	Cylinder bracket, L for EO/LO-85	30	KK 07 14 03	Tube w/cone	56	KK 08 25 06	End piece for tie rod
	KK 08 22 49	Cylinder bracket, L for EO/LO-100 (From 22.06.01)	31	KK 01 29 40	Washer	57	KK 03 28 50	Hex screw M20 x 50 mm w/nut
9	KK 07 18 27	Plate	32	KK 03 29 23	Hex screw M24 x 270 mm w/nut	58	KK 08 22 12	Tie rod 70 x 40 mm
10	KK 07 21 67	Plate, 2 holes	33	KK 07 18 26	Plate	59	KK 08 22 14	Axle D40 x 432 mm
			34	KK 01 16 41	Bushing	60	KK 01 07 00	Ring pin D12
			35	KK 08 22 34	Support w/bushing, rear	61	KK 01 03 15	Bolt w/head D25.3 x 60 mm
			36	KK 02 99 20	Grease nipple	62	KK 35 11 39	Screw, R
			37	KK 01 09 09	Plastic cover	63	KK 07 21 73	Tube
			38	KK 08 15 79	Spanner holer without lock hole	64	KK 07 17 15	Machine stand, H = 700 (Before 01.08.01)
			39	KK 01 06 50	Spanner		KK 08 16 24	Tube for machine stand (From 01.08.01)
			40	KK 08 15 78	Spanner holder w/lock hole	65	KK 07 17 14	Bolt
			41	KK 08 15 49	U-bolt M12	66	KK 07 17 11	Spring
			42	KK 03 28 80	Hex screw M20 x 80 mm w/nut	67	KK 07 17 13	Bolt
						68	KK 07 17 12	Bolt
						69	KK 01 60 13	Flange nut M24
						70	KK 03 50 25	Cylinder screw M10 x 30 mm




71	KK 01 60 06	Lock nut M10
72	KK 07 17 10	Fix for machine stand
73	KK 01 58 30	Nut M20
74	KK 01 28 13	Conical bushing
75	KK 03 28 40	Hex screw M20 x 40 mm w/nut
76	KK 03 28 92	Hex screw M20 x 90 mm w/nut
77	KK 03 28 60	Hex screw M20 x 60 mm w/nut
78	KK 03 28 13	Hex screw M20 x 170 mm w/nut
79	KK 03 28 22	Hex screw M20 x 190 mm w/nut
80	KK 03 29 26	Hex screw M24 x 265 mm w/nut
81	KK 03 29 25	Hex screw M24 x 250 mm w/nut
82	KK 03 27 25	Hex screw M16 x 27 mm w/nut
83	KK 03 27 35	Hex screw M16 x 35 mm w/nut
84	KK 03 27 10	Hex screw M16 x 155 mm w/nut
85	KK 03 28 24	Hex screw M20 x 105 mm w/nut
86	KK 03 28 85	Hex screw M20 x 85 mm w/nut
87	KK 03 28 95	Hex screw M20 x 95 mm
88	KK 01 60 12	Flange nut M20
89	KK 03 27 40	Hex screw M16 x 40 mm w/nut
90	KK 07 95 96	Conical bushing
91	KK 08 16 22	Adjustable machine stand (From 01.08.01)
92	KK 03 27 60	Hex screw M16 x 60 mm (From 01.08.01)
93	KK 07 43 19	Bushing (From 01.08.01)
94	KK 01 28 25	Nut M16 (From 01.08.01)
95	KK 08 26 30	Support ext. kit welded (From 01.09.02)
96	KK 08 26 48	Washer
97	KK 08 26 46	Conical bushing D32 ext. kit
98	KK 03 27 35	Hex screw M16 x 35 mm
99	KK 08 26 47	Inner conical to screw ext. kit
100	KK 01 03 28	Bolt w/ head 25,3 x 80 mm


Not ill.	KK 08 01 87	Machine stand cpl. (From 01.08.01)
	KK 07 08 07	Stay cpl.




Замовлення запчастин
(050)-407-68-47
(050)-407-68-45



1	KK 35 36 91	Hydraulic cylinder D110 x 1010 mm cpl. (see plate no. 1180)	38	KK 01 27 85	Hose 1/4", L = 2250 mm
2	KK 07 17 94	Bolt w/head D35 x 90 mm	39	KK 01 23 74	Hose 1/4", L = 750 mm
3	KK 01 10 21	Roll pin D12 x 50 mm	40	KK 01 26 71	Hose 1/4", L = 1000 mm
4	KK 01 15 85	Gasket ring 3/8"	41	KK 01 27 92	Hose 1/4", L = 1750 mm
5	KK 01 20 62	Banjo 3/8", H = 17	42	KK 08 14 81	Bracket angle
6	KK 01 20 59	Banjobolt 3/8" x 31	43	KK 01 01 49	Bushing D42 x d35 x 10 mm
7	KK 01 25 47	Banjo 3/8"	44	KK 01 23 75	Hydraulic tube D12
8	KK 01 22 67	Cuttet ring for D12 mm hydraulic tube	45	KK 35 22 47	Stop D40 x 35 mm
9	KK 01 22 64	Nut M18 x 1,5	46	KK 01 35 00	Hose wrapper D32 x 250 mm
10	KK 01 20 56	Angle, 90°	47	KK 01 36 80	Threaded coupling, 3/8" outer - 3/8" inner, L = 18
11	KK 01 22 61	Threaded coupling 3/8" - 3/8"			
12	KK 01 25 08	Lock valve 3/8", double	Not ill.	KK 01 25 09	Strip, green
13	KK 01 25 48	Banjo 3/8" w/adjustable end		KK 01 27 34	Strip, blue
14	KK 01 21 21	Threaded coupling 3/8" for D12 mm tube		KK 01 27 35	Strip, red
15	KK 03 33 21	Countersunk screw M6 x 20 mm		KK 01 35 29	Strip, yellow
16	KK 01 35 31	Clamp 1/4", D7		KK 30 90 29	Strip, PLT4HC 7,5 x 340 mm
17	KK 01 23 19	Swivel 3/8"			
18	KK 01 25 77	Threaded coupling, 3/8" outer - 3/8" inner L = 59 mm			
19	KK 35 36 92	Hydraulic cylinder D90 x 520 mm w/overflow cpl. (see plate no. 1181)			
20	KK 01 03 28	Bolt w/head D25.3 x 78 mm			
21	KK 01 10 20	Roll pin D12 x 40 mm			
22	KK 01 03 19	Bolt w/head D25.3 x 120 mm			
23	KK 01 00 08	Bushing D35 x d26 x 10 mm			
24	KK 01 27 40	Turn-over valve 3/8"			
25	KK 03 35 25	Hex screw M10 x 25 mm			
26	KK 03 35 16	Hex screw M10 x 16 mm			
27	KK 35 36 65	Turn-over cylinder D80 x 585 mm cpl. (see plate no. 1111)			
28	KK 01 27 07	Bulkhead pipe 3/8"			
29	KK 03 24 50	Hex screw M8 x 50 mm w/nut			
30	KK 01 23 24	Cover			
31	KK 01 23 23	Plastic part			
32	KK 01 15 96	Hose wrapper D12.5 x 250 mm			
33	KK 01 35 01	Hose wrapper D32 x 400 mm			
34	KK 01 21 58	Quick coupling 1/2" - 3/8"			
35	KK 01 20 80	Threaded coupling 3/8", D3.0 mm choke (Before 01.04.02)			
	KK 01 20 78	Threaded coupling 3/8" - 3/8", D2.0 mm choke (From 01.04.02)			
36	KK 01 27 78	Hose 3/8", L = 1000 mm			
37	KK 01 27 73	Hose 3/8", L = 1300 mm			




1	KK 35 36 91	Hydraulic cylinder D110 x 1010 mm cpl. (see plate no. 1180)	38	KK 01 27 85	Hose 1/4", L = 2250 mm
2	KK 07 17 94	Bolt w/head D35 x 90 mm	39	KK 01 23 74	Hose 1/4", L = 750 mm
3	KK 01 10 21	Roll pin D12 x 50 mm	40	KK 01 26 71	Hose 1/4", L = 1000 mm
4	KK 01 15 85	Gasket ring 3/8"	41	KK 01 27 92	Hose 1/4", L = 1750 mm
5	KK 01 20 62	Banjo 3/8", H = 17	42	KK 08 14 81	Bracket angle
6	KK 01 20 59	Banjobolt 3/8" x 31	43	KK 01 01 49	Bushing D42 x d35 x 10 mm
7	KK 01 26 77	Hose 1/4", L = 1250 mm	44	KK 01 25 08	Lock valve 3/8", double
8	KK 01 20 80	Threaded coupling 3/8", D3.0 mm choke	45	KK 01 35 00	Hose wrapper D32 x 250 mm
9	KK 01 20 84	Banjobolt 3/8" x 31, D2,0 w/ choke	46	KK 01 36 80	Threaded coupling, 3/8" outer - 3/8" inner, L = 18
10	KK 01 20 56	Angle, 90°			
11	KK 01 22 61	Threaded coupling 3/8" - 3/8"	Not ill.	KK 01 25 09	Strip, green
12	KK 01 27 23	Valve w/ handle 3/8"		KK 01 27 34	Strip, blue
13	KK 01 25 48	Banjo 3/8" w/adjustable end		KK 01 27 35	Strip, red
14	KK 35 22 47	Stop D40 x 35 mm		KK 01 35 29	Strip, yellow
15	KK 03 33 21	Countersunk screw M6 x 20 mm		KK 30 90 29	Strip, PLT4HC 7,5 x 340 mm
16	KK 01 35 31	Clamp 1/4", D7			
17	KK 01 23 19	Swivel 3/8"			
18	KK 01 25 77	Threaded coupling, 3/8" outer - 3/8" inner L = 59 mm			
19	KK 35 36 92	Hydraulic cylinder D90 x 520 mm w/overflow cpl. (see plate no. 1181)			
20	KK 01 03 28	Bolt w/head D25.3 x 78 mm			
21	KK 01 10 20	Roll pin D12 x 40 mm			
22	KK 01 03 19	Bolt w/head D25.3 x 120 mm			
23	KK 01 00 08	Bushing D35 x d26 x 10 mm			
24	KK 01 27 42	Sequence valve 3/8"			
25	KK 03 35 25	Hex screw M10 x 25 mm			
26	KK 03 35 16	Hex screw M10 x 16 mm			
27	KK 35 36 65	Turn-over cylinder D80 x 585 mm cpl. (see plate no. 1111)			
28	KK 01 27 07	Bulkhead pipe 3/8"			
29	KK 03 24 50	Hex screw M8 x 50 mm w/nut			
30	KK 01 23 24	Cover			
31	KK 01 23 23	Plastic part			
32	KK 01 15 96	Hose wrapper D12.5 x 250 mm			
33	KK 01 35 01	Hose wrapper D32 x 400 mm			
34	KK 01 21 58	Quick coupling 1/2" - 3/8"			
35	KK 01 20 80	Threaded coupling 3/8", D3.0 mm choke (Before 01.04.02)			
	KK 01 20 78	Threaded coupling 3/8" - 3/8", D2.0 mm choke (From 01.04.02)			
36	KK 01 27 78	Hose 3/8", L = 1000 mm			
37	KK 01 27 73	Hose 3/8", L = 1300 mm			



1	KK 35 36 71	Cylinder tube (for turn-over cylinder KK 35 36 64)
	KK 35 36 78	Cylinder tube (for turn-over cylinder KK 35 36 65)
2	KK 35 36 72	Piston rod w/piston (for turn-over cylinder KK 35 36 64)
	KK 35 36 79	Piston rod w/piston (for turn-over cylinder KK 35 36 65)
3	KK 03 20 01	Set screw M6 x 6 mm
4	KK 01 19 18	Piston packing
5	KK 01 18 24	O-ring D74.5
6	KK 01 18 76	Support ring
7	KK 35 36 75	Rod cap
8	KK 03 20 08	Set screw M5 x 8 mm
9	KK 01 19 51	Rod packing
10	KK 01 19 12	Scraper
11	KK 02 99 18	Grease nipple M6
12	KK 35 36 73	Rod bearing
13	KK 01 12 61	Circlip
14	KK 01 12 23	Spherical ball bearing
Not ill.	KK 01 30 66	Packing set cpl.
	KK 35 36 64	Turn-over cylinder D80 x 300 mm cpl. (for headstock mod. 200)
	KK 35 36 65	Turn-over cylinder D80 x 375 mm cpl. (for headstock mod. 300)



Замовлення запчастин
(050)-407-68-47
(050)-407-68-45



1	KK 35 36 73	Clevis
2	KK 02 99 18	Grease nipple D6 x 1 mm
3	KK 01 12 61	Circlip
4	KK 01 12 23	Bearing
5	KK 35 38 28	Holder for pin
6	KK 35 36 10	Rod cap
7	KK 01 19 12	Scraper D50 x d40
8	KK 01 19 51	Rod packing
9	KK 01 65 41	Support ring
10	UH 87 20 82	O-ring D104,5 x 3 mm
11	KK 35 36 48	Piston rod w/piston, short
12	KK 01 65 40	Piston packing
13	KK 35 38 29	Pin
14	KK 35 36 47	Cylinder tube D110
15	KK 35 36 49	Piston rod w/piston, long
16	KK 01 18 99	O-ring D39,34 x 2.62 mm
17	KK 35 36 99	Adjustable nut
18	KK 35 36 98	Adjustable bolt
19	KK 35 36 89	Scraper

Not ill.	KK 01 30 84	Packings cpl.
	KK 35 36 91	Hydraulic cylinder D110 x 1010 mm cpl.




Замовлення запчастин
(050)-407-68-47
(050)-407-68-45




1	KK 35 36 93	Cylinder tube D90
2	KK 01 65 39	Piston packing
3	KK 35 36 94	Piston rod w/piston
4	KK 35 36 95	Rod cap
5	KK 01 65 24	O-ring D79.2 x 5.7 mm
6	KK 01 65 25	Support ring
7	KK 01 19 51	Rod packing
8	KK 01 19 12	Scraper D50 x d40
9	KK 01 18 99	O-ring D39.34 x 2.62 mm
10	KK 35 36 97	Adjustable nut
11	KK 35 36 96	Adjustable bolt
12	KK 35 36 89	Scraper
13	KK 03 20 40	Cylinder screw M10 x 40 mm
14	KK 35 35 85	Clevis
Not ill.	KK 01 30 85	Packings cpl.
	KK 35 36 92	Hydraulic cylinder D90 x 520 mm cpl.




Замовлення запчастин
(050)-407-68-47
(050)-407-68-45



1	KK 01 13 03	Tyre 200 x 14.5	25	KK 08 40 50	Wheel holder
	KK 01 13 46	Tyre 26 x 12-12 (Before 15.03.02)	26	KK 01 05 89	Ball D15
	KK 01 31 00	Tyre 26 x 12-12 (From 15.03.02)	27	KK 01 37 02	Spring
	KK 01 13 05	Inner tube for 200 x 14.5	28	KK 03 28 30	Hex screw M20 x 30 mm
	KK 01 13 49	Inner tube for 26 x 12-12	29	KK 01 10 52	Pin D12 x 80 mm
	KK 01 13 79	Rim 200 x 14.5 (Before 15.03.02)	30	KK 08 40 77	Lock ring
	KK 08 41 06	Rim 200 x 14.5 (From 15.03.02)	31	KK 01 11 68	Packing (Before 05.09.01)
	KK 01 14 19	Rim 26 x 12-12 (Before 15.03.02)	32	KK 01 05 17	Bearing (Before 05.09.01)
	KK 08 41 07	Rim 26 x 12-12 (From 15.03.02)	33	KK 01 12 00	Bearing (Before 05.09.01)
2	KK 01 14 01	Cover kit cpl.	34	KK 01 29 34	Washer (Before 05.09.01)
3	KK 08 40 80	Axle D50 x 285 mm for 200 x 14.5 (Before 05.09.01)	35	KK 01 60 00	Lock nut M20 (Before 05.09.01)
	KK 08 40 92	Axle 200 x 14.5 (From 05.09.01) (Before 15.03.02)	36	KK 01 11 57	End cap (Before 05.09.01)
	KK 08 41 12	Axle 200 x 14.5 (From 15.03.02)	37	KK 06 18 99	Contra nut M24
	KK 08 40 81	Axle D50 x 335 mm for 26 x 12 - 12 (Before 05.09.01)	38	KK 01 30 04	Washer
	KK 08 40 93	Axle 26 x 12-12 (From 05.09.01) (Before 15.03.02)	39	KK 02 99 20	Grease nipple
	KK 08 41 13	Axle 26 x 12-12 (From 15.03.02)	40	KK 03 28 45	Hex screw M20 x 45 mm w/nut
4	KK 08 40 62	Axle, lower	41	KK 01 09 06	Plastic part
5	KK 08 40 61	Axle, upper	42	KK 01 12 15	Conical bushing D80 (From 05.09.01)
6	KK 01 07 00	Ring pin D12	43	KK 01 12 28	Conical bushing D62 (From 05.09.01) (Before 15.03.02)
7	KK 03 28 90	Hex screw M20 x 90 mm w/nut		KK 01 05 91	Conical bearing (From 15.03.02)
8	KK 08 40 70	Wheel arm, H = 700	44	KK 01 31 02	Washer (From 05.09.01)
	KK 08 40 45	Wheel arm, H = 800 (From 01.11.01)	45	KK 01 31 03	Lock nut M30 (From 05.09.01)
9	KK 08 40 67	Bolt w/adjusting handle	46	KK 01 31 04	Washer D42 x d30 x 3 (From 05.09.01)
10	KK 01 10 48	Roll pin D12 x 60 mm	47	KK 01 31 05	Hub cap (From 15.03.02)
11	KK 03 27 85	Hex screw M16 x 85 mm w/nut	48	KK 01 31 06	Z-lamell (From 15.03.02)
12	KK 08 40 65	Adjustable plate			
13	KK 03 27 60	Hex screw M16 x 60 mm w/lock nut	Not ill.	KK 08 40 15	Depth wheel double w/wheel 200 x 14.5, H = 700
14	KK 08 40 69	Bolt w/adjusting handle		KK 08 40 16	Depth wheel double w/wheel 26 x 12-12, H = 700
15	KK 03 28 65	Hex screw M20 x 65 mm w/lock nut		KK 08 40 18	Depth/transport wheel 200 x 14.5, H = 800 (From 01.11.01)
16	KK 01 60 25	Lock nut M16		KK 08 40 19	Depth/transport wheel 26 x 12-12, H = 800 (From 01.11.01)
17	KK 01 60 00	Lock nut M20		KK 08 40 91	Depth stop cpl.
18	KK 08 40 66	Axle D40 x 245 mm		KK 08 41 02	Wheel 200 x 14.5 cpl. w/axle (for EO/LO plough) (From 15.03.02)
19	KK 08 40 55	Axle cpl.		KK 08 41 03	Wheel 26 x 12-12 cpl. w/axle R. (From 15.03.02)
20	KK 01 16 33	Bearing		KK 08 41 04	Wheel 26 x 12-12 cpl. w/axle L. (From 15.03.02)
21	KK 08 80 63	Stop screw			
22	KK 08 40 90	Depth wheel stop			
23	KK 01 10 35	Pin D6 x 30 mm			
24	KK 01 02 55	Bolt w/head D16 x 51 mm			



1	KK 07 48 56	Axle w/bearing cpl. (for depth/transport wheel)	28	KK 02 99 32	Grease nipple	50	KK 07 48 73	Axle
2	KK 07 48 75	Axle	29	KK 01 60 00	Lock nut M20 (Before 01.01.02)	51	KK 01 37 00	Spring
3	KK 07 48 93	Axle		KK 01 31 03	Lock nut KM6 M30 (Rebuilding kit EO/LO. Check dimension !)	52	KK 01 29 16	Washer
4	KK 01 10 48	Roll pin D12 x 60 mm		KK 01 31 09	Lock nut KM7 M35 (From 21.05.02)	53	KK 07 48 76	Lock
5	KK 01 07 00	Pin D12	30	KK 01 29 34	Lock washer (Before 21.05.02)	54	KK 06 40 86	Protection for damper block (From 01.05.00)
6	KK 07 48 64	Switch bracket		KK 01 31 04	Lock washer D42 x d30 x 3 (Rebuilding kit EO/LO. Check dimension !)	55	KK 06 40 79	Holder for damper block (From 01.05.00)
7	KK 07 48 65	Wheel arm (for depth/transport wheel)		KK 01 31 08	Lock washer D58 x d35 x 2,5 (From 21.05.02)	56	KK 01 30 04	Washer
8	KK 03 29 80	Hex screw M24 x 80 mm w/nut				57	KK 01 29 56	Washer
9	KK 03 27 65	Hex screw M16 x 65 mm w/nut (From 01.04.01)	31	KK 01 31 02	Washer MB6 (Rebuilding kit EO/LO. Check dimension !)	58	KK 07 48 41	Axle w/short bracket shaft cpl. (for depth wheel 200 x 14.5)
10	KK 07 48 44	Bracket for scraper (From 01.04.01)		KK 01 31 10	Washer MB7 (From 21.05.02)	59	KK 07 48 62	Axle w/bracket shaft cpl. (for depth wheel 26 x 12-12)
11	KK 07 48 38	Scraper (for wheel 200 x 14.5)	32	KK 01 12 00	Bearing (Before 21.05.02)			
	KK 07 48 43	Scraper (for wheel 26 x 12-12) (Before 01.01.02)		KK 01 05 91	Conical bearing (From 21.05.02)	60	KK 03 27 40	Hex screw M16 x 40 mm w/nut (From 01.05.00)
	KK 07 46 24	Scraper (for wheel 26 x 12-12) (From 01.01.02)	33	KK 01 05 17	Bearing (Before 21.05.02)			
				KK 01 12 15	Conical bearing (From 21.05.02)	61	KK 01 02 55	Bolt D16 x 51 mm
12	KK 03 26 40	Hex screw M12 x 40 mm w/nut	34	KK 01 11 68	Z - lamell	62	KK 01 16 36	Bushing D20 x D16 x 10 mm
13	KK 01 60 38	Flange nut M12 (From 01.04.01)	35	KK 01 13 03	Tyre 200 x 14.5	63	KK 07 48 50	Wheel bracket, rear mounted depth wheel
14	KK 03 28 07	Hex screw M20 x 100 mm w/nut		KK 01 13 05	Inner tube 200 x 14.5		KK 07 48 39	Wheel bracket, rear mounted depth wheel w/bearing
15	KK 01 60 12	Flange nut M20	36	KK 07 40 80	Axle 200 x 14.5 (Before 21.05.02)			
16	KK 03 27 70	Hex screw M16 x 70 mm w/nut (for depth/transport wheel) (Before 01.04.01)		KK 08 41 10	Axle 200 x 14.5 (From 21.05.02)	64	KK 02 99 20	Grease nipple
	KK 03 27 75	Hex screw M16 x 75 mm w/nut (for depth wheel) (Before 01.04.01)	37	KK 07 40 93	Axle 26 x 12-12 (Before 27.05.02)	65	KK 03 28 50	Hex screw M20 x 50 mm w/nut
				KK 08 41 11	Axle 26 x 12-12 (From 27.05.02)	66	KK 03 23 90	Hex screw M6 x 90 mm
			38	KK 01 13 46	Tyre 26 x 12-12 (Before 27.05.02)	67	KK 01 29 55	Washer
				KK 01 31 00	Tyre 26 x 12-12 (From 27.05.02)	68	KK 03 27 45	Hex screw M16 x 45 mm w/nut
17	KK 07 48 35	Clamp bracket (Before 01.04.01)		KK 01 13 49	Inner tube 26 x 12-12	69	KK 01 10 52	Roll pin D12 x 80 mm
18	KK 07 48 36	Bracket for scraper (Before 01.04.01)	39	KK 01 14 02	Cover kit cpl.	70	KK 07 48 67	Crank for shock absorber
19	KK 10 68 63	Bushing (Before 01.04.01)	40	KK 06 40 89	Spring (From 01.05.00)	71	KK 08 40 40	Rotation bolt (From 01.05.00)
20	KK 01 29 19	Washer (Before 01.04.01)	41	KK 03 26 65	Hex screw M12 x 60 mm (From 01.05.00)	72	KK 06 40 97	Crank screw cpl.
21	KK 01 29 11	Washer 6,4 x 12,5 x 1,5 mm	42	KK 08 40 43	Crank (From 01.05.00)	73	KK 06 40 24	Stop screw
22	KK 03 28 90	Hex screw M20 x 90 mm w/nut	43	KK 01 60 18	Lock nut M6	74	KK 06 40 30	Clevis
23	KK 07 48 66	Wheel arm (for depth wheel)	44	KK 01 29 31	Washer	75	KK 01 13 79	Rim 200 x 14.5 (Before 21.05.02)
24	KK 03 29 80	Hex screw M24 x 80 mm w/nut	45	KK 35 36 30	Shock absorber		KK 08 41 06	Rim 200 x 14.5 (From 21.05.02)
25	KK 07 90 63	Washer	46	KK 01 10 35	Roll pin D6 x 30 mm	76	KK 01 14 19	Rim 26 x 12-12 (Before 27.05.02)
26	KK 01 14 01	Cover kit cpl.	47	KK 07 48 70	Bracket arm for shock absorber		KK 08 41 07	Rim 26 x 12-12 (From 27.05.02)
27	KK 01 11 57	Hub cap (Before 01.01.02)	48	KK 35 60 42	Spring		KK 07 48 86	Clamp w/fixing lug (200 mm tube)
	KK 01 31 05	Hub cap (From 21.05.02)	49	KK 07 48 74	Handle	77	KK 01 60 01	Lock nut M24



Not ill.	KK 06 40 47	Stop cpl.
	KK 08 40 00	Depth wheel 200 x 14.5 rear mounted without shock absorber cpl.
	KK 08 40 01	Depth wheel 200 x 14.5 rear mounted w/shock absorber cpl.
	KK 08 40 02	Depth wheel 26 x 12-12 rear mounted w/shock absorber cpl.
	KK 08 40 03	Depth wheel 200 x 14.5 frame mounted without shock absorber cpl.
	KK 08 40 10	Depth/transport wheel 200 x 14.5 rear mounted without shock absorber cpl.
	KK 08 40 11	Depth/transport wheel 200 x 14.5 rear mounted w/shock absorber cpl.
	KK 08 40 12	Depth/transport wheel 26 x 12-12 rear mounted w/shock absorber cpl.
	KK 08 40 13	Depth/transport wheel 200 x 14.5 frame mounted without shock absorber cpl.
	KK 08 41 00	Wheel 200 x 14.5 cpl. w/axle (From 21.05.02)
	KK 08 41 01	Wheel 26 x 12-12 cpl. w/axle (From 27.05.02)




Замовлення запчастин
(050)-407-68-47
(050)-407-68-45



1	KK 03 27 16	Hex screw M16 x 140 mm w/nut (VD, VX, ED and LD plough)	24	KK 07 48 90	Clamp (150 mm tube)
	KK 03 27 19	Hex screw M16 x 190 mm w/nut (EM/LM plough)		KK 07 48 87	Clamp (200 mm tube)
	KK 03 27 27	Hex screw M16 x 160 mm w/nut (ED/LD-HD plough)	25	KK 07 48 89	Clamp w/fixing lug (150 mm tube)
				KK 07 48 86	Clamp w/fixing lug (200 mm tube)
2	KK 01 03 15	Bolt D25.3 x 60 mm	26	KK 07 48 81	Plate, over (for ES and LS plough)
3	KK 07 08 05	Adjustable stay			
4	KK 01 10 20	Roll pin D12 x 40 mm			
5	KK 07 48 80	Wheel bracket, frame mounted wheel			
6	KK 07 48 85	Plate, lower (ED and LD plough)			
	KK 07 49 71	Plate, lower (ED/LD-HD, 200 tube)			
7	KK 07 48 84	Plate, upper (ED and LD plough)			
	KK 07 49 70	Plate, upper (ED/LD-HD, 200 tube)			
8	KK 07 48 88	Plate (for VD and VX plough)			
9	KK 07 48 91	Plate (for EM/LM plough)			
10	KK 07 48 82	Plate, under (for ES and LS plough)			
11	KK 01 30 05	Washer			
12	KK 01 16 14	Bushing D30 x D16 x 28 mm			
13	KK 03 27 65	Hex screw M16 x 65 mm w/nut			
14	KK 01 16 15	Bushing D40 x D24 x 15.5 mm			
15	KK 03 29 25	Hex screw M24 x 250 mm w/nut			
16	KK 03 29 20	Hex screw M24 x 200 mm w/nut			
17	KK 03 28 22	Hex screw M20 x 190 mm w/nut			
18	KK 03 28 36	Hex screw M20 x 240 mm w/nut			
19	KK 08 40 42	Pin (From 01.05.00)			
20	KK 06 82 51	Washer			
21	KK 08 40 84	Stop screw (for ES/LS ploughs only) (From 01.04.01)			
22	KK 07 48 46	Transportation support (for ES/LS ploughs only) (From 01.04.01)			
23	KK 06 18 99	Contra nut M24 (for ES/LS ploughs only) (From 01.04.01)			



Замовлення запчастин
(050)-407-68-47
(050)-407-68-45



1	KK 70 99 84	Kverneland EO-85
	KK 70 99 86	Kverneland LO-85
2	KK 70 99 85	Kverneland EO-100
	KK 70 99 87	Kverneland EO-100
3	KK 70 97 37	Arrow
4	KK 70 98 31	Kverneland w/arrow
5	KK 70 92 34	Info., spring
6	KK 70 94 79	Info., nuts
7	KK 70 98 95	Safty sign, sharp edges
8	KK 70 98 43	Safty sign, parking support
9	KK 70 98 23	Safty sign, crush danger
10	KK 70 98 42	Safty sign, reversible plough
11	KK 70 98 44	Safty sign, read instruction manual
12	KK 70 98 41	Safty sign, danger, tractor/implement
13	KK 71 99 11	Turnbuckle adjustment



Замовлення запчастин
(050)-407-68-47
(050)-407-68-45

Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page
KK 01 00 08 37		KK 01 05 91 49		KK 01 12 15 49		KK 01 16 94 33		KK 01 23 19 37		KK 01 27 92 39		KK 01 30 84 43		KK 01 33 46 7	
KK 01 00 08 39		KK 01 06 06 31		KK 01 12 23 41		KK 01 16 97 31		KK 01 23 19 39		KK 01 28 13 35		KK 01 30 85 45		KK 01 33 46 7	
KK 01 01 49 37		KK 01 06 50 33		KK 01 12 23 43		KK 01 16 97 33		KK 01 23 23 37		KK 01 28 25 35		KK 01 31 00 47		KK 01 33 46 9	
KK 01 01 49 39		KK 01 06 55 31		KK 01 12 28 47		KK 01 17 50 23		KK 01 23 23 39		KK 01 29 06 27		KK 01 31 00 49		KK 01 33 61 11	
KK 01 01 55 11		KK 01 07 00 29		KK 01 12 52 31		KK 01 17 50 25		KK 01 23 24 37		KK 01 29 11 49		KK 01 31 02 47		KK 01 33 61 13	
KK 01 01 55 13		KK 01 07 00 31		KK 01 12 59 23		KK 01 18 24 41		KK 01 23 24 39		KK 01 29 13 19		KK 01 31 02 49		KK 01 33 61 17	
KK 01 01 55 17		KK 01 07 00 33		KK 01 12 59 25		KK 01 18 66 23		KK 01 23 74 37		KK 01 29 16 49		KK 01 31 03 47		KK 01 33 61 7	
KK 01 01 55 7		KK 01 07 00 47		KK 01 12 61 41		KK 01 18 66 25		KK 01 23 74 39		KK 01 29 19 13		KK 01 31 03 49		KK 01 33 85 11	
KK 01 01 56 11		KK 01 07 00 49		KK 01 12 61 43		KK 01 18 76 41		KK 01 23 75 37		KK 01 29 19 49		KK 01 31 04 47		KK 01 33 85 13	
KK 01 01 56 13		KK 01 08 18 25		KK 01 12 62 31		KK 01 18 99 43		KK 01 25 08 37		KK 01 29 19 5		KK 01 31 04 49		KK 01 33 85 17	
KK 01 01 56 17		KK 01 08 51 29		KK 01 12 66 23		KK 01 18 99 45		KK 01 25 08 39		KK 01 29 19 9		KK 01 31 05 47		KK 01 33 85 7	
KK 01 01 56 7		KK 01 09 06 47		KK 01 12 66 25		KK 01 19 12 41		KK 01 25 09 37		KK 01 29 22 13		KK 01 31 05 49		KK 01 35 00 37	
KK 01 01 57 29		KK 01 09 07 33		KK 01 13 03 47		KK 01 19 12 43		KK 01 25 09 39		KK 01 29 22 15		KK 01 31 06 47		KK 01 35 00 39	
KK 01 01 58 31		KK 01 09 09 25		KK 01 13 03 49		KK 01 19 12 45		KK 01 25 47 37		KK 01 29 22 5		KK 01 31 08 49		KK 01 35 01 37	
KK 01 02 55 47		KK 01 09 09 33		KK 01 13 05 47		KK 01 19 18 41		KK 01 25 48 37		KK 01 29 22 9		KK 01 31 09 49		KK 01 35 01 39	
KK 01 02 55 49		KK 01 09 58 31		KK 01 13 05 49		KK 01 19 51 41		KK 01 25 48 39		KK 01 29 27 5		KK 01 31 10 49		KK 01 35 29 37	
KK 01 02 93 31		KK 01 10 20 37		KK 01 13 46 47		KK 01 19 51 43		KK 01 25 77 37		KK 01 29 27 9		KK 01 32 28 11		KK 01 35 29 39	
KK 01 03 15 33		KK 01 10 20 39		KK 01 13 46 49		KK 01 19 51 45		KK 01 25 77 39		KK 01 29 29 11		KK 01 32 28 13		KK 01 35 31 37	
KK 01 03 15 53		KK 01 10 20 53		KK 01 13 49 47		KK 01 20 56 37		KK 01 26 71 37		KK 01 29 29 13		KK 01 32 28 13		KK 01 35 31 39	
KK 01 03 19 37		KK 01 10 21 37		KK 01 13 49 49		KK 01 20 56 39		KK 01 26 71 39		KK 01 29 29 17		KK 01 32 28 15		KK 01 36 80 37	
KK 01 03 19 39		KK 01 10 21 39		KK 01 13 79 47		KK 01 20 59 37		KK 01 26 77 39		KK 01 29 29 7		KK 01 32 28 17		KK 01 36 80 39	
KK 01 03 28 35		KK 01 10 35 47		KK 01 13 79 49		KK 01 20 59 39		KK 01 27 07 37		KK 01 29 31 49		KK 01 32 28 7		KK 01 37 00 49	
KK 01 03 28 37		KK 01 10 35 49		KK 01 14 01 47		KK 01 20 62 37		KK 01 27 07 39		KK 01 29 34 47		KK 01 32 28 9		KK 01 37 02 47	
KK 01 03 28 39		KK 01 10 37 19		KK 01 14 01 49		KK 01 20 62 39		KK 01 27 23 39		KK 01 29 34 49		KK 01 32 34 13		KK 01 37 10 31	
KK 01 03 45 29		KK 01 10 42 19		KK 01 14 02 49		KK 01 20 78 37		KK 01 27 34 37		KK 01 29 40 33		KK 01 32 34 5		KK 01 37 50 31	
KK 01 03 71 31		KK 01 10 48 47		KK 01 14 19 47		KK 01 20 78 39		KK 01 27 34 39		KK 01 29 42 31		KK 01 32 34 9		KK 01 58 13 15	
KK 01 03 72 31		KK 01 10 48 49		KK 01 14 19 49		KK 01 20 80 37		KK 01 27 35 37		KK 01 29 55 49		KK 01 33 32 13		KK 01 58 13 15	
KK 01 03 73 31		KK 01 10 52 47		KK 01 15 85 37		KK 01 20 80 39		KK 01 27 35 39		KK 01 29 56 49		KK 01 33 32 15		KK 01 58 16 27	
KK 01 05 17 47		KK 01 10 52 49		KK 01 15 85 39		KK 01 20 80 39		KK 01 27 40 37		KK 01 29 60 25		KK 01 33 32 5		KK 01 58 17 15	
KK 01 05 17 49		KK 01 11 22 31		KK 01 15 96 37		KK 01 20 84 39		KK 01 27 42 39		KK 01 29 63 29		KK 01 33 32 9		KK 01 58 17 15	
KK 01 05 32 23		KK 01 11 57 47		KK 01 15 96 39		KK 01 21 21 37		KK 01 27 73 37		KK 01 29 68 31		KK 01 33 32 9		KK 01 58 17 15	
KK 01 05 32 25		KK 01 11 57 49		KK 01 16 14 53		KK 01 21 58 37		KK 01 27 73 39		KK 01 29 68 33		KK 01 33 33 13		KK 01 58 17 15	
KK 01 05 72 23		KK 01 11 68 47		KK 01 16 15 53		KK 01 21 58 39		KK 01 27 78 37		KK 01 29 78 31		KK 01 33 33 7		KK 01 58 17 15	
KK 01 05 72 25		KK 01 11 68 49		KK 01 16 33 47		KK 01 22 61 37		KK 01 27 78 39		KK 01 30 04 47		KK 01 33 33 9		KK 01 58 17 17	
KK 01 05 88 31		KK 01 12 00 47		KK 01 16 36 49		KK 01 22 61 39		KK 01 27 85 37		KK 01 30 04 49		KK 01 33 46 11		KK 01 58 17 23	
KK 01 05 89 47		KK 01 12 00 49		KK 01 16 41 31		KK 01 22 64 37		KK 01 27 85 39		KK 01 30 05 53		KK 01 33 46 13		KK 01 58 25 15	
KK 01 05 91 47		KK 01 12 15 47		KK 01 16 41 33		KK 01 22 67 37		KK 01 27 92 37		KK 01 30 66 41		KK 01 33 46 17		KK 01 58 25 15	

Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page
KK 01 58 25	15	KK 01 65 25	45	KK 03 27 25	9	KK 03 27 75	17	KK 03 28 60	35	KK 03 31 18	13	KK 03 50 25	33	KK 06 16 99	33
KK 01 58 25	17	KK 01 65 39	45	KK 03 27 27	53	KK 03 27 75	25	KK 03 28 65	21	KK 03 31 19	13	KK 03 50 31	23	KK 06 18 99	47
KK 01 58 25	17	KK 01 65 40	43	KK 03 27 30	13	KK 03 27 75	49	KK 03 28 65	47	KK 03 31 74	13	KK 03 50 48	21	KK 06 18 99	53
KK 01 58 25	17	KK 01 65 41	43	KK 03 27 35	13	KK 03 27 75	7	KK 03 28 70	29	KK 03 31 75	15	KK 03 50 60	21	KK 06 20 20	21
KK 01 58 25	27	KK 02 97 27	19	KK 03 27 35	35	KK 03 27 85	47	KK 03 28 80	25	KK 03 31 75	5	KK 03 50 72	21	KK 06 20 25	13
KK 01 58 30	23	KK 02 97 27	19	KK 03 27 35	35	KK 03 27 95	27	KK 03 28 80	33	KK 03 31 75	9	KK 03 51 65	19	KK 06 20 25	9
KK 01 58 30	23	KK 02 99 18	31	KK 03 27 35	5	KK 03 28 03	21	KK 03 28 85	25	KK 03 32 51	13	KK 03 52 09	19	KK 06 30 90	11
KK 01 58 30	35	KK 02 99 18	41	KK 03 27 35	9	KK 03 28 05	29	KK 03 28 85	35	KK 03 32 51	15	KK 03 52 15	21	KK 06 30 90	13
KK 01 58 32	5	KK 02 99 18	43	KK 03 27 40	11	KK 03 28 05	31	KK 03 28 90	47	KK 03 32 51	5	KK 03 52 16	21	KK 06 30 90	13
KK 01 58 34	13	KK 02 99 20	19	KK 03 27 40	13	KK 03 28 07	21	KK 03 28 90	49	KK 03 32 51	9	KK 05 07 06	19	KK 06 30 90	15
KK 01 58 34	9	KK 02 99 20	23	KK 03 27 40	17	KK 03 28 07	29	KK 03 28 92	35	KK 03 32 56	13	KK 05 30 90	11	KK 06 30 90	17
KK 01 58 41	27	KK 02 99 20	25	KK 03 27 40	35	KK 03 28 07	49	KK 03 28 95	35	KK 03 32 56	15	KK 05 30 90	13	KK 06 30 90	5
KK 01 60 00	47	KK 02 99 20	31	KK 03 27 40	49	KK 03 28 13	35	KK 03 29 20	53	KK 03 32 56	5	KK 05 30 90	13	KK 06 30 90	7
KK 01 60 00	47	KK 02 99 20	33	KK 03 27 40	7	KK 03 28 22	35	KK 03 29 23	33	KK 03 32 56	9	KK 05 30 90	15	KK 06 30 90	9
KK 01 60 00	49	KK 02 99 20	47	KK 03 27 45	33	KK 03 28 22	53	KK 03 29 25	35	KK 03 32 86	13	KK 05 30 90	17	KK 06 30 91	15
KK 01 60 01	49	KK 02 99 20	49	KK 03 27 45	49	KK 03 28 24	21	KK 03 29 25	53	KK 03 32 86	15	KK 05 30 90	5	KK 06 30 91	5
KK 01 60 04	23	KK 02 99 32	49	KK 03 27 50	11	KK 03 28 24	35	KK 03 29 26	35	KK 03 32 86	5	KK 05 30 90	7	KK 06 30 92	15
KK 01 60 06	35	KK 03 10 30	25	KK 03 27 50	13	KK 03 28 30	23	KK 03 29 29	25	KK 03 32 86	9	KK 05 30 90	9	KK 06 30 92	5
KK 01 60 12	35	KK 03 20 01	41	KK 03 27 50	15	KK 03 28 30	47	KK 03 29 34	25	KK 03 32 95	13	KK 05 33 87	13	KK 06 33 88	13
KK 01 60 12	49	KK 03 20 08	41	KK 03 27 50	17	KK 03 28 36	53	KK 03 29 56	29	KK 03 32 95	15	KK 05 33 87	5	KK 06 33 88	5
KK 01 60 13	15	KK 03 20 40	45	KK 03 27 50	25	KK 03 28 40	19	KK 03 29 80	49	KK 03 32 95	5	KK 05 33 87	9	KK 06 33 88	9
KK 01 60 13	33	KK 03 20 51	31	KK 03 27 50	7	KK 03 28 40	21	KK 03 29 80	49	KK 03 32 95	9	KK 05 68 73	27	KK 06 36 07	7
KK 01 60 15	11	KK 03 23 90	49	KK 03 27 50	9	KK 03 28 40	21	KK 03 30 04	13	KK 03 33 21	37	KK 05 70 63	19	KK 06 36 07	9
KK 01 60 15	13	KK 03 24 50	37	KK 03 27 52	33	KK 03 28 40	23	KK 03 30 06	15	KK 03 33 21	39	KK 05 70 64	19	KK 06 38 01	5
KK 01 60 15	15	KK 03 24 50	39	KK 03 27 60	35	KK 03 28 40	31	KK 03 30 06	27	KK 03 33 32	5	KK 05 70 65	19	KK 06 38 01	5
KK 01 60 15	17	KK 03 26 02	31	KK 03 27 60	47	KK 03 28 40	35	KK 03 30 07	27	KK 03 35 16	37	KK 05 70 66	19	KK 06 40 24	49
KK 01 60 15	7	KK 03 26 40	49	KK 03 27 62	21	KK 03 28 45	21	KK 03 30 16	15	KK 03 35 16	39	KK 05 70 67	19	KK 06 40 30	49
KK 01 60 18	49	KK 03 26 55	19	KK 03 27 65	11	KK 03 28 45	21	KK 03 31 00	13	KK 03 35 25	37	KK 05 70 68	19	KK 06 40 47	51
KK 01 60 22	21	KK 03 26 65	19	KK 03 27 65	13	KK 03 28 45	47	KK 03 31 00	5	KK 03 35 25	39	KK 05 70 89	19	KK 06 40 79	49
KK 01 60 25	47	KK 03 26 65	49	KK 03 27 65	17	KK 03 28 50	21	KK 03 31 00	9	KK 03 35 40	23	KK 06 01 08	19	KK 06 40 86	49
KK 01 60 31	23	KK 03 27 02	25	KK 03 27 65	49	KK 03 28 50	33	KK 03 31 07	15	KK 03 36 30	31	KK 06 01 09	19	KK 06 40 89	49
KK 01 60 38	49	KK 03 27 10	35	KK 03 27 65	53	KK 03 28 50	49	KK 03 31 07	5	KK 03 42 25	27	KK 06 01 19	19	KK 06 40 97	49
KK 01 60 45	21	KK 03 27 16	53	KK 03 27 65	7	KK 03 28 55	19	KK 03 31 07	9	KK 03 42 28	27	KK 06 06 57	27	KK 06 61 70	23
KK 01 60 49	21	KK 03 27 19	53	KK 03 27 70	25	KK 03 28 55	29	KK 03 31 07	9	KK 03 42 50	27	KK 06 07 03	19	KK 06 61 75	23
KK 01 60 50	25	KK 03 27 25	31	KK 03 27 70	49	KK 03 28 60	19	KK 03 31 11	15	KK 03 44 46	27	KK 06 12 80	19	KK 06 61 78	23
KK 01 60 58	25	KK 03 27 25	35	KK 03 27 75	11	KK 03 28 60	21	KK 03 31 16	15	KK 03 50 20	19	KK 06 12 91	19	KK 06 61 82	23
KK 01 65 24	45	KK 03 27 25	5	KK 03 27 75	13	KK 03 28 60	21	KK 03 31 17	15	KK 03 50 21	19	KK 06 15 15	21	KK 06 61 89	23

Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page
KK 06 61 90	23	KK 07 03 95	5	KK 07 16 72	33	KK 07 30 41	5	KK 07 30 81	15	KK 07 32 57	5	KK 07 33 50	13	KK 07 36 15	5
KK 06 68 11	27	KK 07 03 96	9	KK 07 17 10	35	KK 07 30 42	15	KK 07 30 81	9	KK 07 32 60	5	KK 07 33 51	13	KK 07 36 15	9
KK 06 68 11	27	KK 07 03 97	9	KK 07 17 11	33	KK 07 30 42	5	KK 07 30 88	13	KK 07 32 61	5	KK 07 33 52	13	KK 07 36 16	13
KK 06 68 12	27	KK 07 03 98	9	KK 07 17 12	33	KK 07 30 43	15	KK 07 30 88	15	KK 07 32 63	5	KK 07 33 53	13	KK 07 36 16	15
KK 06 68 61	27	KK 07 03 99	9	KK 07 17 13	33	KK 07 30 43	5	KK 07 30 88	5	KK 07 32 64	5	KK 07 33 54	13	KK 07 36 16	5
KK 06 68 68	27	KK 07 06 39	27	KK 07 17 14	33	KK 07 30 44	15	KK 07 30 88	9	KK 07 32 66	5	KK 07 34 06	5	KK 07 36 16	9
KK 06 68 69	27	KK 07 06 40	5	KK 07 17 15	33	KK 07 30 44	5	KK 07 30 89	13	KK 07 32 66	9	KK 07 34 07	5	KK 07 36 34	11
KK 06 68 73	27	KK 07 06 40	9	KK 07 17 93	29	KK 07 30 45	15	KK 07 30 89	15	KK 07 32 67	5	KK 07 34 11	5	KK 07 36 34	13
KK 06 68 80	27	KK 07 06 41	5	KK 07 17 94	29	KK 07 30 45	5	KK 07 30 89	5	KK 07 32 67	9	KK 07 34 12	5	KK 07 36 34	17
KK 06 68 81	27	KK 07 06 41	9	KK 07 17 94	37	KK 07 30 54	13	KK 07 30 89	9	KK 07 32 72	13	KK 07 34 14	5	KK 07 36 34	7
KK 06 70 16	19	KK 07 06 42	5	KK 07 17 94	39	KK 07 30 54	15	KK 07 30 91	13	KK 07 32 73	13	KK 07 34 15	5	KK 07 36 35	11
KK 06 70 25	19	KK 07 06 42	9	KK 07 18 26	33	KK 07 30 54	9	KK 07 30 91	15	KK 07 32 75	13	KK 07 34 17	9	KK 07 36 35	13
KK 06 70 26	19	KK 07 06 53	27	KK 07 18 27	33	KK 07 30 55	13	KK 07 30 91	5	KK 07 32 76	13	KK 07 34 18	9	KK 07 36 35	17
KK 06 70 31	19	KK 07 08 05	53	KK 07 18 53	33	KK 07 30 55	15	KK 07 30 91	9	KK 07 32 78	13	KK 07 34 35	9	KK 07 36 35	7
KK 06 70 31	31	KK 07 08 07	35	KK 07 21 67	33	KK 07 30 55	9	KK 07 30 92	13	KK 07 32 79	13	KK 07 34 36	9	KK 07 38 00	13
KK 06 70 39	19	KK 07 12 07	21	KK 07 21 73	33	KK 07 30 56	13	KK 07 30 92	15	KK 07 32 80	5	KK 07 34 40	9	KK 07 38 00	5
KK 06 70 40	19	KK 07 12 08	21	KK 07 30 00	5	KK 07 30 56	15	KK 07 30 92	5	KK 07 32 81	5	KK 07 34 41	9	KK 07 38 00	9
KK 06 70 51	19	KK 07 12 09	21	KK 07 30 01	5	KK 07 30 56	9	KK 07 30 92	9	KK 07 32 86	5	KK 07 34 64	13	KK 07 38 01	13
KK 06 70 57	19	KK 07 12 11	21	KK 07 30 02	15	KK 07 30 57	13	KK 07 32 24	9	KK 07 32 87	5	KK 07 34 65	13	KK 07 38 01	5
KK 06 70 59	19	KK 07 12 12	21	KK 07 30 02	5	KK 07 30 57	15	KK 07 32 25	9	KK 07 32 90	5	KK 07 34 70	13	KK 07 38 01	9
KK 06 70 60	19	KK 07 12 28	21	KK 07 30 03	15	KK 07 30 57	9	KK 07 32 27	9	KK 07 32 90	9	KK 07 34 71	13	KK 07 38 03	5
KK 06 70 68	19	KK 07 12 55	33	KK 07 30 03	5	KK 07 30 62	13	KK 07 32 28	9	KK 07 32 91	5	KK 07 36 07	7	KK 07 38 03	5
KK 06 70 70	19	KK 07 12 70	21	KK 07 30 04	15	KK 07 30 62	15	KK 07 32 30	15	KK 07 32 91	9	KK 07 36 07	9	KK 07 38 04	9
KK 06 70 75	19	KK 07 12 71	21	KK 07 30 04	5	KK 07 30 62	9	KK 07 32 30	9	KK 07 33 00	15	KK 07 36 08	13	KK 07 38 04	9
KK 06 70 76	19	KK 07 12 72	21	KK 07 30 05	15	KK 07 30 63	13	KK 07 32 31	15	KK 07 33 00	5	KK 07 36 08	15	KK 07 38 05	9
KK 06 70 77	19	KK 07 12 73	21	KK 07 30 05	5	KK 07 30 63	15	KK 07 32 31	9	KK 07 33 00	9	KK 07 36 08	5	KK 07 38 07	5
KK 06 70 80	19	KK 07 12 74	21	KK 07 30 06	15	KK 07 30 63	9	KK 07 32 36	9	KK 07 33 01	15	KK 07 36 08	9	KK 07 38 08	5
KK 06 70 90	19	KK 07 12 75	21	KK 07 30 06	5	KK 07 30 64	13	KK 07 32 37	9	KK 07 33 01	5	KK 07 36 09	13	KK 07 38 26	13
KK 06 70 92	19	KK 07 12 80	21	KK 07 30 07	15	KK 07 30 64	15	KK 07 32 39	9	KK 07 33 01	9	KK 07 36 09	15	KK 07 38 26	9
KK 06 82 51	53	KK 07 12 81	21	KK 07 30 07	5	KK 07 30 64	9	KK 07 32 40	9	KK 07 33 10	5	KK 07 36 09	5	KK 07 38 26	9
KK 07 03 88	9	KK 07 14 03	33	KK 07 30 08	5	KK 07 30 65	13	KK 07 32 41	9	KK 07 33 10	9	KK 07 36 09	9	KK 07 38 29	13
KK 07 03 89	9	KK 07 14 17	33	KK 07 30 09	5	KK 07 30 65	15	KK 07 32 42	9	KK 07 33 11	5	KK 07 36 14	13	KK 07 38 29	9
KK 07 03 90	5	KK 07 14 92	33	KK 07 30 30	15	KK 07 30 65	9	KK 07 32 50	5	KK 07 33 11	9	KK 07 36 14	15	KK 07 38 30	5
KK 07 03 91	5	KK 07 14 95	33	KK 07 30 30	5	KK 07 30 80	13	KK 07 32 51	5	KK 07 33 28	13	KK 07 36 14	7	KK 07 38 31	5
KK 07 03 92	9	KK 07 15 08	21	KK 07 30 31	15	KK 07 30 80	15	KK 07 32 56	15	KK 07 33 29	13	KK 07 36 14	9	KK 07 38 31	9
KK 07 03 93	9	KK 07 15 29	21	KK 07 30 31	5	KK 07 30 80	9	KK 07 32 56	5	KK 07 33 38	13	KK 07 36 15	13	KK 07 38 42	9
KK 07 03 94	5	KK 07 16 70	33	KK 07 30 40	5	KK 07 30 81	13	KK 07 32 57	15	KK 07 33 39	13	KK 07 36 15	15	KK 07 40 80	49

Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page
KK 07 40 93	49	KK 07 48 90	53	KK 07 68 58	27	KK 08 14 96	31	KK 08 22 58	33	KK 08 32 17	15	KK 08 40 13	51	KK 08 41 12	47
KK 07 43 19	35	KK 07 48 91	53	KK 07 68 58	27	KK 08 14 99	31	KK 08 22 59	33	KK 08 32 18	15	KK 08 40 15	47	KK 08 41 13	47
KK 07 43 95	29	KK 07 48 93	49	KK 07 68 59	27	KK 08 15 33	31	KK 08 22 60	33	KK 08 32 20	15	KK 08 40 16	47	KK 08 50 76	27
KK 07 43 97	29	KK 07 49 10	21	KK 07 68 72	27	KK 08 15 49	33	KK 08 22 61	33	KK 08 32 21	15	KK 08 40 18	47	KK 08 60 80	23
KK 07 45 73	31	KK 07 49 11	21	KK 07 69 43	27	KK 08 15 78	33	KK 08 22 62	33	KK 08 32 22	15	KK 08 40 19	47	KK 08 60 81	23
KK 07 46 24	49	KK 07 49 70	53	KK 07 69 44	27	KK 08 15 79	33	KK 08 22 63	33	KK 08 32 23	15	KK 08 40 40	49	KK 08 60 82	23
KK 07 48 35	49	KK 07 49 71	53	KK 07 70 23	21	KK 08 16 22	35	KK 08 22 64	33	KK 08 32 24	15	KK 08 40 42	53	KK 08 60 83	23
KK 07 48 36	49	KK 07 60 76	25	KK 07 70 24	21	KK 08 16 24	33	KK 08 22 65	33	KK 08 32 28	5	KK 08 40 43	49	KK 08 60 84	23
KK 07 48 38	49	KK 07 64 00	25	KK 07 90 63	49	KK 08 20 09	31	KK 08 22 66	33	KK 08 32 29	5	KK 08 40 45	47	KK 08 60 85	23
KK 07 48 39	49	KK 07 64 06	23	KK 07 95 96	35	KK 08 20 46	31	KK 08 22 68	33	KK 08 32 35	15	KK 08 40 50	47	KK 08 60 86	25
KK 07 48 41	49	KK 07 64 06	25	KK 08 01 87	35	KK 08 22 00	31	KK 08 22 80	33	KK 08 32 35	7	KK 08 40 55	47	KK 08 60 87	25
KK 07 48 43	49	KK 07 64 07	23	KK 08 14 10	31	KK 08 22 11	33	KK 08 22 81	33	KK 08 33 00	15	KK 08 40 61	47	KK 08 60 89	23
KK 07 48 44	49	KK 07 64 07	25	KK 08 14 30	31	KK 08 22 12	33	KK 08 22 82	33	KK 08 33 01	15	KK 08 40 62	47	KK 08 60 90	23
KK 07 48 46	53	KK 07 64 09	23	KK 08 14 31	31	KK 08 22 13	33	KK 08 22 83	33	KK 08 34 06	15	KK 08 40 65	47	KK 08 61 00	25
KK 07 48 50	49	KK 07 64 09	25	KK 08 14 32	31	KK 08 22 14	33	KK 08 22 84	33	KK 08 34 07	15	KK 08 40 66	47	KK 08 61 01	23
KK 07 48 56	49	KK 07 64 10	23	KK 08 14 33	31	KK 08 22 15	33	KK 08 22 85	33	KK 08 34 08	15	KK 08 40 67	47	KK 08 61 01	25
KK 07 48 62	49	KK 07 64 10	25	KK 08 14 34	31	KK 08 22 28	33	KK 08 22 95	33	KK 08 34 09	15	KK 08 40 69	47	KK 08 61 10	23
KK 07 48 64	49	KK 07 64 27	25	KK 08 14 37	31	KK 08 22 29	33	KK 08 22 96	33	KK 08 34 15	15	KK 08 40 70	47	KK 08 61 11	23
KK 07 48 65	49	KK 07 64 99	23	KK 08 14 39	29	KK 08 22 34	33	KK 08 25 06	33	KK 08 34 16	15	KK 08 40 77	47	KK 08 61 12	23
KK 07 48 66	49	KK 07 64 99	25	KK 08 14 40	29	KK 08 22 35	31	KK 08 25 21	33	KK 08 34 17	15	KK 08 40 80	47	KK 08 61 13	23
KK 07 48 67	49	KK 07 65 15	25	KK 08 14 42	29	KK 08 22 36	33	KK 08 25 22	33	KK 08 34 18	15	KK 08 40 81	47	KK 08 61 14	23
KK 07 48 70	49	KK 07 65 17	25	KK 08 14 43	29	KK 08 22 37	33	KK 08 25 24	33	KK 08 38 02	15	KK 08 40 84	53	KK 08 61 15	23
KK 07 48 73	49	KK 07 65 18	25	KK 08 14 49	29	KK 08 22 38	33	KK 08 25 25	33	KK 08 38 03	15	KK 08 40 90	47	KK 08 68 01	27
KK 07 48 74	31	KK 07 65 27	25	KK 08 14 50	31	KK 08 22 39	33	KK 08 25 26	33	KK 08 38 04	15	KK 08 40 91	47	KK 08 80 63	47
KK 07 48 74	49	KK 07 65 32	25	KK 08 14 52	29	KK 08 22 40	33	KK 08 25 28	33	KK 08 38 05	15	KK 08 40 92	47	KK 10 68 63	49
KK 07 48 75	49	KK 07 65 33	25	KK 08 14 53	29	KK 08 22 42	33	KK 08 25 29	33	KK 08 38 06	15	KK 08 40 93	47	KK 30 90 29	37
KK 07 48 76	49	KK 07 65 37	25	KK 08 14 55	31	KK 08 22 45	33	KK 08 26 30	35	KK 08 38 07	15	KK 08 41 00	51	KK 30 90 29	39
KK 07 48 80	53	KK 07 65 75	25	KK 08 14 57	31	KK 08 22 48	33	KK 08 26 46	35	KK 08 38 08	15	KK 08 41 01	51	KK 31 00 75	33
KK 07 48 81	53	KK 07 65 77	25	KK 08 14 58	31	KK 08 22 49	33	KK 08 26 47	35	KK 08 38 09	5	KK 08 41 02	47	KK 35 11 39	33
KK 07 48 82	53	KK 07 68 12	27	KK 08 14 59	31	KK 08 22 50	33	KK 08 26 48	35	KK 08 38 10	5	KK 08 41 03	47	KK 35 22 47	37
KK 07 48 84	53	KK 07 68 13	27	KK 08 14 61	29	KK 08 22 51	33	KK 08 32 10	15	KK 08 40 00	51	KK 08 41 04	47	KK 35 22 47	39
KK 07 48 85	53	KK 07 68 17	27	KK 08 14 67	31	KK 08 22 52	33	KK 08 32 11	15	KK 08 40 01	51	KK 08 41 06	47	KK 35 35 85	45
KK 07 48 86	49	KK 07 68 18	27	KK 08 14 79	31	KK 08 22 53	33	KK 08 32 12	15	KK 08 40 02	51	KK 08 41 06	49	KK 35 36 10	43
KK 07 48 86	53	KK 07 68 25	27	KK 08 14 80	31	KK 08 22 55	33	KK 08 32 13	15	KK 08 40 03	51	KK 08 41 07	47	KK 35 36 30	49
KK 07 48 87	53	KK 07 68 26	27	KK 08 14 81	37	KK 08 22 56	33	KK 08 32 14	15	KK 08 40 10	51	KK 08 41 07	49	KK 35 36 47	43
KK 07 48 88	53	KK 07 68 33	27	KK 08 14 81	39	KK 08 22 56	33	KK 08 32 15	15	KK 08 40 11	51	KK 08 41 10	49	KK 35 36 48	43
KK 07 48 89	53	KK 07 68 34	27	KK 08 14 95	31	KK 08 22 57	33	KK 08 32 16	15	KK 08 40 12	51	KK 08 41 11	49	KK 35 36 49	43

Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page
KK 35 36 64	41	KK 35 36 73	41	KK 35 36 89	45	KK 35 36 92	45	KK 35 36 98	43	KK 70 92 34	55	KK 70 98 42	55	KK 70 99 86	55
KK 35 36 65	37	KK 35 36 73	43	KK 35 36 91	37	KK 35 36 93	45	KK 35 36 99	43	KK 70 94 79	55	KK 70 98 43	55	KK 70 99 87	55
KK 35 36 65	39	KK 35 36 75	41	KK 35 36 91	39	KK 35 36 94	45	KK 35 38 28	43	KK 70 97 37	55	KK 70 98 44	55	KK 71 99 11	55
KK 35 36 65	41	KK 35 36 78	41	KK 35 36 91	43	KK 35 36 95	45	KK 35 38 29	43	KK 70 98 23	55	KK 70 98 95	55	KK 80 60 90	25
KK 35 36 71	41	KK 35 36 79	41	KK 35 36 92	37	KK 35 36 96	45	KK 35 60 42	31	KK 70 98 31	55	KK 70 99 84	55	UH 87 20 82	43
KK 35 36 72	41	KK 35 36 89	43	KK 35 36 92	39	KK 35 36 97	45	KK 35 60 42	49	KK 70 98 41	55	KK 70 99 85	55		



Замовлення запчастин
(050)-407-68-47
(050)-407-68-45