


Spare Part List

Model LF-LM




Замовлення запчастин
(050)-407-68-47
(050)-407-68-45



243A

243A



Plough bodies no. 6, 7, 8 and 9
For reversible Plough mod. LF-LM


Ill. no.	Part no.	Description
1	07 30 00	Share 12" for reversible point R.H.
	07 30 01	Share 12" for reversible point L.H.
	07 30 02	Share 14" for reversible point R.H.
	07 30 03	Share 14" for reversible point L.H.
	07 30 04	Share 16" for reversible point R.H.
	07 30 05	Share 16" for reversible point L.H.
	07 30 06	Share 18" for reversible point R.H.
	07 30 07	Share 18" for reversible point L.H.
	07 30 08	Share 20" for reversible point R.H.
	07 30 09	Share 20" for reversible point L.H.
	05 30 90	Reversible point R.H.
	06 30 90	Reversible point L.H.
	07 34 11	Saddle R.H.
	07 34 12	Saddle L.H.
	01 33 32	Bolt M14x32mm w/nut
	03 31 07	Bolt M12x35mm w/nut
	07 32 60	Mouldboard 12"-16" no. 6 R.H.
	07 32 61	Mouldboard 12"-16" no. 6 L.H.
	07 32 63	Mouldboard 12"-14" no. 7 R.H.
	07 32 64	Mouldboard 12"-14" no. 7 L.H.
	07 32 80	Mouldboard 12" no. 8 R.H.
	07 32 81	Mouldboard 12" no. 8 L.H.
	07 32 86	Mouldboard 14"-18" no. 8 R.H.
	07 32 87	Mouldboard 14"-18" no. 8 L.H.
	07 32 90	Mouldboard 14"-20" no. 9 R.H.
	07 32 91	Mouldboard 14"-20" no. 9 L.H.
	03 31 00	Bolt M12x30mm w/nut
	01 32 28	Bolt M12x32mm w/nut
	01 32 34	Bolt M12x38mm w/nut
	07 32 50	Shinpiece no. 7 and 8 R.H.
	07 32 51	Shinpiece no. 7 and 8 L.H.
	07 32 56	Shinpiece no. 6 and 9 R.H.
	07 32 57	Shinpiece no. 6 and 9 L.H.


243A

243A

Plough bodies no. 6, 7, 8 and 9
For reversible Plough mod. LF-LM

Ill. no.	Part no.	Description
11	07 32 54	Bracket R.H.
12	07 32 55	Bracket L.H.
13	03 27 35	Bolt M16x35mm w/nut
14	07 38 03	Stay
15	07 36 00	Landside short R.H.
16	07 36 01	Landside short L.H.
17	01 58 32	Nut M20
18	01 38 00	Bracket for stay L.H.
19	07 38 01	Washer D ø 12 T 3,2
20	05 33 87	Mouldboard extension (Extras)
21	06 33 88	Mouldboard extension (Extras)
22	03 19 80	Bolt M16x80mm w/nut
23	07 33 10	Bracket R.H.
24	07 33 11	Bracket L.H.
25	07 33 00	Trashboard R.H.
26	07 33 01	Trashboard L.H.
	07 06 40	Trashboard cpl. R.H.
	07 06 41	Trashboard cpl. L.H.
	07 06 42	Trashboard cpl. R.H. and L.H.
	07 30 91	Share-knife R.H.
	07 30 92	Share-knife L.H.
	07 30 20	Share 12" R.H.
	07 30 21	Share 12" L.H.
	07 30 22	Share 14" R.H.
	07 30 23	Share 14" L.H.
	07 30 24	Share 16" R.H.
	07 30 25	Share 16" L.H.
	07 34 14	Bracket R.H. for 16" share only
	07 34 15	Bracket L.H. for 16" share only
	07 32 66	Bracket R.H. for 16" for body no. 6 and 9)
	07 32 67	Bracket L.H. (For body no. 6 and 9)
	07 36 04	Landside long R.H.
	07 36 05	Landside long L.H.






Turn-over device


Ill. no.	Part no.	Description
1	06 21 53	Headstock
2	03 28 75	Bolt M20x75mm w/nut
3	01 06 06	Spanner (19-27)
4	01 06 27	Pin M12
5	01 07 00	Pin Ø25x53mm
6	01 03 15	Screw L.H.
7	35 11 40	Turnbuckle
8	35 11 44	Lock-nut
9	35 11 48	Screw R.H.
10	36 11 39	Turnbuckle cpl.
11	07 16 40	Main shaft
12	07 43 40	Plate
13	07 43 41	Bush
14	07 43 42	Bolt
15	01 58 30	Nut M20
16	07 04 58	Kit-lower cross-shaft cpl.
17	06 43 20	Cross-shaft cat. II L 935mm
18	06 43 21	Cross-shaft cat. III L 965mm
19	06 43 17	Collar
20	03 28 60	Bolt
21	07 02 16	Bolt M20x60mm w/nut
22	06 21 19	Screw with handle
23	07 16 52	Headstock
24	06 02 52	Washer
25	03 27 25	Pivot pin with bearing
26	02 99 20	Bolt M16x27mm
27	07 02 00	Grease-nipple
28	35 23 00	Turn-over device cpl.
29	01 03 28	Cylinder cpl. Ø50x200mm (ill. page 11)
30	06 19 42	Pin Ø25x78mm
31	03 25 45	Hoseholder
32	01 15 17	Bolt M10x45mm w/nut
33	01 15 67	Hose L 2800mm
	01 15 65	Threaded coupling
	01 21 14	Ring
		Quick coupling

Frame for mod. LF-LM



Ill. no.	Part no.	Description
1	03 27 10	Bolt M16x155mm w/nut
2	01 29 22	Washer
3	07 11 77	Tube 4 furrow mod. LF
	07 11 78	Tube 5 furrow mod. LF
	07 11 79	Tube 6 furrow mod. LF
	07 11 97	Tube 4 furrow mod. LM
	07 11 98	Tube 5 furrow mod. LM
	07 11 99	Tube 6 furrow mod. LM
4	07 16 72	Plate
5	07 16 14	Plate
6	03 28 13	Bolt M20x170mm w/nut
7	07 11 92	Main tube 4 furrow mod. LF
	07 11 93	Main tube 5 furrow mod. LF
	07 11 94	Main tube 6 furrow mod. LF
	07 11 95	Main tube 4 furrow mod. LM
	07 11 96	Main tube 5 furrow mod. LM
	07 11 97	Main tube 6 furrow mod. LM
8	07 90 68	Plate
9	01 07 00	Pin M12
10	01 00 08	Spacing tube
11	01 03 18	Pin Ø25x100mm
12	07 19 72	Steering arm mod. LF
	07 19 90	Steering arm mod. LM
13	07 40 15	Steering arm
14	07 40 17	Pin
15	01 29 42	Washer
16	03 27 70	Bolt M16x70mm w/nut
17	07 60 08	Pin
18	07 16 05	Slide rails
19	03 27 80	Bolt M16x80mm w/nut
20	06 21 60	Pivot pin
21	01 03 28	Pin
22	07 40 10	Cylinder bracket
23	01 07 04	Roll-pin Ø8x60mm
24	01 16 86	Bush
25	07 01 35	Main support w/bush 01 16 86
26	02 99 22	Grease nipple
27	07 19 50	Support
28	03 27 95	Bolt M16x95mm w/nut
29	06 18 41	Cylinder bracket

Frame for mod. LF-LM



Ill. no.	Part no.	Description
30	01 16 56	Bush
31	07 01 36	Main cross beam mod. LF
32	07 01 40	Main cross beam mod. LM
33	07 17 10	Bracket
34	07 17 13	Pin
35	03 27 45	Bolt M16x45mm
36	07 17 12	Bolt
37	07 17 11	Spring
38	07 17 14	Pin
39	07 17 15	Machine stand
40	01 10 18	Roll pin Ø10x40mm
41	01 60 13	Nut M14
42	01 58 35	Nut M20
43	03 27 30	Bolt M16x30mm
44	03 28 18	Bolt M20x180mm w/nut
	01 09 10	Plastic cover

Beam and rear parts mod. LF-LM



Ill. no.	Part no.	Description
1	07 15 28	Plate for beam 01 12 11
2	03 50 60	Shear-bolt
3	01 60 22	Nut M30
4	07 12 06	Centre beam for beam height 700mm
5	07 12 07	Centre beam for beam height 800mm
6	07 12 09	Beam L.H.
7	07 20 23	Main bolt M30x72mm
8	06 15 15	Bolt
9	07 14 13	Spacing-tube
10	01 58 41	Tapered bush, rear
11	03 27 60	Nut M24
12	07 40 50	Bolt M16x60mm w/nut
13	03 27 50	Wheel support
14	07 16 64	Bolt M16x50mm w/nut
15	07 16 90	Bush
16	03 27 02	Beam support
17	03 27 75	Bolt M16x75mm w/nut
18	07 60 35	Support for arm
19	07 60 38	Left bracket for disc-coupler, beam height 700mm
20	07 60 37	Left bracket for disc-coupler, beam height 800mm
21	07 60 30	Right bracket for disc-coupler, beam height 700mm
22	07 60 34	Right bracket for disc-coupler, beam height 800mm
23	07 60 35	Arm for disc-coupler
24	03 28 80	Plate
25	03 28 90	Bolt M20x80mm w/nut
26	06 20 20	Bolt M20x90mm w/nut
27	03 28 40	Washer
28	07 12 08	Bolt M20x40mm w/nut
29	03 41 22	Beam R.H.
30	07 18 53	Set screw M12x27mm
31	03 27 25	Pointer
32	07 14 10	Bolt M16x27mm
33	07 14 11	Tapered bush
34	07 14 12	Spacing-tube, outward
35	07 14 12	Spacing tube, inner
36	07 14 02	Spacing-tube cpl. (ill. 32 and 33)
37	07 01 32	Bolt
38	07 15 29	Indicator w/set screw
Not ill.	03 28 65	Plate for beam 07 12 12
	07 12 11	Bolt M20x65mm w/nut
	07 12 12	Beam cpl. H 700mm (ill. no. 2-6 and 27 mount.)
		Beam cpl. H 800mm (ill. no. 2-6 and 27 mount.)

Additional body mod. LF-LM



Ill. no.	Part no.	Description
1	07 17 03	Tube mod. LF
2	07 17 04	Tube mod. LM
3	03 28 45	Bolt M20x45mm w/nut
4	07 10 45	Plate, outer
5	07 10 47	Plate, inner
6	07 11 58	Fastening piece
7	03 27 02	Bolt M16x110mm w/nut
	07 11 72	Tube mod. LF
	07 11 73	Tube mod. LM




Замовлення запчастин

(050)-407-68447

(050)-407-6845

Hydraulic
width lock valve for furrow "singel variwidth adjustment"



Ill. no.	Part no.	Description
1	01 03 28	Pin Ø25x78mm
2	35 21 84	Cylinder Ø75x400mm (ill. page 13)
3	01 22 12	Hose L 900mm
4	01 15 67	Threaded coupling
5	01 15 65	Ring
6	03 50 10	Bolt M8x90mm w/nut
7	01 21 68	Change-over valve
8	01 15 11	Hose L 1250mm
9	03 25 45	Bolt M10x45mm w/nut
10	06 19 42	Hose-holder
11	07 16 86	Bracket for valve
12	01 15 17	Hose L 2800mm
13	01 07 00	Pin M12
14	35 19 41	Cylinder with lock-valve (ill. page 12)
15	01 03 18	Pin Ø25x100mm

АгровеР

Агро

Замовлення запчастин


(050) 407-68-47

(050) 407-68-45

187C


187C

Disc coulters with needle bearings



Ill. no.	Part no.	Description
1	03 13 40	Set-screw M8x40mm
2	05 61 56	Cap
3	01 07 75	O-ring
4	01 12 66	Circlip
5	05 61 12	Disc-coulter plain, bare 18"
6	05 61 14	Disc-coulter plain 20"
7	06 61 02	Bearing with needle
8	06 06 24	Bearing cpl.(comprising diag. no. 1, 3, 4 and 6-9
9	01 07 72	Rubber ring for bearing
10	06 61 08	Shaft Ø30mm w/01 12 92 mount.
11	02 99 20	Grease nipple M8x1mm
12	06 61 40	Stem for disc-coulter R.H. 18" H 700mm
13	07 61 08	Stem for disc-coulter R.H. 20" H 800mm
14	06 61 42	Stem for disc-coulter L.H. 18" H 700mm
15	07 61 09	Stem for disc-coulter L.H. 20" H 800mm
16	03 17 30	Bolt M20x30mm without nut
17	03 17 40	Bolt M20x40mm without nut for Excentric nut
18	06 61 70	Securing bracket
19	06 61 90	Stop journal
20	03 04 40	Bolt M12x40mm and nut
21	06 61 78	Excenter (From 01.05.82)
22	01 12 92	Ring (For shaft 06 61 08)

Hydraulic Cylinder BMV Ø 50 x 200 mm



Ill. no.	Part no.	Description
1	01 19 15	Packing
3	03 50 22	Bolt M10x50mm w/nut
4	35 22 60	Rod clevis
5	35 22 66	Piston rod with piston
6	01 15 73	Threaded coupling
7	01 21 02	Threaded coupling (1,0mm)
8	01 15 65	Ring
9	01 18 10	O-ring
10	35 22 58	Rod-cap
11	35 22 52	Clevis cap
12	35 22 80	Cylinder tube
13	35 22 90	Tie rod and nut
14	01 19 09	Packing
15	01 19 52	Scraper seal
16	01 15 94	Plug
	01 19 45	Packing set

237B

237B

Hydraulic Cylinder Ø 75




Ill. no.	Part no.	Description
1	01 21 03	Threaded coupling Ø1,4
2	35 21 61	Clevis cap
3	01 15 65	Ring
4	01 15 94	Plug
5	01 19 06	Packing
6	35 21 69	Piston rod
7	01 60 40	Nut
8	35 21 75	Rod clevis
9	01 19 11	Scraper seal
10	35 21 72	Rod cap
11	35 21 64	Tie rod w/nut Ø1,2
12	01 18 02	O-ring
13	35 21 66	Cylinder tube
14	01 19 50	Packing
15	01 21 02	Threaded coupling Ø1,0
16	01 21 80	Banjo coupling
17	01 21 46	Threaded coupling Ø1,0
18	01 21 77	Ring
19	01 15 67	Threaded coupling
20	01 15 92	Lock valve
21	01 21 47	Threaded coupling Ø1,4
Not ill.	01 19 40	Packing set Ø75
	35 23 72	Cylinder cpl. without lock valve
	35 19 41	Cylinder cpl. with lock valve

223A

223A

Hydraulic Cylinder Ø 75 x 400 mm




Ill. no.	Part no.	Description
1	01 19 06	Packing
4	35 21 87	Piston rod with piston
5	35 21 76	Rod clevis
6	35 21 61	Clevis cap
7	01 15 65	Washer
8	01 21 13	Plug
9	01 18 02	O-ring
10	35 21 72	Rod cap
11	01 19 50	Packing
12	01 19 11	Packing
13	35 21 86	Cylinder tube L 454mm
14	35 22 95	Tie-rod and nut
No ill.	01 19 40	Packing-set cpl. Ø75

АгровеР
Замовлення запчастин
(050)-407-68-47
(050)-407-68-45

Manure skimmer/Maize skimmer Mod. 1986

Ill. no.	Part no.	Description
2	03 42 28	Set-screw M16x32mm
4	07 06 39	Bracket w/set-screw 03 42 28(Mod. LB-LC, LD-LE, LG-LH, LF-LM)
5	03 42 28	Set-screw M16x32mm
9	07 68 17	Arm R.H. H 700mm(Mod. LB-LC, LD-LE, LG-LH, LF-LM)
	07 68 18	Arm L.H. H 700mm(Mod. LB-LC, LD-LE, LG-LH, LF-LM)
	07 68 25	Arm R.H. H 800mm(Mod. LB-LC, LD-LE, LG-LH, LF-LM)
	07 68 26	Arm L.H. H 800mm(Mod. LB-LC, LD-LE, LG-LH, LF-LM)
10	07 68 12	Maize mouldboard R.H.
	07 68 13	Maize mouldboard L.H.
11	06 68 80	Mouldboard R.H.
	06 68 81	Mouldboard L.H.
12	03 30 06	Bolt M10x30mm w/nut
13	05 68 73	Share short R.H.
	06 68 73	Share short L.H.
14	06 68 68	Share long R.H.
	06 68 69	Share long L.H.
15	01 29 06	Washer Ø25/10,5x3,4mm



Замовлення запчастин
(050)-407-68-47
(050)-407-68-45


Depth-Wheel mod. LF-LM

Ill. no.	Part no.	Description
1	01 11 57	End cap
2	01 60 10	Nut M16
3	01 29 27	Washer Ø34-17mm
4	01 12 00	Ball-bearing 6206
5	01 00 31	Spacing tube L 67,2mm
6	01 12 31	Ball-bearing 6305
7	01 08 06	Packing (Supplied as pair)
8	01 13 03	Rubber tyre LP200x14,5-6
	01 13 03	Rubber tyre LP26"-12x12
	01 13 05	Tube for LP200x14,5
	01 13 05	Tube for LP26"x12x12
	01 13 49	Centre for LP200x14,5
	01 13 47	Centre for LP26"x12x12
	01 13 64	Rubber wheel cpl. with axle and bearing LP200x14,5
	01 13 65	Rubber wheel cpl. with axle and bearing LP26"x12x12
9	06 42 22	Axle for wheel LP200x14,5
	06 42 23	Axle for wheel LP26"x12x12
10	01 60 37	Nut M30
11	02 99 20	Grease nipple
12	01 12 72	Circlip
13	01 04 61	Pin Ø16 L 47mm
14	06 40 30	Stop
15	01 58 32	Nut M20
16	06 40 36	Stop screw
17	06 40 39	Stop cpl. (Comprising 14-16 mount.)
18	06 40 75	Support
19	06 40 86	Lock for dimmer resistance
20	06 40 87	Dimmer resistance
21	06 40 78	Bracket for dimmer resistance
22	03 27 40	Bolt M16x40mm w/nut 01 58 25
23	06 40 81	Depth-wheel arm for H 700mm
24	06 40 74	Depth-wheel arm for H 800mm
25	06 40 73	Spacing tube
26	03 36 70	Bolt M12x70mm full threaded
	01 29 19	Washer Ø23-12,5 T 3,2mm
	06 40 89	Spring
	06 04 75	Depth-wheel cpl. LP200"x14,5 H 700mm
	06 04 82	Depth-wheel cpl. LP200"x12x12 H 700mm
	07 04 19	Depth-wheel cpl. LP200"x14,5 H 800mm
	07 04 43	Depth-wheel cpl. LP200"x12x12 H 800mm

340

340

Combi transport/depth-wheel



Ill. no.	Part no.	Description
1	01 11 57	End-cap
2	01 60 00	Nut M20
3	01 29 34	Washer
4	01 12 00	Ball-bearing
5	01 13 79	Centre
6	01 05 17	Ball-bearing
7	01 11 68	Packing
8	01 13 03	Rubber tyre
9	01 13 05	Tube
10	07 40 80	Axle
11	03 51 78	Bolt M20x110mm w/nut
12	07 40 79	Axle support
13	02 99 20	Grease-nipple
14	03 27 45	Bolt M20x45mm w/nut
15	06 40 30	Clevis
16	01 58 32	Nut M20
17	06 40 36	Stop screw
18	06 40 39	Stop clevis cpl.
19	35 21 45	Shock absorber
20	01 04 64	Pin
21	01 12 72	Circlip
22	02 99 20	Grease nipple
23	01 04 61	Pin
24	07 40 60	Bearing
25	07 40 78	Location piece
26	03 27 60	Bolt M16x60mm w/nut
27	01 07 00	Pin M12
28	07 40 65	Lock pin
29	03 27 35	Bolt M16x35mm
30	01 29 24	Washer Ø70/16,5x10mm
31	06 82 51	Thrust-washer
32	07 40 70	Transport/depth-wheel
33	01 07 49	Ball-bearing SKF-51210
34	07 86 08	Pin Ø50x284mm
	01 29 55	Washer Ø70/50,5x1mm
	07 04 91	Combi transport/depth-wheel

PART NO.	PAGE	ILL. NO.	PART NO.	PAGE	ILL. NO.	PART NO.	PAGE	ILL. NO.	PART NO.	PAGE	ILL. NO.	PART NO.	PAGE	ILL. NO.
010008	5	10	011594	12	4	031340	10	1	062119	4	21	071177	5	3
010031	15	5	011656	6	30	031730	10	15	062153	4	1	071178	5	3
010315	4	6	011686	5	24	031740	10	15	062160	5	20	071179	5	3
010318	5	11	011802	12	12	031980	3	19	063090	2	2	071192	5	3
010328	9	15	011802	13	9	032545	4	29	063388	3	18	071193	5	7
010328	4	27	011810	11	9	032545	9	9	064030	15	14	071194	5	7
010328	5	21	011906	12	5	032565	9	9	064030	16	15	071195	5	7
010328	9	1	011906	13	1	032702	7	16	064036	15	16	071196	5	7
010461	15	13	011909	11	14	032702	8	6	064036	15	17	071197	5	7
010461	16	22	011911	12	9	032710	5	1	064039	15	16	071198	5	3
010464	16	19	011911	13	12	032725	7	24	064073	16	17	071199	5	3
010606	4	3	011940	12	0	032730	6	42	064074	15	23	071206	7	2
010627	4	4	011940	13	0	032735	3	12	064075	0	0	071207	7	2
010700	4	5	011945	11	16	032735	16	28	064075	15	17	071208	7	2
010700	5	9	011950	12	14	032740	15	21	064078	15	20	071209	7	2
010700	9	13	011950	13	11	032745	6	34	064081	15	22	071211	7	2
010700	16	26	011952	11	15	032745	7	13	064086	15	18	071212	7	3
010704	5	23	012102	11	7	032750	5	19	064087	0	0	071212	7	3
010772	10	32	012102	12	15	032760	16	25	064087	15	19	071402	7	2
010775	10	3	012113	13	8	032770	5	16	064089	15	26	071403	7	2
010806	15	7	012114	4	33	032775	7	17	064222	15	9	071409	7	2
010910	6	44	012146	12	17	032780	5	19	064223	15	9	071410	7	2
011018	6	39	012147	12	21	032795	5	28	064317	4	18	071412	7	2
011157	15	1	012168	9	7	032813	5	26	064320	4	16	071413	7	2
011157	16	1	012177	12	18	032818	6	43	064321	4	16	071528	7	3
011168	16	7	012180	12	16	032840	7	23	064360	4	17	071529	7	3
011200	15	4	012212	9	3	032845	8	22	066102	10	6	071529	7	3
011231	15	6	012906	14	15	032860	7	38	066108	10	8	071605	5	18
011266	10	4	012919	15	25	032865	7	24	066140	10	10	071614	5	5
011272	15	12	012922	5	2	032875	4	22	066142	10	11	071652	4	3
011292	10	26	012924	16	29	032880	7	23	066170	10	16	071664	7	3
011303	15	8	012934	16	3	032890	7	24	066178	10	25	071672	5	4
011305	15	8	012955	16	34	033100	2	5	066190	10	17	071686	9	11
011305	16	8	013228	2	8	033670	15	24	066868	14	14	071690	7	15
011331	15	8	013332	2	9	034122	14	28	066869	14	14	071703	8	1
011346	15	8	013800	3	16	034228	14	2	066881	14	11	071710	6	32
011347	15	8	015830	4	15	034228	9	5	068251	16	30	071711	6	36
011349	15	8	015832	3	15	035010	11	3	070132	7	36	071712	6	35
011364	15	8	015832	15	15	035022	11	6	070135	5	25	071714	6	33
011365	15	8	015832	16	16	035060	7	2	070136	6	31	071715	6	37
011379	16	5	015835	6	41	035178	16	10	070140	6	31	071853	7	12
011511	9	8	015841	7	10	035090	2	2	070200	4	25	074060	16	23
011517	9	30	016000	16	2	056112	10	5	070216	4	20	074065	16	27
011517	4	12	016010	15	2	056114	10	5	070419	15	26	074070	16	31
011565	4	32	016013	6	40	056156	10	2	070491	16	34	074078	16	24
011565	9	5	016022	7	3	056873	14	13	070639	14	4	074079	16	11
011565	11	8	016037	15	10	060252	4	23	070643	3	21	074080	16	9
011565	12	3	016040	12	7	060475	15	26	070641	3	21	074342	5	13
011565	13	3	029920	4	25	060482	15	26	070642	3	21	076008	5	17
011567	4	31	029920	10	9	060624	10	6	070642	8	3	076030	7	20
011567	9	4	029920	15	11	061515	7	8	071045	8	4	076031	7	19
011567	12	19	029920	16	12	061841	5	29	071104	8	5	076034	7	21
011573	11	6	029920	16	21	061942	4	28	071158	8	4	076035	7	18
011592	12	20	029922	5	26	061942	9	10	071172	8	7	076037	7	22
011594	11	16	030440	10	18	062020	7	25	071173	8	7	076038	7	19
									071176	5	7	076108	10	23

I N D E X

PART NO.	PAGE	ILL. NO.	PART NO.	PAGE	ILL. NO.	PART NO.	PAGE	ILL. NO.
076109	10	11	.	.	.	.	.	.
076812	14	10	.	.	.	.	.	.
076813	14	10	.	.	.	.	.	.
076817	14	9	.	.	.	.	.	.
076818	14	9	.	.	.	.	.	.
076825	14	9	.	.	.	.	.	.
076826	14	9	.	.	.	.	.	.
077023	7	6	.	.	.	.	.	.
078608	16	35	.	.	.	.	.	.
079068	5	8	.	.	.	.	.	.
351139	4	10	.	.	.	.	.	.
351140	4	7	.	.	.	.	.	.
351144	4	8	.	.	.	.	.	.
351148	4	9	.	.	.	.	.	.
351941	9	14	.	.	.	.	.	.
351941	12	0	.	.	.	.	.	.
352145	16	18	.	.	.	.	.	.
352161	12	2	.	.	.	.	.	.
352161	13	6	.	.	.	.	.	.
352164	12	11	.	.	.	.	.	.
352166	12	13	.	.	.	.	.	.
352169	12	16	.	.	.	.	.	.
352172	12	10	.	.	.	.	.	.
352172	13	10	.	.	.	.	.	.
352175	12	8	.	.	.	.	.	.
352176	13	5	.	.	.	.	.	.
352184	9	2	.	.	.	.	.	.
352186	13	13	.	.	.	.	.	.
352187	13	4	.	.	.	.	.	.
352252	11	11	.	.	.	.	.	.
352258	11	10	.	.	.	.	.	.
352260	11	4	.	.	.	.	.	.
352266	11	5	.	.	.	.	.	.
352280	11	12	.	.	.	.	.	.
352290	11	13	.	.	.	.	.	.
352295	13	14	.	.	.	.	.	.
352300	4	26	.	.	.	.	.	.
352372	12	0	.	.	.	.	.	.
361116	4	10	.	.	.	.	.	.



Замовлення запчастин
(050)-407-68-47
(050)-407-68-45



Замовлення запчастин

(050)-407-68-47

(050)-407-68-45



Замовлення запчастин

(050)-407-68-47

(050)-407-68-45