

Spare Parts List

Model PN/RN

Semi mounted plough

No 733042

Hannover
Agro

Замовлення запчастин


(050)-407-68-47

(050)-407-68-45



Notes

GB Model	GB Interbody clearance	GB Headstock
D Modell	D Körperlängsabstand	D Drehwerk
F Modèle	F Dégagement sous age	F Type de tête
E Modelo	E Separación entre cuerpos	E Tipo de cabezal



GB Serial number	Type: HD=Heavy Duty SL=Vibromat OL=On-land	GB Body no.
D Seriennummer		D Körper no.
F Numéro de série		F Type no.
E Numero de serie		E Tipo no.

Замовлення запчастин


- (GB)** Complete model code and serial number must be stated to avoid mistakes when ordering spare parts and misunderstandings regarding service consultations. The identification plate is located on the headstock.
- (F)** Le code complet et le numéro de série doivent être indiqués pour éviter des erreurs lors de la commande de pièces de rechange et des malentendus concernant des demandes de Service-Après-Vente. La plaque d'identité est située sur la tête.
- (D)** Um bei Ersatzteilbestellungen und Serviceleistungen Fehler und Mißverständnisse zu vermeiden ist es erforderlich, daß die genaue Bezeichnung und die Seriennummer angegeben werden. Die Plakette befindet sich am Drehwerk.
- (E)** Debe figura el código completo del modelo y el número de serie para evitar errores al pedir las piezas de recambio y al hacer consultas técnicas. La placa de identificación esta situada en el cabezal.

Plate		Page
244	Bodies no 6, 7, 8, 9 and 28	4
367	Bodies no 12, 15 and 19	8
1089	Bodies no. 29 and no. 30	12
458	Auto Reset Beam	16
1009	Beam (Shear bolt)	18
1073	Disc coultter 18" and 20", E-saddle (From 01.01.99)	20
1007	Disc coultter for shear bolt beam	22
341	Manure skimmer / Maize skimmer	24
1211	Front frame for PN/RN	26
1212	Main frame for PN/RN	28
1213	Wheel for PN/RN	30
1029	Hydraulic layout for turnover PG and PN/RN	32
1266	Relief valve kit	34
1214	Hydraulic layout for lifting PN/RN	36
1215	Hydraulic for furrow adjustment	38
1084	Hydraulic cylinder D100 x 400 mm w/stop (From 15.05.99) (Before 01.10.00) ...	40
1283	Hydraulic cylinder D100 x 400 mm w/stop (From 01.06.04)	42
1130	Hydraulic cylinder w/stop and bellow D100 x 190 mm (From 01.07.00)	44
1195	Hydraulic cylinder D75 x 200 mm (353904 - 353906) (From 01.04.01)	46
1216	Transfers	48
	Index	50

(050)-407-68-47
(050)-407-68-45



1	KK 07 30 00	Share 12" R (30 cm)	KK 07 38 03	Stay R + L for body no. 6, 7 and 8 A - saddle, L = 560 (And no. 9 before 01.12.95)	KK 07 06 41	Trashboard, L cpl.		
	KK 07 30 01	Share 12" L (30 cm)			KK 07 06 42	Trashboard, R + L cpl.		
	KK 07 30 02	Share 14" R (35 cm)	KK 07 38 31	Stay R + L for body no. 9 E - saddle, L = 725 (From 01.12.95)	17	KK 01 33 32	Cone screw M14 x 34 mm w/nut	
	KK 07 30 03	Share 14" L (35 cm)			18	KK 03 27 25	Hex screw M16 x 27 mm w/nut	
	KK 07 30 04	Share 16" R (40 cm)	KK 07 38 30	Stay R + L for body no. 9 A - saddle, L = 710 (From 01.12.95)	19	KK 03 31 07	Oval screw M12 x 35 mm w/nut	
	KK 07 30 05	Share 16" L (40 cm)			20	KK 01 32 34	Cone screw M12 x 38 mm w/nut	
	KK 07 30 06	Share 18" R (45 cm)	KK 06 38 01	Extra stay R + L, no. 9 E - saddle L = 550 (From 01.12.95)	21	KK 07 30 91	Share knife, R	
	KK 07 30 07	Share 18" L (45 cm)				KK 07 30 92	Share knife, L	
	KK 07 30 08	Share 20" R (50 cm)	KK 07 03 94	Extra stay R for body no. 9 E - saddle, cpl. w. bracket (pos. 12) (From 01.12.95)		KK 06 30 91	Share knife, R (for Sweden)	
	KK 07 30 09	Share 20" L (50 cm)	KK 07 03 95	Extra stay L for body no. 9 E - saddle, cpl. w. bracket (pos. 12) (From 01.12.95)		KK 06 30 92	Share knife, L (for Sweden)	
2	KK 05 30 90	Reversible point, R			23	KK 07 36 09	Landside, long R + L	
	KK 06 30 90	Reversible point, L	KK 07 38 03	Extra stay R + L, no. 9 A - saddle L = 560 (From 01.12.95)	24	KK 07 32 66	Bracket for stay, body no. 6 and 9, R	
3	KK 07 34 06	Saddle, R (for E-saddle)				KK 07 32 67	Bracket for stay, body no. 6 and 9, L	
	KK 07 34 07	Saddle, L (for E-saddle)	KK 07 03 90	Extra stay R for body no. 9 A - saddle, cpl. w. bracket (pos. 12) (From 01.12.95)	25	KK 07 34 14	Connecting plate, 16" - 20", R	
	KK 07 34 11	Saddle, R (for A-saddle)				KK 07 34 15	Connecting plate, 16" - 20", L	
	KK 07 34 12	Saddle, L (for A-saddle)	KK 07 03 91	Extra stay L for body no. 9 A - saddle, cpl. w. bracket (pos. 12) (From 01.12.95)	26	KK 07 30 40	Flush fit share 12", R	
4	KK 01 33 32	Cone screw M14 x 34 mm w/nut				KK 07 30 41	Flush fit share 12", L	
5	KK 03 31 00	Oval screw M12 x 30 mm w/nut	KK 08 38 09	Stay R + L for body no. 28 A - saddle (From 01.03.03)		KK 07 30 42	Flush fit share 14", R	
6	KK 07 32 60	Mouldboard 12" - 16" no. 6, R	KK 08 38 10	Stay R + L for body no. 28 E - saddle (From 01.03.03)		KK 07 30 43	Flush fit share 14", L	
	KK 07 32 61	Mouldboard 12" - 16" no. 6, L				KK 07 30 44	Flush fit share 16", R	
	KK 07 32 63	Mouldboard 12" - 14" no. 7, R	10	KK 07 36 08	Landside, R and L, short		KK 07 30 45	Flush fit share 16", L
	KK 07 32 64	Mouldboard 12" - 14" no. 7, L	11	KK 01 58 32	Nut M20 mm	27	KK 07 30 30	Flush point, R
	KK 07 32 80	Mouldboard 12" no. 8, R	12	KK 07 38 00	Bracket for stay, R for body no. 6, 7, 8 (And no. 9 before 01.12.95)		KK 07 30 31	Flush point, L
	KK 07 32 81	Mouldboard 12" no. 8, L				28	KK 01 29 27	Washer 17 x 30 x 3 mm (for use with two stays)
	KK 07 32 86	Mouldboard 14" - 18" no. 8, R	KK 07 38 01	Bracket for stay, L for body no. 6, 7, 8 (And no. 9 before 01.12.95)	30	KK 07 36 15	Furrow widener, R	
	KK 07 32 87	Mouldboard 14" - 18" no. 8, L				KK 07 36 16	Furrow widener, L	
	KK 07 32 90	Mouldboard 14" - 20" no. 9, R	KK 07 38 07	Bracket for stay, R for body no. 9 (From 01.12.95)	31	KK 07 30 88	Landside knife w/screw, R	
	KK 07 32 91	Mouldboard 14" - 20" no. 9, L				KK 07 30 89	Landside knife w/screw, L	
	KK 08 32 28	Mouldboard no. 28, R (From 01.03.03)	KK 07 38 08	Bracket for stay, L for body no. 9 (From 01.12.95)	32	KK 03 32 51	Screw M16 x 50 mm w/nut (for E-saddle) (Before 01.02.00)	
	KK 08 32 29	Mouldboard no. 28, L (From 01.03.03)				KK 03 32 56	Screw M16 x 55 mm w/ nut (for E-saddle) (From 01.02.00)	
7	KK 07 32 50	Shinpiece for no. 8, R	13	KK 01 29 19	Washer 12.5 x 23 x 3.2 mm		KK 03 32 86	Screw M16 x 85 mm w/nut (for A-saddle) (Before 01.02.00)
	KK 07 32 51	Shinpiece for no. 8, L	14	KK 05 33 87	Mouldboard extension, R		KK 03 32 95	Screw M16 x 95 mm w/nut (for A-saddle) (From 01.02.00)
	KK 07 32 56	Shinpiece for no. 6 and 9, R		KK 06 33 88	Mouldboard extension, L			
	KK 07 32 57	Shinpiece for no. 6 and 9, L	15	KK 07 33 10	Bracket for trashboard, R			
				KK 07 33 11	Bracket for trashboard, L			
8	KK 03 27 35	Hex screw M16 x 35 mm w/nut	16	KK 07 33 00	Trashboard, R			
9	KK 06 38 01	Stay R + L for body no. 6, 7 and 8 E - saddle, L = 550 (And no. 9 before 01.12.95)		KK 07 33 01	Trashboard L	33	KK 03 31 75	Screw M14 x 50 mm w/nut
				KK 07 06 40	Trashboard, R cpl.	34	KK 01 29 22	Washer 17 x 40 x 4.58 mm



35	KK 06 36 07	Plate	104	KK 03 27 40	Hex screw M16 x 40 mm w/nut (for ploughs w/E-saddle) (Before 01.03.00)	
	KK 07 36 07	Plate cpl.		KK 03 27 50	Hex screw M16 x 50 mm w/nut (for ploughs w/E-saddle) (From 01.03.00)	
36	KK 01 33 46	Screw M14 x 45 mm w/nut		KK 03 27 65	Hex screw M16 x 65 mm w/nut (for ploughs w/share bolt beam)	
37	KK 07 36 14	Wearing plate		KK 03 27 75	Hex screw M16 x 75 mm w/nut (for ploughs w/A-beam)	
38	KK 01 33 33	Cone screw M14 x 34 mm		105	KK 01 33 46	Cone screw M14 x 45 mm w/ flange nut (for ploughs w/E-saddle) (Before 01.03.00)
39	KK 08 32 35	Mouldboard knife R and L (From 01.12.01)			KK 01 33 61	Cone screw M14 x 60 mm w/ flange nut (for ploughs w/E-saddle) (From 01.03.00)
40	KK 08 30 91	Ejector key (bodies no. 8, 9 and 28)			KK 01 33 85	Cone screw M14 x 85 mm w/ flange nut (for ploughs w/share bolt beam and A-beam)
41	KK 08 30 90	Quick fit point (bodies no. 8, 9 and 28)		106	KK 01 60 15	Flange nut M14
42	KK 08 30 10	Quick fit holder, R (bodies no. 8, 9 and 28)		107	KK 01 29 29	Washer (for ploughs w/E-saddle) (From 01.03.00)
	KK 08 30 11	Quick fit holder, L (bodies no. 8, 9 and 28)				
43	KK 08 30 16	Quick fit share R, 14" (bodies no. 8, 9 and 28)				
	KK 08 30 17	Quick fit share L, 14" (bodies no. 8, 9 and 28)				
	KK 08 30 18	Quick fit share R, 16" (bodies no. 8, 9 and 28)				
	KK 08 30 19	Quick fit share L, 16" (bodies no. 8, 9 and 28)				
	KK 08 30 20	Quick fit share R, 18" (bodies no. 8, 9 and 28)				
	KK 08 30 21	Quick fit share L, 18" (bodies no. 8, 9 and 28)				
	KK 08 30 22	Quick fit share R, 20" (bodies no. 8, 9 and 28)				
	KK 08 30 23	Quick fit share L, 20" (bodies no. 8, 9 and 28)				
44	KK 89 33 34	Cone screw w/ oval head M14 x 34 mm (bodies no. 8, 9 and 28)				

Замовлення запчаст


(050)-407-68-47

(050)-407-68-45


Pos. 100 - 107 Eco-share from 01.04.00

100	KK 05 30 90	Reversible point, R
	KK 06 30 90	Reversible point, L
101	KK 01 32 28	Cone screw M12 x 34 mm w/nut
102	KK 07 36 34	Eco-share, R
	KK 07 36 35	Eco-share, L
103	KK 01 01 55	Bushing (for ploughs w/share bolt beam)
	KK 01 01 56	Bushing (for ploughs w/A-beam)

Замовлення запчастин
(050)-407-68-47
(050)-407-68-45




1	KK 01 29 19	Washer		KK 07 32 31	Shinpiece no. 19, L		KK 07 03 93	Extra stay L for body no. 19 A - saddle cpl.
2	KK 07 33 00	Trashboard, R	16	KK 07 32 39	Connecting piece no. 12 and 15, R			w. bracket (pos. 6) (From 01.12.95)
	KK 07 33 01	Trashboard, L		KK 07 32 40	Connecting piece no. 12 and 15, L	20	KK 07 36 09	Landside, long, R + L
	KK 07 06 40	Trashboard, R cpl.		KK 07 32 66	Connecting piece no. 19, R	21	KK 07 36 08	Landside, short, R + L
	KK 07 06 41	Trashboard, L cpl.		KK 07 32 67	Connecting piece no. 19, L	22	KK 03 27 25	Hex screw M16 x 27 mm
	KK 07 06 42	Trashboard, R + L cpl.	17	KK 03 27 50	Hex screw M16 x 50 mm w/nut (for use with two stays)	23	KK 01 32 34	Cone screw M12 x 38 mm w/nut
3	KK 07 33 10	Bracket, R		KK 03 27 35	Hex screw M16 x 35 mm w/nut (for use with one stay only)	24	KK 01 32 28	Cone screw M12 x 34 mm w/nut
	KK 07 33 11	Bracket, L				25	KK 05 30 90	Reversible point, R
4	KK 03 31 00	Oval screw M12 x 30 mm w/nut					KK 06 30 90	Reversible point, L
5	KK 01 58 34	Nut M20 mm	18	KK 01 29 27	Washer 17 x 30 x 3 mm (for use with two stays)	26	KK 07 30 54	Share 14", R
6	KK 07 38 00	Bracket, R					KK 07 30 55	Share 14", L
	KK 07 38 01	Bracket, L	19	KK 07 38 05	Stay R + L for body no. 12 and 15 E - saddle, L = 540 (And no. 19 before 12.01.95)		KK 07 30 56	Share 16", R
7	KK 05 33 87	Mouldboard extention, R		KK 07 38 31	Stay R + L for body no. 19 E - saddle, L = 730 (From 12.01.95)		KK 07 30 57	Share 16", L
	KK 06 33 88	Mouldboard extention, L		KK 07 38 04	Stay R + L for body no. 12 and 15 A - saddle, L = 550 (And no. 19 before 12.01.95)		KK 07 30 80	Share 18", R
8	KK 07 32 36	Mouldboard no. 12, R		KK 07 38 26	Stay R + L for body no. 19 A - saddle, L = 770 (From 12.01.95)		KK 07 30 81	Share 18", L
	KK 07 32 37	Mouldboard no. 12, L		KK 07 38 26	Extra stay R + L, no. 15 E - saddle L = 770 (From 01.12.96)	27	KK 07 30 91	Share knife, R
	KK 07 32 24	Mouldboard no. 15, R		KK 07 03 88	Extra stay R for body no. 15 E - saddle cpl. w. bracket (pos. 6) (From 01.12.96)		KK 07 30 92	Share knife, L
	KK 07 32 25	Mouldboard no. 15, L		KK 07 03 89	Extra stay L for body no. 15 E - saddle cpl. w. bracket (pos. 6) (From 01.12.96)	28	KK 07 30 88	Landside knife, R w/nuts
	KK 07 32 90	Mouldboard no. 19, R		KK 07 38 29	Extra stay R + L, no. 15 A - saddle L = 785 (From 01.12.96)		KK 07 30 89	Landside knife, L w/nuts
	KK 07 32 91	Mouldboard no. 19, L		KK 07 03 98	Extra stay R for body no. 15 A - saddle cpl. w. bracket (pos. 6) (From 01.12.96)	29	KK 07 36 15	Furrow widener, R
9	KK 01 33 32	Cone screw M14 x 34 mm w/nut		KK 07 03 99	Extra stay L for body no. 15 A - saddle cpl. w. bracket (pos. 6) (From 01.12.96)		KK 07 36 16	Furrow widener, L
10	KK 03 31 07	Oval screw M12 x 35 mm w/nut		KK 07 38 42	Extra stay R + L, no. 19 E - saddle L = 570 (From 01.12.95)	30	KK 03 31 75	Screw M14 x 50 mm w/nut
11	KK 07 30 62	Share 14", R		KK 07 03 96	Extra stay R for body no. 19 E - saddle cpl. w. bracket (pos. 6) (From 01.12.95)	31	KK 03 32 51	Screw M16 x 50 mm w/nut (for E-saddle) (Before 01.02.00)
	KK 07 30 63	Share 14", L		KK 07 03 97	Extra stay L for body no. 19 E - saddle cpl. w. bracket (pos. 6) (From 01.12.95)		KK 03 32 56	Screw M16 x 56 mm w/nut (for E-saddle) (From 01.02.00)
	KK 07 30 64	Share 16", R		KK 07 38 04	Extra stay R + L, no. 19 A - saddle L = 550 (From 01.12.95)		KK 03 32 86	Screw M16 x 85 mm w/nut (for A-saddle) (Before 01.02.00)
	KK 07 30 65	Share 16", L		KK 07 03 92	Extra stay R for body no. 19 A - saddle cpl. w. bracket (pos. 6) (From 01.12.95)		KK 03 32 95	Screw M16 x 95 mm w/nut (for A-saddle) (From 01.02.00)
12	KK 06 20 25	Nut M16 mm				32	KK 01 29 22	Washer 17 x 40 x 4.58 mm
13	KK 07 34 35	Saddle, R (for E-saddle)				34	KK 01 33 33	Cone screw M14 x 34 mm w/nut
	KK 07 34 36	Saddle, L (for E-saddle)				35	KK 06 36 07	Plate for On-Land ploughs
	KK 07 34 40	Saddle, R (for A-saddle)					KK 07 36 07	Plate for On-Land ploughs cpl.
	KK 07 34 41	Saddle, L (for A-saddle)				36	KK 01 33 46	Screw M14 x 45 mm w/nut
14	KK 07 34 17	Connecting plate no. 12 and 15, R				37	KK 03 31 07	Oval screw M12 x 35 mm
	KK 07 34 18	Connecting plate no. 12 and 15, L				38	KK 07 36 14	Wearing plate
15	KK 07 32 41	Shinpiece no. 12, R				39	KK 01 33 32	Cone screw M14 x 34 mm
	KK 07 32 42	Shinpiece no. 12, L						
	KK 07 32 27	Shinpiece no. 15, R						
	KK 07 32 28	Shinpiece no. 15, L						
	KK 07 32 30	Shinpiece no. 19, R						



40	KK 08 32 35	Mouldboard knife R and L (From 01.12.01)	105	KK 01 33 46	Cone screw M14 x 45 mm w/flange nut (for ploughs w/E-saddle) (Before 01.03.00)
41	KK 08 30 90	Quick fit point (body no.19)			
42	KK 08 30 10	Quick fit holder, R (body no.19)		KK 01 33 61	Cone screw M14 x 60 mm w/flange nut (for ploughs w/E-saddle) (From 01.03.00)
	KK 08 30 11	Quick fit holder, L (body no.19)			
43	KK 08 30 16	Quick fit share R, 14" (body no.19)		KK 01 33 85	Cone screw M14 x 85 mm w/flange nut (for ploughs w/share bolt beam and A-beam)
	KK 08 30 17	Quick fit share L, 14" (body no.19)			
	KK 08 30 18	Quick fit share R, 16" (body no.19)			
	KK 08 30 19	Quick fit share L, 16" (body no.19)	106	KK 01 60 15	Flange nut M14
	KK 08 30 20	Quick fit share R, 18" (body no.19)	107	KK 01 29 29	Washer (for ploughs w/E-saddle) (From 01.03.00)
	KK 08 30 21	Quick fit share L, 18" (body no.19)			
	KK 08 30 22	Quick fit share R, 20" (body no.19)			
	KK 08 30 23	Quick fit share L, 20" (body no.19)			
44	KK 89 33 34	Cone screw w/ oval head M14 x 34 mm (body no.19)			
45	KK 08 30 91	Ejector key (body no.19)			

Pos. 100 - 107 Eco-share from 01.04.00

100	KK 05 30 90	Reversible point, R
	KK 06 30 90	Reversible point, L
101	KK 01 32 28	Cone screw M12 x 34 mm w/nut
102	KK 07 36 34	Eco-share, R
	KK 07 36 35	Eco-share, L
103	KK 01 01 55	Bushing (for ploughs w/share bolt beam)
	KK 01 01 56	Bushing (for ploughs w/A-beam)
104	KK 03 27 40	Hex screw M16 x 40 mm w/nut (for ploughs w/E-saddle) (Before 01.03.00)
	KK 03 27 50	Hex screw M16 x 50 mm w/nut (for ploughs w/E-saddle) (From 01.03.00)
	KK 03 27 65	Hex screw M16 x 65 mm w/nut (for ploughs w/share bolt beam)
	KK 03 27 75	Hex screw M16 x 75 mm w/nut (for ploughs w/A-beam)


Замовлення запчастин
(050)-407-68-47
(050)-407-68-45



1	KK 07 33 00	Trashboard, R	15	KK 08 34 15	Saddle R, A-saddle (for body no. 29)	KK 03 30 16	Oval screw M10 x 30 mm (for body no. 30)		
	KK 07 33 01	Trashboard, L		KK 08 34 16	Saddle L, A-saddle (for body no. 29)				
2	KK 08 33 00	Bracket, R		KK 08 34 06	Saddle R, A-saddle (for body no. 30)	KK 01 58 13	Nut M10		
	KK 08 33 01	Bracket, L		KK 08 34 07	Saddle L, A-saddle (for body no. 30)	23	KK 07 30 62 Share 14", R (for body no. 30)		
3	KK 07 36 15	Furrow widener, R	16	KK 05 30 90	Reversible point, R		KK 07 30 63 Share 14", L (for body no. 30)		
	KK 07 36 16	Furrow widener, L		KK 06 30 90	Reversible point, L		KK 07 30 64 Share 16", R (for body no. 30)		
4	KK 01 33 32	Cone screw M14 x 34 mm	17	KK 01 32 28	Cone screw M12 x 34 mm		KK 07 30 65 Share 16", L (for body no. 30)		
	KK 01 60 13	Flange nut M14		KK 01 58 17	Nut M12	24	KK 08 32 11 Slat no 1, R		
5	KK 07 36 09	Landside, long R + L	18	KK 07 30 91	Share knife, R		KK 08 32 21 Slat no 1, L		
6	KK 08 34 17	Saddle R, E-saddle (for body no. 29)		KK 07 30 92	Share knife, L	25	KK 08 32 12 Slat no 2, R		
	KK 08 34 18	Saddle L, E-saddle (for body no. 29)		KK 06 30 91	Share knife, R (for Sweeden)		KK 08 32 22 Slat no 2, L		
	KK 08 34 08	Saddle R, E-saddle (for body no. 30)		KK 06 30 92	Share knife, L (for Sweeden)	26	KK 08 32 13 Slat no 3, R		
	KK 08 34 09	Saddle L, E-saddle (for body no. 30)	19	KK 07 30 02	Share 14", R (for body no. 29)		KK 08 32 23 Slat no 3, L		
7	KK 03 31 16	Oval screw M12 x 35 mm (for body no. 29 and 30)		KK 07 30 03	Share 14", L (for body no. 29)	27	KK 08 32 14 Slat no 4, R		
	KK 01 58 17	Nut M12		KK 07 30 54	Share 14", R (for body no. 30)		KK 08 32 24 Slat no 4, L		
	KK 03 31 07	Oval screw M12 x 35 mm (for body no. 30) (Before 01.01.01)		KK 07 30 55	Share 14", L (for body no. 30)	28	KK 07 30 88 Landside knife, R		
	KK 01 58 17	Nut M12		KK 07 30 04	Share 16", R (for body no. 29)		KK 07 30 89 Landside knife, L		
8	KK 03 31 17	Oval screw M12 x 45 mm (for body no. 29 and 30)		KK 07 30 05	Share 16", L (for body no. 29)	29	KK 03 31 75 Screw M14 x 50 mm		
	KK 01 58 17	Nut M12		KK 07 30 56	Share 16", R (for body no. 30)		KK 01 60 15 Flange nut M14		
	KK 03 31 11	Oval screw M12 x 45 mm (for body no. 30) (Before 01.01.01)		KK 07 30 57	Share 16", L (for body no. 30)	30	KK 03 32 51 Screw M16 x 50 mm (for E-saddle) (Before 01.02.00)		
	KK 01 58 17	Nut M12		KK 07 30 06	Share 18", R (for body no. 29)		KK 03 32 56 Screw M16 x 56 mm (for E-saddle) (From 01.02.00)		
	KK 03 31 11	Oval screw M12 x 45 mm (for body no. 30) (Before 01.01.01)		KK 07 30 07	Share 18", L (for body no. 29)		KK 01 58 25 Nut M16		
	KK 01 58 17	Nut M12		KK 07 30 80	Share 18", R (for body no. 30)		KK 03 32 86 Screw M16 x 85 mm (for A-saddle) (Before 01.02.00)		
9	KK 08 32 10	Slat support, R		KK 07 30 81	Share 18", L (for body no. 30)		KK 03 32 95 Screw M16 x 95 mm (for A-saddle) (From 01.02.00)		
	KK 08 32 20	Slat support, L	20	KK 08 32 15	Connecting piece, plastic (for slat 1-2)		KK 01 58 25 Nut M16		
10	KK 08 38 03	Stay		KK 08 32 18	Connecting piece, plastic (for slat 2) (for body no. 29)		31	KK 01 29 22 Washer 17 x 40 x 4.58 mm	
11	KK 08 38 05	Stay 1, saddle A (for body no. 29)		KK 08 32 16	Connecting piece, plastic (for slat 2-3) (for body no. 30)		32	KK 07 30 42 Flush fit share 14", R (for body no. 29)	
	KK 08 38 06	Stay 2, saddle A (for body no. 29)						KK 07 30 43 Flush fit share 14", L (for body no. 29)	
	KK 08 38 02	Stay, saddle A (for body no. 30)		KK 08 32 17	Connecting piece, plastic (for slat 3-4)			KK 07 30 44 Flush fit share 16", R (for body no. 29)	
	KK 08 38 07	Stay 1, saddle E (for body no. 29)	21	KK 07 32 56	Shinpiece, R (for body no. 29)			KK 07 30 45 Flush fit share 16", L (for body no. 29)	
	KK 08 38 08	Stay 2, saddle E (for body no. 29)		KK 07 32 57	Shinpiece, L (for body no. 29)			33	KK 07 30 30 Flush fit point, R
	KK 08 38 04	Stay, saddle E (for body no. 30)		KK 07 32 30	Shinpiece, R (for body no. 30)			KK 07 30 31 Flush fit point, L	
12	KK 07 36 08	Landside, short R + L		KK 07 32 31	Shinpiece, L (for body no. 30)			34	KK 08 32 35 Mouldboard knife R and L (From 01.12.01)
13	KK 03 27 50	Hex screw M16 x 50 mm	22	KK 03 30 06	Oval screw M10 x 30 mm (for body no. 29)				
	KK 01 58 25	Nut M16		KK 01 58 13	Nut M10				
14	KK 07 36 14	Wearing plate							




35	KK 08 30 91	Ejector key
36	KK 08 30 90	Quick fit point
37	KK 08 30 10	Quick fit holder, R
	KK 08 30 11	Quick fit holder, L
38	KK 89 33 34	Cone screw w/ oval head M14 x 34 mm
39	KK 08 30 16	Quick fit share R, 14"
	KK 08 30 17	Quick fit share L, 14"
	KK 08 30 18	Quick fit share R, 16"
	KK 08 30 19	Quick fit share L, 16"
	KK 08 30 20	Quick fit share R, 18"
	KK 08 30 21	Quick fit share L, 18"
	KK 08 30 22	Quick fit share R, 20"
	KK 08 30 23	Quick fit share L, 20"

105	KK 01 33 46	Cone screw M14 x 45 mm (for ploughs w/E-saddle) (Before 01.03.00)
	KK 01 33 61	Cone screw M14 x 60 mm (for ploughs w/E-saddle) (From 01.03.00)
	KK 01 33 85	Cone screw M14 x 85 mm (for ploughs w/share bolt beam and A-beam)
106	KK 01 60 15	Flange nut M14
107	KK 01 29 29	Washer (for ploughs w/E-saddle) (From 01.03.00)

Pos. 100 - 107 Eco-share from 01.04.00

100	KK 05 30 90	Reversible point, R
	KK 06 30 90	Reversible point, L
101	KK 01 32 28	Cone screw M12 x 34 mm
	KK 01 58 17	Nut M12
102	KK 07 36 34	Eco-share, R
	KK 07 36 35	Eco-share, L
103	KK 01 01 55	Bushing (for ploughs w/share bolt beam)
	KK 01 01 56	Bushing (for ploughs w/A-beam)
104	KK 03 27 40	Hex screw M16 x 40 (for ploughs w/E-saddle) (Before 01.03.00)
	KK 03 27 50	Hex screw M16 x 50 mm (for ploughs w/E-saddle) (From 01.03.00)
	KK 01 58 25	Nut M16
	KK 03 27 65	Hex screw M16 x 65 mm w/nut (for ploughs w/share bolt beam)
	KK 01 58 25	Nut M16
	KK 03 27 75	Hex screw M16 x 75 mm w/nut (for ploughs w/A-beam)
	KK 01 58 25	Nut ;16





1	KK 05 70 67	Blade no 4	33	KK 03 26 55	Hex screw M12 x 55 mm w/nut (for extra additional leaf spring cpl.)
2	KK 03 50 20	Hex screw w/flange M10 x 34 mm w/nut	34	KK 06 70 77	Bushing (for extra additional leaf spring cpl.)
3	KK 05 70 66	Blade no 3	35	KK 06 70 75	Linkage (for extra additional leaf spring cpl.)
4	KK 02 99 20	Grease nipple M8 x 1	36	KK 06 70 76	Bolt D15.7 (for extra additional leaf spring cpl.)
5	KK 06 70 59	Bolt	37	KK 02 97 27	Split pin D5 x 32 mm (for extra additional leaf spring cpl.)
6	KK 01 10 37	Roll pin D10 x 40 mm	38	KK 06 12 91	Threaded piece
7	KK 06 70 57	Bolt (Before 01.08.02)			
	KK 06 70 16	Bolt (From 01.08.02)	Not ill.	KK 05 07 06	Leaf spring cpl. (1 x ill. no. 3, 13, 14, 16, 17 and 22 + 2 x ill. no. 1, 2, 20 and 29)
8	KK 03 28 60	Hex screw M20 x 60 mm w/nut		KK 06 07 03	Leaf spring HD cpl. (1 x ill. no 3, 16, 17 22 and 32 + 2 x ill. no. 1, 2, 20, 23 and 29)
9	KK 06 70 51	Adjustment screw w/threaded piece		KK 06 01 19	Spacer kit w/ hex screws R & L cpl.
10	KK 06 70 40	Holder (Before 01.08.02)			
	KK 06 70 25	Holder (From 01.08.02)			
11	KK 06 70 68	Bracket (Before 01.08.02)			
	KK 06 70 92	Bracket (From 01.08.02)			
12	KK 06 70 39	Adjustment screw M24 x 90 mm			
13	KK 05 70 89	Bolt			
14	KK 02 97 27	Split pin D5 x 32 mm			
15	KK 06 70 80	Spring arm			
16	KK 03 26 65	Hex screw M12 x 65 mm w/nut			
17	KK 05 70 63	Main blade			
18	KK 06 70 60	Regulator (Before 01.08.02)			
	KK 06 70 90	Regulator (From 01.08.02)			
19	KK 06 70 70	Tie rod (Before 01.08.02)			
	KK 06 70 26	Tie rod (From 01.08.02)			
20	KK 05 70 64	Blade no 1			
21	KK 06 70 31	Axle D22 x 53 mm			
22	KK 05 70 65	Blade no 2			
23	KK 05 70 68	Blade no 5			
24	KK 06 12 80	Beam			
25	KK 03 52 09	Hex screw M20 x 50 mm w/threaded piece			
26	KK 03 28 40	Hex screw M20 x 40 mm w/nut			
27	KK 06 01 08	Spacer cpl. w/hex screws R			
	KK 06 01 09	Spacer cpl. w/hex screws L			
28	KK 03 51 65	Hex screw M20 x 50 mm w/flange nut			
29	KK 03 50 21	Hex screw w/flange M10 x 30.5 mm w/nut			
30	KK 01 10 42	Roll pin D6 x 40 mm (to be mounted into roll pin 011037)			
31	KK 03 28 55	Hex screw M20 x 55 mm			
32	KK 01 29 13	Washer			



For LS, RL, LM, RM and RG ploughs

For LD, LO, RS, RX, LB, and RB ploughs




1	KK 07 12 08	Beam, R (Before 15.08.01)		KK 03 28 60	Hex screw M20 x 60 mm (for LB, LO and RB only) (From 01.04.02)
	KK 07 12 72	Beam, R (From 15.08.01)	23	KK 01 60 49	Lock nut M20 (From 01.04.02)
2	KK 07 12 09	Beam, L (Before 15.08.01)			
	KK 07 12 73	Beam, L (From 15.08.01)	Not ill.	KK 07 12 11	Beam, H = 700 mm cpl. (ill. no. 1, 2, 3 and 5 - 8) (Before 15.08.01)
3	KK 07 12 28	Support, H = 700 mm (Before 15.08.01)		KK 07 12 80	Beam, H = 700 mm cpl. (ill. no. 1, 2, 3 and 5 - 8) (From 15.08.01)
	KK 07 12 71	Support, H = 700 mm (From 15.08.01)		KK 07 12 12	Beam, H = 800 mm cpl. (ill. no. 1, 2, 4 and 5 - 8) (Before 15.08.01)
4	KK 07 12 07	Support, H = 800 mm (Before 15.08.01)		KK 07 12 81	Beam, H = 800 mm cpl. (ill. no. 1, 2, 4 and 5 - 8) (From 15.08.01)
	KK 07 12 70	Support, H = 800 mm (From 15.08.01)			
5	KK 07 70 24	Main bolt M30 x 72 mm, L (Before 15.08.01)			
	KK 07 12 75	Main bolt M30 x 84 mm, L (From 15.08.01)			
6	KK 07 70 23	Main bolt M30 x 72 mm, R (Before 15.08.01)			
	KK 07 12 74	Main bolt M30 x 84 mm, R (From 15.08.01)			
7	KK 01 60 22	Nut M30, R			
8	KK 01 60 45	Nut M30, L			
9	KK 07 49 10	Plate for support, H = 700 mm (for LS, RL, LM, RM and RG ploughs only)			
10	KK 07 49 11	Plate for support, H = 800 mm (for LS, RL, LM, RM and RG ploughs only)			
11	KK 06 15 15	Bushing D28 x D20.5 x 35.2 mm			
12	KK 03 28 40	Hex screw M20 x 40 mm w/nut (Before 01.04.02)			
	KK 03 28 45	Hex screw M20 x 45 mm (From 01.04.02)			
	KK 03 28 50	Hex screw M20 x 50 mm w/nut (for disc coultter, for front piece and rear beam)			
	KK 03 28 60	Hex screw M20 x 60 mm w/nut (for front piece w/disc coultter)			
13	KK 03 28 65	Hex screw M20 x 65 mm w/nut			
14	KK 03 52 15	Hex screw M20 x 80 mm w/flange nut qual. 12.9			
	KK 03 52 16	Hex screw M20 x 90 mm w/flange nut qual. 12.9 (for RL ploughs front section, rear leg only)			
15	KK 03 28 07	Hex screw M20 x 100 mm			
	KK 03 28 03	Hex screw M20 x 110 mm (for LB, LO and RB only) (From 01.04.02)			
	KK 03 28 24	Hex screw M20 x 105 mm (when using fixing device KK 07 72 95 for RL plough) (From 01.04.02)			
16	KK 06 20 20	Washer			
17	KK 03 50 60	Shear bolt M20 x 62 mm w/nut (for support H = 800 mm) (Before 15.08.01)			
	KK 03 50 48	Shear bolt M20 x 72 mm w/nut (for support H = 800 mm) (From 15.08.01)			
18	KK 03 50 72	Shear bolt M20 x 81 mm w/nut (for support H = 700 mm)			
19	KK 07 15 08	Plate for support H = 700 mm (for LD, LO, RS, RX, LB and RB ploughs only)			
20	KK 07 15 29	Plate for support H = 800 mm (for LD, LO, RS, RX, LB and RB ploughs only)			
21	KK 03 27 62	Hex screw M16 x 60 w/nut qual. 12.9			
22	KK 03 28 40	Hex screw M20 x 40 mm w/nut (Before 01.04.02)			
	KK 03 28 45	Hex screw M20 x 45mm (From 01.04.02)			



1	KK 07 64 06	Disc coulters 18"	22	KK 03 28 30	Hex screw M20 x 30 mm
	KK 07 64 07	Disc coulters 20"		KK 01 58 30	Nut M20
2	KK 07 64 09	Disc coulters, notched 18"	23	KK 03 28 40	Hex screw M20 x 40 mm
	KK 07 64 10	Disc coulters, notched 20"		KK 01 58 30	Nut M20
3	KK 07 64 99	Plate	24	KK 01 60 31	Cone nut M16
4	KK 03 35 40	Screw M10 x 40 mm			
	KK 01 60 04	Lock nut M10			
5	KK 01 17 50	O-ring 124,5 x 4 mm			
6	KK 01 18 66	O-ring 67 x 3 mm			
7	KK 01 12 59	Circlip I 62 x 2 mm			
8	KK 01 12 66	Circlip A 30 x 1,5 mm			
9	KK 01 05 72	Bearing			
10	KK 01 05 32	Gasket ring			
11	KK 08 60 89	Bearing housing cpl. (ill. 3 - 11)			
	KK 08 60 90	Bearing housing cpl. w/axle			
12	KK 08 61 01	Axle			
	KK 08 60 80	Disc coulters arm w/bearing 18", R			
	KK 08 60 81	Disc coulters arm w/bearing 18", L			
	KK 08 60 82	Disc coulters arm w/bearing 20", R			
	KK 08 60 83	Disc coulters arm w/bearing 20", L			
	KK 08 60 84	Disc coulters arm w/bearing 20", lowered R			
	KK 08 60 85	Disc coulters arm w/bearing 20", lowered L			
13	KK 08 61 10	Arm 18", R			
	KK 08 61 12	Arm 20", R			
	KK 08 61 14	Arm 20", lowered R			
14	KK 08 61 11	Arm 18", L			
	KK 08 61 13	Arm 20", L			
	KK 08 61 15	Arm 20", lowered L			
15	KK 06 61 70	Bracket			
16	KK 02 99 20	Grease nipple			
17	KK 06 61 90	Clip			
18	KK 03 50 31	Hex screw M12 x 45 mm			
	KK 01 58 17	Nut M12			
19	KK 06 61 89	Bracket 18"			
	KK 06 61 82	Bracket 20"			
20	KK 06 61 78	Eccentric			
21	KK 06 61 75	U-bolt			




Замовлення запчастин
(050)-407-68-47
(050)-407-68-45




1	KK 07 64 06	Disc coulters 18"
	KK 07 64 07	Disc coulters 20"
2	KK 01 17 50	O-ring
3	KK 01 18 66	O-ring
4	KK 01 12 59	Circlip
5	KK 01 12 66	Circlip
6	KK 01 05 72	Ball bearing
7	KK 01 08 18	Rubber ring (Before 01.01.99)
	KK 01 05 32	Gasket ring (From 01.01.99)
8	KK 08 60 90	Bearing housing cpl. (ill. no. 2-3-4-5-6-7-8-10) (Before 01.01.99)
	KK 08 60 89	Bearing housing cpl. (ill. no. 2-3-4-5-6-7-8) (From 01.01.99)
9	KK 07 60 76	Axle (Before 01.01.99)
	KK 08 61 01	Axle (From 01.01.99)
	KK 08 60 86	Disc coulters arm w/bearing (From 01.01.99)
	KK 08 60 87	Disc coulters bearing cpl. (ill. no. 4-6-7-8) (From 01.01.99)
10	KK 02 99 20	Grease nipple
11	KK 07 65 75	Arm
12	KK 07 64 00	Support
13	KK 07 65 27	Axle
14	KK 03 27 02	Hex screw M16 x 110 mm w/nut
15	KK 03 10 30	Hex screw M10 x 30 mm
16	KK 07 64 09	Disc coulters 18" notched
	KK 07 64 10	Disc coulters 20" notched
17	KK 03 28 50	Hex screw M20 x 50 mm
18	KK 03 28 40	Hex screw M20 x 40 mm
19	KK 06 61 78	Eccentric for bracket
20	KK 07 49 31	Bracket
21	KK 01 29 60	Washer 20.5 x 40 x 3.4 mm
22	KK 07 49 36	Plate w/threads
23	KK 07 49 30	Tube
24	KK 03 27 75	Hex screw M16 x 75 mm w/nut
25	KK 07 65 15	Supporting piece for tube
26	KK 07 49 39	Extended tube
27	KK 03 27 85	Hex screw M16 x 85 mm w/nut
28	KK 07 49 38	Support
29	KK 07 49 37	Support
30	KK 07 64 99	Plate






1	KK 07 68 12	Mouldboard maize R	11	KK 06 68 11	Arm R, H = 700 mm for HD beam and std. beam H700
	KK 07 68 13	Mouldboard maize L		KK 07 68 58	Arm R, H = 750 mm for std. beam H800 (From 01.12.00)
2	KK 06 68 80	Mouldboard R	16	KK 07 06 53	Fixing bracket with screw and nut (for beam 071240 and 071241)
	KK 07 69 43	Mouldboard R, plastic	17	KK 03 44 46	Setscrew M24 x 53 mm
	KK 06 68 81	Mouldboard L	18	KK 01 58 41	Nut M24
	KK 07 69 44	Mouldboard L, plastic	19	KK 01 58 16	Nut M10
3	KK 03 30 06	Oval screw M10 x 30 mm	20	KK 08 50 76	Clevis
4	KK 05 68 73	Share, short R	21	KK 06 68 61	Bracket HD beam
	KK 06 68 73	Share, short L			
5	KK 06 68 68	Share, long R			
	KK 06 68 69	Share, long L			
6	KK 01 29 06	Washer 10.5 x 25 x 3.4			
7	KK 01 58 25	Nut M16			
22	KK 08 68 01	Skimmer extension			
23	KK 03 30 07	Oval screw M10 x 35 mm			
for all turnable ploughs with Auto Reset beams:					
8	KK 03 27 95	Hex screw M16 x 95 mm			
9	KK 03 42 28	Setscrew M16 x 32 mm			
10	KK 06 06 57	Bracket cpl.			
11	KK 06 68 11	Arm R, H = 700 mm			
	KK 07 68 58	Arm R, H = 750 mm (From 01.12.00)			
	KK 06 68 12	Arm L, H = 700 mm			
	KK 07 68 59	Arm L, H = 750 mm (From 01.12.00)			
for all turnable ploughs with Shear Bolt beams:					
12	KK 07 06 39	Bracket with screws (for LB, LD, RB, RS, RX)			
	KK 07 68 72	Bracket (for LM, LS, RG, RL, RM, VD)			
13	KK 03 42 25	Setscrew M16 x 25 mm			
14	KK 03 42 50	Setscrew M16 x 50 mm			
15	KK 07 68 17	Arm R, H = 700 mm			
	KK 07 68 18	Arm L, H = 700 mm			
	KK 07 68 25	Arm R, H = 800 mm			
	KK 07 68 26	Arm L, H = 800 mm			
	KK 07 68 33	Arm R, H = 700 mm (for VD plough only) (Before 15.03.98)			
	KK 07 68 34	Arm L, H = 700 mm (for VD plough only) (Before 15.03.98)			
for beams on conventional ploughs:					







1	KK 06 43 21	Crossshaft Cat 3, L = 965 mm	36	KK 07 98 24	Stand, H = 700 (for RN w/high beams)
2	KK 06 43 60	Stop collar	37	KK 08 80 02	Lever arm w/bushing
3	KK 03 28 65	Hex screw M20 x 65 mm w/nut	38	KK 01 16 91	Bushing D60 x D75 x 60 mm
4	KK 06 43 17	Bushing	39	KK 01 06 55	Spanner 70
5	KK 08 11 50	Headstock	40	KK 01 06 06	Spanner 19 - 27
6	KK 07 88 98	Axle D50x305	41	KK 01 06 50	Spanner 26 - 36
7	KK 07 97 65	Link w/bushing	42	KK 01 10 31	Roll pin D10 x 70 mm
8	KK 02 99 20	Grease nipple M8x1	43	KK 01 07 00	Pin D12
9	KK 02 99 27	Grease M8 x 1 90°	44	KK 01 03 35	Bolt D25 x 155 mm
10	KK 01 16 82	Bushing D50 x D62 x 50 mm	45	KK 01 03 29	Bolt D25 x 93 mm
11	KK 03 27 30	Hex screw M16 x 30 mm w/nut	46	KK 35 11 39	Screw, R
12	KK 06 25 05	Bracket for hose	47	KK 35 11 48	Lock nut
13	KK 03 52 35	Hex screw M20 x 30 mm w/flange nut	48	KK 35 11 44	Tube
14	KK 01 21 85	Hose bracket	49	KK 35 11 40	Screw, L
15	KK 06 25 06	Plate	50	KK 36 11 16	Turnbuckle cpl. (520 - 720)
16	KK 03 24 03	Hex screw M8 x 130 mm w/nut	51	KK 08 21 77	Chain w/spring
17	KK 03 24 75	Hex screw M8 x 75 mm w/nut	52	KK 08 21 79	Bolt for chain
18	KK 06 24 58	Arm	53	KK 01 10 32	Roll pin D10 x 50 mm
19	KK 06 25 00	Holder for spanner	54	KK 01 01 53	Bushing
20	KK 03 51 65	Hex screw M20 x 50 mm w/flange nut	55	KK 01 10 20	Roll pin D12 x 40 mm
21	KK 08 00 80	Front piece (Adjustable high)		KK 01 00 08	Bushing
22	KK 03 27 30	Hex screw M16 x 30 mm		KK 08 05 68	Fixing device (From 01.05.04)
23	KK 08 10 44	Support			
24	KK 03 28 28	Hex screw M20 x 220 mm w/nut			
25	KK 07 85 64	Connection plate			
26	KK 08 10 98	Hose bracket			
27	KK 07 85 46	Axle D60 w/lock plate			
28	KK 03 27 50	Hex screw M16 x 50 mm w/nut			
29	KK 03 28 20	Hex screw M20 x 200 mm w/nut			
30	KK 07 72 81	Arm bended			
31	KK 07 72 80	Arm streight			
32	KK 07 85 50	Spacing tube			
33	KK 08 80 25	Towing tube, short L = 2157 mm (for PN/RN-100 5-(5+1) - 6-(6+1) furrows and PN/RN-115 5-7 furrows)			
	KK 08 80 26	Towing tube, long L = 3130 mm (for PN/RN-100 7-8 furrows)			
34	KK 08 10 85	Parking bracket			
35	KK 07 85 31	Stand, H = 550 (for PN/RN standard legs)			
	KK 07 85 30	Stand, H = 630 (for PN w/high beams)			



1	KK 03 28 22	Hex screw M20 x 190 mm	29	KK 03 27 92	Hex screw M16 x 90 mm w/ nut
2	KK 08 24 96	Beam support, RN100 - 14" and RN115 - 16"	30	KK 01 58 30	Nut M20
	KK 08 24 97	Beam support, RN100 - 16" and RN115 - 18"	31	KK 03 28 28	Hex screw M20 x 220 mm on 2. beamholder
	KK 08 24 98	Beam support, RN100 - 18"	32	KK 07 12 59	2 balls w/bolt M16 x 90 mm and locktite
3	KK 06 16 37	Plate	33	KK 06 28 36	Hex screw M20 x 240 mm (From 01.09.04)
4	KK 07 12 56	2 balls w/bolt M16 x 50 mm and locktite	34	KK 08 80 79	Plate (From 01.09.04)
5	KK 08 45 36	Beam support w/balls PN100 - 14" and PN115 - 16"	35	KK 08 80 78	Plate (From 01.09.04)
	KK 08 45 37	Beam support w/balls PN100 - 16" and PN115 - 18"	36	KK 07 70 26	Bushing (with hydr. front furrow) (From 01.09.04)
	KK 08 45 38	Beam support w/balls PN100 - 18"	37	KK 07 70 27	Bushing (with hydr. front furrow) (From 01.09.04)
6	KK 03 27 45	Hex screw M16 x 45 mm	38	KK 01 30 00	Washer (with hydr. front furrow) (From 01.09.04)
7	KK 01 58 25	Nut M16	39	KK 08 49 10	Beam support w/ balls PN100 - 14" & PN115 - 16" (From 01.09.04)
8	KK 08 80 10	Main tube 5 furrow, PN/RN-100		KK 08 49 11	Beam support w/ balls PN100 - 16" & PN115 - 18" (From 01.09.04)
	KK 08 80 11	Main tube 6 furrow, PN/RN-100		KK 08 49 12	Beam support w/ balls PN100 - 18" (From 01.09.04)
	KK 08 80 12	Main tube 7 furrow, PN/RN-100			
	KK 08 80 13	Main tube 8 furrow, PN/RN-100			
	KK 08 80 14	Main tube 5 furrow, PN/RN-115			
	KK 08 80 15	Main tube 6 furrow, PN/RN-115			
	KK 08 80 16	Main tube 7 furrow, PN/RN-115			
9	KK 08 80 49	Threaded plate			
10	KK 03 28 45	Hex screw M20 x 45 mm			
11	KK 08 80 45	Fixing device			
12	KK 07 71 28	Adjustable plate			
13	KK 07 71 33	Wearing plate			
14	KK 03 50 88	Countersunk flat head screw M16 x 50 mm			
15	KK 08 80 42	Frame support plate			
16	KK 03 28 21	Hex screw M20 x 210 mm			
17	KK 08 80 00	Tube w/bushing			
18	KK 03 28 50	Hex screw M20 x 50 mm			
19	KK 08 80 19	Threaded plate			
20	KK 08 80 17	Additional tube, PN/RN100			
	KK 08 80 18	Additional tube, PN/RN115			
21	KK 01 09 40	Plastic cover 150 x 150 x 12.5 mm			
22	KK 01 16 91	Bushing			
23	KK 02 99 20	Grease nipple			
26	KK 08 12 33	Fixing for stay, upper			
27	KK 08 12 34	Fixing for stay, lower			
	KK 08 12 33 R	Fixing for stay, upper and lower (pos. 7 and pos. 8 are delivered together)			
28	KK 01 01 68	Bushing D30 x d16 x 41			






1	KK 07 88 44	Universal joint w/bushing	35	KK 08 11 41	Scraper bracket L
2	KK 01 16 82	Bushing 50x62x50mm	36	KK 08 10 80	Axle
3	KK 07 90 75	Axle w/lock plate	37	KK 07 89 23	Wheel hub
4	KK 03 27 50	Hex screw M16x50 w/nut	38	KK 01 07 46	Bearing 40x80x10/7mm
5	KK 02 99 22	Grease nipple M8 x 1, 90°	39	KK 01 05 48	Nilos
6	KK 02 99 20	Grease nipple M8 x 1	40	KK 07 94 16	Gasket w/rubber packing
7	KK 08 80 00	Tube w/bushing	41	KK 01 07 31	Lock ring
8	KK 08 80 20	Bracket tube	42	KK 01 07 30	Special nut
9	KK 01 11 63	Conical washer	43	KK 01 11 62	Screw M18x47.5
10	KK 08 10 70	Bracket	44	KK 03 28 30	Hex screw M20x30
11	KK 03 29 21	Hex screw M24 x 190 mm w/nut			
12	KK 06 22 70	U-bolt	Not ill.	KK 01 13 84	Wheel 400x22.5 w/8 ply cpl.
13	KK 08 10 96	Axle		KK 01 14 08	Wheel 400x22.5 w/14 ply cpl.
14	KK 07 88 49	Plate		KK 01 14 50	Wheel 500x22.5 w/8 ply cpl.
15	KK 07 89 56	Plate			
16	KK 01 60 12	Flange nut M20			
17	KK 01 13 68	Tyre 400x22.5/8			
	KK 01 14 14	Tyre 400x22.5/14			
	KK 01 14 15	Tyre 500x22.5/8			
	KK 01 13 70	Rim for tyre 400x22.5			
	KK 01 14 53	Rim for tyre 500x22.5			
18	KK 01 29 22	Washer			
19	KK 03 27 60	Hex screw M16x60 w/nut			
20	KK 01 07 00	Pin			
21	KK 08 10 68	Cover			
22	KK 01 09 21	Plastic plug			
23	KK 08 10 75	Cylinder bracket			
24	KK 08 10 84	Spacing tube			
25	KK 03 29 00	Hex screw M24x100			
26	KK 07 91 91	Axle D50x478			
27	KK 08 21 50	Wheel arm, L			
28	KK 08 10 81	Cap			
29	KK 03 28 80	Hex screw M20x80 w/nut			
30	KK 08 11 40	Scraper bracket R			
31	KK 03 27 45	Hex screw M16x45 w/nut			
32	KK 08 11 42	Scraper for 400x22.5 and 500x22.5			
33	KK 03 28 05	Hex screw M20x120 mm w/nut			
34	KK 08 21 51	Wheel arm, L			



Замовлення запчастин
(050)-407-68-47
(050)-407-68-45



1	KK 01 10 59	Pin D10 x 60 mm
2	KK 07 85 84	Axle D35 x 110 mm
3	KK 07 85 83	Axle D35 x 150 mm
4	KK 35 27 79	Cylinder D100 x 400 w/stop (Before 15.05.99) (see plate no. 1025)
	KK 35 38 13	Cylinder D100 x 400 w/stop (From 15.05.99) (Before 01.10.00) (see plate no. 1084)
	KK 35 38 34	Cylinder D100 x 400 w/stop (From 01.10.00) (Before 01.06.04) (see plate no. 1145)
	KK 35 46 00	Cylinder D100 x 400 w/stop (From 01.06.04) (see plate no. 1283)
5	KK 01 25 51	Banjobolt w/filter
6	KK 01 15 85	Gasket ring 3/8"
7	KK 01 25 48	Banjo adjustable
8	KK 01 27 23	Valve w/handle 3/8"
9	KK 01 22 61	Threaded coupling 3/8" - 3/8"
10	KK 01 27 96	Hose 3/8" x 5000 mm
11	KK 01 26 55	Hose 3/8" x 350 mm
12	KK 01 20 62	Banjo
13	KK 01 25 22	Plastic D18 x 2 mm
14	KK 01 23 24	Cover
15	KK 03 24 60	Hex screw M8 x 60 mm
16	KK 03 23 35	Hex screw M6 x 35 mm
17	KK 01 20 69	Cover
18	KK 01 20 68	Plastic D18 x 1 mm
19	KK 01 20 60	Threaded coupling 3/8" - 1/2"
20	KK 01 15 65	Gasket ring 1/4"
21	KK 03 24 35	Hex screw M8 x 35 mm
22	KK 01 21 14	Quick coupling plug
23	KK 01 25 70	Banjo double
24	KK 01 35 18	Swivel 3/8" w/sleeve
25	KK 01 35 22	Hose 1/4" L=1800 mm
26	KK 01 27 00	Clamp
27	KK 35 22 46	Stop clips D35 x D50
Not ill.	KK 01 35 20	Hose clamp





1	KK 01 26 55	Hose 3/8", L = 350 mm
2	KK 01 23 25	T - coupling 3/8"
3	KK 01 35 17	Relief valve 3/8", 250 bar
4	KK 01 15 85	Gasket ring 3/8"
5	KK 01 23 07	Banjo bolt 3/8" - 3/8"
6	KK 01 20 62	Banjo 3/8"
7	KK 01 35 19	Hose D6, L = 1000 mm NITRIK



Замовлення запчастин
(050)-407-68-47
(050)-407-68-45



1	KK 01 03 37	Bolt D25 x 180 mm
2	KK 35 36 35	Hydraulic cylinder w/stop and bellow D100 x 190 mm (see plate no. 1130)
3	KK 01 22 61	Threaded coupling 3/8" - 3/8"
4	KK 01 20 62	Banjo
5	KK 01 15 85	Bounded seal
6	KK 01 20 59	Banjo bolt L = 31 mm
7	KK 01 09 61	Filter
8	KK 01 09 60	Filter cap
9	KK 35 22 46	Stop clips D35 x D50
10	KK 01 21 16	Hydraulic hose holder
11	KK 01 20 60	Threaded coupling 3/8" - 1/2"
12	KK 01 15 65	Bounded seal
13	KK 01 21 14	Fast coupling plug
14	KK 01 27 80	Hose 3/8" x 8000 mm for 6 furrow
	KK 01 27 81	Hose 3/8" x 9000 mm for 7 furrow
	KK 01 26 58	Hose 3/8" x 9400 mm for 8 furrow
15	KK 01 20 68	Plastic D18 x 1 mm
16	KK 01 20 69	Cover
17	KK 03 23 35	Hex screw M6 x 35 mm
18	KK 01 04 13	Axle D25 x 210 mm
19	KK 01 10 20	Roll pin




Замовлення запчастин
(050)-407-68-47
(050)-407-68-45



1	KK 35 39 04	Furrow adjustment cylinder D75 x 200 mm cpl. (see plate no. 1195)
2	KK 01 03 19	Bolt w/head D25.3 x 120 mm
3	KK 01 10 20	Roll pin D12 x 40 mm
4	KK 01 03 28	Bolt w/head D25.3 x 78 mm
5	KK 01 15 65	Gasket ring 1/2"
6	KK 01 27 28	Banjo bolt
7	KK 01 21 77	Gasket ring
8	KK 01 21 46	Banjo bolt 1/2" w/1.0 mm choke
9	KK 01 21 02	Threaded coupling 3/8" - 1/2"
10	KK 01 15 23	Hose 3/8", L = 4500 mm w/angle coupling
11	KK 01 15 12	Hose 3/8", L = 4500 mm



Замовлення запчастин
(050)-407-68-47
(050)-407-68-45



1	KK 35 37 98	Cylinder tube
2	KK 01 65 31	Sliding ring
3	KK 01 65 32	Packing
4	KK 03 20 06	Screw M6 x 20 mm
5	KK 35 37 83	Piston
6	KK 01 65 10	O-ring D40
7	KK 35 37 99	Piston rod
8	KK 01 17 19	O-ring D93
9	KK 01 17 24	Support
10	KK 35 37 95	Lock ring
11	KK 35 37 39	Rod cap
12	KK 01 17 25	Seal for piston rod
13	KK 01 17 27	Scraper
14	KK 35 37 85	Stopping nut
15	KK 03 20 16	Screw M10 x 45 mm
16	KK 35 37 73	Clevis

Not ill.	KK 01 36 05	Packings cpl.
	KK 35 38 13	Hydraulic cylinder D100 x 400 mm w/stop cpl.



Замовлення запчастин
(050)-407-68-47
(050)-407-68-45



1	KK 35 38 84	Cylinder tube
2	KK 01 65 31	Sliding ring
3	KK 01 65 32	Packing
4	KG00917800	Screw M6 x 20 mm
5	KK 35 37 83	Piston
6	KK 01 65 10	O-ring D40
7	KK 35 38 85	Piston rod
8	KK 01 17 19	O-ring D93
9	KK 01 17 24	Support
10	KK 35 37 95	Lock ring
11	KK 35 37 39	Rod cap
12	KK 01 17 25	Seal for piston rod
13	KK 01 17 27	Scraper
14	KK 35 37 85	Stopping nut
15	KK 03 20 16	Screw M10 x 45 mm
16	KK 35 37 73	Clevis

Not ill.	KK 01 36 05	Packings cpl.
	KK 35 46 00	Hydraulic cylinder D100 x 400 mm w/stop cpl.



Замовлення запчастин
(050)-407-68-47
(050)-407-68-45




1	KK 35 35 57	Cylinder tube
2	KK 01 19 08	Piston packing
3	KK 35 35 58	Piston rod w/piston
4	KK 01 18 06	O-ring D94
5	KK 35 35 59	End cap w/packings
6	KK 01 26 37	Seal for piston rod
7	KK 01 20 39	Scraper
8	KK 01 35 97	Wire clamp D110
9	KK 01 35 95	Bellow
10	KK 01 26 19	O-ring D50
11	KK 01 37 05	Spring ring
12	KK 01 35 94	Ring for bellow
13	KK 35 45 30	Stop
14	KK 35 35 61	Clevis
15	UH 82 52 35	Cylinder screw M8 x 35 mm

Not ill.	KK 01 26 40	Packings set
	KK 35 36 35	Hydraulic cylinder w/stop and bellow D100 x 190 mm cpl.




Замовлення запчастин
(050)-407-68-47
(050)-407-68-45



1	KK 35 39 38	Cylinder tube (for cylinder KK 35 39 04 and KK 35 39 05)
	KK 35 39 39	Cylinder tube (for cylinder KK 35 39 06)
2	KK 35 39 40	Piston rod (for cylinder KK 35 39 04 and KK 35 39 06)
	KK 35 39 41	Piston rod (for cylinder KK 35 39 05)
3	KK 01 30 93	Piston packing
4	KK 01 30 96	O-ring D67 x 4 mm
5	KK 01 30 95	Support ring
6	KK 03 33 06	Hex screw M6 x 8 mm
7	KK 35 39 27	Packing seal
8	KK 01 30 94	Piston rod packing
9	KK 01 30 92	Scraper
10	KK 03 21 10	Set screw M8 x 8 mm (for cylinder KK 35 39 05)
11	KK 35 39 46	Pin for stop (for cylinder KK 35 39 05)
12	KK 35 39 45	Stop (for cylinder KK 35 39 05)
13	UH 82 56 40	Cylinder screw M12 x 40 mm
14	KK 35 39 23	Clevis

Not ill.	KK 01 30 87	Packings cpl.
	KK 35 39 04	Hydraulic cylinder D75 x 200 mm cpl.
	KK 35 39 05	Hydraulic cylinder D75 x 200 mm w/stop cpl.
	KK 35 39 06	Hydraulic cylinder D75 x 200 mm w/90° twisted end cap cpl.







4



11



1	KK 70 99 96	Kverneland PN-100
	KK 70 99 98	Kverneland RN-100
2	KK 70 99 97	Kverneland PN-115
	KK 70 99 99	Kverneland RN-115
3	KK 70 97 37	Arrow
4	KK 70 98 31	Kverneland w/arrow
5	KK 70 94 79	Info. nuts
6	KK 70 98 43	Safty sign, parking support
7	KK 70 98 42	Safty sign, reversible plough
8	KK 70 98 44	Safty sign, read instruction manual
9	KK 70 98 41	Safty sign, danger, tractor/implement
10	KK 70 98 95	Safty sign, sharp edges
11	KK 70 99 08	Wheel adjustment



Замовлення запчастин
(050)-407-68-47
(050)-407-68-45

Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page
KG00917800 43		KK 01 10 31 27		KK 01 17 27 41		KK 01 26 40 45		KK 01 33 32 13		KK 01 58 17 21		KK 02 99 20 27		KK 03 27 60 31	
KK 01 00 08 27		KK 01 10 32 27		KK 01 17 27 43		KK 01 26 55 33		KK 01 33 32 5		KK 01 58 25 13		KK 02 99 20 29		KK 03 27 62 19	
KK 01 01 53 27		KK 01 10 37 17		KK 01 17 50 21		KK 01 26 55 35		KK 01 33 32 9		KK 01 58 25 13		KK 02 99 20 31		KK 03 27 65 11	
KK 01 01 55 11		KK 01 10 42 17		KK 01 17 50 23		KK 01 26 58 37		KK 01 33 32 9		KK 01 58 25 13		KK 02 99 22 31		KK 03 27 65 15	
KK 01 01 55 15		KK 01 10 59 33		KK 01 18 06 45		KK 01 27 00 33		KK 01 33 33 7		KK 01 58 25 15		KK 02 99 27 27		KK 03 27 65 7	
KK 01 01 55 7		KK 01 11 62 31		KK 01 18 66 21		KK 01 27 23 33		KK 01 33 33 9		KK 01 58 25 15		KK 03 10 30 23		KK 03 27 75 11	
KK 01 01 56 11		KK 01 11 63 31		KK 01 18 66 23		KK 01 27 28 39		KK 01 33 46 11		KK 01 58 25 15		KK 03 20 06 41		KK 03 27 75 15	
KK 01 01 56 15		KK 01 12 59 21		KK 01 19 08 45		KK 01 27 80 37		KK 01 33 46 15		KK 01 58 25 25		KK 03 20 16 41		KK 03 27 75 23	
KK 01 01 56 7		KK 01 12 59 23		KK 01 20 39 45		KK 01 27 81 37		KK 01 33 46 7		KK 01 58 25 29		KK 03 20 16 43		KK 03 27 75 7	
KK 01 01 68 29		KK 01 12 66 21		KK 01 20 59 37		KK 01 27 96 33		KK 01 33 46 7		KK 01 58 30 21		KK 03 21 10 47		KK 03 27 85 23	
KK 01 03 19 39		KK 01 12 66 23		KK 01 20 60 33		KK 01 29 06 25		KK 01 33 46 9		KK 01 58 30 21		KK 03 23 35 33		KK 03 27 92 29	
KK 01 03 28 39		KK 01 13 68 31		KK 01 20 60 37		KK 01 29 13 17		KK 01 33 61 11		KK 01 58 30 29		KK 03 23 35 37		KK 03 27 95 25	
KK 01 03 29 27		KK 01 13 70 31		KK 01 20 62 33		KK 01 29 19 5		KK 01 33 61 15		KK 01 58 32 5		KK 03 24 03 27		KK 03 28 03 19	
KK 01 03 35 27		KK 01 13 84 31		KK 01 20 62 35		KK 01 29 19 9		KK 01 33 61 7		KK 01 58 34 9		KK 03 24 35 33		KK 03 28 05 31	
KK 01 03 37 37		KK 01 14 08 31		KK 01 20 62 37		KK 01 29 22 13		KK 01 33 85 11		KK 01 58 41 25		KK 03 24 60 33		KK 03 28 07 19	
KK 01 04 13 37		KK 01 14 14 31		KK 01 20 68 33		KK 01 29 22 31		KK 01 33 85 15		KK 01 60 04 21		KK 03 24 75 27		KK 03 28 20 27	
KK 01 05 32 21		KK 01 14 15 31		KK 01 20 68 37		KK 01 29 22 5		KK 01 33 85 7		KK 01 60 12 31		KK 03 26 55 17		KK 03 28 21 29	
KK 01 05 32 23		KK 01 14 50 31		KK 01 20 69 33		KK 01 29 22 9		KK 01 35 17 35		KK 01 60 13 13		KK 03 26 65 17		KK 03 28 22 29	
KK 01 05 48 31		KK 01 14 53 31		KK 01 20 69 37		KK 01 29 27 5		KK 01 35 18 33		KK 01 60 15 11		KK 03 27 02 23		KK 03 28 24 19	
KK 01 05 72 21		KK 01 15 12 39		KK 01 21 02 39		KK 01 29 27 9		KK 01 35 19 35		KK 01 60 15 13		KK 03 27 25 5		KK 03 28 28 27	
KK 01 05 72 23		KK 01 15 23 39		KK 01 21 14 33		KK 01 29 29 11		KK 01 35 20 33		KK 01 60 15 15		KK 03 27 25 9		KK 03 28 28 29	
KK 01 06 06 27		KK 01 15 65 33		KK 01 21 14 37		KK 01 29 29 15		KK 01 35 22 33		KK 01 60 15 7		KK 03 27 30 27		KK 03 28 30 21	
KK 01 06 50 27		KK 01 15 65 37		KK 01 21 16 37		KK 01 29 29 7		KK 01 35 94 45		KK 01 60 22 19		KK 03 27 30 27		KK 03 28 30 31	
KK 01 06 55 27		KK 01 15 65 39		KK 01 21 46 39		KK 01 29 60 23		KK 01 35 95 45		KK 01 60 31 21		KK 03 27 35 5		KK 03 28 40 17	
KK 01 07 00 27		KK 01 15 85 33		KK 01 21 77 39		KK 01 30 87 47		KK 01 35 97 45		KK 01 60 45 19		KK 03 27 35 9		KK 03 28 40 19	
KK 01 07 00 31		KK 01 15 85 35		KK 01 21 85 27		KK 01 30 92 47		KK 01 36 05 41		KK 01 60 49 19		KK 03 27 40 11		KK 03 28 40 19	
KK 01 07 30 31		KK 01 15 85 37		KK 01 22 61 33		KK 01 30 93 47		KK 01 36 05 43		KK 01 65 10 41		KK 03 27 40 15		KK 03 28 40 21	
KK 01 07 31 31		KK 01 16 82 27		KK 01 22 61 37		KK 01 30 94 47		KK 01 37 05 45		KK 01 65 10 43		KK 03 27 40 7		KK 03 28 40 23	
KK 01 07 46 31		KK 01 16 82 31		KK 01 23 07 35		KK 01 30 95 47		KK 01 58 13 13		KK 01 65 31 41		KK 03 27 45 29		KK 03 28 45 19	
KK 01 08 18 23		KK 01 16 91 27		KK 01 23 24 33		KK 01 30 96 47		KK 01 58 13 13		KK 01 65 31 43		KK 03 27 45 31		KK 03 28 45 19	
KK 01 09 21 31		KK 01 16 91 29		KK 01 23 25 35		KK 01 32 28 11		KK 01 58 16 25		KK 01 65 32 41		KK 03 27 50 11		KK 03 28 45 29	
KK 01 09 40 29		KK 01 17 19 41		KK 01 25 22 33		KK 01 32 28 13		KK 01 58 17 13		KK 01 65 32 43		KK 03 27 50 13		KK 03 28 50 19	
KK 01 09 60 37		KK 01 17 19 43		KK 01 25 48 33		KK 01 32 28 15		KK 01 58 17 13		KK 02 97 27 17		KK 03 27 50 15		KK 03 28 50 23	
KK 01 09 61 37		KK 01 17 24 41		KK 01 25 51 33		KK 01 32 28 7		KK 01 58 17 13		KK 02 97 27 17		KK 03 27 50 27		KK 03 28 50 29	
KK 01 10 20 27		KK 01 17 24 43		KK 01 25 70 33		KK 01 32 28 9		KK 01 58 17 13		KK 02 99 20 17		KK 03 27 50 31		KK 03 28 55 17	
KK 01 10 20 37		KK 01 17 25 41		KK 01 26 19 45		KK 01 32 34 5		KK 01 58 17 13		KK 02 99 20 21		KK 03 27 50 7		KK 03 28 60 17	
KK 01 10 20 39		KK 01 17 25 43		KK 01 26 37 45		KK 01 32 34 9		KK 01 58 17 15		KK 02 99 20 23		KK 03 27 50 9		KK 03 28 60 19	

Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page
KK 03 28 60	19	KK 03 42 25	25	KK 06 06 57	25	KK 06 61 82	21	KK 07 03 95	5	KK 07 30 04	13	KK 07 30 64	9	KK 07 32 57	13
KK 03 28 65	19	KK 03 42 28	25	KK 06 07 03	17	KK 06 61 89	21	KK 07 03 96	9	KK 07 30 04	5	KK 07 30 65	13	KK 07 32 57	5
KK 03 28 65	27	KK 03 42 50	25	KK 06 12 80	17	KK 06 61 90	21	KK 07 03 97	9	KK 07 30 05	13	KK 07 30 65	9	KK 07 32 60	5
KK 03 28 80	31	KK 03 44 46	25	KK 06 12 91	17	KK 06 68 11	25	KK 07 03 98	9	KK 07 30 05	5	KK 07 30 80	13	KK 07 32 61	5
KK 03 29 00	31	KK 03 50 20	17	KK 06 12 91	29	KK 06 68 11	25	KK 07 03 99	9	KK 07 30 06	13	KK 07 30 80	9	KK 07 32 63	5
KK 03 29 21	31	KK 03 50 21	17	KK 06 15 15	19	KK 06 68 12	25	KK 07 06 39	25	KK 07 30 06	5	KK 07 30 81	13	KK 07 32 64	5
KK 03 30 06	13	KK 03 50 31	21	KK 06 16 37	29	KK 06 68 61	25	KK 07 06 40	5	KK 07 30 07	13	KK 07 30 81	9	KK 07 32 66	5
KK 03 30 06	25	KK 03 50 48	19	KK 06 20 20	19	KK 06 68 68	25	KK 07 06 40	9	KK 07 30 07	5	KK 07 30 88	13	KK 07 32 66	9
KK 03 30 07	25	KK 03 50 60	19	KK 06 20 25	9	KK 06 68 69	25	KK 07 06 41	5	KK 07 30 08	5	KK 07 30 88	5	KK 07 32 67	5
KK 03 30 16	13	KK 03 50 72	19	KK 06 22 70	31	KK 06 68 73	25	KK 07 06 41	9	KK 07 30 09	5	KK 07 30 88	9	KK 07 32 67	9
KK 03 31 00	5	KK 03 50 88	29	KK 06 24 58	27	KK 06 68 80	25	KK 07 06 42	5	KK 07 30 30	13	KK 07 30 89	13	KK 07 32 80	5
KK 03 31 00	9	KK 03 51 65	17	KK 06 25 00	27	KK 06 68 81	25	KK 07 06 42	9	KK 07 30 30	5	KK 07 30 89	5	KK 07 32 81	5
KK 03 31 07	13	KK 03 51 65	27	KK 06 25 05	27	KK 06 70 16	17	KK 07 06 53	25	KK 07 30 31	13	KK 07 30 89	9	KK 07 32 86	5
KK 03 31 07	5	KK 03 52 09	17	KK 06 25 06	27	KK 06 70 25	17	KK 07 12 07	19	KK 07 30 31	5	KK 07 30 91	13	KK 07 32 87	5
KK 03 31 07	9	KK 03 52 15	19	KK 06 30 90	11	KK 06 70 26	17	KK 07 12 08	19	KK 07 30 40	5	KK 07 30 91	5	KK 07 32 90	5
KK 03 31 07	9	KK 03 52 16	19	KK 06 30 90	13	KK 06 70 31	17	KK 07 12 09	19	KK 07 30 41	5	KK 07 30 91	9	KK 07 32 90	9
KK 03 31 11	13	KK 03 52 35	27	KK 06 30 90	15	KK 06 70 39	17	KK 07 12 11	19	KK 07 30 42	13	KK 07 30 92	13	KK 07 32 91	5
KK 03 31 16	13	KK 05 07 06	17	KK 06 30 90	5	KK 06 70 40	17	KK 07 12 12	19	KK 07 30 42	5	KK 07 30 92	5	KK 07 32 91	9
KK 03 31 17	13	KK 05 30 90	11	KK 06 30 90	7	KK 06 70 51	17	KK 07 12 28	19	KK 07 30 43	13	KK 07 30 92	9	KK 07 33 00	13
KK 03 31 75	13	KK 05 30 90	13	KK 06 30 90	9	KK 06 70 57	17	KK 07 12 56	29	KK 07 30 43	5	KK 07 32 24	9	KK 07 33 00	5
KK 03 31 75	5	KK 05 30 90	15	KK 06 30 91	13	KK 06 70 59	17	KK 07 12 59	29	KK 07 30 44	13	KK 07 32 25	9	KK 07 33 00	9
KK 03 31 75	9	KK 05 30 90	5	KK 06 30 91	5	KK 06 70 60	17	KK 07 12 70	19	KK 07 30 44	5	KK 07 32 27	9	KK 07 33 01	13
KK 03 32 51	13	KK 05 30 90	7	KK 06 30 92	13	KK 06 70 68	17	KK 07 12 71	19	KK 07 30 45	13	KK 07 32 28	9	KK 07 33 01	5
KK 03 32 51	5	KK 05 30 90	9	KK 06 30 92	5	KK 06 70 70	17	KK 07 12 72	19	KK 07 30 45	5	KK 07 32 30	13	KK 07 33 01	9
KK 03 32 51	9	KK 05 33 87	5	KK 06 33 88	5	KK 06 70 75	17	KK 07 12 73	19	KK 07 30 54	13	KK 07 32 30	9	KK 07 33 10	5
KK 03 32 56	13	KK 05 33 87	9	KK 06 33 88	9	KK 06 70 76	17	KK 07 12 74	19	KK 07 30 54	9	KK 07 32 31	13	KK 07 33 10	9
KK 03 32 56	5	KK 05 68 73	25	KK 06 36 07	7	KK 06 70 77	17	KK 07 12 75	19	KK 07 30 55	13	KK 07 32 31	9	KK 07 33 11	5
KK 03 32 56	9	KK 05 70 63	17	KK 06 36 07	9	KK 06 70 80	17	KK 07 12 80	19	KK 07 30 55	9	KK 07 32 36	9	KK 07 33 11	9
KK 03 32 86	13	KK 05 70 64	17	KK 06 38 01	5	KK 06 70 90	17	KK 07 12 81	19	KK 07 30 56	13	KK 07 32 37	9	KK 07 34 06	5
KK 03 32 86	5	KK 05 70 65	17	KK 06 38 01	5	KK 06 70 92	17	KK 07 15 08	19	KK 07 30 56	9	KK 07 32 39	9	KK 07 34 07	5
KK 03 32 86	9	KK 05 70 66	17	KK 06 43 17	27	KK 07 03 88	9	KK 07 15 29	19	KK 07 30 57	13	KK 07 32 40	9	KK 07 34 11	5
KK 03 32 95	13	KK 05 70 67	17	KK 06 43 21	27	KK 07 03 89	9	KK 07 30 00	5	KK 07 30 57	9	KK 07 32 41	9	KK 07 34 12	5
KK 03 32 95	5	KK 05 70 68	17	KK 06 43 60	27	KK 07 03 90	5	KK 07 30 01	5	KK 07 30 62	13	KK 07 32 42	9	KK 07 34 14	5
KK 03 32 95	9	KK 05 70 89	17	KK 06 61 70	21	KK 07 03 91	5	KK 07 30 02	13	KK 07 30 62	9	KK 07 32 50	5	KK 07 34 15	5
KK 03 33 06	47	KK 06 01 08	17	KK 06 61 75	21	KK 07 03 92	9	KK 07 30 02	5	KK 07 30 63	13	KK 07 32 51	5	KK 07 34 17	9
KK 03 33 32	5	KK 06 01 09	17	KK 06 61 78	21	KK 07 03 93	9	KK 07 30 03	13	KK 07 30 63	9	KK 07 32 56	13	KK 07 34 18	9
KK 03 35 40	21	KK 06 01 19	17	KK 06 61 78	23	KK 07 03 94	5	KK 07 30 03	5	KK 07 30 64	13	KK 07 32 56	5	KK 07 34 35	9

Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page
KK 07 34 36	9	KK 07 38 26	9	KK 07 68 34	25	KK 08 10 84	31	KK 08 30 20	15	KK 08 34 06	13	KK 08 61 12	21	KK 35 37 39	43
KK 07 34 40	9	KK 07 38 26	9	KK 07 68 58	25	KK 08 10 85	27	KK 08 30 20	7	KK 08 34 07	13	KK 08 61 13	21	KK 35 37 73	41
KK 07 34 41	9	KK 07 38 29	9	KK 07 68 58	25	KK 08 10 96	31	KK 08 30 21	11	KK 08 34 08	13	KK 08 61 14	21	KK 35 37 73	43
KK 07 36 07	7	KK 07 38 30	5	KK 07 68 59	25	KK 08 10 98	27	KK 08 30 21	15	KK 08 34 09	13	KK 08 61 15	21	KK 35 37 83	41
KK 07 36 07	9	KK 07 38 31	5	KK 07 68 72	25	KK 08 11 40	31	KK 08 30 21	7	KK 08 34 15	13	KK 08 68 01	25	KK 35 37 83	43
KK 07 36 08	13	KK 07 38 31	9	KK 07 69 43	25	KK 08 11 41	31	KK 08 30 22	11	KK 08 34 16	13	KK 08 80 00	29	KK 35 37 85	41
KK 07 36 08	5	KK 07 38 42	9	KK 07 69 44	25	KK 08 11 42	31	KK 08 30 22	15	KK 08 34 17	13	KK 08 80 00	31	KK 35 37 85	43
KK 07 36 08	9	KK 07 49 10	19	KK 07 70 23	19	KK 08 11 50	27	KK 08 30 22	7	KK 08 34 18	13	KK 08 80 02	27	KK 35 37 95	41
KK 07 36 09	13	KK 07 49 11	19	KK 07 70 24	19	KK 08 12 33	29	KK 08 30 23	11	KK 08 38 02	13	KK 08 80 10	29	KK 35 37 95	43
KK 07 36 09	5	KK 07 49 30	23	KK 07 71 28	29	KK 08 12 33	29	KK 08 30 23	15	KK 08 38 03	13	KK 08 80 11	29	KK 35 37 98	41
KK 07 36 09	9	KK 07 49 31	23	KK 07 71 33	29	KK 08 12 34	29	KK 08 30 23	7	KK 08 38 04	13	KK 08 80 12	29	KK 35 37 99	41
KK 07 36 14	13	KK 07 49 36	23	KK 07 72 80	27	KK 08 21 50	31	KK 08 30 90	11	KK 08 38 05	13	KK 08 80 13	29	KK 35 38 13	33
KK 07 36 14	7	KK 07 49 37	23	KK 07 72 81	27	KK 08 21 51	31	KK 08 30 90	15	KK 08 38 06	13	KK 08 80 14	29	KK 35 38 13	41
KK 07 36 14	9	KK 07 49 38	23	KK 07 85 30	27	KK 08 21 77	27	KK 08 30 90	7	KK 08 38 07	13	KK 08 80 15	29	KK 35 38 34	33
KK 07 36 15	13	KK 07 49 39	23	KK 07 85 31	27	KK 08 21 79	27	KK 08 30 91	11	KK 08 38 08	13	KK 08 80 16	29	KK 35 38 84	43
KK 07 36 15	5	KK 07 60 76	23	KK 07 85 46	27	KK 08 24 96	29	KK 08 30 91	15	KK 08 38 09	5	KK 08 80 17	29	KK 35 38 85	43
KK 07 36 15	9	KK 07 64 00	23	KK 07 85 50	27	KK 08 24 97	29	KK 08 30 91	7	KK 08 38 10	5	KK 08 80 18	29	KK 35 39 04	39
KK 07 36 16	13	KK 07 64 06	21	KK 07 85 64	27	KK 08 24 98	29	KK 08 32 10	13	KK 08 45 36	29	KK 08 80 19	29	KK 35 39 04	47
KK 07 36 16	5	KK 07 64 06	23	KK 07 85 83	33	KK 08 30 10	11	KK 08 32 11	13	KK 08 45 37	29	KK 08 80 20	31	KK 35 39 05	47
KK 07 36 16	9	KK 07 64 07	21	KK 07 85 84	33	KK 08 30 10	15	KK 08 32 12	13	KK 08 45 38	29	KK 08 80 25	27	KK 35 39 06	47
KK 07 36 34	11	KK 07 64 07	23	KK 07 88 44	31	KK 08 30 10	7	KK 08 32 13	13	KK 08 50 76	25	KK 08 80 26	27	KK 35 39 23	47
KK 07 36 34	15	KK 07 64 09	21	KK 07 88 49	31	KK 08 30 11	11	KK 08 32 14	13	KK 08 60 80	21	KK 08 80 42	29	KK 35 39 27	47
KK 07 36 34	7	KK 07 64 09	23	KK 07 88 98	27	KK 08 30 11	15	KK 08 32 15	13	KK 08 60 81	21	KK 08 80 45	29	KK 35 39 38	47
KK 07 36 35	11	KK 07 64 10	21	KK 07 89 23	31	KK 08 30 11	7	KK 08 32 16	13	KK 08 60 82	21	KK 35 11 392	27	KK 35 39 39	47
KK 07 36 35	15	KK 07 64 10	23	KK 07 89 56	31	KK 08 30 16	11	KK 08 32 17	13	KK 08 60 83	21	KK 35 11 40	27	KK 35 39 40	47
KK 07 36 35	7	KK 07 64 99	21	KK 07 90 75	31	KK 08 30 16	15	KK 08 32 18	13	KK 08 60 84	21	KK 35 11 44	27	KK 35 39 41	47
KK 07 38 00	5	KK 07 64 99	23	KK 07 91 91	31	KK 08 30 16	7	KK 08 32 20	13	KK 08 60 85	21	KK 35 11 48	27	KK 35 39 45	47
KK 07 38 00	9	KK 07 65 15	23	KK 07 94 16	31	KK 08 30 17	11	KK 08 32 21	13	KK 08 60 86	23	KK 35 22 46	33	KK 35 39 46	47
KK 07 38 01	5	KK 07 65 27	23	KK 07 97 65	27	KK 08 30 17	15	KK 08 32 22	13	KK 08 60 87	23	KK 35 22 46	37	KK 35 45 30	45
KK 07 38 01	9	KK 07 65 75	23	KK 07 98 24	27	KK 08 30 17	7	KK 08 32 23	13	KK 08 60 89	21	KK 35 27 79	33	KK 35 46 00	33
KK 07 38 03	5	KK 07 68 12	25	KK 08 00 80	27	KK 08 30 18	11	KK 08 32 24	13	KK 08 60 89	23	KK 35 35 57	45	KK 35 46 00	43
KK 07 38 03	5	KK 07 68 13	25	KK 08 10 44	27	KK 08 30 18	15	KK 08 32 28	5	KK 08 60 90	21	KK 35 35 58	45	KK 36 11 16	27
KK 07 38 04	9	KK 07 68 17	25	KK 08 10 68	31	KK 08 30 18	7	KK 08 32 29	5	KK 08 60 90	23	KK 35 35 59	45	KK 70 94 79	49
KK 07 38 04	9	KK 07 68 18	25	KK 08 10 70	31	KK 08 30 19	11	KK 08 32 35	13	KK 08 61 01	21	KK 35 35 61	45	KK 70 97 37	49
KK 07 38 05	9	KK 07 68 25	25	KK 08 10 75	31	KK 08 30 19	15	KK 08 32 35	7	KK 08 61 01	23	KK 35 36 35	37	KK 70 98 31	49
KK 07 38 07	5	KK 07 68 26	25	KK 08 10 80	31	KK 08 30 19	7	KK 08 33 00	13	KK 08 61 10	21	KK 35 36 35	45	KK 70 98 41	49
KK 07 38 08	5	KK 07 68 33	25	KK 08 10 81	31	KK 08 30 20	11	KK 08 33 01	13	KK 08 61 11	21	KK 35 37 39	41	KK 70 98 42	49

Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page
KK 70 98 43	49	KK 70 98 95	49	KK 70 99 96	49	KK 70 99 98	49	KK 89 33 34	11	KK 89 33 34	7	UH 82 56 40	47		
KK 70 98 44	49	KK 70 99 08	49	KK 70 99 97	49	KK 70 99 99	49	KK 89 33 34	15	UH 82 52 35	45				



Замовлення запчастин
(050)-407-68-47
(050)-407-68-45