

Spare Parts List

Model PX/RX-SL-OL and with cat. 4


Semi-mounted plough

No 733029



Notes

GB Model	GB Interbody clearance	GB Headstock
D Modell	D Körperlängsabstand	D Drehwerk
F Modèle	F Dégagement sous age	F Type de tête
E Modelo	E Separación entre cuerpos	E Tipo de cabezal



GB Serial number	Type: HD=Heavy Duty SL=Vibromat OL=On-land	GB Body no.
D Seriennummer		D Körper no.
F Numéro de série		F Type no.
E Numero de serie		E Tipo no.

Замовлення запчастин

(GB) Complete model code and serial number must be stated to avoid mistakes when ordering spare parts and misunderstandings regarding service consultations. The identification plate is located on the headstock.

(F) Le code complet et le numéro de série doivent être indiqués pour éviter des erreurs lors de la commande de pièces de rechange et des malentendus concernant des demandes de Service-Après-Vente. La plaque d'identité est située sur la tête.

(D) Um bei Ersatzteilbestellungen und Serviceleistungen Fehler und Mißverständnisse zu vermeiden ist es erforderlich, daß die genaue Bezeichnung und die Seriennummer angegeben werden. Die Plakette befindet sich am Drehwerk.

(E) Debe figura el código completo del modelo y el número de serie para evitar errores al pedir las piezas de recambio y al hacer consultas técnicas. La placa de identificación esta situada en el cabezal.

Plate	Page
244	Bodies no 6, 7, 8, 9 and 284
367	Bodies no 12, 15 and 198
494	Body no 14 (Plastic mouldboard)12
414	Body no 20 (Finger Body) (Before 01.03.99)14
1089	Bodies no. 29 and no. 3016
458	Auto Reset Beam20
489	Beam (Shear bolt) and beam support22
491	Vibromat type SL24
187	Disc coulter for Auto Reset beam (Before 01.01.99)26
1073	Disc coulter 18" and 20", E-saddle (From 01.01.99)28
1044	Disc coulter LD, LO, SL, RB, RS, RT (rear frame) and RX30
	(RS, RX from 15.09.99, RB from 01.05.01)30
1000	Springloaded disc coulter32
341	Manure skimmer / Maize skimmer34
547	Additional tubes PX/RX36
585	Turn-over device for PX/RX, cat. 438
540	Front, front part for PX/RX, 6 - 8 furrow40
544	Front, rear part for PX/RX, 6 - 8 furrow42
545	Center section for PX/RX44
546	Truck46
583	Front, front part for PX/RX cat. 448
586	Center section for PX/RX, cat. 450
584	On-Land equipment for PX/RX, cat. 3 and 452
519	On-Land set (Before 01.08.98)54
520	Hydraulic for On-Land set. (Before 01.08.98)56
549	Hydraulic, center section for PX/RX and RX-SL (Before 01.04.96)58
587	Hydraulic for middle section (From 01.04.96)60
548	Hydraulic, rear part for PX/RX and RX-SL62
550	Layout for turn-over hydraulic, PX/RX and RX/SL64
1266	Relief valve kit68
588	Hydraulic for turn-over and alignment cylinder, for PX/RX cat. 3 and 470
551	Hinge ram (Before 01.03.97)72
1120	Hinge ram (From 01.03.97)74
474	Hydraulic cylinder D75 x 200 mm (Before 01.07.96)76
890	Hydraulic cylinder D75 x 200 mm (353704 - 353707)78
1192	Hydraulic cylinder D50 x 200 mm (353901 - 353903) (From 01.04.01)80
543	Support cylinder D75 x 200 mm (Before 01.01.96)82
1104	Support cylinder D80 x 240 mm84
1026	Hydraulic cylinder D100 x 215 mm w/stop (Before 01.06.00)86
486	Cylinder for wheel D100 x 215 mm w/stop (PB/RB from 15.11.95,88
	PS/RS from 08.03.93 and PD from 01.12.96) (Before 01.06.00)88
1129	Hydraulic cylinder D100 x 200 mm w/stop and bellow (From 01.06.00, w/garmax from 01.08.00)90
552	Hydraulic cylinders for PX/RX and PS/RS On-land92
542	Turn-over cylinder D80 x 440 mm (Before 01.04.98)94
1047	Turn-over cylinder D80 x 440 mm (From 01.04.98)96
1144	Turn-over cylinder D80 x 440 mm (From 01.09.00)98
1048	Turn-over cylinder D100 x 440 mm (Before 01.04.98)100
1049	Turn-over cylinder D100 x 440 mm (From 01.04.98)102
590	Turn-over cylinder D115 x 600 mm (Before 01.09.00)104
1147	Hydraulic cylinder D115 x 600 mm (From 01.09.00)106
457	Arm and fixing device for depth wheel, PX/RX On-Land108
582	Fix for wheel (From 01.09.95, serial no. PX223 and RX261 and110
	PM/RM from 01.04.00)110
150	Front and middle wheel (for BB plough, before 01.05.95)112
581	Wheel 10/75 x 15.3 for PX/RX, cat. 4114
557	Wheel 200 x 14.5 w/axle for PX/RX 6 - 8 furrow116
527	Wheel 400 x 15.5", 400 x 22.5", 500 x 22.5", 500 x 26.6", 14.9 x 24" and 12.5 x 18"118
	(From 01.03.97)118
518	Depth wheel for On-Land set. PS/RS - PX/RX (PS/RS before 01.08.98)120
1088	Depth/transport wheel 99 (From 01.06.99)122
1228	Bracket for depth/ transport wheel 99 (From 01.06.99)126
1119	Transfers128
	Index130




1	KK 07 30 00	Share 12" R (30 cm)	KK 07 38 03	Stay R + L for body no. 6, 7 and 8 A - saddle, L = 560 (And no. 9 before 01.12.95)	KK 07 06 41	Trashboard, L cpl.		
	KK 07 30 01	Share 12" L (30 cm)			KK 07 06 42	Trashboard, R + L cpl.		
	KK 07 30 02	Share 14" R (35 cm)	KK 07 38 31	Stay R + L for body no. 9 E - saddle, L = 725 (From 01.12.95)	17	KK 03 33 32	Cone screw M14 x 34 mm w/nut	
	KK 07 30 03	Share 14" L (35 cm)			18	KK 03 27 25	Hex screw M16 x 27 mm w/nut	
	KK 07 30 04	Share 16" R (40 cm)	KK 07 38 30	Stay R + L for body no. 9 A - saddle, L = 710 (From 01.12.95)	19	KK 03 31 07	Oval screw M12 x 35 mm w/nut	
	KK 07 30 05	Share 16" L (40 cm)			20	KK 01 32 34	Cone screw M12 x 38 mm w/nut	
	KK 07 30 06	Share 18" R (45 cm)	KK 06 38 01	Extra stay R + L, no. 9 E - saddle L = 550 (From 01.12.95)	21	KK 07 30 91	Share knife, R	
	KK 07 30 07	Share 18" L (45 cm)				KK 07 30 92	Share knife, L	
	KK 07 30 08	Share 20" R (50 cm)	KK 07 03 94	Extra stay R for body no. 9 E - saddle, cpl. w. bracket (pos. 12) (From 01.12.95)		KK 06 30 91	Share knife, R (for Sweden)	
	KK 07 30 09	Share 20" L (50 cm)	KK 07 03 95	Extra stay L for body no. 9 E - saddle, cpl. w. bracket (pos. 12) (From 01.12.95)		KK 06 30 92	Share knife, L (for Sweden)	
2	KK 05 30 90	Reversible point, R			23	KK 07 36 09	Landside, long R + L	
	KK 06 30 90	Reversible point, L	KK 07 38 03	Extra stay R + L, no. 9 A - saddle L = 560 (From 01.12.95)	24	KK 07 32 66	Bracket for stay, body no. 6 and 9, R	
3	KK 07 34 06	Saddle, R (for E-saddle)				KK 07 32 67	Bracket for stay, body no. 6 and 9, L	
	KK 07 34 07	Saddle, L (for E-saddle)	KK 07 03 90	Extra stay R for body no. 9 A - saddle, cpl. w. bracket (pos. 12) (From 01.12.95)	25	KK 07 34 14	Connecting plate, 16" - 20", R	
	KK 07 34 11	Saddle, R (for A-saddle)				KK 07 34 15	Connecting plate, 16" - 20", L	
	KK 07 34 12	Saddle, L (for A-saddle)	KK 07 03 91	Extra stay L for body no. 9 A - saddle, cpl. w. bracket (pos. 12) (From 01.12.95)	26	KK 07 30 40	Flush fit share 12", R	
4	KK 01 33 32	Cone screw M14 x 34 mm w/nut				KK 07 30 41	Flush fit share 12", L	
5	KK 03 31 00	Oval screw M12 x 30 mm w/nut	KK 08 38 09	Stay R + L for body no. 28 A - saddle (From 01.03.03)		KK 07 30 42	Flush fit share 14", R	
6	KK 07 32 60	Mouldboard 12" - 16" no. 6, R	KK 08 38 10	Stay R + L for body no. 28 E - saddle (From 01.03.03)		KK 07 30 43	Flush fit share 14", L	
	KK 07 32 61	Mouldboard 12" - 16" no. 6, L				KK 07 30 44	Flush fit share 16", R	
	KK 07 32 63	Mouldboard 12" - 14" no. 7, R	10	KK 07 36 08	Landside, R and L, short		KK 07 30 45	Flush fit share 16", L
	KK 07 32 64	Mouldboard 12" - 14" no. 7, L	11	KK 01 58 32	Nut M20 mm	27	KK 07 30 30	Flush point, R
	KK 07 32 80	Mouldboard 12" no. 8, R	12	KK 07 38 00	Bracket for stay, R for body no. 6, 7, 8 (And no. 9 before 01.12.95)		KK 07 30 31	Flush point, L
	KK 07 32 81	Mouldboard 12" no. 8, L				28	KK 01 29 27	Washer 17 x 30 x 3 mm (for use with two stays)
	KK 07 32 86	Mouldboard 14" - 18" no. 8, R	KK 07 38 01	Bracket for stay, L for body no. 6, 7, 8 (And no. 9 before 01.12.95)	30	KK 07 36 15	Furrow widener, R	
	KK 07 32 87	Mouldboard 14" - 18" no. 8, L	KK 07 38 07	Bracket for stay, R for body no. 9 (From 01.12.95)		KK 07 36 16	Furrow widener, L	
	KK 07 32 90	Mouldboard 14" - 20" no. 9, R			31	KK 07 30 88	Landside knife w/screw, R	
	KK 07 32 91	Mouldboard 14" - 20" no. 9, L	KK 07 38 08	Bracket for stay, L for body no. 9 (From 01.12.95)		KK 07 30 89	Landside knife w/screw, L	
	KK 08 32 28	Mouldboard no. 28, R (From 01.03.03)			32	KK 03 32 51	Screw M16 x 50 mm w/nut (for E-saddle) (Before 01.02.00)	
	KK 08 32 29	Mouldboard no. 28, L (From 01.03.03)	13	KK 01 29 19	Washer 12.5 x 23 x 3.2 mm		KK 03 32 56	Screw M16 x 55 mm w/ nut (for E-saddle) (From 01.02.00)
7	KK 07 32 50	Shinpiece for no. 8, R	14	KK 05 33 87	Mouldboard extension, R		KK 03 32 86	Screw M16 x 85 mm w/nut (for A-saddle) (Before 01.02.00)
	KK 07 32 51	Shinpiece for no. 8, L					KK 03 32 95	Screw M16 x 95 mm w/nut (for A-saddle) (From 01.02.00)
	KK 07 32 56	Shinpiece for no. 6 and 9, R	15	KK 06 33 88	Mouldboard extension, L			
	KK 07 32 57	Shinpiece for no. 6 and 9, L						
8	KK 03 27 35	Hex screw M16 x 35 mm w/nut	16	KK 07 33 10	Bracket for trashboard, R			
9	KK 06 38 01	Stay R + L for body no. 6, 7 and 8 E - saddle, L = 550 (And no. 9 before 01.12.95)		KK 07 33 11	Bracket for trashboard, L			
				KK 07 33 00	Trashboard, R			
				KK 07 33 01	Trashboard L			
				KK 07 06 40	Trashboard, R cpl.	33	KK 03 31 75	Screw M14 x 50 mm w/nut
						34	KK 01 29 22	Washer 17 x 40 x 4.58 mm




35	KK 06 36 07	Plate
	KK 07 36 07	Plate cpl.
36	KK 01 33 46	Screw M14 x 45 mm w/nut
37	KK 07 36 14	Wearing plate
38	KK 01 33 33	Cone screw M14 x 34 mm
39	KK 08 32 35	Mouldboard knife R and L (From 01.12.01)
Pos. 100 - 107 Eco-share from 01.04.00		
100	KK 05 30 90	Reversible point, R
	KK 06 30 90	Reversible point, L
101	KK 01 32 28	Cone screw M12 x 34 mm w/nut
102	KK 07 36 34	Eco-share, R
	KK 07 36 35	Eco-share, L
103	KK 01 01 55	Bushing (for ploughs w/share bolt beam)
	KK 01 01 56	Bushing (for ploughs w/A-beam)
104	KK 03 27 40	Hex screw M16 x 40 mm w/nut (for ploughs w/E-saddle) (Before 01.03.00)
	KK 03 27 50	Hex screw M16 x 50 mm w/nut (for ploughs w/E-saddle) (From 01.03.00)
	KK 03 27 65	Hex screw M16 x 65 mm w/nut (for ploughs w/share bolt beam)
	KK 03 27 75	Hex screw M16 x 75 mm w/nut (for ploughs w/A-beam)
105	KK 01 33 46	Cone screw M14 x 45 mm w/flange nut (for ploughs w/E-saddle) (Before 01.03.00)
	KK 01 33 61	Cone screw M14 x 60 mm w/flange nut (for ploughs w/E-saddle) (From 01.03.00)
	KK 01 33 85	Cone screw M14 x 85 mm w/flange nut (for ploughs w/share bolt beam and A-beam)
106	KK 01 60 15	Flange nut M14
107	KK 01 29 29	Washer (for ploughs w/E-saddle) (From 01.03.00)





1	KK 01 29 19	Washer	KK 07 32 31	Shinpiece no. 19, L	KK 07 03 93	Extra stay L for body no. 19 A - saddle cpl.		
2	KK 07 33 00	Trashboard, R	16	KK 07 32 39	Connecting piece no. 12 and 15, R	w. bracket (pos. 6) (From 01.12.95)		
	KK 07 33 01	Trashboard, L		KK 07 32 40	Connecting piece no. 12 and 15, L	20	KK 07 36 09	Landside, long, R + L
	KK 07 06 40	Trashboard, R cpl.		KK 07 32 66	Connecting piece no. 19, R	21	KK 07 36 08	Landside, short, R + L
	KK 07 06 41	Trashboard, L cpl.		KK 07 32 67	Connecting piece no. 19, L	22	KK 03 27 25	Hex screw M16 x 27 mm
	KK 07 06 42	Trashboard, R + L cpl.	17	KK 03 27 50	Hex screw M16 x 50 mm w/nut (for use with two stays)	23	KK 01 32 34	Cone screw M12 x 38 mm w/nut
3	KK 07 33 10	Bracket, R		KK 03 27 35	Hex screw M16 x 35 mm w/nut (for use with one stay only)	24	KK 01 32 28	Cone screw M12 x 34 mm w/nut
	KK 07 33 11	Bracket, L				25	KK 05 30 90	Reversible point, R
4	KK 03 31 00	Oval screw M12 x 30 mm w/nut	18	KK 01 29 27	Washer 17 x 30 x 3 mm (for use with two stays)	26	KK 06 30 90	Reversible point, L
5	KK 01 58 34	Nut M20 mm					KK 07 30 54	Share 14", R
6	KK 07 38 00	Bracket, R	19	KK 07 38 05	Stay R + L for body no. 12 and 15 E - saddle, L = 540 (And no. 19 before 12.01.95)		KK 07 30 55	Share 14", L
	KK 07 38 01	Bracket, L		KK 07 38 31	Stay R + L for body no. 19 E - saddle, L = 730 (From 12.01.95)		KK 07 30 56	Share 16", R
7	KK 05 33 87	Mouldboard extention, R		KK 07 38 04	Stay R + L for body no. 12 and 15 A - saddle, L = 550 (And no. 19 before 12.01.95)		KK 07 30 57	Share 16", L
	KK 06 33 88	Mouldboard extention, L		KK 07 38 26	Stay R + L for body no. 19 A - saddle, L = 770 (From 12.01.95)		KK 07 30 80	Share 18", R
8	KK 07 32 36	Mouldboard no. 12, R		KK 07 38 26	Extra stay R + L, no. 15 E - saddle L = 770 (From 01.12.96)		KK 07 30 81	Share 18", L
	KK 07 32 37	Mouldboard no. 12, L		KK 07 03 88	Extra stay R for body no. 15 E - saddle cpl. w. bracket (pos. 6) (From 01.12.96)	27	KK 07 30 91	Share knife, R
	KK 07 32 24	Mouldboard no. 15, R		KK 07 03 89	Extra stay L for body no. 15 E - saddle cpl. w. bracket (pos. 6) (From 01.12.96)		KK 07 30 92	Share knife, L
	KK 07 32 25	Mouldboard no. 15, L		KK 07 38 29	Extra stay R + L, no. 15 A - saddle L = 785 (From 01.12.96)	28	KK 07 30 88	Landside knife, R w/nuts
	KK 07 32 90	Mouldboard no. 19, R		KK 07 03 98	Extra stay R for body no. 15 A - saddle cpl. w. bracket (pos. 6) (From 01.12.96)		KK 07 30 89	Landside knife, L w/nuts
	KK 07 32 91	Mouldboard no. 19, L		KK 07 03 99	Extra stay L for body no. 15 A - saddle cpl. w. bracket (pos. 6) (From 01.12.96)	29	KK 07 36 15	Furrow widener, R
9	KK 01 33 32	Cone screw M14 x 34 mm w/nut		KK 07 38 42	Extra stay R + L, no. 19 E - saddle L = 570 (From 01.12.95)		KK 07 36 16	Furrow widener, L
10	KK 03 31 07	Oval screw M12 x 35 mm w/nut		KK 07 03 96	Extra stay R for body no. 19 E - saddle cpl. w. bracket (pos. 6) (From 01.12.95)	30	KK 03 31 75	Screw M14 x 50 mm w/nut
11	KK 07 30 62	Share 14", R		KK 07 03 97	Extra stay L for body no. 19 E - saddle cpl. w. bracket (pos. 6) (From 01.12.95)	31	KK 03 32 51	Screw M16 x 50 mm w/nut (for E-saddle) (Before 01.02.00)
	KK 07 30 63	Share 14", L		KK 07 38 04	Extra stay R + L, no. 19 A - saddle L = 550 (From 01.12.95)		KK 03 32 56	Screw M16 x 56 mm w/nut (for E-saddle) (From 01.02.00)
	KK 07 30 64	Share 16", R		KK 07 03 92	Extra stay R for body no. 19 A - saddle cpl. w. bracket (pos. 6) (From 01.12.95)		KK 03 32 86	Screw M16 x 85 mm w/nut (for A-saddle) (Before 01.02.00)
	KK 07 30 65	Share 16", L					KK 03 32 95	Screw M16 x 95 mm w/nut (for A-saddle) (From 01.02.00)
12	KK 06 20 25	Nut M16 mm				32	KK 01 29 22	Washer 17 x 40 x 4.58 mm
13	KK 07 34 35	Saddle, R (for E-saddle)				34	KK 01 33 33	Cone screw M14 x 34 mm w/nut
	KK 07 34 36	Saddle, L (for E-saddle)				35	KK 06 36 07	Plate for On-Land ploughs
	KK 07 34 40	Saddle, R (for A-saddle)					KK 07 36 07	Plate for On-Land ploughs cpl.
	KK 07 34 41	Saddle, L (for A-saddle)				36	KK 01 33 46	Screw M14 x 45 mm w/nut
14	KK 07 34 17	Connecting plate no. 12 and 15, R				37	KK 03 31 07	Oval screw M12 x 35 mm
	KK 07 34 18	Connecting plate no. 12 and 15, L				38	KK 07 36 14	Wearing plate
15	KK 07 32 41	Shinpiece no. 12, R				39	KK 01 33 32	Cone screw M14 x 34 mm
	KK 07 32 42	Shinpiece no. 12, L						
	KK 07 32 27	Shinpiece no. 15, R						
	KK 07 32 28	Shinpiece no. 15, L						
	KK 07 32 30	Shinpiece no. 19, R						



40	KK 08 32 35	Mouldboard knife R and L (From 01.12.01)
Pos. 100 - 107 Eco-share from 01.04.00		
100	KK 05 30 90	Reversible point, R
	KK 06 30 90	Reversible point, L
101	KK 01 32 28	Cone screw M12 x 34 mm w/nut
102	KK 07 36 34	Eco-share, R
	KK 07 36 35	Eco-share, L
103	KK 01 01 55	Bushing (for ploughs w/share bolt beam)
	KK 01 01 56	Bushing (for ploughs w/A-beam)
104	KK 03 27 40	Hex screw M16 x 40 mm w/nut (for ploughs w/E-saddle) (Before 01.03.00)
	KK 03 27 50	Hex screw M16 x 50 mm w/nut (for ploughs w/E-saddle) (From 01.03.00)
	KK 03 27 65	Hex screw M16 x 65 mm w/nut (for ploughs w/share bolt beam)
	KK 03 27 75	Hex screw M16 x 75 mm w/nut (for ploughs w/A-beam)
105	KK 01 33 46	Cone screw M14 x 45 mm w/flange nut (for ploughs w/E-saddle) (Before 01.03.00)
	KK 01 33 61	Cone screw M14 x 60 mm w/flange nut (for ploughs w/E-saddle) (From 01.03.00)
	KK 01 33 85	Cone screw M14 x 85 mm w/flange nut (for ploughs w/share bolt beam and A-beam)
106	KK 01 60 15	Flange nut M14
107	KK 01 29 29	Washer (for ploughs w/E-saddle) (From 01.03.00)







26	KK 03 30 04	Oval screw M10 x 20 mm w/nut
27	KK 07 33 50	Trashboard plastic, R
	KK 07 33 51	Trashboard plastic, L
28	KK 07 33 52	Support, R
	KK 07 33 53	Support, L
29	KK 05 33 87	Mouldboard extension, R
	KK 06 33 88	Mouldboard extension, L
31	KK 03 27 30	Hex screw M16 x 13 mm w/nut
32	KK 06 20 25	Nut M16 mm
33	KK 07 30 88	Landside knife w/nuts, R
	KK 07 30 89	Landside knife w/nuts, L
34	KK 03 32 51	Screw M16 x 50 mm w/nut (for E-sad- dle) (Before 01.02.00)
	KK 03 32 56	Screw M16 x 55 mm w/nut (for E-sad- dle) (From 01.02.00)
	KK 03 32 86	Screw M16 x 85 mm w/nut (for A-sad- dle) (Before 01.02.00)
	KK 03 32 95	Screw M16 x 95 mm w/nut (for A-sad- dle) (From 01.02.00)
35	KK 03 31 74	Screw M14 x 45 mm w/nut



1	KK 01 33 32	Cone screw M14 x 34 mm w/nut	21	KK 07 33 03	Bracket, R		KK 07 30 89	Landside knife w/nut, L
2	KK 07 30 54	Share 14", R		KK 07 33 04	Bracket, L	44	KK 01 29 22	Washer 17 x 40 x 4.58 mm
	KK 07 30 55	Share 14", L	22	KK 01 29 19	Washer 12.5 x 23 x 3.2 mm	45	KK 03 31 75	Screw M14 x 50 mm w/nut
	KK 07 30 56	Share 16", R	23	KK 03 27 40	Hex screw M16 x 40 mm w/nut	46	KK 03 32 51	Screw M16 x 50 mm w/nut (for E-saddle)
	KK 07 30 57	Share 16", L	24	KK 07 36 08	Landside, short, R + L		KK 03 32 86	Screw M16 x 85 mm w/nut (for A-saddle)
	KK 07 30 80	Share 18", R	25	KK 07 36 09	Landside, long, R + L	47	KK 06 36 07	Plate (For On-land ploughs only)
	KK 07 30 81	Share 18", L	26	KK 07 38 22	Stay front (for E-saddle)		KK 07 36 07	Plate cpl. (For On-land ploughs only)
3	KK 05 30 90	Reversible point, R		KK 07 38 16	Stay front (for A-saddle)	48	KK 01 33 46	Screw M14 x 45 mm w/nut
	KK 06 30 90	Reversible point, L	27	KK 01 58 30	Nut M20 mm (Before 01.06.93)	50	KK 07 36 14	Wearing plate
4	KK 07 32 45	Mouldboard, R	28	KK 07 38 17	Stay (Before 01.06.93)	51	KK 01 33 32	Cone screw M14 x 34 mm
	KK 07 32 46	Mouldboard, L	29	KK 07 38 15	Stay, rear (for A-saddle) (Before 01.06.93)			
5	KK 03 31 73	Oval screw M14 x 38 mm w/nut		KK 07 38 20	Stay, R cpl. (for E-saddle) (Before 01.06.93)			
7	KK 01 32 28	Cone screw M12 x 34 mm w/nut		KK 07 38 21	Stay, L cpl. (for E-saddle) (Before 01.06.93)			
8	KK 01 32 34	Cone screw M12 x 38 mm w/nut		KK 07 38 10	Stay, R cpl. (for A-saddle) (Before 01.06.93)			
9	KK 07 30 91	Share knife, R		KK 07 38 11	Stay, L cpl (for A-saddle) (Before 01.06.93)			
	KK 07 30 92	Share knife, L						
	KK 06 30 91	Share knife, R (for Sweden)						
	KK 06 30 92	Share knife, L (for Sweden)						
10	KK 07 34 70	Saddle, R (for E-saddle)	31	KK 07 15 00	Spacer			
	KK 07 34 71	Saddle, L (for E-saddle)	32	KK 03 31 81	Oval screw M14 x 85 mm w/nut			
	KK 07 34 64	Saddle, R (for A-saddle)	33	KK 07 36 15	Furrow widener, R			
	KK 07 34 65	Saddle, L (for A-saddle)		KK 07 30 16	Furrow widener, L			
11	KK 03 31 00	Oval screw M12 x 30 mm w/nut	34	KK 07 30 62	Share 14", R			
12	KK 07 32 72	Shinpiece, R		KK 07 30 63	Share 14", L			
	KK 07 32 73	Shinpiece, L		KK 07 30 64	Share 16", R			
13	KK 03 31 08	Oval screw M12 x 40 mm w/nut		KK 07 30 65	Share 16", L			
14	KK 03 27 30	Hex screw M16 x 30 mm w/nut	35	KK 07 38 05	Stay (for E-saddle) (From 01.06.93)			
16	KK 03 31 75	Oval screw M14 x 50 mm w/nut		KK 07 38 03	Stay (for A-saddle) (From 01.06.93)			
17	KK 07 32 75	Connecting piece, R	36	KK 07 38 34	Bracket for stay, R+L			
	KK 07 32 76	Connecting piece, L	37	KK 07 38 35	Spacing tube 27 x 20.5 x 80 mm			
18	KK 03 31 07	Oval screw M12 x 35 mm w/nut	38	KK 07 38 36	Spacing tube 27 x 20.5 x 69 mm			
19	KK 07 33 00	Trashboard, R	39	KK 07 38 12	Bracket for stay, R			
	KK 07 33 01	Trashboard, L		KK 07 38 13	Bracket for stay, L			
	KK 07 02 92	Trashboard, R cpl.	40	KK 01 30 01	Washer 14 x 30 x 7.5 mm			
	KK 07 02 93	Trashboard, L cpl.	41	KK 01 58 34	Nut M20 mm			
	KK 07 02 94	Trashboard, R + L cpl.	42	KK 03 31 85	Oval screw M14 x 130 mm w/flangenut			
20	KK 07 33 32	Mouldboard extension, R (extra)	43	KK 07 30 88	Landside knife w/nut, R			
	KK 07 33 33	Mouldboard extension,, L (extra)						




1	KK 07 33 00	Trashboard, R	15	KK 08 34 15	Saddle R, A-saddle (for body no. 29)	KK 03 30 16	Oval screw M10 x 30 mm (for body no. 30)
	KK 07 33 01	Trashboard, L		KK 08 34 16	Saddle L, A-saddle (for body no. 29)		
2	KK 08 33 00	Bracket, R		KK 08 34 06	Saddle R, A-saddle (for body no. 30)	KK 01 58 13	Nut M10
	KK 08 33 01	Bracket, L		KK 08 34 07	Saddle L, A-saddle (for body no. 30)	23	KK 07 30 62 Share 14", R (for body no. 30)
3	KK 07 36 15	Furrow widener, R	16	KK 05 30 90	Reversible point, R		KK 07 30 63 Share 14", L (for body no. 30)
	KK 07 36 16	Furrow widener, L		KK 06 30 90	Reversible point, L		KK 07 30 64 Share 16", R (for body no. 30)
4	KK 01 33 32	Cone screw M14 x 34 mm	17	KK 01 32 28	Cone screw M12 x 34 mm		KK 07 30 65 Share 16", L (for body no. 30)
	KK 01 60 13	Flange nut M14		KK 01 58 17	Nut M12	24	KK 08 32 11 Slat no 1, R
5	KK 07 36 09	Landside, long R + L	18	KK 07 30 91	Share knife, R		KK 08 32 21 Slat no 1, L
6	KK 08 34 17	Saddle R, E-saddle (for body no. 29)		KK 07 30 92	Share knife, L	25	KK 08 32 12 Slat no 2, R
	KK 08 34 18	Saddle L, E-saddle (for body no. 29)		KK 06 30 91	Share knife, R (for Sweeden)		KK 08 32 22 Slat no 2, L
	KK 08 34 08	Saddle R, E-saddle (for body no. 30)		KK 06 30 92	Share knife, L (for Sweeden)	26	KK 08 32 13 Slat no 3, R
	KK 08 34 09	Saddle L, E-saddle (for body no. 30)	19	KK 07 30 02	Share 14", R (for body no. 29)		KK 08 32 23 Slat no 3, L
7	KK 03 31 16	Oval screw M12 x 35 mm (for body no. 29 and 30)		KK 07 30 03	Share 14", L (for body no. 29)	27	KK 08 32 14 Slat no 4, R
	KK 01 58 17	Nut M12		KK 07 30 54	Share 14", R (for body no. 30)		KK 08 32 24 Slat no 4, L
	KK 03 31 07	Oval screw M12 x 35 mm (for body no. 30) (Before 01.01.01)		KK 07 30 55	Share 14", L (for body no. 30)	28	KK 07 30 88 Landside knife, R
	KK 01 58 17	Nut M12		KK 07 30 04	Share 16", R (for body no. 29)		KK 07 30 89 Landside knife, L
8	KK 03 31 17	Oval screw M12 x 45 mm (for body no. 29 and 30)		KK 07 30 05	Share 16", L (for body no. 29)	29	KK 03 31 75 Screw M14 x 50 mm
	KK 01 58 17	Nut M12		KK 07 30 56	Share 16", R (for body no. 30)		KK 01 60 15 Flange nut M14
	KK 03 31 11	Oval screw M12 x 45 mm (for body no. 30) (Before 01.01.01)		KK 07 30 57	Share 16", L (for body no. 30)	30	KK 03 32 51 Screw M16 x 50 mm (for E-saddle) (Before 01.02.00)
	KK 01 58 17	Nut M12		KK 07 30 06	Share 18", R (for body no. 29)		KK 03 32 56 Screw M16 x 56 mm (for E-saddle) (From 01.02.00)
	KK 03 31 11	Oval screw M12 x 45 mm (for body no. 30) (Before 01.01.01)		KK 07 30 07	Share 18", L (for body no. 29)		KK 01 58 25 Nut M16
	KK 01 58 17	Nut M12		KK 07 30 80	Share 18", R (for body no. 30)		KK 03 32 86 Screw M16 x 85 mm (for A-saddle) (Before 01.02.00)
9	KK 08 32 10	Slat support, R	20	KK 08 32 15	Connecting piece, plastic (for slat 1-2)		KK 03 32 95 Screw M16 x 95 mm (for A-saddle) (From 01.02.00)
	KK 08 32 20	Slat support, L		KK 08 32 18	Connecting piece, plastic (for slat 2) (for body no. 29)		KK 01 58 25 Nut M16
10	KK 08 38 03	Stay		KK 08 32 16	Connecting piece, plastic (for slat 2-3) (for body no. 30)	31	KK 01 29 22 Washer 17 x 40 x 4.58 mm
11	KK 08 38 05	Stay 1, saddle A (for body no. 29)		KK 08 32 17	Connecting piece, plastic (for slat 3-4)	32	KK 07 30 42 Flush fit share 14", R (for body no. 29)
	KK 08 38 06	Stay 2, saddle A (for body no. 29)	21	KK 07 32 56	Shinpiece, R (for body no. 29)		KK 07 30 43 Flush fit share 14", L (for body no. 29)
	KK 08 38 02	Stay, saddle A (for body no. 30)		KK 07 32 57	Shinpiece, L (for body no. 29)		KK 07 30 44 Flush fit share 16", R (for body no. 29)
	KK 08 38 07	Stay 1, saddle E (for body no. 29)		KK 07 32 30	Shinpiece, R (for body no. 30)		KK 07 30 45 Flush fit share 16", L (for body no. 29)
	KK 08 38 08	Stay 2, saddle E (for body no. 29)		KK 07 32 31	Shinpiece, L (for body no. 30)	33	KK 07 30 30 Flush fit point, R
	KK 08 38 04	Stay, saddle E (for body no. 30)	22	KK 03 30 06	Oval screw M10 x 30 mm (for body no. 29)		KK 07 30 31 Flush fit point, L
12	KK 07 36 08	Landside, short R + L		KK 01 58 13	Nut M10	34	KK 08 32 35 Mouldboard knife R and L (From 01.12.01)
13	KK 03 27 50	Hex screw M16 x 50 mm					
	KK 01 58 25	Nut M16					
14	KK 07 36 14	Wearing plate					



Pos. 100 - 107 Eco-share from 01.04.00		
100	KK 05 30 90	Reversible point, R
	KK 06 30 90	Reversible point, L
101	KK 01 32 28	Cone screw M12 x 34 mm
	KK 01 58 17	Nut M12
102	KK 07 36 34	Eco-share, R
	KK 07 36 35	Eco-share, L
103	KK 01 01 55	Bushing (for ploughs w/share bolt beam)
	KK 01 01 56	Bushing (for ploughs w/A-beam)
104	KK 03 27 40	Hex screw M16 x 40 (for ploughs w/E-saddle) (Before 01.03.00)
	KK 03 27 50	Hex screw M16 x 50 mm (for ploughs w/E-saddle) (From 01.03.00)
	KK 01 58 25	Nut M16
	KK 03 27 65	Hex screw M16 x 65 mm w/nut (for ploughs w/share bolt beam)
	KK 01 58 25	Nut M16
	KK 03 27 75	Hex screw M16 x 75 mm w/nut (for ploughs w/A-beam)
	KK 01 58 25	Nut ;16
105	KK 01 33 46	Cone screw M14 x 45 mm (for ploughs w/E-saddle) (Before 01.03.00)
	KK 01 33 61	Cone screw M14 x 60 mm (for ploughs w/E-saddle) (From 01.03.00)
	KK 01 33 85	Cone screw M14 x 85 mm (for ploughs w/share bolt beam and A-beam)
106	KK 01 60 15	Flange nut M14
107	KK 01 29 29	Washer (for ploughs w/E-saddle) (From 01.03.00)




Замовлення запчастин
(050)-407-68-47
(050)-407-68-45




1	KK 05 70 67	Blade no 4	33	KK 03 26 55	Hex screw M12 x 55 mm w/nut (for extra additional leaf spring cpl.)
2	KK 03 50 20	Hex screw w/flange M10 x 34 mm w/nut	34	KK 06 70 77	Bushing (for extra additional leaf spring cpl.)
3	KK 05 70 66	Blade no 3	35	KK 06 70 75	Linkage (for extra additional leaf spring cpl.)
4	KK 02 99 20	Grease nipple M8 x 1	36	KK 06 70 76	Bolt D15.7 (for extra additional leaf spring cpl.)
5	KK 06 70 59	Bolt	37	KK 02 97 27	Split pin D5 x 32 mm (for extra additional leaf spring cpl.)
6	KK 01 10 37	Roll pin D10 x 40 mm	38	KK 06 12 91	Threaded piece
7	KK 06 70 57	Bolt (Before 01.08.02)			
	KK 06 70 16	Bolt (From 01.08.02)	Not ill.	KK 05 07 06	Leaf spring cpl. (1 x ill. no. 3, 13, 14, 16, 17 and 22 + 2 x ill. no. 1, 2, 20 and 29)
8	KK 03 28 60	Hex screw M20 x 60 mm w/nut		KK 06 07 03	Leaf spring HD cpl. (1 x ill. no 3, 16, 17 22 and 32 + 2 x ill. no. 1, 2, 20, 23 and 29)
9	KK 06 70 51	Adjustment screw w/threaded piece		KK 06 01 19	Spacer kit w/ hex screws R & L cpl.
10	KK 06 70 40	Holder (Before 01.08.02)			
	KK 06 70 25	Holder (From 01.08.02)			
11	KK 06 70 68	Bracket (Before 01.08.02)			
	KK 06 70 92	Bracket (From 01.08.02)			
12	KK 06 70 39	Adjustment screw M24 x 90 mm			
13	KK 05 70 89	Bolt			
14	KK 02 97 27	Split pin D5 x 32 mm			
15	KK 06 70 80	Spring arm			
16	KK 03 26 65	Hex screw M12 x 65 mm w/nut			
17	KK 05 70 63	Main blade			
18	KK 06 70 60	Regulator (Before 01.08.02)			
	KK 06 70 90	Regulator (From 01.08.02)			
19	KK 06 70 70	Tie rod (Before 01.08.02)			
	KK 06 70 26	Tie rod (From 01.08.02)			
20	KK 05 70 64	Blade no 1			
21	KK 06 70 31	Axle D22 x 53 mm			
22	KK 05 70 65	Blade no 2			
23	KK 05 70 68	Blade no 5			
24	KK 06 12 80	Beam			
25	KK 03 52 09	Hex screw M20 x 50 mm w/threaded piece			
26	KK 03 28 40	Hex screw M20 x 40 mm w/nut			
27	KK 06 01 08	Spacer cpl. w/hex screws R			
	KK 06 01 09	Spacer cpl. w/hex screws L			
28	KK 03 51 65	Hex screw M20 x 50 mm w/flange nut			
29	KK 03 50 21	Hex screw w/flange M10 x 30.5 mm w/nut			
30	KK 01 10 42	Roll pin D6 x 40 mm (to be mounted into roll pin 011037)			
31	KK 03 28 55	Hex screw M20 x 55 mm			
32	KK 01 29 13	Washer			






1	KK 03 27 12	Hex screw M16 x 240 mm w/nut
2	KK 07 15 75	Bracket for beam, upper
	KK 07 97 80	Bracket for beam w/cut, upper (for RS plough only, from 01.06.96)
	KK 07 47 50	Bracket for beam, upper (for RX plough only)
3	KK 07 70 23	Main bolt M30 x 72 mm R
	KK 07 70 24	Main bolt M30 x 72 mm L
4	KK 07 12 09	Beam, L
5	KK 07 12 28	Support, H = 700 mm (for PS/RS from 15.09.93)
	KK 07 12 07	Support, H = 800 mm
6	KK 01 62 22	Flange nut M30 R
	KK 01 60 45	Flange nut M30 L
7	KK 07 14 17	Spacing tube
8	KK 06 15 15	Tube 28/20.5 x 35.2 mm
9	KK 07 12 08	Beam, R
10	KK 07 15 76	Bracket for beam, lower
	KK 07 97 81	Bracket for beam w/cut, lower (for PS plough only, from 01.06.96)
	KK 07 47 51	Bracket for beam, lower (for RX plough only)
11	KK 03 28 82	Hex screw M20 x 80 mm w/nut
12	KK 03 28 07	Hex screw M20 x 100 mm w/nut
13	KK 06 20 20	Washer
14	KK 03 28 45	Hex screw M20 x 45 mm w/nut
15	KK 03 29 25	Hex screw M24 x 250 mm w/nut
16	KK 07 15 08	Plate, H = 700 mm
	KK 07 15 29	Plate, H = 800 mm
17	KK 03 50 72	Shear bolt M20 x 81 mm w/nut, H = 700 mm (for PS/RS from 15.09.93)
	KK 03 50 60	Shear bolt M20 x 62 mm w/nut, H = 800 mm
18	KK 03 52 47	Hex screw M16 x 270 mm w/lock nut
19	KK 01 29 98	Washer
Not ill.	KK 07 12 11	Beam, H = 700 mm cpl.
	KK 07 12 12	Beam, H = 800 mm cpl.





1	KK 07 27 57	Beam SL H = 700	33	KK 03 27 74	Hex screw M16 x 70 mm
	KK 07 27 77	Beam SL H = 800 mm	34	KK 01 60 25	Lock nut M16
2	KK 07 27 55	Beam/depth wheel support (Before 01.06.99)	35	KK 01 29 98	Washer D50 x D16.5 x 10 mm
	KK 07 47 60	Beam/depth wheel support (From 01.06.99) (Before 15.11.02)	36	KK 01 30 00	Washer D45 x D26 x 10 mm
	KK 08 26 40	Beam/depth wheel support (From 15.11.02)	37	KK 01 12 69	Circlip (From 01.01.02)
3	KK 07 28 20	Link, R (From 01.01.02)	38	KK 07 28 24	Cover for spring (From 01.01.02)
4	KK 07 28 21	Link, L (From 01.01.02)	39	KK 01 28 74	Cup spring for spring cover (From 01.01.02)
5	KK 07 27 73	Spacing tube		KK 07 28 25	24 pieces of KK 01 28 74, cup spring for spring cover cpl. (From 01.01.02)
6	KK 06 70 49	Adjusting screw	40	KK 07 27 88	Beam holder (for LB/RB ploughs only)
7	KK 01 58 34	Nut M20, H = 12	41	KK 07 27 89	Beam holder, rear (for LB ploughs only)
8	KK 07 27 71	Threaded piece M20	42	KK 07 27 92	Bushing (for LB/RB ploughs only)
9	KK 03 27 29	Hex screw M16 x 280 mm w/nut (From 01.01.02)	43	KK 07 27 66	Link, L (Before 01.01.02)
10	KK 07 28 19	Holder (From 01.01.02)	44	KK 07 27 70	Rubber damper (Before 01.01.02)
11	KK 07 28 22	Bushing (From 01.01.02)	45	KK 07 27 67	Holder (Before 01.01.02)
12	KK 03 51 34	Hex screw M12 x 80 mm w/lock nut	46	KK 03 28 36	Hex screw M20 x 240 mm w/nut (Before 01.01.02)
13	KK 03 51 38	Hex screw M12 x 120 mm w/lock nut	47	KK 01 58 30	Nut M20 (Before 01.01.02)
14	KK 03 51 56	Hex screw M16 x 85 mm w/lock nut	48	KK 07 27 65	Link, R (Before 01.01.02)
15	KK 01 60 25	Lock nut (From 01.01.02)	49	KK 03 27 14	Hex screw M16 x 270 mm w/ nut
16	KK 07 27 69	Holder for shear bolt			
17	KK 03 42 25	Set screw M16 x 25 mm			
18	KK 07 69 36	Bracket for manure skimmer w/set screw			
19	KK 03 28 90	Hex screw M20 x 90 mm w/nut			
20	KK 03 50 87	Shear bolt M20 x 90 mm (Before 15.03.97)			
	KK 03 50 87	Shear bolt M20 x 90 mm, strong (From 15.03.97)			
21	KK 03 19 41	Cone bolt M16 x 40 mm			
22	KK 07 27 61	Spacer			
23	KK 07 27 51	Beam bracket			
24	KK 07 27 60	Spacer			
25	KK 07 70 21	Bolt L = 95 mm			
26	KK 01 60 01	Lock nut M24			
27	KK 02 99 18	Grease nipple			
28	KK 07 27 59	Plate, beam holder			
29	KK 03 27 12	Hex screw M16 x 240 mm w/nut (Before 01.01.97)			
	KK 03 27 24	Hex screw M16 x 250 mm w/nut (From 01.01.97)			
30	KK 03 29 25	Hex screw M24 x 250 mm w/nut (Before 01.01.97)			
	KK 03 29 26	Hex screw M24 x 265 mm w/nut (From 01.01.97)			
31	KK 01 58 30	Nut M20			
32	KK 07 14 17	Supporting sleeve			


Замовлення запчастин
(050)-407-68-47
(050)-407-68-45



1	KK 03 13 40	Hex screw M8 x 40 mm
2	KK 05 61 56	Cap
3	KK 01 07 75	O-ring D54.5 x 3 mm
4	KK 01 12 66	Circlip
5	KK 01 12 92	Washer D30 x 45 x 2.5 mm
6	KK 05 61 12	Disc 18"
	KK 05 61 14	Disc 20"
	KK 05 61 15	Disc 18" Notched
	KK 05 61 16	Disc 20" Notched
7	KK 06 61 02	Hub w/needles
	KK 06 61 24	Hub cpl (ill 1, 3 - 5 and 7 - 9)
8	KK 01 07 72	Seal ring
9	KK 06 61 08	Axle D30
10	KK 02 99 20	Grease nipple M8 x 1 mm
11	KK 06 61 40	Disc coulters arm 18" R
	KK 06 61 43	Disc coulters arm 20" R
12	KK 06 61 90	Clip
13	KK 03 50 31	Hex screw M12 x 45 mm w/nut
14	KK 06 61 85	Bracket
15	KK 06 61 42	Disc coulters arm 18" L
	KK 06 61 45	Disc coulters arm 20" L
16	KK 01 60 31	Cone nut M16
17	KK 06 61 89	Bracket 18"
	KK 06 61 82	Bracket 20"
18	KK 06 61 78	Eccentric
19	KK 06 61 75	U - bolt
20	KK 03 17 30	Hex screw M20 x 30 mm
	KK 03 17 40	Hex screw M20 x 40 mm (for eccentric nut)



Замовлення запчастин
(050)-407-68-47
(050)-407-68-45




1	KK 07 64 06	Disc coulters 18"	22	KK 03 28 30	Hex screw M20 x 30 mm
	KK 07 64 07	Disc coulters 20"		KK 01 58 30	Nut M20
2	KK 07 64 09	Disc coulters, notched 18"	23	KK 03 28 40	Hex screw M20 x 40 mm
	KK 07 64 10	Disc coulters, notched 20"		KK 01 58 30	Nut M20
3	KK 07 64 99	Plate	24	KK 01 60 31	Cone nut M16
4	KK 03 35 40	Screw M10 x 40 mm			
	KK 01 60 04	Lock nut M10			
5	KK 01 17 50	O-ring 124,5 x 4 mm			
6	KK 01 18 66	O-ring 67 x 3 mm			
7	KK 01 12 59	Circlip I 62 x 2 mm			
8	KK 01 12 66	Circlip A 30 x 1,5 mm			
9	KK 01 05 72	Bearing			
10	KK 01 05 32	Gasket ring			
11	KK 08 60 89	Bearing housing cpl. (ill. 3 - 11)			
	KK 08 60 90	Bearing housing cpl. w/axle			
12	KK 08 61 01	Axle			
	KK 08 60 80	Disc coulters arm w/bearing 18", R			
	KK 08 60 81	Disc coulters arm w/bearing 18", L			
	KK 08 60 82	Disc coulters arm w/bearing 20", R			
	KK 08 60 83	Disc coulters arm w/bearing 20", L			
	KK 08 60 84	Disc coulters arm w/bearing 20", lowered R			
	KK 08 60 85	Disc coulters arm w/bearing 20", lowered L			
13	KK 08 61 10	Arm 18", R			
	KK 08 61 12	Arm 20", R			
	KK 08 61 14	Arm 20", lowered R			
14	KK 08 61 11	Arm 18", L			
	KK 08 61 13	Arm 20", L			
	KK 08 61 15	Arm 20", lowered L			
15	KK 06 61 70	Bracket			
16	KK 02 99 20	Grease nipple			
17	KK 06 61 90	Clip			
18	KK 03 50 31	Hex screw M12 x 45 mm			
	KK 01 58 17	Nut M12			
19	KK 06 61 89	Bracket 18"			
	KK 06 61 82	Bracket 20"			
20	KK 06 61 78	Eccentric			
21	KK 06 61 75	U-bolt			



Замовлення запчастин
(050)-407-68-47
(050)-407-68-45


1044 Disc coultter LD, LO, SL, RB, RS, RT (rear frame) and RX
(RS, RX from 15.09.99, RB from 01.05.01)




**1044 Disc coulters LD, LO, SL, RB, RS, RT (rear frame) and RX
(RS, RX from 15.09.99, RB from 01.05.01)**


1	KK 07 64 06	Disc coulters 18"		KK 08 61 01	Axle (From 01.01.99)
	KK 07 64 07	Disc coulters 20"		KK 08 60 86	Disc coulters arm w/bearing (From 01.01.99)
2	KK 07 64 09	Disc coulters 18" notched		KK 08 60 87	Disc coulters bearing cpl. (ill. no. 4-6-7-8) (From 01.01.99)
	KK 07 64 10	Disc coulters 20" notched	32	KK 01 29 60	Washer
3	KK 01 18 66	O-ring	33	KK 07 64 99	Plate
4	KK 01 12 59	Circlip			
5	KK 01 12 66	Circlip			
6	KK 01 05 72	Ball bearing			
7	KK 01 08 18	Rubber ring (Before 01.01.99)			
	KK 01 05 32	Gasket ring (From 01.01.99)			
8	KK 80 60 90	Bearing housing cpl. (ill. no. 2-3-4-5-6-7-8-9-15) (Before 01.01.99)			
	KK 08 61 00	Bearing housing cpl. (ill. no. 2-3-4-5-6-7-8-15) (From 01.01.99)			
9	KK 02 99 20	Grease nipple			
10	KK 07 65 75	Arm (From serial no. LD7112)			
11	KK 03 27 02	Hex screw M16 x 110 mm w/nut			
12	KK 07 64 00	Support			
13	KK 07 65 27	Axle			
14	KK 03 27 70	Hex screw M16 x 70 mm w/nut			
15	KK 07 64 27	Excenter			
16	KK 07 65 32	Tube R			
17	KK 07 65 33	Tube L			
18	KK 01 60 50	Excentric nut M16 (Before 01.09.98)			
	KK 01 60 58	Flange nut M16 (From 01.09.98)			
19	KK 03 29 34	Hex screw M24 x 325 mm w/nut for forward extended disc coulters)			
	KK 03 28 85	Hex screw M20 x 85 mm w/nut			
20	KK 07 65 17	Tube disc coulters (for SL)			
	KK 07 65 18	Tube for forward extended disc coulters (for SL)			
21	KK 03 10 30	Screw M10 x 30 mm			
22	KK 01 17 50	O-ring			
23	KK 01 09 09	Cover			
24	KK 03 27 50	Hex screw M16 x 50 mm			
25	KK 03 29 29	Hex screw M24 x 290 mm w/nut			
26	KK 03 27 75	Hex screw M16 x 75 mm w/nut			
27	KK 03 28 80	Hex screw M20 x 80 mm w/nut			
28	KK 07 65 37	Bushing D20 x D24 x 40 mm			
29	KK 07 65 77	Bracket for forward extended disc coulters			
30	KK 07 65 15	Supporting piece for tube			
31	KK 07 60 76	Bolt (Before 01.01.99)			






1	KK 07 65 45	Outer tube	30	KK 01 05 83	Gasket ring
2	KK 07 60 23	Spring	31	KK 07 62 85	Axle
3	KK 07 60 22	Spring	32	KK 07 64 09	Disc 18"
4	KK 07 65 48	Clevis w/M20 axle		KK 07 64 07	Disc 20"
5	KK 01 58 34	Nut M20, H = 12		KK 07 62 94	Disc 22" (From 01.07.97)
6	KK 07 65 44	Inner tube	33	KK 07 64 99	Plate
7	KK 07 60 58	Bolt	34	KK 03 51 14	Hex screw M10 x 40 mm w/ lock nut
8	KK 01 10 32	Sleeve D10 x 50 mm	35	KK 03 33 25	Hex screw M6 x 25 mm
9	KK 03 27 25	Hex screw M16 x 27 mm	36	KK 03 27 92	Hex screw M16 x 90 mm
10	KK 07 60 08	Pivot pin	37	KK 07 60 72	Bushing
11	KK 07 60 66	Plate w/axle, L (Before 01.10.02)	38	KK 01 60 12	Flange nut M20
	KK 07 64 35	Plate w/axle D20, L (From 01.10.02)	39	KK 01 60 04	Lock nut M10
	KK 07 60 68	Plate w/axle, R (Before 01.10.02)	40	KK 01 58 25	Nut M16
	KK 07 64 34	Plate w/axle D20, R (From 01.06.02)			
12	KK 03 27 02	Hex screw M16 x 110 mm w/nut (Before 01.10.02)			
	KK 03 51 78	Hex screw M20 x 110 mm w/ flange nut (From 01.10.02)			
13	KK 07 64 00	Support (Before 01.10.02)			
	KK 07 64 37	Support (From 01.10.02)			
14	KK 03 27 75	Hex screw M16 x 75 mm			
15	KK 07 60 65	Hoop, L + R			
16	KK 07 60 53	U-bracket			
17	KK 01 07 72	Gasket ring			
18	KK 01 12 03	Bearing			
19	KK 02 99 20	Grease nipple			
20	KK 07 60 70	Bearing housing			
21	KK 07 64 09	Disc 18" notched			
	KK 07 64 10	Disc 20" notched			
	KK 07 61 48	Disc 22" notched (From 01.07.97)			
22	KK 07 62 96	Arm (Before 01.10.02)			
	KK 07 64 30	Arm (From 01.10.02)			
23	KK 01 62 08	Bearing			
24	KK 01 29 95	Washer			
	KK 07 62 98	Washer (From 01.07.97)			
25	KK 02 97 22	Pin D5 x 50 mm			
26	KK 01 60 52	Nut 1" x 9/16"			
27	KK 07 62 97	Cap			
28	KK 03 34 01	Hex screw M8 x 16 mm			
29	KK 01 05 84	Gasket ring			





1	KK 07 68 12	Mouldboard maize R	11	KK 06 68 11	Arm R, H = 700 mm for HD beam and std. beam H700
	KK 07 68 13	Mouldboard maize L		KK 07 68 58	Arm R, H = 750 mm for std. beam H800 (From 01.12.00)
2	KK 06 68 80	Mouldboard R	16	KK 07 06 53	Fixing bracket with screw and nut (for beam 071240 and 071241)
	KK 07 69 43	Mouldboard R, plastic	17	KK 03 44 46	Setscrew M24 x 53 mm
	KK 06 68 81	Mouldboard L	18	KK 01 58 41	Nut M24
	KK 07 69 44	Mouldboard L, plastic	19	KK 01 58 16	Nut M10
3	KK 03 30 06	Oval screw M10 x 30 mm	20	KK 08 50 76	Clevis
4	KK 05 68 73	Share, short R	21	KK 06 68 61	Bracket HD beam
	KK 06 68 73	Share, short L			
5	KK 06 68 68	Share, long R			
	KK 06 68 69	Share, long L			
6	KK 01 29 06	Washer 10.5 x 25 x 3.4			
7	KK 01 58 25	Nut M16			
22	KK 08 68 01	Skimmer extension			
23	KK 03 30 07	Oval screw M10 x 35 mm			
for all turnable ploughs with Auto Reset beams:					
8	KK 03 27 95	Hex screw M16 x 95 mm			
9	KK 03 42 28	Setscrew M16 x 32 mm			
10	KK 06 06 57	Bracket cpl.			
11	KK 06 68 11	Arm R, H = 700 mm			
	KK 07 68 58	Arm R, H = 750 mm (From 01.12.00)			
	KK 06 68 12	Arm L, H = 700 mm			
	KK 07 68 59	Arm L, H = 750 mm (From 01.12.00)			
for all turnable ploughs with Shear Bolt beams:					
12	KK 07 06 39	Bracket with screws (for LB, LD, RB, RS, RX)			
	KK 07 68 72	Bracket (for LM, LS, RG, RL, RM, VD)			
13	KK 03 42 25	Setscrew M16 x 25 mm			
14	KK 03 42 50	Setscrew M16 x 50 mm			
15	KK 07 68 17	Arm R, H = 700 mm			
	KK 07 68 18	Arm L, H = 700 mm			
	KK 07 68 25	Arm R, H = 800 mm			
	KK 07 68 26	Arm L, H = 800 mm			
	KK 07 68 33	Arm R, H = 700 mm (for VD plough only) (Before 15.03.98)			
	KK 07 68 34	Arm L, H = 700 mm (for VD plough only) (Before 15.03.98)			
for beams on conventional ploughs:					






1	KK 07 91 71	Tube, rear PX/RX100
	KK 07 93 43	Tube, rear PX/RX-115
2	KK 03 28 40	Hex screw M20 x 40 mm w/nut
3	KK 07 91 55	Plate, outer
4	KK 07 91 56	Plate w/thread, inner
5	KK 07 91 54	Plate, bended, outer
6	KK 07 91 70	Tube, front for PX/RX-100
	KK 07 93 38	Tube, front for PX/RX-115




Замовлення запчастин
(050)-407-68-47
(050)-407-68-45




1	KK 07 85 82	Roll
2	KK 07 95 69	Arm
3	KK 07 95 97	Spacer
4	KK 07 95 57	Spacer
5	KK 07 95 68	Arm
6	KK 07 95 96	Conical bushing
7	KK 03 23 35	Hex screw M6 x 35 mm
8	KK 01 27 10	Clamp for 6 hoses
9	KK 03 28 30	Hex screw M20 x 30 mm w/nut
10	KK 06 19 40	Fix
11	KK 06 23 95	Plate
12	KK 07 91 91	Axle
13	KK 03 27 30	Hex screw M16 x 30 mm w/nut
14	KK 07 95 75	Plate
15	KK 03 29 27	Hex screw M24 x 275 mm w/nut
16	KK 07 95 91	Contra nut M30
17	KK 07 95 90	Foot screw M30 x 130 mm
18	KK 07 95 70	Bracket
19	KK 01 16 82	Bushing
20	KK 07 95 58	Lifting arm w/bushing cpl.
21	KK 02 99 20	Grease nipple




Замовлення запчастин
(050)-407-68-47
(050)-407-68-45



1	KK 06 43 19	Cross shaft, L = 825 mm, cat. II	29	KK 01 06 50	Spanner 27 - 36
	KK 06 43 20	Cross shaft, L = 935 mm, cat. II	30	KK 01 06 06	Spanner 19 - 27
	KK 06 43 21	Cross shaft, L = 965 mm, cat. III	31	KK 03 27 25	Hex screw M16 x 27 mm w/nut
	KK 06 43 23	Cross shaft, L = 860 mm, cat. III	32	KK 07 92 33	U-bracket
2	KK 06 43 60	Collar	33	KK 07 92 30	Support for transport and crowbar
3	KK 03 28 60	Hex screw M20 x 60 mm w/nut	34	KK 07 27 68	Plate for spare bolts
4	KK 06 43 17	Bushing	35	KK 03 24 03	Hex screw M8 x 30 mm w/nut
5	KK 07 88 70	Headstock (Before 01.10.99)	36	KK 07 97 54	Fixing device (From 15.06.96, serial no. PX275 and RX283)
	KK 08 11 50	Headstock (From 01.10.99)	37	KK 07 97 63	Fixing for link, R (H = 80 mm) (From 15.06.96, serial no. PX275 and RX283)
6	KK 01 16 82	Bushing		KK 07 97 64	Fixing for link, L (H = 80 mm) (From 15.06.96, serial no. PX275 and RX283)
7	KK 07 88 76	Link w/bushings (Before 15.06.96, serial no. PX275 and RX283)		KK 07 97 60	Fixing for link, R (H = 160 mm) (From 15.06.96, serial no. PX275 and RX283)
8	KK 02 99 20	Grease nipple M8		KK 07 97 61	Fixing for link, L (H = 160 mm) (From 15.06.96, serial no. PX275 and RX283)
9	KK 07 93 62	Support for headstock, 2 holes (Before 15.06.96, serial no. PX275 and RX283)	38	KK 07 97 51	Plate for fixing (From 15.06.96, serial no. PX275 and RX283)
	KK 07 88 53	Support for headstock, 4 holes (Before 15.06.96, serial no. PX275 and RX283)	39	KK 07 97 65	Link w/bushing (From 15.06.96, serial no. PX275 and RX283)
10	KK 07 93 63	Fixing for link, R (H = 80 mm) (Before 15.06.96, serial no. PX275 and RX283)	40	KK 07 95 96	Spring washer (From 15.06.96, serial no. PX275 and RX283)
	KK 07 93 60	Fixing for link, R (H = 160 mm) (Before 15.06.96, serial no. PX275 and RX283)	41	KK 01 28 51	Bushing (From 15.06.96, serial no. PX275 and RX283)
	KK 07 88 50	Fixing for link, R (35 mm)	42	KK 03 29 00	Hex screw M24 x 100 mm w/nut (From 15.06.96, serial no. PX275 and RX283)
11	KK 03 29 20	Hex screw M24 x 200 mm w/nut	43	KK 01 06 55	Spanner for hydraulic cylinder
12	KK 03 28 22	Hex screw M20 x 190 mm w/nut			
13	KK 07 88 98	Axle D50 x 305 mm			
14	KK 03 27 30	Hex screw M16 x 30 mm w/nut			
15	KK 03 28 65	Hex screw M20 x 65 mm w/nut (Before 15.06.96, serial no. PX275 and RX283)			
16	KK 07 91 12	Hose bushing (Before 15.06.96, serial no. PX275 and RX283)			
17	KK 07 88 51	Plate for fixing (Before 15.06.96, serial no. PX275 and RX283)			
18	KK 07 92 04	Fixing device (Before 15.06.96, serial no. PX275 and RX283)			
19	KK 07 89 11	Supporting device for beam, H = 700 mm			
	KK 07 89 17	Supporting device for beam, H = 800 mm			
20	KK 03 28 75	Hex screw M20 x 75 mm w/nut			
21	KK 01 02 98	Bolt w/handle D19 x 95 mm			
22	KK 07 89 15	Fixing for supporting device			
23	KK 07 93 64	Fixing for link, L (H = 80 mm) (Before 15.06.96, serial no. PX275 and RX283)			
	KK 07 93 61	Fixing for link, L (H = 160 mm) (Before 15.06.96, serial no. PX275 and RX283)			
	KK 07 89 49	Fixing for link, L (35 mm) (Before 15.06.96, serial no. PX275 and RX283)			
24	KK 03 28 40	Hex screw M20 x 40 mm w/nut			
25	KK 01 21 85	Fixing for 2 hoses			
26	KK 06 25 06	Piece for fix			
27	KK 03 24 70	Hex screw M8 x 70 mm w/nut			
28	KK 06 25 05	Bracket for fix			




1	KK 07 88 92	Arm w/bend	29	KK 01 07 00	Pin D12 mm		KK 07 97 83	Stop for packerarm, L (for 2 or 3 furrow, rear part) (From 01.05.97)
2	KK 06 24 39	Roll for arm	30	KK 07 91 78	Main tube, front (for PX/RX-100, 4 furrow)			
3	KK 07 88 93	Arm		KK 07 91 76	Main tube, front (for PX/RX-100, 5 furrow)	59	KK 03 27 92	Hex screw M16 x 90 mm (12.9)
4	KK 01 10 05	Roll pin D10 x 70 mm		KK 07 93 34	Main tube, front (for PX/RX-115, 4 furrow)	60	KK 07 99 14	Plate for reinforcement plate PX (Reinforcement kit)
5	KK 07 88 89	Spacer for arm		KK 07 93 35	Main tube, front (for PX/RX-115, 5 furrow)			
6	KK 07 92 64	Main tube, rear (for PX/RX-100, 4 furrow)	31	KK 03 28 60	Hex screw M20 x 60 mm w/nut	61	KK 07 99 13	Reinforcement plate PX (Reinforcement kit)
	KK 07 92 50	Main tube, rear (for PX/RX-100, 5 furrow)	32	KK 07 91 59	Fix for cylinder	62	KK 03 27 28	Hex screw M16 x 280 mm w/ nut (Reinforcement kit)
7	KK 07 76 76	Hoop w/plate for supporting cylinder, 6 - 8 furrow	33	KK 06 12 91	Threaded piece w/handle M20			
			34	KK 03 28 45	Hex screw M20 x 45 mm w/nut	63	KK 03 28 33	Hex screw M20 x 290 mm w/ nut (Reinforcement kit)
8	KK 07 29 78	Beam support w/balls, rear (Before 01.06.99)	35	KK 03 27 60	Hex screw M16 x 60 mm w/nut			
	KK 07 47 64	Beam support w/balls, rear (From 01.06.99)	36	KK 07 76 99	Fix for cylinder	64	KK 03 29 29	Hex screw M24 x 290 mm w/ nut (Reinforcement kit)
	KK 07 47 52	Beam support (for PX only)	37	KK 07 91 60	Main support			
9	KK 03 28 18	Hex screw M20 x 180 mm w/nut	38	KK 07 88 80	Lever			
	KK 03 28 28	Hex screw M20 x 220 mm w/nut (From serial no. PX275 and RX283)	39	KK 07 92 01	Fix for supportin cylinder	Not ill.	KK 36 11 16	Turnbuckle cpl.
10	KK 06 22 70	U-bolt M20	40	KK 03 27 45	Hex screw M16 x 45 mm w/nut			
11	KK 07 88 94	Fix for arm (Before 01.11.93)	41	KK 03 52 47	Hex screw M16 x 270 mm w/lock nut			
	KK 07 88 90	Fix for arm (From 01.11.93)	42	KK 07 88 67	Bearing for lever			
12	KK 07 88 97	Axle for arm	43	KK 02 99 20	Grease nipple M8			
13	KK 03 28 16	Hex screw M20 x 150 mm w/nut	44	KK 07 93 65	Tube (From 15.06.96, serial no. PX275 and RX 283)			
14	KK 07 92 35	Fix for hose	45	KK 03 23 45	Hex screw M6 x 35 mm w/nut			
15	KK 07 89 21	Main tube, front	46	KK 01 20 69	Cover			
16	KK 07 88 88	Plate for arm (From 01.11.93)	47	KK 01 20 68	Clamp for hose			
17	KK 07 88 54	Fix for arm (Before 01.11.93)	48	KK 01 20 67	Plate			
	KK 07 88 91	Fix for arm (From 01.11.93)	49	KK 03 29 25	Hex screw M24 x 250 mm w/nut			
18	KK 03 28 22	Hex screw M20 x 190 mm w/nut	50	KK 07 89 00	Beam support w/ balls			
19	KK 07 88 49	Plate for main tube	51	KK 07 12 55	Ball			
20	KK 07 89 56	Plate for main tube	52	KK 06 16 37	Steering plate			
21	KK 01 58 30	Nut M20	53	KK 01 29 98	Washer			
22	KK 03 28 13	Hex screw M20 x 170 mm w/nut	54	KK 01 60 25	Lock nut M16			
23	KK 06 70 79	Adjustable screw M24 x 90 mm w/contra nut	55	KK 03 27 40	Hex screw M16 x 40 mm w/nut			
			56	KK 03 27 52	Hex screw M16 x 50 mm w/ball			
24	KK 01 03 28	Bolt w/head D25.3 x 78 mm	57	KK 07 14 04	Bushing (From 01.04.01)			
25	KK 35 11 39	Screw, R	58	KK 07 97 07	Stop for packerarm, R (From 01.10.96)			
26	KK 35 61 31	Nut		KK 07 97 08	Stop for packerarm, L (From 01.10.96)			
27	KK 35 11 44	Tube		KK 07 97 82	Stop for packerarm, R (for 2 or 3 furrow, rear part) (From 01.05.97)			
28	KK 35 11 40	Screw, L						



1	KK 03 29 23	Hex screw M24 x 270 mm w/nut	28	KK 03 28 80	Hex screw M20 x 80 mm w/nut
2	KK 03 29 50	Hex screw M24 x 50 mm w/nut		KK 03 27 75	Hex screw M16 x 75 mm w/nut
3	KK 03 28 36	Hex screw M20 x 240 mm w/nut	29	KK 01 22 90	Assembly tube for hoses D63 x 400 mm
4	KK 03 28 42	Hex screw M20 x 270 mm w/nut	30	KK 01 23 70	Coil for hose 1/2"
5	KK 01 16 82	Bushing	31	KK 01 15 96	Hydraulic hose holder, L = 250 mm
6	KK 07 91 33	Axle	32	KK 07 91 82	Plate
7	KK 07 91 91	Axle D50 x 478 mm	33	KK 07 14 12	Bushing cpl.
8	KK 03 27 25	Hex screw M16 x 27 mm w/nut			
9	KK 07 91 72	Main frame, rear (for PX/RX-100, 2 furrow)			
	KK 07 91 73	Main frame, rear (for PX/RX-100, 3 furrow)			
	KK 07 91 74	Main frame, rear (for PX/RX-100, 4 furrow)			
	KK 07 93 32	Main frame, rear (for PX/RX-115, 2 furrow)			
	KK 07 93 33	Main frame, rear (for PX/RX-115, 3 furrow)			
10	KK 07 91 84	Fixing device w/bushing, rear (for PX/RX-100)			
	KK 07 97 94	Fixing device w/bushing, rear (for PX/RX-115)			
11	KK 07 91 65	Fix for parallel tube			
12	KK 07 91 30	Main parallel tube			
13	KK 07 91 31	Secondary parallel tube			
14	KK 07 91 40	Fixing device, front			
15	KK 07 91 50	Axle			
16	KK 07 88 38	Axle D50 x 174 mm			
17	KK 03 27 40	Hex screw M16 x 40 mm w/nut			
18	KK 07 92 64	Main tube, rear (for PX/RX-100, 4 furrow)			
	KK 07 92 50	Main tube, rear (for PX/RX-100/115, 5 furrow)			
	KK 07 91 80	Main tube, rear (for PX/RX-100, 6 furrow)			
	KK 07 95 52	Main tube, rear (for PX/RX-100, 7 furrow)			
19	KK 07 88 40	Link, rear			
	KK 07 88 44	Link w/bushing, rear			
20	KK 02 99 20	Grease nipple M8			
21	KK 03 26 50	Hex screw M12 x 50 mm w/nut			
22	KK 07 91 53	Lock for axle			
23	KK 07 91 49	Cover			
24	KK 07 65 31	Washer D66 x D21 x 10 mm			
	KK 01 29 24	Washer D70 x D16.5 x10 mm			
25	KK 07 92 68	Link			
26	KK 03 27 30	Hex screw M16 x 30 mm w/nut			
27	KK 07 89 53	Axle w/flange, L = 37 mm			
	KK 07 93 97	Axle w/flange, L = 43 mm			






1	KK 07 96 09	Fix for wheel suspension	31	KK 07 91 35	Supporting bar for 400 x 22.5
	KK 07 97 16	Fix for wheel suspension, cat. 4	32	KK 07 97 18	Plate, cat. 4
2	KK 03 52 17	Hex screw M20 x 240 mm w/flange nut	33	KK 30 12 23	Cone, cat. 4
	KK 03 52 18	Hex screw M20 x 260 mm w/flange nut, cat. 4	34	KK 07 97 37	Plate
3	KK 07 96 10	Axle D60 x 467 mm (From 20.10.94 - serial no. PX183 and RX143)		KK 07 95 55	Wire - Not ill.
4	KK 03 27 50	Hex screw M16 x 50 mm w/nut			
5	KK 01 16 91	Bushing			
6	KK 02 99 20	Grease nipple D8 x 1			
7	KK 07 96 01	Wheel suspension			
8	KK 07 88 38	Axle			
9	KK 03 27 40	Hex screw M16 x 40 mm w/nut			
10	KK 03 28 05	Hex screw M20 x 120 mm w/nut			
11	KK 07 92 62	Arm for wheel 400 x 15.5 w/bushing, R			
	KK 07 92 08	Arm for wheel 400 x 22.5 w/bushing, R			
	KK 07 97 35	Arm for wheel 400 x 22.5 w/bushing, R, cat. 4			
12	KK 01 60 12	Lock nut M20			
13	KK 01 29 68	Washer			
14	KK 07 91 36	Plate			
15	KK 30 31 23	U-bolt M20			
16	KK 01 58 17	Nut M12			
17	KK 03 26 35	Hex screw M12 x 35 mm			
18	KK 03 26 45	Hex screw M12 x 45 mm			
19	KK 03 52 27	Hex screw M20 x 270 mm w/flange nut, cat. 4			
20	KK 07 95 30	Bracket			
21	KK 07 95 18	Plate			
22	KK 01 29 13	Washer			
23	KK 01 28 70	Disc washer			
24	KK 07 95 56	Wire			
25	KK 07 95 35	Bracket			
26	KK 07 95 33	Arm			
27	KK 01 28 71	Disc washer			
28	KK 03 26 06	Hex screw M12 x 130 mm w/nut			
29	KK 07 92 63	Arm for wheel 400 x 15.5 w/bushing, L			
	KK 07 92 09	Arm for wheel 400 x 22.5 w/bushing, L			
	KK 07 97 36	Arm for wheel 400 x 22.5 w/bushing, L, cat. 4			
30	KK 07 92 28	Supporting bar for 400 x 15.5			




Замовлення запчастин
(050)-407-68-47
(050)-407-68-45







1	KK 07 96 46	Protective device for tractor wheel	33	KK 07 95 95	Plate
2	KK 01 02 98	Bolt w/handle	34	KK 07 93 89	Tube, L = 75 mm
3	KK 07 93 98	Fix for machine stand	35	KK 07 93 88	Tube, L = 55 mm
4	KK 03 28 75	Hex screw M20 x 75 mm w/nut	36	KK 03 29 08	Hex screw M24 x 150 mm w/nut
5	KK 07 93 96	Plate	37	KK 07 98 60	Main wheel suspension
6	KK 03 28 26	Hex screw M20 x 260 mm w/nut	38	KK 01 16 82	Bushing
7	KK 07 89 11	Machine stand	39	KK 07 95 80	Link w/bushing
	KK 07 89 17	Machine stand, long	40	KK 02 99 20	Grease nipple
8	KK 06 25 05	Piece for hose assemblies	41	KK 07 43 89	Cross shaft, L = 965 mm, cat. 4
9	KK 01 21 85	Fix for 2 hoses		KK 07 43 90	Cross shaft, L = 1165 mm, cat. 4
10	KK 06 25 06	Piece for hose assemblies		KK 06 43 21	Cross shaft, L = 965 mm, cat. 3
11	KK 07 27 68	Holder for bolts (for RX plough)	42	KK 06 43 60	Stop ring
12	KK 03 24 03	Hex screw M8 x 130 mm w/nut	43	KK 01 06 55	Spanner for hydraulic cylinder
13	KK 07 94 79	Inner tube		Pos. 46 - 63	Parts for supporting wheel (From 01.05.97)
14	KK 07 94 74	Main tube, front 6 x 100	46	KK 03 27 25	Hex screw M16 x 27
	KK 07 94 72	Main tube, front 7 x 100	47	KK 07 98 58	Axle D40 x 165 mm
	KK 07 94 78	Main tube, front 8 x 100	48	KK 03 28 18	Hex screw M20 x 180 mm w/nut
	KK 07 93 30	Main tube, front 6 x 115	49	KK 07 98 57	Bushing D50 x D40 x 22 mm
	KK 07 93 31	Main tube, front 7 x 115	50	KK 01 16 83	Bushing D62 x D50 x 80 mm
15	KK 03 28 60	Hex screw M20 x 60 mm w/nut	51	KK 07 98 60	Wheel suspension, upper cpl.
16	KK 03 29 27	Hex screw M24 x 275 mm w/nut	52	KK 02 99 20	Grease nipple
17	KK 07 95 96	Spring washer	53	KK 07 98 64	Washer
18	KK 03 23 35	Hex screw M6 x 35 mm	54	KK 01 16 97	Bushing D50 x D40 x 40 mm
19	KK 03 29 30	Hex screw M24 x 280 mm w/nut	55	KK 07 98 72	Bushing D35 x D25 x 130 mm
20	KK 01 27 10	Clamp for 6 hoses	56	KK 07 98 75	Wheel arm cpl.
21	KK 06 19 48	Fix for 6 hoses	57	KK 03 28 05	Hex screw M20 x 120 mm w/nut
22	KK 03 28 40	Hex screw M20 x 40 mm w/nut	58	KK 07 98 80	Axle D50 x 125 mm
23	KK 07 91 12	Tube for hoses	59	KK 07 98 78	Axle D40 x 120 mm
24	KK 07 95 79	Plate	60	KK 07 98 71	Plate
25	KK 03 27 30	Hex screw M16 x 30 mm w/nut	61	KK 07 98 65	Cross arm cpl.
26	KK 06 43 17	Bushing for 60 mm cross shaft	62	KK 06 70 79	Foot screw M24 x 90 mm w/nut
27	KK 07 93 90	Headstock, cat. 4	63		
	KK 07 97 45	Headstock, cat. 3			
28	KK 07 92 30	Lever			
29	KK 01 06 50	Spanner 27 - 36			
30	KK 01 06 06	Spanner 19 - 27			
31	KK 07 99 33	Axle			
32	KK 07 95 78	Fixing device for draw			




1	KK 03 29 23	Hex screw M24 x 270 mm w/nut		KK 07 99 06	Axle (From 01.02.97)	
2	KK 03 29 50	Hex screw M24 x 50 mm w/nut		31	KK 07 96 78	Axle
3	KK 03 52 17	Hex screw M20 x 240 mm w/flange nut		32	KK 03 28 03	Hex screw M20 x 110 mm w/nut
4	KK 03 28 26	Hex screw M20 x 260 mm w/nut		33	KK 07 65 31	Washer
5	KK 07 91 33	Axle		34	KK 03 52 18	Hex screw M20 x 260 mm w/flange nut
6	KK 07 91 91	Axle D50 x 485 mm		35	KK 30 12 23	Cone
7	KK 03 27 25	Hex screw M16 x 27 mm w/nut		36	KK 07 96 91	Fixing device for PX/RX-100
8	KK 01 16 82	Bushing			KK 07 97 25	Fixing device for PX/RX-115
9	KK 07 91 84	Fixing device, rear (for PX/RX-100)		37	KK 07 97 19	Plate, lower
	KK 07 97 94	Fixing device, rear (for PX/RX-115)		38	KK 07 96 80	Threaded piece
10	KK 07 91 72	Main tube, rear 2 x 100		39	KK 07 85 51	Support, inner
	KK 07 91 73	Main tube, rear 3 x 1000 mm		40	KK 07 91 75	Main tube, front 6 x 100
	KK 07 91 74	Main tube, rear 4 x 100			KK 07 91 77	Main tube, front 7 x 100
	KK 07 93 32	Main tube, rear 2 x 115			KK 07 91 79	Main tube, front 8 x 100
	KK 07 93 33	Main tube, rear 3 x 115			KK 07 93 36	Main tube, front 6 x 115
11	KK 07 91 31	Secondary parallel tube			KK 07 93 37	Main tube, front 7 x 115
12	KK 07 91 30	Main parallel tube		41	KK 07 96 51	Turning link (Before 01.02.97)
13	KK 01 01 48	Tube			KK 07 99 00	Turning link (From 01.02.97)
14	KK 03 23 70	Hex screw M6 x 70 mm		42	KK 06 70 65	Adjustment screw M24 x 65 mm
15	KK 01 25 29	Cover for clamp		43	KK 07 96 67	Main tube, rear
16	KK 01 25 28	Clamp		44	KK 01 28 51	Bushing
17	KK 07 91 95	Fix		45	KK 01 29 68	Washer
18	KK 03 28 39	Hex screw M20 x 230 mm w/nut				
19	KK 07 91 65	Fix for parallel tube			KK 07 99 12	Side bracket for turning link (From 01.04.00)
20	KK 03 52 27	Hex screw M20 x 270 mm w/flange nut				
21	KK 07 96 93	Cover				
22	KK 03 29 25	Hex screw M24 x 250 mm w/nut				
23	KK 03 28 33	Hex screw M20 x 290 mm w/nut				
24	KK 07 93 97	Axle				
25	KK 07 91 53	Lock for axle (Before 01.02.97)				
	KK 07 99 10	Lock for axle (From 01.02.97)				
26	KK 03 51 27	Hex screw M12 x 50 mm w/lock nut (Before 01.02.97)				
	KK 03 51 36	Hex screw M12 x 90 mm w/lock nut (From 01.02.97)				
27	KK 06 70 39	Foot screw M24 x 90 mm				
28	KK 06 18 99	Contra nut M24				
29	KK 01 16 68	Slide bearing, PM9060DX (Before 01.02.97)				
	KK 01 16 69	Slide bearing, PM11550DX (From 01.02.97)				
30	KK 07 96 61	Axle (Before 01.02.97)				




1	KK 03 51 78	Hex screw M20 x 110 mm w/flange nut	30	KK 03 51 68	Hex screw M20 x 60 mm w/flange nut
2	KK 07 95 94	Lock piece	31	KK 07 96 85	Axle
3	KK 03 28 80	Hex screw M20 x 80 mm	32	KK 03 27 25	Hex screw M16 x 27 mm w/nut
4	KK 03 28 70	Hex screw M20 x 70 mm w/nut	33	KK 02 99 20	Grease nipple
5	KK 07 95 93	Plate	34	KK 01 16 87	Bushing
6	KK 07 97 70	Slide, 6 furrow for cat. 3	35	KK 07 97 13	Roll cpl.
	KK 07 97 71	Slide, 7 - 8 furrow for cat. 3	36	KK 01 08 09	Gasket ring
	KK 07 95 85	Slide, 6 - 7 and 8 furrow for cat. 4	37	KK 36 11 07	Turnbuckle cpl. (1500 - 1700)
7	KK 03 28 26	Hex screw M20 x 260 mm w/nut, for 6 furrow, front	38	KK 01 03 15	Bolt w/head D25.3 x 60 mm
	KK 03 28 05	Hex screw M20 x 120 mm w/nut, for 7 and 8 furrow, front	39	KK 01 10 20	Pin D12 x 40 mm
8	KK 07 94 73	Spacer for 6 furrow, front	40	KK 07 99 30	Mechanical stop
9	KK 07 96 14	Tube	41	KK 01 60 00	Lock nut M20
10	KK 01 29 68	Washer			
11	KK 07 97 72	Support for slide, 6 furrow for cat. 3	Not ill.	KK 01 08 91	Shackle w/bolt
	KK 07 97 75	Support for slide, 7 and 8 furrow for cat. 3			
	KK 07 95 86	Support for slide, 6, 7 and furrow for cat. 4			
12	KK 03 28 26	Hex screw M20 x 80 mm w/nut			
13	KK 07 92 97	Fix for cylinder (Before 01.05.01)			
14	KK 03 28 80	Hex screw M20 x 80 mm w/nut (From 01.05.01)			
15	KK 03 28 95	Hex screw M20 x 95 mm w/nut (Before 01.05.01)			
16	KK 06 70 73	Foot screw M20 x 50 mm			
17	KK 01 58 34	Nut M20			
18	KK 03 27 30	Hex screw M16 x 30 mm w/nut			
19	KK 07 92 96	Plate			
20	KK 07 91 75	Main tube, front 6 x 100			
	KK 07 91 77	Main tube, front 7 x 100			
	KK 07 91 79	Main tube, front 8 x 100			
	KK 07 93 36	Main tube, front 6 x 115			
	KK 07 93 37	Main tube, front 7 x 115			
21	KK 06 12 91	Threaded piece			
22	KK 07 93 65	Tube			
23	KK 07 96 88	Support (Before 01.05.01)			
24	KK 07 96 79	Chain			
25	KK 07 97 92	Fix support (From 01.05.01)			
26	KK 07 96 75	Indicator			
27	KK 07 96 15	Fix for indicator			
28	KK 03 42 28	Set screw M16 x 40 mm			
29	KK 07 96 90	Bracket			


 Замоклення запчастин
 (050)-407-68-47
 (050)-407-68-45




1	KK 07 92 97	Bracket for cylinder
2	KK 03 28 55	Hex screw M20 x 55 mm
	KK 06 12 79	Threaded piece M20
3	KK 03 28 45	Hex screw M20 x 45 mm
4	KK 03 28 30	Hex screw M20 x 30 mm
5	KK 03 28 26	Hex screw M20 x 260 mm w/nut
6	KK 07 92 96	Plate for cylinder bracket
7	KK 07 94 95	Support
8	KK 01 16 82	Bushing
9	KK 07 92 88	Roll w/bushing
10	KK 02 99 20	Grease nipple M8 x 1 mm
11	KK 03 27 40	Hex screw M16 x 40 mm w/nut
12	KK 07 92 84	Fix for roll
13	KK 03 28 50	Hex screw M20 x 50 mm
14	KK 07 94 97	Impact for roll, forward 5 and 6 furrows
	KK 07 92 79	Impact for roll, forward 7 and 8 furrows
15	KK 03 27 60	Hex screw M16 x 60 mm w/nut
16	KK 07 94 98	Bracket
17	KK 03 51 62	Hex screw M20 x 90 mm w/flange nut w/lock
18	KK 07 92 73	Plate
19	KK 01 29 68	Washer
20	KK 03 28 05	Hex screw M20 x 120 mm w/nut
21	KK 07 93 85	Support for slide, forward 5 and 6 furrows
	KK 07 93 78	Support for slide, forward 7 and 8 furrows
	KK 07 93 46	Support for slide (for PX/RX-100 only) (From 28.11.97)
22	KK 07 93 06	Fix for depth wheel
23	KK 07 94 93	Axle L = 250 mm
24	KK 03 27 25	Hex screw M16 x 27 mm
25	KK 03 27 06	Hex screw M16 x 130 mm w/nut
26	KK 07 93 25	Arm for wheel
27	KK 07 93 28	Fixing for device w/bushing and grease nipple
28	KK 06 40 73	Tube
29	KK 07 93 81	Cover for hose
30	KK 07 92 85	Axle L = 185 mm
31	KK 07 93 67	Slide, forward 5 and 6 furrows
	KK 07 93 68	Slide, forward 7 and 8 furrows
	KK 07 93 45	Slide (for PX/RX-100 only) (From 28.11.97)





1	KK 01 20 56	Angle 3/8"
2	KK 01 22 61	Threaded coupling
3	KK 01 15 85	Gasket ring 3/8"
4	KK 01 27 79	Hose 3/8", L = 7000 mm
5	KK 01 15 32	Hose 3/8", L = 2250 mm
6	KK 01 03 28	Bolt M25.3 x 78 mm
7	KK 01 07 00	Pin D12 (Before 01.08.97)
	KK 01 10 20	Roll pin D12 x 40 mm (From 01.08.97)
8	KK 35 23 32	Cylinder D80 x 900 mm, front (7 and 8 furrows) (see plate no. 552)
	KK 35 23 33	Cylinder D80 x 680 mm, front (5 and 6 furrows) (see plate no. 552)
9	KK 01 58 30	Nut M20
10	KK 35 60 42	Spring
11	KK 03 28 11	Hex screw M20 x 130 mm
12	KK 07 93 75	Arm for valve (Before 01.08.94)
	KK 07 94 68	Arm for valve (From 01.08.94)
13	KK 07 93 76	Spacer for arm
14	KK 07 93 70	Plate for impact (Before 01.08.94)
	KK 07 94 66	Plate for impact (From 01.08.94)
15	KK 07 93 77	Lock on impact
16	KK 01 25 11	Adapter (Before 01.08.94)
	KK 07 94 69	Adapter for valve (From 01.08.94)
17	KK 03 26 70	Hex screw M12 x 70 mm
18	KK 03 28 70	Hex screw M20 x 70 mm w/nut
19	KK 03 27 55	Hex screw M16 x 55 mm
20	KK 01 29 22	Washer
21	KK 01 15 12	Hose 3/8", L = 4500 mm
22	KK 01 20 60	Threaded coupling 3/8" - 1/2"
23	KK 01 15 65	Gasket ring 1/2"
24	KK 01 21 14	Quick coupling
25	KK 01 27 95	Hose 3/8", L = 2500 mm
26	KK 06 19 40	Fix for hose
27	KK 01 27 10	Bracket for hose
28	KK 03 33 25	Hex screw M6 x 25 mm
29	KK 01 17 66	O-ring
30	KK 01 25 10	Valve
31	KK 03 24 45	Hex screw M8 x 45 mm (Before 01.08.94)
	KK 03 24 70	Hex screw M8 x 70 mm (From 01.08.94)







1	KK 35 33 70	Hydraulic cylinder D100 x 215 mm w/stop (Before 25.09.95) (see plate no. 1026)		KK 01 27 79	Hose 3/8", L = 7000 mm for 6 furrow, front part
	KK 35 34 98	Hydraulic cylinder D100 x 215 mm w/D35 mm bushing cpl. (From 25.09.95) (see plate no. 486)		KK 01 27 80	Hose 3/8", L = 8000 mm for 7 furrow, front part
2	KK 01 22 61	Threaded coupling 3/8" - 3/8"	37	KK 01 27 81	Hose 3/8", L = 9000 mm for 8 furrow, front part
3	KK 01 15 85	Gasket ring 3/8"	38	KK 01 27 95	Hose 3/8", L = 2500 mm (for tractor)
4	KK 01 15 30	Hose 3/8", L = 1600 mm	39	KK 07 94 87	Fix for valve
5	KK 01 27 73	Hose 3/8", L = 1300 mm	40	KK 01 25 28	Clamp
6	KK 01 20 56	Angle 3/8"	41	KK 01 25 29	Cover for clamp
7	KK 01 20 60	Threaded coupling 3/8" - 1/2"	42	KK 03 23 35	Hex screw M6 x 35 mm w/nut
8	KK 01 15 65	Gasket ring 1/2"		KK 35 22 38	Stop (Before 01.03.98)
9	KK 01 23 37	Special nipple		KK 35 22 47	Stop (From 01.03.98)
10	KK 01 23 28	O-ring	Not ill.	KK 07 89 75	Dual control cpl.
	KK 01 18 27	O-ring (From 15.11.95)			
11	KK 35 34 51	Accumulator, 55 bar			
12	KK 01 03 28	Bolt w/head D25.3 x 78 mm			
13	KK 01 10 20	Roll pin D12 x 40 mm			
14	KK 01 03 37	Bolt w/head D25 x 180 mm			
15	KK 01 07 00	Pin D12			
16	KK 07 95 15	Fix for accumulator			
17	KK 35 34 50	Accumulator, 15 bar			
18	KK 03 26 50	Hex screw M12 x 50 mm w/nut			
19	KK 03 27 45	Hex screw M16 x 45 mm w/nut			
20	KK 01 27 45	Oil distributor w/valve			
21	KK 03 26 30	Hex screw M12 x 30 mm w/nut			
22	KK 01 20 62	Banjo coupling 3/8" - 3/8"			
23	KK 01 23 32	Valve 3/8"			
24	KK 01 23 19	Swivel 3/8"			
25	KK 01 27 30	Angle 3/8"			
26	KK 01 23 30	Valve 3/8"			
27	KK 01 15 79	Nipple 3/8" - 3/8"			
28	KK 01 21 41	Choke 2.0 - M8 x 12 mm			
29	KK 01 27 29	T-coupling 3/8"			
30	KK 01 15 43	Hose 3/8", L = 2400 mm			
	KK 01 15 31	Hose 3/8", L = 2000 mm			
31	KK 01 23 07	Banjo bolt 3/8"			
33	KK 01 23 60	Hose 3/8", L = 2750 mm			
36	KK 01 27 96	Hose 3/8", L = 5000 mm for 4 furrow, front part			
	KK 01 27 97	Hose 3/8", L = 6000 mm for 5 furrow, front part			





Замовлення запчастин
(050)-407-68-47
(050)-407-68-45






1	KK 35 34 98	Cylinder D100 x 215 mm w/D35 mm bushing cpl. (see plate no. 486) (Before 01.08.00)	35	KK 03 26 65	Hex screw M12 x 65 mm w/nut
	KK 35 38 38	Cylinder D100 x 200 mm w/ garmax, stop and bellow (From 01.08.00)	36	KK 01 23 62	Hose 3/8", L = 2400 mm
2	KK 01 22 61	Threaded coupling 3/8" - 3/8"	37	KK 01 23 56	Hose 1/2", L = 7000 mm (for PX/RX-100, 6 furrow front)
3	KK 01 15 85	Gasket ring 3/8"		KK 01 23 57	Hose 1/2", L = 8000 mm (for PX/RX-100, 7 furrow front and PX/RX-115, 6 furrow front)
4	KK 35 22 38	Stop (Before 01.03.98)		KK 01 23 58	Hose 1/2", L = 9000 mm (for PX/RX-100, 8 furrow front and PX/RX-115, 7 furrow front)
	KK 35 22 47	Stop (From 01.03.98)			
5	KK 01 20 56	Angular coupling 3/8", 90°	38	KK 01 15 72	Threaded coupling 1/2" - 1/2"
6	KK 01 15 65	Gasket ring 1/2"	39	KK 01 23 53	Hose 1/2", L = 2500 mm
7	KK 01 20 60	Threaded coupling 3/8" - 1/2"	40	KK 01 21 14	Quick coupling 1/2"
8	KK 01 21 44	Banjo bolt 1/2"	41	KK 01 23 52	Hose 1/2", L = 2400 mm
9	KK 01 21 77	Gasket ring 22 mm	42	KK 06 19 34	Fixing for valve
10	KK 01 27 09	Adapter			
11	KK 01 25 66	Pin			
12	KK 01 25 65	Angle			
13	KK 01 22 87	Manometer coupling			
14	KK 01 27 50	Manometer			
15	KK 01 23 27	Threaded coupling 1/2" - 1 1/4"			
16	KK 01 18 27	O-ring			
17	KK 35 34 51	Accumulator 55 bar			
18	KK 01 29 51	Washer			
19	KK 07 97 24	Axle			
20	KK 01 10 59	Roll pin D10 x 60 mm			
21	KK 01 03 37	Bolt w/head D25 x 180 mm			
22	KK 01 07 00	Pin D12			
23	KK 07 95 15	Fix for accumulator			
24	KK 35 34 50	Accumulator 15 bar			
25	KK 03 26 50	Hex screw M12 x 50 mm w/nut			
26	KK 03 27 45	Hex screw M16 x 45 mm w/nut			
27	KK 12 78 95	Hose 3/8", L = 2400 mm (for PX plough)			
	KK 01 23 63	Hose 3/8", L = 2000 mm (for RX plough)			
28	KK 01 23 61	Hose 3/8", L = 1150 mm			
29	KK 01 27 73	Hose 3/8", L = 1300 mm			
30	KK 01 27 45	Distributor valve			
31	KK 03 26 30	Hex screw M12 x 30 mm w/nut			
32	KK 01 23 60	Hose 3/8", L = 2750 mm			
33	KK 01 27 30	Angle 3/8"			
34	KK 01 25 67	Valve			





1	KK 35 23 30	Hinge ram (Before 01.03.97) (see plate no. 551)
	KK 35 35 38	Hinge ram (From 01.03.97) (see plate no. 1120)
2	KK 01 15 85	Gasket ring 3/8"
3	KK 01 22 61	Threaded coupling 3/8" - 3/8"
4	KK 01 27 29	T-coupling 3/8"
5	KK 01 22 08	Hose 3/8", L = 500 mm
6	KK 01 15 11	Hose 3/8", L = 1250 mm
7	KK 03 28 80	Hex screw M20 x 80 mm w/nut
8	KK 07 95 09	Fixing for hose (for PX plough) (Before 01.12.96)
9	KK 07 95 46	Fixing for hose (for RX-SL plough)
10	KK 06 19 42	Clamp for 2 hoses
11	KK 03 25 45	Hex screw M10 x 45 mm w/nut
12	KK 03 28 39	Hex screw M20 x 230 mm w/nut
13	KK 03 23 70	Hex screw M6 x 70 mm w/nut
14	KK 01 20 69	Cover
15	KK 01 20 68	Clamp for hose
16	KK 07 91 16	Fixing for hose (for RX plough)
17	KK 01 23 60	Hose 3/8", L = 2750 mm (for PX/RX-SL plough)
	KK 01 15 43	Hose 3/8", L = 2400 mm (for RX plough)
18	KK 07 97 69	Fixing for hose (for PX plough)
19	KK 07 92 27	Plate for valve (From 01.02.94)
	KK 07 96 08	Plate for valve (From 01.06.95)
20	KK 01 27 30	Angle 3/8" - 3/8"
21	KK 01 20 59	Banjo bolt 3/8"
22	KK 01 25 76	Banjo coupling 3/8", long
23	KK 03 23 45	Hex screw M6 x 45 mm w/nut
24	KK 07 95 32	Arm for valve
25	KK 03 33 05	Hex screw M5 x 25 mm w/nut
26	KK 07 95 19	Piece
27	KK 03 24 20	Hex screw M8 x 20 mm w/nut
28	KK 07 95 31	Clamp piece
29	KK 01 23 31	Valve
30	KK 03 23 35	Hex screw M6 x 35 mm w/nut





1	KK 01 21 46	Banjo bolt 1/2" (for cylinder KK 35 23 70) (Before 01.08.96)	22	KK 07 85 84	Axle D35 x 110 mm, 12 furrow
	KK 01 20 81	Banjo bolt 3/8" w/1.0 mm choke (for cylinder KK 35 37 04) (From 01.08.96) (Before 01.09.99)		KK 01 12 70	Circlip
	KK 01 35 80	Banjo bolt 8/8" w/1.0 mm choke (for cylinder KK 35 37 04) (From 01.09.99)	23	KK 01 10 19	Roll pin D10 x 50 mm
2	KK 01 21 77	Gasket ring D22 (for cylinder KK 35 23 70) (Before 01.08.96)	24	KK 06 25 16	Axle D25.4 x 150 mm
	KK 01 15 85	Gasket ring 3/8" (for cylinder KK 35 37 04) (From 01.08.96)		KK 07 95 92	Axle D35 x 150 mm, 12 furrow
3	KK 01 15 65	Gasket ring 1/2" (for cylnder KK 35 23 70) (Before 01.08.96)	25	KK 01 27 95	Hose 3/8", L = 2500 mm
	KK 01 15 85	Gasket ring 3/8" (for cylinder KK 35 37 04) (From 01.08.96)	26	KK 01 23 51	Hose 1/4", L = 850 mm
4	KK 01 03 28	Bolt D25.3 x 78 mm	27	KK 01 22 66	Ring for 10 mm tube
5	KK 01 20 62	Banjo 3/8"	28	KK 01 22 63	Nut M16 for 10 mm tube
6	KK 01 20 75	Threaded coupling 3/8" - 3/8" w/1.0 mm choke	29	KK 07 91 10	Plate w/tube
7	KK 01 22 61	Threaded coupling 3/8" - 3/8"	30	KK 01 21 80	Banjo cpl. (Before 16.02.95)
8	KK 01 15 85	Gasket ring 3/8"	31	KK 01 15 67	Threaded coupling 3/8" - 1/2" (Before 16.02.95)
9	KK 03 23 50	Hex screw M6 x 50 mm	32	KK 01 21 44	Banjo bolt 1/2" w/choke (Before 16.02.95)
10	KK 35 23 70	Hydraulic cylinder for furrow width adjustment D75 x 200 mm cpl. (see plate no. 474) (Before 01.08.96)	33	KK 01 25 14	Lock valve for supporting cylinder (Before 16.02.95)
	KK 35 37 04	Hydraulic cylinder for furrow width adjustment D75 x 200 mm cpl. (see plate no. 890) (From 01.08.96) (Before 01.04.01)	34	KK 35 23 34	Supporting cylinder D75 x 200 mm cpl. (see plate no. 543) (Before 01.01.96)
	KK 35 39 04	Hydraulic cylinder for furrow width adjustment D75 x 200 mm cpl. (see plate no. 1195) (From 01.04.01)		KK 35 27 77	Supporting cylinder D80 x 240 mm cpl. (see plate no. 1104) (From 01.01.96)
				KK 35 34 08	Turn-over cylinder D115 x 600 mm cpl. (see plate no. 590) (Before 01.09.00)
				KK 35 38 35	Hydraulic cylinder D115 x 600 mm cpl. (see plate no. 1147) (From 01.09.00)
11	KK 01 07 00	Pin D12 mm	35	KK 07 91 15	Axle w/2 holes D35 x 140 mm
12	KK 01 22 12	Hose 3/8", L = 900 mm	36	KK 01 10 21	Roll pin D12 x 50 mm
13	KK 01 58 11	Nut M8	37	KK 01 21 14	Plug for quick coupling
14	KK 07 76 82	Ball for valve	38	KK 01 20 60	Threaded coupling 3/8" - 1/2"
15	KK 01 23 39	Valve 4/2	39	KK 01 15 23	Hose 3/8", L = 4500 mm
16	KK 01 27 29	T-coupling 3/8"	40	KK 01 15 12	Hose 3/8", L = 4500 mm
17	KK 01 27 23	Tap w/handle 3/8"	41	KK 01 27 04	Hose assembly coil D30 x 1300 mm
18	KK 01 27 33	Banjo bolt 3/8" x 43 mm	42	KK 01 15 96	Hydraulic hose holder, L = 250 mm
19	KK 01 27 24	Connection piece for 3/8" tap	43	KK 01 15 11	Hose 3/8", L = 1250 mm
20	KK 35 23 57	Turn-over cylinder D100 x 440 mm cpl. for PX/RX w/supporting cylinder (see plate no. 1048) (Before 01.01.98)	44	KK 01 22 12	Hose 3/8", L = 900 mm
	KK 35 38 10	Turn-over cylinder D100 x 440 mm cpl. (see plate no. 1049) (From 01.01.98)	45	KK 01 15 41	Hose 3/8", L = 700 mm
	KK 35 23 84	Turn-over cylinder D80 x 440 mm cpl. for PX/RX without supporting cylinder (see plate no. 542) (Before 01.01.98)			
	KK 35 38 03	Turn-over cylinder D80 x 440 mm cpl. (see plate no. 1047) (From 01.01.98)			
	KK 35 38 32	Turn-over cylinder D80 x 440 mm cpl. (see plate no. 1144) (From 01.09.00)			
	KK 35 23 99	Turn-over cylinder D115 x 440 mm cp. for PX/RX w/supporting cylinder. (see plate no. 590)			
21	KK 01 04 72	Axle D25 x 82 mm			



Замовлення запчастин

(050)-407-68-47

(050)-407-68-45



Замовлення запчастин

(050)-407-68-47


(050)-407-68-45



1	KK 01 26 55	Hose 3/8", L = 350 mm
2	KK 01 23 25	T - coupling 3/8"
3	KK 01 35 17	Relief valve 3/8", 250 bar
4	KK 01 15 85	Gasket ring 3/8"
5	KK 01 23 07	Banjo bolt 3/8" - 3/8"
6	KK 01 20 62	Banjo 3/8"
7	KK 01 35 19	Hose D6, L = 1000 mm NITRIK



Замовлення запчастин
(050)-407-68-47
(050)-407-68-45



1	KK 01 22 61	Threaded coupling 3/8" - 3/8"
2	KK 01 15 85	Gasket ring 3/8"3
3	KK 01 27 23	Valve w/handle 3/8"
4	KK 01 27 33	Banjo bolt 3/8" x 43
5	KK 01 27 24	Coupling for valve
6	KK 01 10 59	Roll pin D10 x 60 mm
7	KK 07 85 84	Bolt w/2 holes, D35 x 110 mm
8	KK 07 95 92	Bolt w/2 holes, D35 x 150 mm
9	KK 35 34 08	Turn-over cylinder D115 x 600 mm cpl. (see plate no. 590) (Before 01.09.00)
	KK 35 38 35	Hydraulic cylinder D115 x 600 mm cpl. (see plate no. 1147) (From 01.09.00)
10	KK 01 20 62	Banjo 3/8", H = 17
11	KK 01 25 51	Banjo bolt 3/8" x 31
12	KK 01 15 11	Hose 3/8", L = 1250 mm
13	KK 01 27 07	Bulkhead piece 3/8" w/nut
14	KK 01 21 14	Quick coupling
15	KK 01 15 65	Gasket ring 1/2"
16	KK 01 20 60	Threaded coupling 3/8" - 1/2"
17	KK 01 15 12	Hose 3/8", L = 4500 mm
18	KK 01 03 28	Bolt w/head D25.3 x 78 mm
19	KK 01 07 00	Pin D12
20	KK 01 20 56	Angular coupling 3/8", 90°
21	KK 35 23 32	Cylinder D80 x 900 mm cpl. for front 6, 7 and 8 furrow, cat. 4 (see plate no. 552)





1	KK 01 20 45	Scraper
2	KK 35 34 07	Rod cap
3	KK 01 20 44	Packing for piston rod
4	KK 01 20 42	Support ring
5	KK 01 20 41	O-ring
6	KK 01 12 98	Circlip
7	KK 35 34 06	Lock ring
8	KK 35 34 05	Pressure rod
9	KK 35 34 04	Pressure plate
10	KK 35 34 03	Piston
11	KK 01 20 43	Packing for piston rod
12	KK 35 34 02	Cylinder house
13	KK 01 17 92	Guide ring
Not ill.	KK 01 20 40	Packings cpl.
	KK 35 23 30	Hinge ram cpl.




Замовлення запчастин
(050)-407-68-47
(050)-407-68-45



1	KK 35 35 39	Cylinder house
2	KK 35 35 42	Piston rod w/piston
3	KK 01 65 07	Glide packing D100
4	KK 01 65 06	Piston packing
5	KK 35 35 43	Pressure plate
6	KK 35 35 44	Pressure rod
7	KK 35 35 46	Lock ring
8	KK 01 65 03	Glide packing D125
9	KK 01 65 05	Support ring
10	KK 01 65 04	O-ring
11	KK 01 12 60	Safty ring
12	KK 01 65 02	Rod packing
13	KK 35 35 45	Rod cap
14	KK 01 65 01	Scraper
Not ill.	KK 01 65 00	Packings cpl.
	KK 35 35 38	Hinge ram D125 x 170 mm cpl.




Замовлення запчастин
(050)-407-68-47
(050)-407-68-45




1	KK 01 19 17	Piston seal D75
2	KK 35 22 67	Piston rod w/rod
3	KK 35 22 62	Rod clevis M30 x 2 mm
4	KK 03 26 50	Hex screw M12 x 50 mm w/nut
5	KK 01 19 10	Scraper packing D32/45 x 7/10 mm
6	KK 01 19 53	Pistonrod packing C32/40 x 6 mm
7	KK 35 22 57	Rod cap w/packing
8	KK 01 18 02	O-ring D70 x 3 mm
9	KK 35 22 84	Cylinder tube D75 mm
10	KK 35 21 61	Clevis cap
11	KK 35 22 92	Tie rod and nut
Not ill.	KK 01 19 47	Packing set cpl.
	KK 35 23 70	Hydraulic cylinder D75 x 200 mm cpl.



Замовлення запчастин
(050)-407-68-47
(050)-407-68-45



1	KK 35 37 32	Cylinder tube for art.no 353704 (cylinder D75 x 200 mm without stop) and 353705 (cylinder D75 x 200 mm w/stop)
	KK 35 37 35	Cylinder tube for art.no 353706 (cylinder D75 x 200 mm w/90° twisted end cap)
	KK 35 37 36	Cylinder tube for art.no 353707 (cylinder D75 x 400 mm w/90° twisted end cap)
2	KK 03 20 06	Screw w/inner hex M6 x 20 mm
3	KK 35 37 27	Piston
4	KK 01 17 36	Piston packing
5	KK 01 17 37	O-ring
6	KK 35 37 44	Piston rod for art.no 353705 (cylinder D75 x 200 mm w/stop)
	KK 35 37 43	Piston rod for art.no 353704 and 353706 (cylinders D75 x 200 mm without stop)
	KK 35 37 46	Piston rod for art.no 353707 (cylinder D75 x 400 mm w/twisted end cap)
7	KK 01 17 38	O-ring
8	KK 01 17 43	Ring
9	KK 01 17 46	Ring (Before 15.03.99)
	KK 35 37 93	Lock spring (From 15.03.99)
10	KK 35 37 26	Packing seal
11	KK 01 17 44	Piston rod packing
12	KK 01 17 45	Scraper
13	KK 35 37 45	Stop for art.no 353705 (cylinder D75 x 200 mm w/stop)
14	KK 03 20 16	Screw w/inner hex M10 x 45 mm
15	KK 35 37 28	Clevis
Not ill.	KK 35 37 29	Packings cpl.
	KK 35 37 04	Cylinder D75 x 200 mm without stop, cpl.
	KK 35 37 05	Cylinder D75 x 200 mm w/stop, cpl.
	KK 35 37 06	Cylinder D75 x 200 mm w/90° twisted end cap, cpl.
	KK 35 37 07	Cylinder D75 x 400 mm w/90° twisted end cap, cpl.



Замовлення запчастин

(050)-407-68-47

(050)-407-68-45



1	KK 35 39 34	Cylinder tube (for cylinder KK 35 39 01 and KK 35 39 02)
	KK 35 39 35	Cylinder tube (for cylinder KK 35 39 03)
2	KK 01 03 90	Piston packing
3	KK 35 39 36	Piston rod (for cylinder KK 35 39 01 and KK 35 39 03)
	KK 35 39 37	Piston rod (for cylinder KK 35 39 02)
4	KK 01 65 17	O-ring D42 x 4 mm
5	KK 03 33 06	Hex screw M6 x 8 mm
6	KK 35 39 26	Packing seal
7	KK 01 30 91	Piston rod packing
8	KK 01 30 89	Scraper
9	KK 03 21 10	Set screw M8 x 8 mm
10	KK 35 39 46	Pin for stop (for cylinder KK 35 39 02)
11	KK 35 39 44	Stop (for cylinder KK 35 39 02)
12	UH 82 56 40	Cylinder screw M12 x 40 mm (for cylinder KK 35 39 02)
13	KK 35 39 22	Clevis
Not ill.	KK 01 30 86	Packings cpl.
	KK 35 39 01	Hydraulic cylinder D50 x 200 mm cpl.
	KK 35 39 02	Hydraulic cylinder D50 x 200 mm w/stop cpl.
	KK 35 39 03	Hydraulic cylinder D50 x 200 mm w/90° twisted end cap cpl.



Замовлення запчастин
(050)-407-68-47
(050)-407-68-45



1	KK 35 21 66	Cylinder tube D75
2	KK 01 18 02	O-ring
3	KK 35 21 64	Tie rod w/nut
4	KK 01 58 17	Nut M12
5	KK 01 15 94	Plug
6	KK 01 15 65	Gasket ring 1/2"
7	KK 35 21 61	Clevis cap
8	KK 01 19 06	Piston packing
9	KK 35 23 38	Piston rod w/piston
10	KK 01 19 50	Packing for piston rod
11	KK 35 21 72	Rod cap w/packings
12	KK 01 19 11	Scraper
13	KK 03 50 15	Cylinder screw M8 x 25 mm
14	KK 01 12 61	Circlip
15	KK 01 12 23	Bearing
16	KK 35 21 53	Head w/bearing
17	KK 02 99 20	Grease nipple
Not ill.	KK 01 19 40	Seal kit
	KK 35 23 34	Supporting cylinder D75 x 200 mm cpl.



Замовлення запчастин
(050)-407-68-47
(050)-407-68-45



1	KK 35 21 53	Clevis
2	KK 01 19 12	Scraper seal
3	KK 01 19 51	Packing
4	KK 35 33 56	Rod cap w/packings
5	KK 01 18 76	Retaining ring
6	KK 01 18 24	O-ring
7	KK 35 27 84	Piston rod w/piston
8	KK 01 19 18	Packing
9	KK 35 27 85	Cylinder tube
Not ill.	KK 01 20 26	Packings set D80 mm cpl.
	KK 35 27 77	Support cylinder D80 x 240 mm cpl.



Замовлення запчастин
(050)-407-68-47
(050)-407-68-45




1	KK 35 33 71	Cylinder tube
2	KK 01 19 08	Piston packing
3	KK 35 33 72	Piston rod w/piston
4	KK 01 18 06	O-ring
5	KK 01 18 88	Support ring
6	KK 35 33 73	End cap
7	KK 01 19 51	Piston rod packing
8	KK 01 19 12	Scraper
9	KK 35 22 99	Stop
10	KK 35 33 92	Clevis
11	KK 03 20 40	Screw M10 x 40 mm

Not ill.	KK 01 20 27	Packing set cpl.
	KK 35 33 70	Hydraulic cylinder w/stop D100 x 215 mm cpl.



Замовлення запчастин
(050)-407-68-47
(050)-407-68-45




1	KK 03 20 40	Cylinder screw M10 x 40 mm
2	KK 35 21 76	Clevis M36 x 2 mm - D25.5
3	KK 35 22 99	Stop M36 x 2 mm
4	KK 01 19 12	Scraper seal
5	KK 01 19 51	Rod seal
6	KK 35 33 73	Rod cap w/seal D100/D40
7	KK 01 18 88	Supporting ring
8	KK 01 18 06	O-ring D94 x 3
9	KK 35 33 72	Piston rod w/rod
10	KK 01 19 08	Piston packing
11	KK 35 33 71	Cylinder tube D100 x 215 mm
12	KK 35 36 29	Rod cap w/seal (1997 - 1998)
13	KK 01 08 49	O-ring D99.5 x 3 (1997 - 1998)
14	KK 35 36 28	Cylinder tube (1997 - 1998)

Not ill.	KK 35 33 70	Cylinder D100 x 215 mm w/stop cpl.
	KK 01 20 27	Packing set cpl.




Замовлення запчастин
(050)-407-68-47
(050)-407-68-45



1	KK 35 38 51	Cylinder tube
2	KK 01 35 97	Thread clamp D110
3	KK 01 19 08	Piston packing set
4	KK 35 33 72	Piston rod
5	KK 01 18 06	O-ring
6	KK 01 18 88	Support ring
7	KK 35 38 50	End cap
8	KK 03 20 02	Screw M6 x 10 mm
9	KK 01 19 51	Piston rod packing
10	KK 01 19 12	Scraper
11	KK 01 35 95	Bellow
12	KK 35 36 27	Stop
13	KK 01 35 96	Thread clamp D80
14	KK 03 20 40	Screw M10 x 40 mm
15	KK 35 33 92	Clevis (for PB/RB plough)
	KK 35 27 74	Clevis w/garmax (for PX/RX plough)
Not ill.	KK 01 30 73	Packing set cpl.
	KK 35 38 37	Hydraulic cylinder D100 x 200 mm w/stop and bellow cpl.
	KK 35 38 38	Hydraulic cylinder D100 x 200 mm w/garmx, stop and bellow cpl.



Замовлення запчастин
(050)-407-68-47
(050)-407-68-45



1	KK 35 21 97	Clevis
2	KK 01 19 12	Scraper D40/D50 x 7/10 mm
3	KK 01 19 51	Packing for piston rod D40/D48 x 6 mm
4	KK 35 33 56	Rod cap w/packings
5	KK 01 18 76	Ring D75 x 2.5 x 1.3 mm
6	KK 01 18 24	O-ring D74.5 x 3 mm
7	KK 35 23 18	Piston rod w/piston (for cylinder KK 35 23 32)
	KK 35 23 39	Piston rod w/piston (for cylinder KK 35 23 33)
8	KK 01 19 18	Packing for piston D80/D60 x 22.4 mm
9	KK 35 23 17	Cylinder tube (for cylinder KK 35 23 32)
	KK 35 23 19	Cylinder tube (for cylinder KK 35 23 33)
Not ill.	KK 35 23 32	Cylinder D80 x 900 mm cpl.
	KK 35 23 33	Cylinder D80 x 690 mm cpl.
	KK 01 20 26	Packings cpl.
	KK 06 02 21	Glue, Loctite 271



Замовлення запчастин
(050)-407-68-47
(050)-407-68-45




Замовлення запчастин
(050)-407-68-47
(050)-407-68-45

1	KK 35 21 97	Clevis
2	KK 01 19 12	Scraper packing
3	KK 01 19 51	Piston rod packing
4	KK 35 33 56	Rod cap w/packings
5	KK 01 18 76	Ring
6	KK 01 18 24	O-ring
7	KK 35 33 55	Piston rod w/piston
8	KK 01 19 18	Packing
9	KK 35 33 54	Cylinder tube
Not ill.	KK 35 23 84	Turn-over cylinder D80 x 440 mm cpl.
	KK 01 20 26	Seal kit for cylinder



Замовлення запчастин
(050)-407-68-47
(050)-407-68-45



1	KK 35 37 51	Clevis
2	KK 03 20 06	Hex screw M6 x 20 mm
3	KK 01 65 14	Scraper
4	KK 01 65 13	Piston packing set
5	KK 35 37 54	Rod cap
6	KK 01 65 08	Aluminium ring D95 x 1.2 mm
7	KK 01 65 12	Support ring
8	KK 01 65 11	O-ring 2.75" x 3.125 mm
9	KK 35 37 60	Seal for piston rod
10	KK 01 65 10	O-ring D40 x 3 mm
11	KK 03 20 16	Hex screw M10 x 45mm
12	KK 35 37 55	Piston
13	KK 01 65 09	Piston packing
14	KK 35 37 59	Cylinder tube
Not ill.	KK 35 37 61	Packing set cpl.
	KK 35 38 03	Turn-over cylinder D80 x 440 mm cpl.



Замовлення запчастин
(050)-407-68-47
(050)-407-68-45



1	KK 35 33 54	Cylinder tube
2	KK 01 19 51	Rod packing
3	KK 01 19 18	Piston packing
4	KK 35 33 55	Piston rod
5	KK 01 18 24	O-ring
6	KK 01 18 76	Support ring
7	KK 35 33 56	Rod cap
8	KK 01 19 12	Scraper
9	KK 03 20 40	Cylinder screw M10 x 40 mm
10	KK 35 21 97	Clevis
Not ill.	KK 01 20 26	Packing set cpl.
	KK 35 38 32	Turn-over cylinder D80 x 440 mm cpl.




Замовлення запчастин
(050)-407-68-47
(050)-407-68-45



1	KK 35 21 97	Clevis
2	KK 01 19 12	Scraper packing
3	KK 01 19 51	Piston rod packing
4	KK 35 33 62	Rod cap w/packings
5	KK 01 18 88	Ring
6	KK 01 18 06	O-ring
7	KK 35 33 61	Piston rod w/piston
8	KK 01 19 08	Packing
9	KK 35 33 60	Cylinder tube
Not ill.	KK 35 23 57	Turn-over cylinder D100 x 440 mm cpl.
	KK 01 20 27	Seal kit for cylinder



Замовлення запчастин
(050)-407-68-47
(050)-407-68-45



1	KK 35 37 51	Clevis
2	KK 03 20 16	Hex screw M10 x 45mm
3	KK 01 17 27	Scraper
4	KK 01 17 25	Piston packing set
5	KK 35 37 39	Rod cap
6	KK 01 17 49	Aluminium ring D107.5 x 1.2 mm
7	KK 01 17 24	Support ring
8	KK 01 17 19	O-ring D93 mm
9	KK 35 37 48	Seal for piston rod
10	KK 01 17 18	O-ring D50 mm
11	KK 03 20 06	Hex screw M6 x 20 mm
12	KK 35 37 49	Piston
13	KK 01 17 17	Piston packing set
14	KK 35 37 38	Cylinder tube
Not ill.	KK 35 37 50	Packing set cpl.
	KK 35 38 10	Turn-over cylinder D100 x 440 mm cpl.



Замовлення запчастин
(050)-407-68-47
(050)-407-68-45



1	KK 35 27 74	Clevis w/bushing (for KK 35 34 08)
	KK 35 21 97	Clevis w/bushing (for KK 35 23 99)
2	KK 01 20 39	Scraper (for KK 35 34 08)
	KK 01 19 12	Scraper (for KK 35 23 99)
3	KK 01 20 32	Piston rod packing (for KK 35 34 08)
	KK 01 19 51	Piston rod packing (for KK 35 23 99)
4	KK 35 34 19	End cap (for KK 35 34 08)
	KK 35 34 55	End cap (for KK 35 23 99)
5	KK 01 17 56	Support ring
6	KK 01 17 55	O-ring
7	KK 35 34 67	Piston rod w/piston (for KK 35 34 08)
	KK 35 34 54	Piston rod w/piston (for KK 35 23 99)
8	KK 01 20 12	Piston packing
9	KK 35 34 66	Cylinder tube (for KK 35 34 08)
	KK 35 34 53	Cylinder tube (for KK 35 23 99)
10	KK 03 20 40	Screw M10 x 40 mm w/nut
Not ill.	KK 01 20 29	Packings cpl. (for KK 35 34 08)
	KK 01 20 11	Packings cpl. (for KK 35 23 99)
	KK 35 34 08	Turn-over cylinder D115 x 600 mm cpl.




Замовлення запчастин
(050)-407-68-47
(050)-407-68-45



1	KK 35 38 55	Cylinder tube
2	KK 01 20 12	Piston packing
3	KK 35 34 67	Piston rod w/piston
4	KK 01 17 55	O-ring D109,5
5	KK 01 17 56	Support ring
6	KK 35 38 54	Rod cap
7	KK 01 20 32	Piston rod packing
8	KK 01 20 39	Scraper
9	KK 03 20 40	Cylinder screw M6 x 10 mm
10	KK 35 27 74	Clevis
Not ill.	KK 01 20 29	Packing set cpl.
	KK 35 38 35	Hydraulic cylinder D115 x 600 mm cpl.




Замовлення запчастин
(050)-407-68-47
(050)-407-68-45



1	KK 06 40 30	Clevis
2	KK 01 58 32	Nut M20
3	KK 06 40 36	Stop screw
4	KK 02 99 20	Grease nipple
5	KK 01 04 61	Axle
6	KK 01 12 72	Circlip
7	KK 06 40 75	Support
8	KK 03 27 50	Hex screw M16 x 50 mm w/nut
9	KK 06 40 86	Lock for cushion
10	KK 06 40 87	Silent block
11	KK 06 40 78	Holder for silent block
	KK 07 48 10	Fix for hydraulic shock absorber (From 01.01.97)
12	KK 03 27 40	Hex screw M16 x 40 mm w/nut
	KK 03 51 44	Hex screw M16 x 60 mm w/lock nut (From 01.01.97)
13	KK 06 40 89	Spring
	KK 35 35 40	Hydraulic shock absorber (From 01.01.97)
14	KK 01 29 19	Washer
15	KK 03 36 70	Hex screw M12 x 70 mm
16	KK 06 40 81	Wheel arm, H = 700 mm
	KK 07 48 01	Wheel arm, H = 700 mm (From 01.01.97)
	KK 06 40 74	Wheel arm, H = 800 mm
	KK 07 48 02	Wheel arm, H = 800 mm (From 01.01.97)
17	KK 03 26 06	Hex screw M12 x 130 mm w/nut
18	KK 07 40 82	Holder for scraper
19	KK 03 36 25	Hex screw M12 x 25 mm w/nut
20	KK 07 40 54	Scraper
21	KK 06 40 73	Spacer

Not ill.	KK 06 40 39	Clevis cpl.
	KK 01 10 42	Roll pin D6 x 40 mm (From 01.01.96)
	KK 07 22 19	Tube (From 01.01.97)






582 Fix for wheel (From 01.09.95, serial no. PX223 and RX261 and PM/RM from 01.04.00)

1	KK 03 28 95	Hex screw M20 x 95 mm w/nut
2	KK 01 10 42	Roll pin D6 x 40 mm
3	KK 07 96 07	Arm for wheel (Before 15.01.02)
4	KK 07 96 71	Axle for shock absorber
5	KK 35 21 45	Shock absorber (for PX/RX)
	KK 35 35 77	Shock absorber (for PM/RM) (Before 01.01.01)
	KK 35 39 20	Shock absorber (for PM/RM) (From 01.01.01)
6	KK 07 96 42	Fix for shock absorber
7	KK 03 27 55	Hex screw M16 x 55 mm w/nut
8	KK 03 10 60	Countersunk screw M20 x 70 mm w/nut
9	KK 07 96 30	Plate (for PM/RM)
	KK 08 24 08	Plate (for PX/RX)
10	KK 08 80 63	Stop screw M24 x 120 mm
11	KK 06 18 99	Counter nut M24
12	KK 08 80 62	Clevis
13	KK 01 02 60	Axle
14	KK 01 10 02	Roll pin
15	KK 02 99 20	Grease nipple
16	KK 03 28 55	Hex screw M20 x 55 mm w/nut
17	KK 07 96 94	Plate (Before 15.01.02)
	KK 08 24 09	Plate (From 15.01.02)
18	KK 03 27 65	Hex screw M16 x 65 mm w/nut
19	KK 07 96 72	Plate, upper for wheel (for PX/RX)
20	KK 07 96 73	Plate, lower for wheel (for PX/RX)
21	KK 30 12 23	Cone (for PX/RX)
22	KK 03 52 29	Hex screw M20 x 290 mm w/lock nut (for PX/RX)
23	KK 03 28 60	Hex screw M20 x 60 mm w/nut
24	KK 01 29 60	Washer
25	KK 07 97 03	Fixing bracket for wheel (for PX/RX)
	KK 08 11 15	Fixing bracket for wheel (for PM/RM)
26	KK 07 96 36	Axle for wheel
27	KK 07 97 30	Plate (for PX/RX)
28	KK 08 24 05	Arm for wheel (From 15.01.02)
29	KK 01 58 34	Nut M20, H = 12 mm
30	KK 01 37 02	Spring
31	KK 01 05 89	Ball
32	KK 01 58 30	Nut M20
33	KK 01 60 00	Lock nut M20





1	KK 07 86 09	Axle
2	KK 01 11 65	Plate ring
3	KK 01 11 66	Seal
4	KK 01 12 42	Roller bearing
5	KK 01 11 60	Hub housing
6	KK 02 99 18	Grease nipple
7	KK 01 13 11	Tyre 11 x 15.3
	KK 01 13 02	Inner tube
8	KK 01 13 71	Rim
9	KK 01 12 43	Roller bearing
10	KK 01 29 53	Washer
11	KK 02 97 28	Cotter pin
12	KK 01 11 61	End cap
13	KK 01 11 64	Nut M30
14	KK 01 11 62	Hub screw M18 x 47.5 mm
15	KK 01 11 63	Tapered washer

Not ill.	KK 01 13 57	Hub cpl.
	KK 07 04 13	Wheel 11 x 15.3 cpl.




Замовлення запчастин
(050)-407-68-47
(050)-407-68-45



1	KK 07 86 09	Axle (Before 01.06.99)
	KK 01 14 84	Axle (From 01.06.99)
2	KK 01 11 65	Sealing plate
3	KK 01 11 66	Gasket ring
4	KK 01 12 42	Bearing
5	KK 01 11 60	Hub
6	KK 02 99 18	Grease nipple
7	KK 01 14 55	Tyre
	KK 01 13 02	Inner tube
8	KK 01 13 71	Rim
	KK 01 14 54	Wheel 10/75 x 15.3, 10 ply
9	KK 01 12 43	Bearing
10	KK 02 97 27	Splinter D5 x 50 mm
11	KK 01 11 61	End cap
12	KK 01 11 64	Nut M30
13	KK 01 29 53	Washer
14	KK 01 11 62	Hub screw M18 x 2.5 x 47.5 mm
15	KK 01 11 63	Lock washer
Not ill.	KK 01 13 72	Hub cpl. (Before 01.06.99)
	KK 01 14 82	Hub cpl. (From 01.06.99)
	KK 07 97 06	Wheel w/hub and axle cpl.



Замовлення запчастин
(050)-407-68-47
(050)-407-68-45



1	KK 01 13 03	Tyre 200 x 14.5
2	KK 01 13 79	Wheel rim w/bearing casing
3	KK 02 99 20	Grease nipple
4	KK 01 11 57	End cap
5	KK 01 60 00	Lock nut M20
6	KK 01 29 60	Washer
7	KK 01 12 00	Bearing 6206
8	KK 01 05 17	Bearing 6208
9	KK 01 11 68	Packing Z209
10	KK 07 40 80	Wheel axle
Not ill.	KK 07 04 93	Wheel w/axle 200 x 14.5 cpl.
	KK 07 69 40	Wheel 200 x 14.5 cpl.



Замовлення запчастин
(050)-407-68-47
(050)-407-68-45


527 Wheel 400 x 15.5", 400 x 22.5", 500 x 22.5", 500 x 26.6", 14.9 x 24" and 12.5 x 18"
(From 01.03.97)



527 Wheel 400 x 15.5", 400 x 22.5", 500 x 22.5", 500 x 26.6", 14.9 x 24" and 12.5 x 18"
(From 01.03.97)

1	KK 01 14 62	Axle D75 x 287
	KK 01 14 84	Axle D50 (for DA plough, middle section only)
2	KK 01 14 61	Hub
	KK 01 14 60	Hub without axle cpl.
3	KK 01 62 01	Bearing 32210
4	KK 01 14 68	Packing w/plate
7	KK 01 14 66	Plate for seal
9	KK 01 14 65	Crown nut
10	KK 01 14 64	Pin
11	KK 01 14 63	Cap for hub D90 mm ADR-65
12	KK 01 62 03	Bearing 30213
13	KK 02 99 20	Grease nipple M8 x 1
14	KK 01 14 79	Wheel bolt M18 x 1.5
15	KK 01 14 69	Nut for wheel M18 x 1.5
16	KK 01 13 44	Rim for tyre 400 x 15.5"
	KK 01 13 70	Rim for tyre 400 x 22.5"
	KK 01 14 53	Rim for tyre 500 x 22.5"
	KK 01 14 78	Rim for tyre 500 x 26.5"
17	KK 01 13 42	Tyre 400 x 15.5", 8 ply (also for DA plough, middle section)
	KK 01 14 16	Tyre 400 x 15.5", 14 ply (also for DA plough, middle section)
	KK 01 13 68	Tyre 400 x 22.5", 8 ply
	KK 01 14 14	Tyre 400 x 22.5", 14 ply
	KK 01 14 51	Tyre 500 x 22.5", 8 ply
	KK 01 14 76	Tyre 500 x 26.5", 8 ply
	KK 01 13 43	Inner tube to 400 x 15.5" tyre
	KK 01 13 69	Inner tube to 400 x 22.5" tyre
	KK 01 14 52	Inner tube to 500 x 22.5" tyre
	KK 01 14 77	Inner tube to 500 x 26.5" tyre
18	KK 01 14 72	Tyre 14.9 x 24", 8 ply
	KK 01 14 73	Inner tube to 14.9 x 24" tyre
19	KK 01 14 74	Rim for tyre 14.9 x 24"
20	KK 01 14 57	Rim for tyre 12.5/80 - 12/18
21	KK 01 14 59	Tyre 12.5/80 - 18/12
	KK 01 14 58	Inner tube for tyre 12.5/80 - 12/18







1	KK 01 11 57	Cover
2	KK 01 60 00	Lock nut M20
3	KK 01 29 34	Washer
4	KK 01 12 00	Bearing 6206
5	KK 01 05 17	Bearing 6208
6	KK 01 11 68	Packing
7	KK 07 94 34	Axle
8	KK 01 60 37	Cone nut M30
9	KK 02 99 20	Grease nipple
10	KK 01 13 79	Rim w/main bearing house
11	KK 01 13 03	Tyre 200 x 14.5
12	KK 01 14 01	Cover kit cpl.
Not ill.	KK 01 14 25	Wheel 200 x 14.5 w/axle and hub cpl.



Замовлення запчастин
(050)-407-68-47
(050)-407-68-45



1	KK 07 48 56	Axle w/bearing cpl. (for depth/transport wheel)	28	KK 02 99 32	Grease nipple	50	KK 07 48 73	Axle
2	KK 07 48 75	Axle	29	KK 01 60 00	Lock nut M20 (Before 01.01.02)	51	KK 01 37 00	Spring
3	KK 07 48 93	Axle		KK 01 31 03	Lock nut KM6 M30 (Rebuilding kit EO/LO. Check dimension !)	52	KK 01 29 16	Washer
4	KK 01 10 48	Roll pin D12 x 60 mm		KK 01 31 09	Lock nut KM7 M35 (From 21.05.02)	53	KK 07 48 76	Lock
5	KK 01 07 00	Pin D12	30	KK 01 29 34	Lock washer (Before 21.05.02)	54	KK 06 40 86	Protection for damper block (From 01.05.00)
6	KK 07 48 64	Switch bracket		KK 01 31 04	Lock washer D42 x d30 x 3 (Rebuilding kit EO/LO. Check dimension !)	55	KK 06 40 79	Holder for damper block (From 01.05.00)
7	KK 07 48 65	Wheel arm (for depth/transport wheel)		KK 01 31 08	Lock washer D58 x d35 x 2,5 (From 21.05.02)	56	KK 01 30 04	Washer
8	KK 03 29 80	Hex screw M24 x 80 mm w/nut				57	KK 01 29 56	Washer
9	KK 03 27 65	Hex screw M16 x 65 mm w/nut (From 01.04.01)	31	KK 01 31 02	Washer MB6 (Rebuilding kit EO/LO. Check dimension !)	58	KK 07 48 41	Axle w/short bracket shaft cpl. (for depth wheel 200 x 14.5)
10	KK 07 48 44	Bracket for scraper (From 01.04.01)		KK 01 31 10	Washer MB7 (From 21.05.02)	59	KK 07 48 62	Axle w/bracket shaft cpl. (for depth wheel 26 x 12-12)
11	KK 07 48 38	Scraper (for wheel 200 x 14.5)	32	KK 01 12 00	Bearing (Before 21.05.02)			
	KK 07 48 43	Scraper (for wheel 26 x 12-12) (Before 01.01.02)		KK 01 05 91	Conical bearing (From 21.05.02)	60	KK 03 27 40	Hex screw M16 x 40 mm w/nut (From 01.05.00)
	KK 07 46 24	Scraper (for wheel 26 x 12-12) (From 01.01.02)	33	KK 01 05 17	Bearing (Before 21.05.02)			
				KK 01 12 15	Conical bearing (From 21.05.02)	61	KK 01 02 55	Bolt D16 x 51 mm
12	KK 03 26 40	Hex screw M12 x 40 mm w/nut	34	KK 01 11 68	Z - lamell	62	KK 01 16 36	Bushing D20 x D16 x 10 mm
13	KK 01 60 38	Flange nut M12 (From 01.04.01)	35	KK 01 13 03	Tyre 200 x 14.5	63	KK 07 48 50	Wheel bracket, rear mounted depth wheel
14	KK 03 28 07	Hex screw M20 x 100 mm w/nut		KK 01 13 05	Inner tube 200 x 14.5		KK 07 48 39	Wheel bracket, rear mounted depth wheel w/bearing
15	KK 01 60 12	Flange nut M20	36	KK 07 40 80	Axle 200 x 14.5 (Before 21.05.02)	64	KK 02 99 20	Grease nipple
16	KK 03 27 70	Hex screw M16 x 70 mm w/nut (for depth/transport wheel) (Before 01.04.01)		KK 08 41 10	Axle 200 x 14.5 (From 21.05.02)	65	KK 03 28 50	Hex screw M20 x 50 mm w/nut
	KK 03 27 75	Hex screw M16 x 75 mm w/nut (for depth wheel) (Before 01.04.01)	37	KK 07 40 93	Axle 26 x 12-12 (Before 27.05.02)	66	KK 03 23 90	Hex screw M6 x 90 mm
				KK 08 41 11	Axle 26 x 12-12 (From 27.05.02)	67	KK 01 29 55	Washer
17	KK 07 48 35	Clamp bracket (Before 01.04.01)	38	KK 01 13 46	Tyre 26 x 12-12 (Before 27.05.02)	68	KK 03 27 45	Hex screw M16 x 45 mm w/nut
18	KK 07 48 36	Bracket for scraper (Before 01.04.01)		KK 01 31 00	Tyre 26 x 12-12 (From 27.05.02)	69	KK 01 10 52	Roll pin D12 x 80 mm
19	KK 10 68 63	Bushing (Before 01.04.01)	39	KK 01 14 02	Cover kit cpl.	70	KK 07 48 67	Crank for shock absorber
20	KK 01 29 19	Washer (Before 01.04.01)	40	KK 06 40 89	Spring (From 01.05.00)	71	KK 08 40 40	Rotation bolt (From 01.05.00)
21	KK 01 29 11	Washer 6,4 x 12,5 x 1,5 mm	41	KK 03 26 65	Hex screw M12 x 60 mm (From 01.05.00)	72	KK 06 40 97	Crank screw cpl.
22	KK 03 28 90	Hex screw M20 x 90 mm w/nut	42	KK 08 40 43	Crank (From 01.05.00)	73	KK 06 40 24	Stop screw
23	KK 07 48 66	Wheel arm (for depth wheel)	43	KK 01 60 18	Lock nut M6	74	KK 06 40 30	Clevis
24	KK 03 29 80	Hex screw M24 x 80 mm w/nut	44	KK 01 29 31	Washer	75	KK 01 13 79	Rim 200 x 14.5 (Before 21.05.02)
25	KK 07 90 63	Washer	45	KK 35 36 30	Shock absorber		KK 08 41 06	Rim 200 x 14.5 (From 21.05.02)
26	KK 01 14 01	Cover kit cpl.	46	KK 01 10 35	Roll pin D6 x 30 mm	76	KK 01 14 19	Rim 26 x 12-12 (Before 27.05.02)
27	KK 01 11 57	Hub cap (Before 01.01.02)	47	KK 07 48 70	Bracket arm for shock absorber		KK 08 41 07	Rim 26 x 12-12 (From 27.05.02)
	KK 01 31 05	Hub cap (From 21.05.02)	48	KK 35 60 42	Spring		KK 07 48 86	Clamp w/fixing lug (200 mm tube)
			49	KK 07 48 74	Handle	77	KK 01 60 01	Lock nut M24



Not ill.	KK 06 40 47	Stop cpl.
	KK 08 40 00	Depth wheel 200 x 14.5 rear mounted without shock absorber cpl.
	KK 08 40 01	Depth wheel 200 x 14.5 rear mounted w/shock absorber cpl.
	KK 08 40 02	Depth wheel 26 x 12-12 rear mounted w/shock absorber cpl.
	KK 08 40 03	Depth wheel 200 x 14.5 frame mounted without shock absorber cpl.
	KK 08 40 10	Depth/transport wheel 200 x 14.5 rear mounted without shock absorber cpl.
	KK 08 40 11	Depth/transport wheel 200 x 14.5 rear mounted w/shock absorber cpl.
	KK 08 40 12	Depth/transport wheel 26 x 12-12 rear mounted w/shock absorber cpl.
	KK 08 40 13	Depth/transport wheel 200 x 14.5 frame mounted without shock absorber cpl.
	KK 08 41 00	Wheel 200 x 14.5 cpl. w/axle (From 21.05.02)
	KK 08 41 01	Wheel 26 x 12-12 cpl. w/axle (From 27.05.02)



Замовлення запчастин
(050)-407-68-47
(050)-407-68-45



1	KK 03 27 16	Hex screw M16 x 140 mm w/nut (VD, VX, ED and LD plough)	24	KK 07 48 90	Clamp (150 mm tube)
	KK 03 27 19	Hex screw M16 x 190 mm w/nut (EM/LM plough)		KK 07 48 87	Clamp (200 mm tube)
	KK 03 27 27	Hex screw M16 x 160 mm w/nut (ED/LD-HD plough)	25	KK 07 48 89	Clamp w/fixing lug (150 mm tube)
				KK 07 48 86	Clamp w/fixing lug (200 mm tube)
2	KK 01 03 15	Bolt D25.3 x 60 mm	26	KK 07 48 81	Plate, over (for ES and LS plough)
3	KK 07 08 05	Adjustable stay			
4	KK 01 10 20	Roll pin D12 x 40 mm			
5	KK 07 48 80	Wheel bracket, frame mounted wheel			
6	KK 07 48 85	Plate, lower (ED and LD plough)			
	KK 07 49 71	Plate, lower (ED/LD-HD, 200 tube)			
7	KK 07 48 84	Plate, upper (ED and LD plough)			
	KK 07 49 70	Plate, upper (ED/LD-HD, 200 tube)			
8	KK 07 48 88	Plate (for VD and VX plough)			
9	KK 07 48 91	Plate (for EM/LM plough)			
10	KK 07 48 82	Plate, under (for ES and LS plough)			
11	KK 01 30 05	Washer			
12	KK 01 16 14	Bushing D30 x D16 x 28 mm			
13	KK 03 27 65	Hex screw M16 x 65 mm w/nut			
14	KK 01 16 15	Bushing D40 x D24 x 15.5 mm			
15	KK 03 29 25	Hex screw M24 x 250 mm w/nut			
16	KK 03 29 20	Hex screw M24 x 200 mm w/nut			
17	KK 03 28 22	Hex screw M20 x 190 mm w/nut			
18	KK 03 28 36	Hex screw M20 x 240 mm w/nut			
19	KK 08 40 42	Pin (From 01.05.00)			
20	KK 06 82 51	Washer			
21	KK 08 40 84	Stop screw (for ES/LS ploughs only) (From 01.04.01)			
22	KK 07 48 46	Transportation support (for ES/LS ploughs only) (From 01.04.01)			
23	KK 06 18 99	Contra nut M24 (for ES/LS ploughs only) (From 01.04.01)			



Замовлення запчастин
(050)-407-68-47
(050)-407-68-45

 **Kverneland**
PX 100

 **Kverneland**
RX 100

 **Kverneland**
PX 115





 **Kverneland**
RX 115

Kverneland



1. ARBEID
WORK
ARBEIT
LABOUR

2. TRANSPORT



1	KK 70 97 66	Kverneland PX100
2	KK 70 97 67	Kverneland RX100
3	KK 70 97 68	Kverneland PX115
4	KK 70 97 69	Kverneland RX115
5	KK 70 94 79	Info., nuts
6	KK 70 97 37	Kverneland w/arrow
7	KK 70 98 43	Safty sign, parking support
8	KK 70 98 95	Safty sign, sharp egdes
9	KK 70 98 23	Safty sign, crush danger
10	KK 70 98 42	Safty sign, reversible point
11	KK 70 98 44	Safty sign, read the instruction manual
12	KK 70 98 41	Safty sign, crush danger, tracktor - implement
13	KK 70 97 81	Speed limit
14	KK 70 93 04	Info., hydraulics
15	KK 70 97 37	Arrow
16	KK 70 92 34	Info., spring
Not ill.	KK 70 97 80	100 inches label (PX/RX upper middle section)
	KK 70 99 43	115 inchel label (PX/RX upper middle section)
	KK 70 97 87	100 inches label (PX/RX lower middle section)
	KK 70 99 42	115 inches label (PX/RX lower middle section)
	KK 70 99 27	100 inches label (PX plough)
	KK 70 99 29	100 inches label (RX plough)
	KK 70 99 28	115 inches label (PX plough)
	KK 70 99 30	115 inches label (RX plough)



Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page
	49	KK 01 05 89111		KK 01 10 48123		KK 01 12 61 83		KK 01 14 25121		KK 01 15 32 57		KK 01 16 87 53		KK 01 18 66 29	
	49	KK 01 05 91123		KK 01 10 52123		KK 01 12 66 27		KK 01 14 51119		KK 01 15 41 65		KK 01 16 91 47		KK 01 18 66 31	
	89	KK 01 06 06 41		KK 01 10 59 61		KK 01 12 66 29		KK 01 14 52119		KK 01 15 43 59		KK 01 16 97 49		KK 01 18 76 85	
KK 01 01 48 51		KK 01 06 06 49		KK 01 10 59 71		KK 01 12 66 31		KK 01 14 53119		KK 01 15 43 63		KK 01 17 17103		KK 01 18 76 93	
KK 01 01 55 11		KK 01 06 50 41		KK 01 11 57117		KK 01 12 69 25		KK 01 14 54115		KK 01 15 65 57		KK 01 17 18103		KK 01 18 76 95	
KK 01 01 55 13		KK 01 06 50 49		KK 01 11 57121		KK 01 12 70 65		KK 01 14 55115		KK 01 15 65 59		KK 01 17 19103		KK 01 18 76 99	
KK 01 01 55 19		KK 01 06 55 41		KK 01 11 57123		KK 01 12 72109		KK 01 14 57119		KK 01 15 65 61		KK 01 17 24103		KK 01 18 88101	
KK 01 01 55 7		KK 01 06 55 49		KK 01 11 60113		KK 01 12 92 27		KK 01 14 58119		KK 01 15 65 65		KK 01 17 25103		KK 01 18 88 87	
KK 01 01 56 11		KK 01 07 00123		KK 01 11 60115		KK 01 12 98 73		KK 01 14 59119		KK 01 15 65 71		KK 01 17 27103		KK 01 18 88 89	
KK 01 01 56 13		KK 01 07 00 43		KK 01 11 61113		KK 01 13 02113		KK 01 14 60119		KK 01 15 65 83		KK 01 17 36 79		KK 01 18 88 91	
KK 01 01 56 19		KK 01 07 00 57		KK 01 11 61115		KK 01 13 02115		KK 01 14 61119		KK 01 15 67 65		KK 01 17 37 79		KK 01 19 06 83	
KK 01 01 56 7		KK 01 07 00 59		KK 01 11 62113		KK 01 13 03117		KK 01 14 62119		KK 01 15 72 61		KK 01 17 38 79		KK 01 19 08101	
KK 01 02 55123		KK 01 07 00 61		KK 01 11 62115		KK 01 13 03121		KK 01 14 63119		KK 01 15 79 59		KK 01 17 43 79		KK 01 19 08 87	
KK 01 02 60111		KK 01 07 00 65		KK 01 11 63113		KK 01 13 03123		KK 01 14 64119		KK 01 15 85 57		KK 01 17 44 79		KK 01 19 08 89	
KK 01 02 98 41		KK 01 07 00 71		KK 01 11 63115		KK 01 13 05123		KK 01 14 65119		KK 01 15 85 59		KK 01 17 45 79		KK 01 19 08 91	
KK 01 02 98 49		KK 01 07 72 27		KK 01 11 64113		KK 01 13 11113		KK 01 14 66119		KK 01 15 85 61		KK 01 17 46 79		KK 01 19 10 77	
KK 01 03 15127		KK 01 07 72 33		KK 01 11 64115		KK 01 13 42119		KK 01 14 68119		KK 01 15 85 63		KK 01 17 49103		KK 01 19 11 83	
KK 01 03 15 53		KK 01 07 75 27		KK 01 11 65113		KK 01 13 43119		KK 01 14 69119		KK 01 15 85 65		KK 01 17 50 29		KK 01 19 12101	
KK 01 03 28 43		KK 01 08 09 53		KK 01 11 65115		KK 01 13 44119		KK 01 14 72119		KK 01 15 85 65		KK 01 17 50 31		KK 01 19 12105	
KK 01 03 28 57		KK 01 08 18 31		KK 01 11 66113		KK 01 13 46123		KK 01 14 73119		KK 01 15 85 65		KK 01 17 55105		KK 01 19 12 85	
KK 01 03 28 59		KK 01 08 49 89		KK 01 11 66115		KK 01 13 49123		KK 01 14 74119		KK 01 15 85 69		KK 01 17 55107		KK 01 19 12 87	
KK 01 03 28 65		KK 01 08 91 53		KK 01 11 68117		KK 01 13 57113		KK 01 14 76119		KK 01 15 85 71		KK 01 17 56105		KK 01 19 12 89	
KK 01 03 28 71		KK 01 09 09 31		KK 01 11 68121		KK 01 13 68119		KK 01 14 77119		KK 01 15 94 83		KK 01 17 56107		KK 01 19 12 91	
KK 01 03 37 59		KK 01 10 02111		KK 01 11 68123		KK 01 13 69119		KK 01 14 78119		KK 01 15 96 45		KK 01 17 66 57		KK 01 19 12 93	
KK 01 03 37 61		KK 01 10 05 43		KK 01 12 00117		KK 01 13 70119		KK 01 14 79119		KK 01 15 96 65		KK 01 17 92 73		KK 01 19 12 95	
KK 01 03 90 81		KK 01 10 19 65		KK 01 12 00121		KK 01 13 71113		KK 01 14 82115		KK 01 16 14127		KK 01 18 02 77		KK 01 19 12 99	
KK 01 04 61109		KK 01 10 20127		KK 01 12 00123		KK 01 13 71115		KK 01 14 84115		KK 01 16 15127		KK 01 18 02 83		KK 01 19 17 77	
KK 01 04 72 65		KK 01 10 20 53		KK 01 12 03 33		KK 01 13 72115		KK 01 14 84119		KK 01 16 36123		KK 01 18 06101		KK 01 19 18 85	
KK 01 05 17117		KK 01 10 20 57		KK 01 12 15123		KK 01 13 79117		KK 01 15 11 63		KK 01 16 68 51		KK 01 18 06 87		KK 01 19 18 93	
KK 01 05 17121		KK 01 10 20 59		KK 01 12 23 83		KK 01 13 79121		KK 01 15 11 65		KK 01 16 69 51		KK 01 18 06 89		KK 01 19 18 95	
KK 01 05 17123		KK 01 10 21 65		KK 01 12 42113		KK 01 13 79123		KK 01 15 11 71		KK 01 16 82 39		KK 01 18 06 91		KK 01 19 18 99	
KK 01 05 32 29		KK 01 10 32 33		KK 01 12 42115		KK 01 14 01121		KK 01 15 12 57		KK 01 16 82 41		KK 01 18 24 85		KK 01 19 40 83	
KK 01 05 32 31		KK 01 10 35123		KK 01 12 43113		KK 01 14 01123		KK 01 15 12 65		KK 01 16 82 45		KK 01 18 24 93		KK 01 19 47 77	
KK 01 05 72 29		KK 01 10 37 21		KK 01 12 43115		KK 01 14 02123		KK 01 15 12 71		KK 01 16 82 49		KK 01 18 24 95		KK 01 19 50 83	
KK 01 05 72 31		KK 01 10 42109		KK 01 12 59 29		KK 01 14 14119		KK 01 15 23 65		KK 01 16 82 51		KK 01 18 24 99		KK 01 19 51101	
KK 01 05 83 33		KK 01 10 42111		KK 01 12 59 31		KK 01 14 16119		KK 01 15 30 59		KK 01 16 82 55		KK 01 18 27 59		KK 01 19 51105	
KK 01 05 84 33		KK 01 10 42 21		KK 01 12 60 75		KK 01 14 19123		KK 01 15 31 59		KK 01 16 83 49		KK 01 18 27 61		KK 01 19 51 85	

Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page
KK 01 19 51	87	KK 01 20 60	65	KK 01 22 87	61	KK 01 25 76	63	KK 01 28 71	47	KK 01 29 68	47	KK 01 33 32	15	KK 01 58 17	17
KK 01 19 51	89	KK 01 20 60	71	KK 01 22 90	45	KK 01 26 55	69	KK 01 28 74	25	KK 01 29 68	51	KK 01 33 32	15	KK 01 58 17	17
KK 01 19 51	91	KK 01 20 62	59	KK 01 23 07	59	KK 01 27 04	65	KK 01 29 06	35	KK 01 29 68	53	KK 01 33 32	17	KK 01 58 17	17
KK 01 19 51	93	KK 01 20 62	65	KK 01 23 07	69	KK 01 27 07	71	KK 01 29 11	23	KK 01 29 68	55	KK 01 33 32	5	KK 01 58 17	17
KK 01 19 51	95	KK 01 20 62	69	KK 01 23 19	59	KK 01 27 09	61	KK 01 29 13	21	KK 01 29 95	33	KK 01 33 32	9	KK 01 58 17	19
KK 01 19 51	99	KK 01 20 62	71	KK 01 23 25	69	KK 01 27 10	39	KK 01 29 13	47	KK 01 29 98	23	KK 01 33 32	9	KK 01 58 17	29
KK 01 19 53	77	KK 01 20 67	43	KK 01 23 27	61	KK 01 27 10	49	KK 01 29 16	123	KK 01 29 98	25	KK 01 33 33	13	KK 01 58 17	47
KK 01 20 11	105	KK 01 20 68	43	KK 01 23 28	59	KK 01 27 10	57	KK 01 29 19	109	KK 01 29 98	43	KK 01 33 33	7	KK 01 58 17	83
KK 01 20 12	105	KK 01 20 68	63	KK 01 23 30	59	KK 01 27 23	65	KK 01 29 19	123	KK 01 30 00	25	KK 01 33 33	9	KK 01 58 25	17
KK 01 20 12	107	KK 01 20 69	43	KK 01 23 31	63	KK 01 27 23	71	KK 01 29 19	13	KK 01 30 01	15	KK 01 33 46	11	KK 01 58 25	17
KK 01 20 26	85	KK 01 20 69	63	KK 01 23 32	59	KK 01 27 24	65	KK 01 29 19	15	KK 01 30 04	123	KK 01 33 46	13	KK 01 58 25	17
KK 01 20 26	93	KK 01 20 75	65	KK 01 23 37	59	KK 01 27 24	71	KK 01 29 19	5	KK 01 30 05	127	KK 01 33 46	15	KK 01 58 25	19
KK 01 20 26	95	KK 01 20 81	65	KK 01 23 39	65	KK 01 27 29	59	KK 01 29 19	9	KK 01 30 73	91	KK 01 33 46	19	KK 01 58 25	19
KK 01 20 26	99	KK 01 21 14	57	KK 01 23 51	65	KK 01 27 29	63	KK 01 29 22	13	KK 01 30 86	81	KK 01 33 46	7	KK 01 58 25	19
KK 01 20 27	101	KK 01 21 14	61	KK 01 23 52	61	KK 01 27 29	65	KK 01 29 22	15	KK 01 30 89	81	KK 01 33 46	7	KK 01 58 25	33
KK 01 20 27	87	KK 01 21 14	65	KK 01 23 53	61	KK 01 27 30	59	KK 01 29 22	17	KK 01 30 91	81	KK 01 33 46	9	KK 01 58 25	35
KK 01 20 27	89	KK 01 21 14	71	KK 01 23 56	61	KK 01 27 30	61	KK 01 29 22	5	KK 01 31 00	123	KK 01 33 61	11	KK 01 58 30	11
KK 01 20 29	105	KK 01 21 41	59	KK 01 23 57	61	KK 01 27 30	63	KK 01 29 22	57	KK 01 31 02	123	KK 01 33 61	13	KK 01 58 30	15
KK 01 20 29	107	KK 01 21 44	61	KK 01 23 58	61	KK 01 27 33	65	KK 01 29 22	9	KK 01 31 03	123	KK 01 33 61	19	KK 01 58 30	25
KK 01 20 32	105	KK 01 21 44	65	KK 01 23 60	59	KK 01 27 33	71	KK 01 29 24	45	KK 01 31 04	123	KK 01 33 61	7	KK 01 58 30	25
KK 01 20 32	107	KK 01 21 46	65	KK 01 23 60	61	KK 01 27 45	59	KK 01 29 27	5	KK 01 31 05	123	KK 01 33 85	11	KK 01 58 30	29
KK 01 20 39	105	KK 01 21 77	61	KK 01 23 60	63	KK 01 27 45	61	KK 01 29 27	9	KK 01 31 08	123	KK 01 33 85	13	KK 01 58 30	29
KK 01 20 39	107	KK 01 21 77	65	KK 01 23 61	61	KK 01 27 50	61	KK 01 29 29	11	KK 01 31 09	123	KK 01 33 85	19	KK 01 58 30	43
KK 01 20 40	73	KK 01 21 80	65	KK 01 23 62	61	KK 01 27 73	59	KK 01 29 29	13	KK 01 31 10	123	KK 01 33 85	7	KK 01 58 30	57
KK 01 20 41	73	KK 01 21 85	41	KK 01 23 63	61	KK 01 27 73	61	KK 01 29 29	19	KK 01 32 28	11	KK 01 35 17	69	KK 01 58 32	109
KK 01 20 42	73	KK 01 21 85	49	KK 01 23 70	45	KK 01 27 79	57	KK 01 29 29	7	KK 01 32 28	13	KK 01 35 19	69	KK 01 58 32	5
KK 01 20 43	73	KK 01 22 08	63	KK 01 25 10	57	KK 01 27 79	59	KK 01 29 31	123	KK 01 32 28	13	KK 01 35 80	65	KK 01 58 34	111
KK 01 20 44	73	KK 01 22 12	65	KK 01 25 11	57	KK 01 27 80	59	KK 01 29 34	121	KK 01 32 28	15	KK 01 35 95	91	KK 01 58 34	13
KK 01 20 45	73	KK 01 22 12	65	KK 01 25 14	65	KK 01 27 81	59	KK 01 29 34	123	KK 01 32 28	17	KK 01 35 96	91	KK 01 58 34	15
KK 01 20 56	57	KK 01 22 61	57	KK 01 25 28	51	KK 01 27 95	57	KK 01 29 51	61	KK 01 32 28	19	KK 01 35 97	91	KK 01 58 34	25
KK 01 20 56	59	KK 01 22 61	59	KK 01 25 28	59	KK 01 27 95	59	KK 01 29 53	113	KK 01 32 28	7	KK 01 37 00	123	KK 01 58 34	33
KK 01 20 56	61	KK 01 22 61	61	KK 01 25 29	51	KK 01 27 95	65	KK 01 29 53	115	KK 01 32 28	9	KK 01 37 02	111	KK 01 58 34	53
KK 01 20 56	71	KK 01 22 61	63	KK 01 25 29	59	KK 01 27 96	59	KK 01 29 55	123	KK 01 32 34	13	KK 01 58 11	65	KK 01 58 34	9
KK 01 20 59	63	KK 01 22 61	65	KK 01 25 51	71	KK 01 27 97	59	KK 01 29 56	123	KK 01 32 34	15	KK 01 58 13	17	KK 01 58 41	35
KK 01 20 60	57	KK 01 22 61	71	KK 01 25 65	61	KK 01 28 51	41	KK 01 29 60	111	KK 01 32 34	5	KK 01 58 13	17	KK 01 60 00	111
KK 01 20 60	59	KK 01 22 63	65	KK 01 25 66	61	KK 01 28 51	51	KK 01 29 60	117	KK 01 32 34	9	KK 01 58 16	35	KK 01 60 00	117
KK 01 20 60	61	KK 01 22 66	65	KK 01 25 67	61	KK 01 28 70	47	KK 01 29 60	31	KK 01 33 32	13	KK 01 58 17	17	KK 01 60 00	121

Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page
KK 01 60 00123		KK 01 65 06 75		KK 02 99 20 55		KK 03 24 70 41		KK 03 27 27127		KK 03 27 52 43		KK 03 28 18 49		KK 03 28 60 43	
KK 01 60 00 53		KK 01 65 07 75		KK 02 99 20 83		KK 03 24 70 57		KK 03 27 28 43		KK 03 27 55111		KK 03 28 22127		KK 03 28 60 49	
KK 01 60 01123		KK 01 65 08 97		KK 02 99 32123		KK 03 25 45 63		KK 03 27 29 25		KK 03 27 55 57		KK 03 28 22 41		KK 03 28 65 41	
KK 01 60 01 25		KK 01 65 09 97		KK 03 10 30 31		KK 03 26 06109		KK 03 27 30 13		KK 03 27 60 43		KK 03 28 22 43		KK 03 28 70 53	
KK 01 60 04 29		KK 01 65 10 97		KK 03 10 60111		KK 03 26 06 47		KK 03 27 30 15		KK 03 27 60 55		KK 03 28 26 49		KK 03 28 70 57	
KK 01 60 04 33		KK 01 65 11 97		KK 03 13 40 27		KK 03 26 30 59		KK 03 27 30 39		KK 03 27 65 11		KK 03 28 26 51		KK 03 28 75 41	
KK 01 60 12123		KK 01 65 12 97		KK 03 17 30 27		KK 03 26 30 61		KK 03 27 30 41		KK 03 27 65111		KK 03 28 26 53		KK 03 28 75 49	
KK 01 60 12 33		KK 01 65 13 97		KK 03 17 40 27		KK 03 26 35 47		KK 03 27 30 45		KK 03 27 65123		KK 03 28 26 53		KK 03 28 80 31	
KK 01 60 12 47		KK 01 65 14 97		KK 03 19 41 25		KK 03 26 40123		KK 03 27 30 49		KK 03 27 65127		KK 03 28 26 55		KK 03 28 80 45	
KK 01 60 13 17		KK 01 65 17 81		KK 03 20 02 91		KK 03 26 45 47		KK 03 27 30 53		KK 03 27 65 13		KK 03 28 28 43		KK 03 28 80 53	
KK 01 60 15 11		KK 02 97 22 33		KK 03 20 06103		KK 03 26 50 45		KK 03 27 35 13		KK 03 27 65 19		KK 03 28 30 29		KK 03 28 80 53	
KK 01 60 15 13		KK 02 97 27115		KK 03 20 06 79		KK 03 26 50 59		KK 03 27 35 5		KK 03 27 65 7		KK 03 28 30 39		KK 03 28 80 63	
KK 01 60 15 17		KK 02 97 27 21		KK 03 20 06 97		KK 03 26 50 61		KK 03 27 35 9		KK 03 27 70123		KK 03 28 30 55		KK 03 28 82 23	
KK 01 60 15 19		KK 02 97 27 21		KK 03 20 16103		KK 03 26 50 77		KK 03 27 40109		KK 03 27 70 31		KK 03 28 33 43		KK 03 28 85 31	
KK 01 60 15 7		KK 02 97 28113		KK 03 20 16 79		KK 03 26 55 21		KK 03 27 40 11		KK 03 27 74 25		KK 03 28 33 51		KK 03 28 90123	
KK 01 60 18123		KK 02 99 18113		KK 03 20 16 97		KK 03 26 65123		KK 03 27 40123		KK 03 27 75 11		KK 03 28 36127		KK 03 28 90 25	
KK 01 60 25 25		KK 02 99 18115		KK 03 20 40105		KK 03 26 65 21		KK 03 27 40 13		KK 03 27 75123		KK 03 28 36 25		KK 03 28 95111	
KK 01 60 25 25		KK 02 99 18 25		KK 03 20 40107		KK 03 26 65 61		KK 03 27 40 15		KK 03 27 75 13		KK 03 28 36 45		KK 03 28 95 53	
KK 01 60 25 43		KK 02 99 20109		KK 03 20 40 87		KK 03 26 70 57		KK 03 27 40 19		KK 03 27 75 19		KK 03 28 39 51		KK 03 29 00 41	
KK 01 60 31 27		KK 02 99 20111		KK 03 20 40 89		KK 03 27 02 31		KK 03 27 40 43		KK 03 27 75 31		KK 03 28 39 63		KK 03 29 08 49	
KK 01 60 31 29		KK 02 99 20117		KK 03 20 40 91		KK 03 27 02 33		KK 03 27 40 45		KK 03 27 75 33		KK 03 28 40 21		KK 03 29 20127	
KK 01 60 37121		KK 02 99 20119		KK 03 20 40 99		KK 03 27 06 55		KK 03 27 40 47		KK 03 27 75 45		KK 03 28 40 29		KK 03 29 20 41	
KK 01 60 38123		KK 02 99 20121		KK 03 21 10 81		KK 03 27 12 23		KK 03 27 40 55		KK 03 27 75 7		KK 03 28 40 37		KK 03 29 23 45	
KK 01 60 45 23		KK 02 99 20123		KK 03 23 35 39		KK 03 27 12 25		KK 03 27 40 7		KK 03 27 92 33		KK 03 28 40 41		KK 03 29 23 51	
KK 01 60 50 31		KK 02 99 20 21		KK 03 23 35 49		KK 03 27 14 25		KK 03 27 45123		KK 03 27 92 43		KK 03 28 40 49		KK 03 29 25127	
KK 01 60 52 33		KK 02 99 20 27		KK 03 23 35 59		KK 03 27 16127		KK 03 27 45 43		KK 03 27 95 35		KK 03 28 42 45		KK 03 29 25 23	
KK 01 60 58 31		KK 02 99 20 29		KK 03 23 35 63		KK 03 27 19127		KK 03 27 45 59		KK 03 28 03 51		KK 03 28 45 23		KK 03 29 25 25	
KK 01 62 01119		KK 02 99 20 31		KK 03 23 45 43		KK 03 27 24 25		KK 03 27 45 61		KK 03 28 05 47		KK 03 28 45 43		KK 03 29 25 43	
KK 01 62 03119		KK 02 99 20 33		KK 03 23 45 63		KK 03 27 25 33		KK 03 27 50109		KK 03 28 05 49		KK 03 28 45 55		KK 03 29 25 51	
KK 01 62 08 33		KK 02 99 20 39		KK 03 23 50 65		KK 03 27 25 41		KK 03 27 50 11		KK 03 28 05 53		KK 03 28 50123		KK 03 29 26 25	
KK 01 62 22 23		KK 02 99 20 41		KK 03 23 70 51		KK 03 27 25 45		KK 03 27 50 13		KK 03 28 05 55		KK 03 28 50 55		KK 03 29 27 39	
KK 01 65 00 75		KK 02 99 20 43		KK 03 23 70 63		KK 03 27 25 49		KK 03 27 50 17		KK 03 28 07123		KK 03 28 55111		KK 03 29 27 49	
KK 01 65 01 75		KK 02 99 20 45		KK 03 23 90123		KK 03 27 25 5		KK 03 27 50 19		KK 03 28 07 23		KK 03 28 55 21		KK 03 29 29 31	
KK 01 65 02 75		KK 02 99 20 47		KK 03 24 03 41		KK 03 27 25 51		KK 03 27 50 31		KK 03 28 11 57		KK 03 28 55 55		KK 03 29 29 43	
KK 01 65 03 75		KK 02 99 20 49		KK 03 24 03 49		KK 03 27 25 53		KK 03 27 50 47		KK 03 28 13 43		KK 03 28 60111		KK 03 29 30 49	
KK 01 65 04 75		KK 02 99 20 49		KK 03 24 20 63		KK 03 27 25 55		KK 03 27 50 7		KK 03 28 16 43		KK 03 28 60 21		KK 03 29 34 31	
KK 01 65 05 75		KK 02 99 20 53		KK 03 24 45 57		KK 03 27 25 9		KK 03 27 50 9		KK 03 28 18 43		KK 03 28 60 41		KK 03 29 50 45	

Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page
KK 03 29 50 51		KK 03 32 56 13		KK 03 51 14 33		KK 05 61 15 27		KK 06 23 95 39		KK 06 40 73 55		KK 06 61 90 27		KK 07 02 93 15	
KK 03 29 80123		KK 03 32 56 17		KK 03 51 27 51		KK 05 61 16 27		KK 06 24 39 43		KK 06 40 74109		KK 06 61 90 29		KK 07 02 94 15	
KK 03 29 80123		KK 03 32 56 5		KK 03 51 34 25		KK 05 61 56 27		KK 06 25 05 41		KK 06 40 75109		KK 06 68 11 35		KK 07 03 88 9	
KK 03 30 04 13		KK 03 32 56 9		KK 03 51 36 51		KK 05 68 73 35		KK 06 25 05 49		KK 06 40 78109		KK 06 68 11 35		KK 07 03 89 9	
KK 03 30 06 17		KK 03 32 86 13		KK 03 51 38 25		KK 05 70 63 21		KK 06 25 06 41		KK 06 40 79123		KK 06 68 12 35		KK 07 03 90 5	
KK 03 30 06 35		KK 03 32 86 15		KK 03 51 44109		KK 05 70 64 21		KK 06 25 06 49		KK 06 40 81109		KK 06 68 61 35		KK 07 03 91 5	
KK 03 30 07 35		KK 03 32 86 17		KK 03 51 56 25		KK 05 70 65 21		KK 06 25 16 65		KK 06 40 86109		KK 06 68 68 35		KK 07 03 92 9	
KK 03 30 16 17		KK 03 32 86 5		KK 03 51 62 55		KK 05 70 66 21		KK 06 30 90 11		KK 06 40 86123		KK 06 68 69 35		KK 07 03 93 9	
KK 03 31 00 13		KK 03 32 86 9		KK 03 51 65 21		KK 05 70 67 21		KK 06 30 90 13		KK 06 40 87109		KK 06 68 73 35		KK 07 03 94 5	
KK 03 31 00 15		KK 03 32 95 13		KK 03 51 68 53		KK 05 70 68 21		KK 06 30 90 13		KK 06 40 89109		KK 06 68 80 35		KK 07 03 95 5	
KK 03 31 00 5		KK 03 32 95 17		KK 03 51 78 33		KK 05 70 89 21		KK 06 30 90 15		KK 06 40 89123		KK 06 68 81 35		KK 07 03 96 9	
KK 03 31 00 9		KK 03 32 95 5		KK 03 51 78 53		KK 06 01 08 21		KK 06 30 90 17		KK 06 40 97123		KK 06 70 16 21		KK 07 03 97 9	
KK 03 31 07 15		KK 03 32 95 9		KK 03 52 09 21		KK 06 01 09 21		KK 06 30 90 19		KK 06 43 17 41		KK 06 70 25 21		KK 07 03 98 9	
KK 03 31 07 17		KK 03 33 05 63		KK 03 52 17 47		KK 06 01 19 21		KK 06 30 90 5		KK 06 43 17 49		KK 06 70 26 21		KK 07 03 99 9	
KK 03 31 07 5		KK 03 33 06 81		KK 03 52 17 51		KK 06 02 21 93		KK 06 30 90 7		KK 06 43 19 41		KK 06 70 31 21		KK 07 04 13113	
KK 03 31 07 9		KK 03 33 25 33		KK 03 52 18 47		KK 06 06 24 27		KK 06 30 90 9		KK 06 43 20 41		KK 06 70 39 21		KK 07 04 93117	
KK 03 31 07 9		KK 03 33 25 57		KK 03 52 18 51		KK 06 06 57 35		KK 06 30 91 15		KK 06 43 21 41		KK 06 70 39 51		KK 07 06 39 35	
KK 03 31 08 15		KK 03 33 32 5		KK 03 52 27 47		KK 06 07 03 21		KK 06 30 91 17		KK 06 43 21 49		KK 06 70 40 21		KK 07 06 40 5	
KK 03 31 11 17		KK 03 34 01 33		KK 03 52 27 51		KK 06 12 79 55		KK 06 30 91 5		KK 06 43 23 41		KK 06 70 49 25		KK 07 06 40 9	
KK 03 31 16 17		KK 03 35 40 29		KK 03 52 29111		KK 06 12 80 21		KK 06 30 92 15		KK 06 43 60 41		KK 06 70 51 21		KK 07 06 41 5	
KK 03 31 17 17		KK 03 36 25109		KK 03 52 47 23		KK 06 12 91 21		KK 06 30 92 17		KK 06 43 60 49		KK 06 70 57 21		KK 07 06 41 9	
KK 03 31 18 13		KK 03 36 70109		KK 03 52 47 43		KK 06 12 91 43		KK 06 30 92 5		KK 06 61 02 27		KK 06 70 59 21		KK 07 06 42 5	
KK 03 31 19 13		KK 03 42 25 25		KK 05 07 06 21		KK 06 12 91 53		KK 06 33 88 13		KK 06 61 08 27		KK 06 70 60 21		KK 07 06 42 9	
KK 03 31 73 15		KK 03 42 25 35		KK 05 30 90 11		KK 06 15 15 23		KK 06 33 88 5		KK 06 61 40 27		KK 06 70 65 51		KK 07 06 53 35	
KK 03 31 74 13		KK 03 42 28 35		KK 05 30 90 13		KK 06 16 37 43		KK 06 33 88 9		KK 06 61 42 27		KK 06 70 68 21		KK 07 08 05127	
KK 03 31 75 15		KK 03 42 28 53		KK 05 30 90 13		KK 06 18 99111		KK 06 36 07 15		KK 06 61 43 27		KK 06 70 70 21		KK 07 12 07 23	
KK 03 31 75 15		KK 03 42 50 35		KK 05 30 90 15		KK 06 18 99127		KK 06 36 07 7		KK 06 61 45 27		KK 06 70 73 53		KK 07 12 08 23	
KK 03 31 75 17		KK 03 44 46 35		KK 05 30 90 17		KK 06 18 99 51		KK 06 36 07 9		KK 06 61 70 29		KK 06 70 75 21		KK 07 12 09 23	
KK 03 31 75 5		KK 03 50 15 83		KK 05 30 90 19		KK 06 19 34 61		KK 06 38 01 5		KK 06 61 75 27		KK 06 70 76 21		KK 07 12 11 23	
KK 03 31 75 9		KK 03 50 20 21		KK 05 30 90 5		KK 06 19 40 39		KK 06 38 01 5		KK 06 61 75 29		KK 06 70 77 21		KK 07 12 12 23	
KK 03 31 81 15		KK 03 50 21 21		KK 05 30 90 7		KK 06 19 40 57		KK 06 40 24123		KK 06 61 78 27		KK 06 70 79 43		KK 07 12 28 23	
KK 03 31 85 15		KK 03 50 31 27		KK 05 30 90 9		KK 06 19 42 63		KK 06 40 30109		KK 06 61 78 29		KK 06 70 79 49		KK 07 12 55 43	
KK 03 32 51 13		KK 03 50 31 29		KK 05 33 87 13		KK 06 19 48 49		KK 06 40 30123		KK 06 61 82 27		KK 06 70 80 21		KK 07 14 04 43	
KK 03 32 51 15		KK 03 50 60 23		KK 05 33 87 5		KK 06 20 20 23		KK 06 40 36109		KK 06 61 82 29		KK 06 70 90 21		KK 07 14 12 45	
KK 03 32 51 17		KK 03 50 72 23		KK 05 33 87 9		KK 06 20 25 13		KK 06 40 39109		KK 06 61 85 27		KK 06 70 92 21		KK 07 14 17 23	
KK 03 32 51 5		KK 03 50 87 25		KK 05 61 12 27		KK 06 20 25 9		KK 06 40 47125		KK 06 61 89 27		KK 06 82 51127		KK 07 14 17 25	
KK 03 32 51 9		KK 03 50 87 25		KK 05 61 14 27		KK 06 22 70 43		KK 06 40 73109		KK 06 61 89 29		KK 07 02 92 15		KK 07 15 00 15	

Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page
KK 07 15 08	23	KK 07 30 04	17	KK 07 30 57	13	KK 07 30 89	9	KK 07 32 66	5	KK 07 33 29	13	KK 07 36 08	9	KK 07 38 04	9
KK 07 15 29	23	KK 07 30 04	5	KK 07 30 57	15	KK 07 30 91	13	KK 07 32 66	9	KK 07 33 32	15	KK 07 36 09	13	KK 07 38 04	9
KK 07 15 75	23	KK 07 30 05	17	KK 07 30 57	17	KK 07 30 91	15	KK 07 32 67	5	KK 07 33 33	15	KK 07 36 09	15	KK 07 38 05	15
KK 07 15 76	23	KK 07 30 05	5	KK 07 30 57	9	KK 07 30 91	17	KK 07 32 67	9	KK 07 33 38	13	KK 07 36 09	17	KK 07 38 05	9
KK 07 22 19109		KK 07 30 06	17	KK 07 30 62	13	KK 07 30 91	5	KK 07 32 72	13	KK 07 33 39	13	KK 07 36 09	5	KK 07 38 07	5
KK 07 27 51	25	KK 07 30 06	5	KK 07 30 62	15	KK 07 30 91	9	KK 07 32 72	15	KK 07 33 50	13	KK 07 36 09	9	KK 07 38 08	5
KK 07 27 55	25	KK 07 30 07	17	KK 07 30 62	17	KK 07 30 92	13	KK 07 32 73	13	KK 07 33 51	13	KK 07 36 14	13	KK 07 38 10	15
KK 07 27 57	25	KK 07 30 07	5	KK 07 30 62	9	KK 07 30 92	15	KK 07 32 73	15	KK 07 33 52	13	KK 07 36 14	15	KK 07 38 11	15
KK 07 27 59	25	KK 07 30 08	5	KK 07 30 63	13	KK 07 30 92	17	KK 07 32 75	13	KK 07 33 53	13	KK 07 36 14	17	KK 07 38 12	15
KK 07 27 60	25	KK 07 30 09	5	KK 07 30 63	15	KK 07 30 92	5	KK 07 32 75	15	KK 07 33 54	13	KK 07 36 14	7	KK 07 38 13	15
KK 07 27 61	25	KK 07 30 16	15	KK 07 30 63	17	KK 07 30 92	9	KK 07 32 76	13	KK 07 34 06	5	KK 07 36 14	9	KK 07 38 15	15
KK 07 27 65	25	KK 07 30 30	17	KK 07 30 63	9	KK 07 32 24	9	KK 07 32 76	15	KK 07 34 07	5	KK 07 36 15	13	KK 07 38 16	15
KK 07 27 66	25	KK 07 30 30	5	KK 07 30 64	13	KK 07 32 25	9	KK 07 32 78	13	KK 07 34 11	5	KK 07 36 15	15	KK 07 38 17	15
KK 07 27 67	25	KK 07 30 31	17	KK 07 30 64	15	KK 07 32 27	9	KK 07 32 79	13	KK 07 34 12	5	KK 07 36 15	17	KK 07 38 20	15
KK 07 27 68	41	KK 07 30 31	5	KK 07 30 64	17	KK 07 32 28	9	KK 07 32 80	5	KK 07 34 14	5	KK 07 36 15	5	KK 07 38 21	15
KK 07 27 68	49	KK 07 30 40	5	KK 07 30 64	9	KK 07 32 30	17	KK 07 32 81	5	KK 07 34 15	5	KK 07 36 15	9	KK 07 38 22	15
KK 07 27 69	25	KK 07 30 41	5	KK 07 30 65	13	KK 07 32 30	9	KK 07 32 86	5	KK 07 34 17	9	KK 07 36 16	13	KK 07 38 26	13
KK 07 27 70	25	KK 07 30 42	17	KK 07 30 65	15	KK 07 32 31	17	KK 07 32 87	5	KK 07 34 18	9	KK 07 36 16	17	KK 07 38 26	9
KK 07 27 71	25	KK 07 30 42	5	KK 07 30 65	17	KK 07 32 31	9	KK 07 32 90	5	KK 07 34 35	9	KK 07 36 16	5	KK 07 38 26	9
KK 07 27 73	25	KK 07 30 43	17	KK 07 30 65	9	KK 07 32 36	9	KK 07 32 90	9	KK 07 34 36	9	KK 07 36 16	9	KK 07 38 29	13
KK 07 27 77	25	KK 07 30 43	5	KK 07 30 80	13	KK 07 32 37	9	KK 07 32 91	5	KK 07 34 40	9	KK 07 36 34	11	KK 07 38 29	9
KK 07 27 88	25	KK 07 30 44	17	KK 07 30 80	15	KK 07 32 39	9	KK 07 32 91	9	KK 07 34 41	9	KK 07 36 34	13	KK 07 38 30	5
KK 07 27 89	25	KK 07 30 44	5	KK 07 30 80	17	KK 07 32 40	9	KK 07 33 00	15	KK 07 34 64	13	KK 07 36 34	19	KK 07 38 31	5
KK 07 27 92	25	KK 07 30 45	17	KK 07 30 80	9	KK 07 32 41	9	KK 07 33 00	17	KK 07 34 64	15	KK 07 36 34	7	KK 07 38 31	9
KK 07 28 19	25	KK 07 30 45	5	KK 07 30 81	13	KK 07 32 42	9	KK 07 33 00	5	KK 07 34 65	13	KK 07 36 35	11	KK 07 38 34	15
KK 07 28 20	25	KK 07 30 54	13	KK 07 30 81	15	KK 07 32 45	15	KK 07 33 00	9	KK 07 34 65	15	KK 07 36 35	13	KK 07 38 35	15
KK 07 28 21	25	KK 07 30 54	15	KK 07 30 81	17	KK 07 32 46	15	KK 07 33 01	15	KK 07 34 70	13	KK 07 36 35	19	KK 07 38 36	15
KK 07 28 22	25	KK 07 30 54	17	KK 07 30 81	9	KK 07 32 50	5	KK 07 33 01	17	KK 07 34 70	15	KK 07 36 35	7	KK 07 38 42	9
KK 07 28 24	25	KK 07 30 54	9	KK 07 30 88	13	KK 07 32 51	5	KK 07 33 01	5	KK 07 34 71	13	KK 07 38 00	13	KK 07 40 54109	
KK 07 28 25	25	KK 07 30 55	13	KK 07 30 88	15	KK 07 32 56	17	KK 07 33 01	9	KK 07 34 71	15	KK 07 38 00	5	KK 07 40 80117	
KK 07 29 78	43	KK 07 30 55	15	KK 07 30 88	17	KK 07 32 56	5	KK 07 33 03	15	KK 07 36 07	15	KK 07 38 00	9	KK 07 40 80123	
KK 07 30 00	5	KK 07 30 55	17	KK 07 30 88	5	KK 07 32 57	17	KK 07 33 04	15	KK 07 36 07	7	KK 07 38 01	13	KK 07 40 82109	
KK 07 30 01	5	KK 07 30 55	9	KK 07 30 88	9	KK 07 32 57	5	KK 07 33 10	5	KK 07 36 07	9	KK 07 38 01	5	KK 07 40 93123	
KK 07 30 02	17	KK 07 30 56	13	KK 07 30 89	13	KK 07 32 60	5	KK 07 33 10	9	KK 07 36 08	13	KK 07 38 01	9	KK 07 43 89 49	
KK 07 30 02	5	KK 07 30 56	15	KK 07 30 89	15	KK 07 32 61	5	KK 07 33 11	5	KK 07 36 08	15	KK 07 38 03	15	KK 07 43 90 49	
KK 07 30 03	17	KK 07 30 56	17	KK 07 30 89	17	KK 07 32 63	5	KK 07 33 11	9	KK 07 36 08	17	KK 07 38 03	5	KK 07 46 24123	
KK 07 30 03	5	KK 07 30 56	9	KK 07 30 89	5	KK 07 32 64	5	KK 07 33 28	13	KK 07 36 08	5	KK 07 38 03	5	KK 07 47 50 23	

Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page
KK 07 47 51 23		KK 07 48 90127		KK 07 64 30 33		KK 07 70 21 25		KK 07 89 15 41		KK 07 91 72 51		KK 07 92 68 45		KK 07 93 68 55	
KK 07 47 52 43		KK 07 48 91127		KK 07 64 34 33		KK 07 70 23 23		KK 07 89 17 41		KK 07 91 73 45		KK 07 92 73 55		KK 07 93 70 57	
KK 07 47 60 25		KK 07 48 93123		KK 07 64 35 33		KK 07 70 24 23		KK 07 89 17 49		KK 07 91 73 51		KK 07 92 79 55		KK 07 93 75 57	
KK 07 47 64 43		KK 07 49 70127		KK 07 64 37 33		KK 07 76 76 43		KK 07 89 21 43		KK 07 91 74 45		KK 07 92 84 55		KK 07 93 76 57	
KK 07 48 01109		KK 07 49 71127		KK 07 64 99 29		KK 07 76 82 65		KK 07 89 49 41		KK 07 91 74 51		KK 07 92 85 55		KK 07 93 77 57	
KK 07 48 02109		KK 07 60 08 33		KK 07 64 99 31		KK 07 76 99 43		KK 07 89 53 45		KK 07 91 75 51		KK 07 92 88 55		KK 07 93 78 55	
KK 07 48 10109		KK 07 60 22 33		KK 07 64 99 33		KK 07 85 51 51		KK 07 89 56 43		KK 07 91 75 53		KK 07 92 96 53		KK 07 93 81 55	
KK 07 48 35123		KK 07 60 23 33		KK 07 65 15 31		KK 07 85 82 39		KK 07 89 75 59		KK 07 91 76 43		KK 07 92 96 55		KK 07 93 85 55	
KK 07 48 36123		KK 07 60 53 33		KK 07 65 17 31		KK 07 85 84 65		KK 07 90 63123		KK 07 91 77 51		KK 07 92 97 53		KK 07 93 88 49	
KK 07 48 38123		KK 07 60 58 33		KK 07 65 18 31		KK 07 85 84 71		KK 07 91 10 65		KK 07 91 77 53		KK 07 92 97 55		KK 07 93 89 49	
KK 07 48 39123		KK 07 60 65 33		KK 07 65 27 31		KK 07 86 09113		KK 07 91 12 41		KK 07 91 78 43		KK 07 93 06 55		KK 07 93 90 49	
KK 07 48 41123		KK 07 60 66 33		KK 07 65 31 45		KK 07 86 09115		KK 07 91 12 49		KK 07 91 79 51		KK 07 93 25 55		KK 07 93 96 49	
KK 07 48 43123		KK 07 60 68 33		KK 07 65 31 51		KK 07 88 38 45		KK 07 91 15 65		KK 07 91 79 53		KK 07 93 28 55		KK 07 93 97 45	
KK 07 48 44123		KK 07 60 70 33		KK 07 65 32 31		KK 07 88 38 47		KK 07 91 16 63		KK 07 91 80 45		KK 07 93 30 49		KK 07 93 97 51	
KK 07 48 46127		KK 07 60 72 33		KK 07 65 33 31		KK 07 88 40 45		KK 07 91 30 45		KK 07 91 82 45		KK 07 93 31 49		KK 07 93 98 49	
KK 07 48 50123		KK 07 60 76 31		KK 07 65 37 31		KK 07 88 44 45		KK 07 91 30 51		KK 07 91 84 45		KK 07 93 32 45		KK 07 94 34121	
KK 07 48 56123		KK 07 61 48 33		KK 07 65 44 33		KK 07 88 49 43		KK 07 91 31 45		KK 07 91 84 51		KK 07 93 32 51		KK 07 94 66 57	
KK 07 48 62123		KK 07 62 85 33		KK 07 65 45 33		KK 07 88 50 41		KK 07 91 31 51		KK 07 91 91 39		KK 07 93 33 45		KK 07 94 68 57	
KK 07 48 64123		KK 07 62 94 33		KK 07 65 48 33		KK 07 88 51 41		KK 07 91 33 45		KK 07 91 91 45		KK 07 93 33 51		KK 07 94 69 57	
KK 07 48 65123		KK 07 62 96 33		KK 07 65 75 31		KK 07 88 53 41		KK 07 91 33 51		KK 07 91 91 51		KK 07 93 34 43		KK 07 94 72 49	
KK 07 48 66123		KK 07 62 97 33		KK 07 65 77 31		KK 07 88 54 43		KK 07 91 35 47		KK 07 91 95 51		KK 07 93 35 43		KK 07 94 73 53	
KK 07 48 67123		KK 07 62 98 33		KK 07 68 12 35		KK 07 88 67 43		KK 07 91 36 47		KK 07 92 01 43		KK 07 93 36 51		KK 07 94 74 49	
KK 07 48 70123		KK 07 64 00 31		KK 07 68 13 35		KK 07 88 70 41		KK 07 91 40 45		KK 07 92 04 41		KK 07 93 36 53		KK 07 94 78 49	
KK 07 48 73123		KK 07 64 00 33		KK 07 68 17 35		KK 07 88 76 41		KK 07 91 49 45		KK 07 92 08 47		KK 07 93 37 51		KK 07 94 79 49	
KK 07 48 74123		KK 07 64 06 29		KK 07 68 18 35		KK 07 88 80 43		KK 07 91 50 45		KK 07 92 09 47		KK 07 93 37 53		KK 07 94 87 59	
KK 07 48 75123		KK 07 64 06 31		KK 07 68 25 35		KK 07 88 88 43		KK 07 91 53 45		KK 07 92 27 63		KK 07 93 38 37		KK 07 94 93 55	
KK 07 48 76123		KK 07 64 07 29		KK 07 68 26 35		KK 07 88 89 43		KK 07 91 53 51		KK 07 92 28 47		KK 07 93 43 37		KK 07 94 95 55	
KK 07 48 80127		KK 07 64 07 31		KK 07 68 33 35		KK 07 88 90 43		KK 07 91 54 37		KK 07 92 30 41		KK 07 93 45 55		KK 07 94 97 55	
KK 07 48 81127		KK 07 64 07 33		KK 07 68 34 35		KK 07 88 91 43		KK 07 91 55 37		KK 07 92 30 49		KK 07 93 46 55		KK 07 94 98 55	
KK 07 48 82127		KK 07 64 09 29		KK 07 68 58 35		KK 07 88 92 43		KK 07 91 56 37		KK 07 92 33 41		KK 07 93 60 41		KK 07 95 09 63	
KK 07 48 84127		KK 07 64 09 31		KK 07 68 58 35		KK 07 88 93 43		KK 07 91 59 43		KK 07 92 35 43		KK 07 93 61 41		KK 07 95 15 59	
KK 07 48 85127		KK 07 64 09 33		KK 07 68 59 35		KK 07 88 94 43		KK 07 91 60 43		KK 07 92 50 43		KK 07 93 62 41		KK 07 95 15 61	
KK 07 48 86123		KK 07 64 09 33		KK 07 68 72 35		KK 07 88 97 43		KK 07 91 65 45		KK 07 92 50 45		KK 07 93 63 41		KK 07 95 18 47	
KK 07 48 86127		KK 07 64 10 29		KK 07 69 36 25		KK 07 88 98 41		KK 07 91 65 51		KK 07 92 62 47		KK 07 93 64 41		KK 07 95 19 63	
KK 07 48 87127		KK 07 64 10 31		KK 07 69 40117		KK 07 89 00 43		KK 07 91 70 37		KK 07 92 63 47		KK 07 93 65 43		KK 07 95 30 47	
KK 07 48 88127		KK 07 64 10 33		KK 07 69 43 35		KK 07 89 11 41		KK 07 91 71 37		KK 07 92 64 43		KK 07 93 65 53		KK 07 95 31 63	
KK 07 48 89127		KK 07 64 27 31		KK 07 69 44 35		KK 07 89 11 49		KK 07 91 72 45		KK 07 92 64 45		KK 07 93 67 55		KK 07 95 32 63	

Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page
KK 07 95 33	47	KK 07 96 42	111	KK 07 97 63	41	KK 08 24 08	111	KK 08 38 08	17	KK 08 61 12	29	KK 35 22 84	77	KK 35 33 56	93
KK 07 95 35	47	KK 07 96 46	49	KK 07 97 64	41	KK 08 24 09	111	KK 08 38 09	5	KK 08 61 13	29	KK 35 22 92	77	KK 35 33 56	95
KK 07 95 46	63	KK 07 96 51	51	KK 07 97 65	41	KK 08 26 40	25	KK 08 38 10	5	KK 08 61 14	29	KK 35 22 99	87	KK 35 33 56	99
KK 07 95 52	45	KK 07 96 61	51	KK 07 97 69	63	KK 08 32 10	17	KK 08 40 00	125	KK 08 61 15	29	KK 35 22 99	89	KK 35 33 60	101
KK 07 95 55	47	KK 07 96 67	51	KK 07 97 70	53	KK 08 32 11	17	KK 08 40 01	125	KK 08 68 01	35	KK 35 23 17	93	KK 35 33 61	101
KK 07 95 56	47	KK 07 96 71	111	KK 07 97 71	53	KK 08 32 12	17	KK 08 40 02	125	KK 08 80 62	111	KK 35 23 18	93	KK 35 33 62	101
KK 07 95 57	39	KK 07 96 72	111	KK 07 97 72	53	KK 08 32 13	17	KK 08 40 03	125	KK 08 80 63	111	KK 35 23 19	93	KK 35 33 70	59
KK 07 95 58	39	KK 07 96 73	111	KK 07 97 75	53	KK 08 32 14	17	KK 08 40 10	125	KK 10 68 63	123	KK 35 23 30	63	KK 35 33 70	87
KK 07 95 68	39	KK 07 96 75	53	KK 07 97 80	23	KK 08 32 15	17	KK 08 40 11	125	KK 12 78 95	61	KK 35 23 30	73	KK 35 33 70	89
KK 07 95 69	39	KK 07 96 78	51	KK 07 97 81	23	KK 08 32 16	17	KK 08 40 12	125	KK 30 12 23	111	KK 35 23 32	57	KK 35 33 71	87
KK 07 95 70	39	KK 07 96 79	53	KK 07 97 82	43	KK 08 32 17	17	KK 08 40 13	125	KK 30 12 23	47	KK 35 23 32	71	KK 35 33 71	89
KK 07 95 75	39	KK 07 96 80	51	KK 07 97 83	43	KK 08 32 18	17	KK 08 40 40	123	KK 30 12 23	51	KK 35 23 32	93	KK 35 33 72	87
KK 07 95 78	49	KK 07 96 85	53	KK 07 97 92	53	KK 08 32 20	17	KK 08 40 42	127	KK 30 31 23	47	KK 35 23 33	57	KK 35 33 72	89
KK 07 95 79	49	KK 07 96 88	53	KK 07 97 94	45	KK 08 32 21	17	KK 08 40 43	123	KK 35 11 39	43	KK 35 23 33	93	KK 35 33 72	91
KK 07 95 80	49	KK 07 96 90	53	KK 07 97 94	51	KK 08 32 22	17	KK 08 40 84	127	KK 35 11 40	43	KK 35 23 34	65	KK 35 33 73	87
KK 07 95 85	53	KK 07 96 91	51	KK 07 98 57	49	KK 08 32 23	17	KK 08 41 00	125	KK 35 11 44	43	KK 35 23 34	83	KK 35 33 73	89
KK 07 95 86	53	KK 07 96 93	51	KK 07 98 58	49	KK 08 32 24	17	KK 08 41 01	125	KK 35 21 45	111	KK 35 23 38	83	KK 35 33 92	87
KK 07 95 90	39	KK 07 96 94	111	KK 07 98 60	49	KK 08 32 28	5	KK 08 41 06	123	KK 35 21 53	83	KK 35 23 39	93	KK 35 33 92	91
KK 07 95 91	39	KK 07 97 03	111	KK 07 98 60	49	KK 08 32 29	5	KK 08 41 07	123	KK 35 21 53	85	KK 35 23 57	101	KK 35 34 02	73
KK 07 95 92	65	KK 07 97 06	115	KK 07 98 64	49	KK 08 32 35	17	KK 08 41 10	123	KK 35 21 61	77	KK 35 23 57	65	KK 35 34 03	73
KK 07 95 92	71	KK 07 97 07	43	KK 07 98 65	49	KK 08 32 35	7	KK 08 41 11	123	KK 35 21 61	83	KK 35 23 70	65	KK 35 34 04	73
KK 07 95 93	53	KK 07 97 08	43	KK 07 98 71	49	KK 08 33 00	17	KK 08 50 76	35	KK 35 21 64	83	KK 35 23 70	77	KK 35 34 05	73
KK 07 95 94	53	KK 07 97 13	53	KK 07 98 72	49	KK 08 33 01	17	KK 08 60 80	29	KK 35 21 66	83	KK 35 23 84	65	KK 35 34 06	73
KK 07 95 95	49	KK 07 97 16	47	KK 07 98 75	49	KK 08 34 06	17	KK 08 60 81	29	KK 35 21 72	83	KK 35 23 84	95	KK 35 34 07	73
KK 07 95 96	39	KK 07 97 18	47	KK 07 98 78	49	KK 08 34 07	17	KK 08 60 82	29	KK 35 21 76	89	KK 35 23 99	65	KK 35 34 08	105
KK 07 95 96	41	KK 07 97 19	51	KK 07 98 80	49	KK 08 34 08	17	KK 08 60 83	29	KK 35 21 97	101	KK 35 27 74	105	KK 35 34 08	65
KK 07 95 96	49	KK 07 97 24	61	KK 07 99 00	51	KK 08 34 09	17	KK 08 60 84	29	KK 35 21 97	105	KK 35 27 74	107	KK 35 34 08	71
KK 07 95 97	39	KK 07 97 25	51	KK 07 99 06	51	KK 08 34 15	17	KK 08 60 85	29	KK 35 21 97	93	KK 35 27 74	91	KK 35 34 19	105
KK 07 96 01	47	KK 07 97 30	111	KK 07 99 10	51	KK 08 34 16	17	KK 08 60 86	31	KK 35 21 97	95	KK 35 27 77	65	KK 35 34 50	59
KK 07 96 07	111	KK 07 97 35	47	KK 07 99 12	51	KK 08 34 17	17	KK 08 60 87	31	KK 35 21 97	99	KK 35 27 77	85	KK 35 34 50	61
KK 07 96 08	63	KK 07 97 36	47	KK 07 99 13	43	KK 08 34 18	17	KK 08 60 89	29	KK 35 22 38	59	KK 35 27 84	85	KK 35 34 51	59
KK 07 96 09	47	KK 07 97 37	47	KK 07 99 14	43	KK 08 38 02	17	KK 08 60 90	29	KK 35 22 38	61	KK 35 27 85	85	KK 35 34 51	61
KK 07 96 10	47	KK 07 97 45	49	KK 07 99 30	53	KK 08 38 03	17	KK 08 61 00	31	KK 35 22 47	59	KK 35 33 54	95	KK 35 34 53	105
KK 07 96 14	53	KK 07 97 51	41	KK 07 99 33	49	KK 08 38 04	17	KK 08 61 01	29	KK 35 22 47	61	KK 35 33 54	99	KK 35 34 54	105
KK 07 96 15	53	KK 07 97 54	41	KK 08 11 15	111	KK 08 38 05	17	KK 08 61 01	31	KK 35 22 57	77	KK 35 33 55	95	KK 35 34 55	105
KK 07 96 30	111	KK 07 97 60	41	KK 08 11 50	41	KK 08 38 06	17	KK 08 61 10	29	KK 35 22 62	77	KK 35 33 55	99	KK 35 34 66	105
KK 07 96 36	111	KK 07 97 61	41	KK 08 24 05	111	KK 08 38 07	17	KK 08 61 11	29	KK 35 22 67	77	KK 35 33 56	85	KK 35 34 67	105

Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page	Art. no	Page
KK 35 34 67107		KK 35 36 28 89		KK 35 37 36 79		KK 35 37 59 97		KK 35 38 38 61		KK 35 39 35 81		KK 70 97 37129		KK 70 99 27129	
KK 35 34 98 59		KK 35 36 29 89		KK 35 37 38103		KK 35 37 60 97		KK 35 38 38 91		KK 35 39 36 81		KK 70 97 66129		KK 70 99 28129	
KK 35 34 98 61		KK 35 36 30123		KK 35 37 39103		KK 35 37 61 97		KK 35 38 50 91		KK 35 39 37 81		KK 70 97 67129		KK 70 99 29129	
KK 35 35 38 63		KK 35 37 04 65		KK 35 37 43 79		KK 35 37 93 79		KK 35 38 51 91		KK 35 39 44 81		KK 70 97 68129		KK 70 99 30129	
KK 35 35 38 75		KK 35 37 04 79		KK 35 37 44 79		KK 35 38 03 65		KK 35 38 54107		KK 35 39 46 81		KK 70 97 69129		KK 70 99 42129	
KK 35 35 39 75		KK 35 37 05 79		KK 35 37 45 79		KK 35 38 03 97		KK 35 38 55107		KK 35 60 42123		KK 70 97 80129		KK 70 99 43129	
KK 35 35 40109		KK 35 37 06 79		KK 35 37 46 79		KK 35 38 10103		KK 35 39 01 81		KK 35 60 42 57		KK 70 97 81129		KK 80 60 90 31	
KK 35 35 42 75		KK 35 37 07 79		KK 35 37 48103		KK 35 38 10 65		KK 35 39 02 81		KK 35 61 31 43		KK 70 97 87129		UH 82 56 40 81	
KK 35 35 43 75		KK 35 37 26 79		KK 35 37 49103		KK 35 38 32 65		KK 35 39 03 81		KK 36 11 07 53		KK 70 98 23129			
KK 35 35 44 75		KK 35 37 27 79		KK 35 37 50103		KK 35 38 32 99		KK 35 39 04 65		KK 36 11 16 43		KK 70 98 41129			
KK 35 35 45 75		KK 35 37 28 79		KK 35 37 51103		KK 35 38 35107		KK 35 39 20111		KK 70 92 34129		KK 70 98 42129			
KK 35 35 46 75		KK 35 37 29 79		KK 35 37 51 97		KK 35 38 35 65		KK 35 39 22 81		KK 70 93 04129		KK 70 98 43129			
KK 35 35 77111		KK 35 37 32 79		KK 35 37 54 97		KK 35 38 35 71		KK 35 39 26 81		KK 70 94 79129		KK 70 98 44129			
KK 35 36 27 91		KK 35 37 35 79		KK 35 37 55 97		KK 35 38 37 91		KK 35 39 34 81		KK 70 97 37129		KK 70 98 95129			


А g r o
Замовлення запчастин
(050)-407-68-47
(050)-407-68-45